



A-Series Computer Systems

CE Handbook

**Software Technology Division
11000 Wolfe Road
Cupertino, California 95014**

NOTICE

The information contained in this document is subject to change without notice.

HEWLETT-PACKARD MAKES NO WARRANTY OF ANY KIND WITH REGARD TO THE MATERIAL, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. Hewlett-Packard shall not be liable for errors contained herein or for incidental or consequential damages in connection with the furnishing, performance, or use of this material.

Hewlett-Packard assumes no responsibility for the use or reliability of its software on equipment that is not furnished by Hewlett-Packard.

This document contains proprietary information which is protected by copyright. All rights are reserved. No part of this document may be photocopied, reproduced, or translated to another language without the prior written consent of Hewlett-Packard Company.

Printing History

The Printing History below identifies the edition of this manual and any updates that are included. Periodically, update packages are distributed which contain replacement pages to be merged into the manual, including an updated copy of this printing history page. Also, the update may contain write-in instructions.

Each reprinting of this manual will incorporate all past updates; however, no new information will be added. Thus, the reprinted copy will be identical in content to prior printings of the same edition with its user-inserted update information. New editions of this manual will contain new information, as well as all updates.

| | |
|----------------|----------|
| First Edition | Jan 1984 |
| Second Edition | Jul 1985 |
| Third Edition | Jan 1987 |
| Fourth Edition | Aug 1992 |

Preface

The purpose of this handbook is to provide the Hewlett-Packard Customer Engineer with a reference for on-site service of the A-Series Computer Systems. This handbook contains information for installation, configuration, performance verification and calibration, and troubleshooting of the system.

Changes since the last edition:

In an effort to keep the size of this document to one volume, obsolete information was deleted. If you still have a need for this information, retain the pages from the previous edition of your CE Handbook. The following has been deleted for this edition:

- AUTO file listing, revisions prior to rev. 5000
- Loading diagnostics from mini-cartridge tape
- Primary System configuration and loading the Primary System, revisions prior to rev. 5000
- Diagnostic media information for 5 1/4-inch and 8-inch floppies, SIF format, and 264x mini-cartridge tape

Table of Contents

Chapter 1 Product Information

| | |
|--|------|
| Board Computers, Box Computers, and System Processor Units | 1-1 |
| Product Number Summary by Processor Family | 1-1 |
| Backplane Slot Requirements by Processor Family | 1-4 |
| Maximum Main Memory by Processor Family | 1-7 |
| Processing Speed by Processor Family | 1-10 |
| Maximum Electrical Requirements and Availability by Product Number | 1-10 |
| Product – Option List by Number | 1-18 |
| Peripheral Devices | 1-31 |

Chapter 2 Environmental/Installation/PM

| | |
|--|------|
| Switch Settings | 2-1 |
| A400/A600+/A900/A990 CPU; A700* Frontplane Lower Byte | 2-1 |
| A400 On-Board I/O Switch (U1001) | 2-3 |
| A400 On-Board I/O Cable Switches | 2-4 |
| A700* Frontplane Upper Byte Switch Settings | 2-4 |
| A900 Sequencer Switch Settings | 2-4 |
| A700* Floating Point Processor | 2-5 |
| A700* Writable Control Store | 2-5 |
| A700* PROM Control Store | 2-6 |
| A900 Control Store | 2-7 |
| A400 Micro 14 (6-Slot) Factory Switch Settings | 2-8 |
| A400 Micro/1000 (16-Slot) Factory Switch Settings | 2-8 |
| A600+ Model 6* (8-Slot) Factory Switch Settings | 2-9 |
| A600+ Micro 16 (6-Slot) Factory Switch Settings | 2-9 |
| A600+ Micro/1000 (16-Slot) Factory Switch Settings | 2-10 |
| A600+ Model 26 (20-Slot) Factory Switch Settings | 2-10 |
| A700* Micro/1000 (16-Slot) Factory Switch Settings | 2-11 |
| A700* Model 27 (20-Slot) Factory Switch Settings | 2-11 |
| A900 Micro/1000 (16-Slot) Factory Switch Settings | 2-12 |
| A900 Model 29 (20-Slot) Factory Switch Settings | 2-12 |
| A990 Factory Switch Settings (16- and 20-Slot) | 2-13 |
| Typical Card Placement and Cabling | 2-14 |
| A400 6-Slot Computer Cards and Priority Diagram | 2-14 |
| A400 6-Slot Computer Cabling Diagram (With External CS/80 Disk) | 2-15 |
| A400 6-Slot Computer Cabling Diagram (With External SCSI Disk) | 2-16 |
| A400 16-Slot System Cards and Priority Diagram | 2-17 |
| A400 16-Slot System Cabling Diagram (With External CS/80 Disk) | 2-18 |
| A400 16-Slot System Cabling Diagram (With External SCSI Disk) | 2-19 |
| A400 16-Slot System Cabling Diagram (With Internal Disk - 12022A Interface) | 2-20 |
| A400 16-Slot System Cabling Diagram (With Internal Disk - 12009A Interface) | 2-21 |
| A400 20-Slot System Cards and Priority Diagram | 2-22 |
| A400 20-Slot System Cabling Diagram (With External CS/80 Disk) | 2-23 |
| A400 20-Slot System Cabling Diagram (With External SCSI Disk) | 2-24 |
| A600+ 6-Slot Computer Cards and Priority Diagram | 2-25 |
| A600+ 6-Slot Computer Cabling Diagram (With External CS/80 Disk) | 2-26 |
| A600+ 6-Slot Computer Cabling Diagram (With External SCSI Disk) | 2-27 |

| | |
|--|------|
| A600+ Model 6* (8-Slot) System Cards and Priority Diagram | 2-28 |
| A600+ Model 6* (8-Slot) System Cabling Diagram | 2-29 |
| A600+ 16-Slot System Cards and Priority Diagram | 2-30 |
| A600+ 16-Slot System Cabling Diagram (With External CS/80 Disk Drive) | 2-31 |
| A600+ 16-Slot System Cabling Diagram (With External SCSI Disk Drive) | 2-32 |
| A600+ 16-Slot System Cabling Diagram (With Internal Disk - 12022A Interface) | 2-33 |
| A600+ 16-Slot System Cabling Diagram (With Internal Disk - 12009A Interface) | 2-34 |
| A600+ 20-Slot System Cards and Priority Diagram | 2-35 |
| A600+ 20-Slot System Cabling Diagram (With External CS/80 Disk Drive) | 2-36 |
| A600+ 20-Slot System Cabling Diagram (With External SCSI Disk Drive) | 2-37 |
| A700* 16-Slot System Cards and Priority Diagram | 2-38 |
| A700* 16-Slot System Cabling Diagram (With External CS/80 Disk Drive) | 2-39 |
| A700* 16-Slot System Cabling Diagram (With External SCSI Disk Drive) | 2-40 |
| A700* 16-Slot System Cabling Diagram (With Internal Disk - 12022A Interface) | 2-41 |
| A700* 16-Slot System Cabling Diagram (With Internal Disk - 12009A Interface) | 2-42 |
| A700* 20-Slot System Cards and Priority Diagram | 2-43 |
| A700* 20-Slot System Cabling Diagram (With External CS/80 Disk) | 2-44 |
| A700* 20-Slot System Cabling Diagram (With External SCSI Disk) | 2-45 |
| A900 16-Slot System Cards and Priority Diagram | 2-46 |
| A900 16-Slot System Cabling Diagram (With External CS/80 Disk) | 2-47 |
| A900 16-Slot System Cabling Diagram (With External SCSI Disk) | 2-48 |
| A900 16-Slot System Cabling Diagram (With Internal Disk - 12022A Interface) | 2-49 |
| A900 16-Slot System Cabling Diagram (With Internal Disk - 12009A Interface) | 2-50 |
| A900 20-Slot System Cards and Priority Diagram | 2-51 |
| A900 20-Slot System Cabling Diagram (With External CS/80 Disk) | 2-52 |
| A900 20-Slot System Cabling Diagram (With External SCSI Disk) | 2-53 |
| A990 16-Slot Upgrade from A400, A600+, or A700* - System Cards and Priority Diagram | 2-54 |
| A990 16-Slot Upgrade from A900 - System Cards and Priority Diagram | 2-55 |
| A990 20-Slot Upgrade from A400, A600+, or A700* - System Cards and Priority Diagram | 2-56 |
| A990 20-Slot Upgrade from A900 - System Cards and Priority Diagram | 2-57 |
| A990 16-Slot System Cabling Diagram (With External CS/80 Disk) | 2-58 |
| A990 16-Slot System Cabling Diagram (With External SCSI Disk) | 2-59 |
| A990 20-Slot System Cards and Priority Diagram | 2-60 |
| A990 20-Slot System Cabling Diagram (With External CS/80 Disk) | 2-61 |
| A990 20-Slot System Cabling Diagram (With External SCSI Disk) | 2-62 |
| I/O Extender Micro/1000 Box (HP 12025A) | 2-63 |
| I/O Extender 20-Slot Box (HP 12025B) | 2-63 |
| LAN/1000 Interface Controller Cabling | 2-64 |
| Memory Configurations | 2-65 |
| Memory Rules | 2-65 |
| Memory Products | 2-66 |
| A900 Control Store Placement | 2-68 |
| A700* WCS/PCS Placement | 2-68 |
| A400 Control Memory Map | 2-69 |
| A600 Control Memory Map | 2-70 |
| A600+ Control Memory Map | 2-70 |
| A700* Control Memory Map | 2-71 |
| A900 Control Memory Map | 2-72 |
| A990 Control Memory Map | 2-73 |
| A-Series Power-Up Sequence | 2-74 |
| Power Supply | 2-77 |
| 6-Slot Box (Cooler) Power Supply Test Points | 2-77 |
| 20-Slot Box Power Supply Test Points | 2-78 |
| 20-Slot Box Power Supply Connections | 2-79 |
| Model 6 115/230 Vac Strapping | 2-80 |
| Micro/1000 Power Supply Test Points | 2-81 |

| | |
|---|------|
| I/O Extender (12025A) Power Supply Test Points | 2-82 |
| I/O Extender (12025B) Power Supply Voltages | 2-82 |
| Battery Backup | 2-83 |
| 8-Slot Card Cages* (Model 6) | 2-83 |
| 16-Slot Card Cages | 2-84 |
| 20-Slot Card Cages | 2-84 |
| A600+ Processor | 2-85 |
| Switches and Connectors for 8-, 16- and 20-Slot Card Cages | 2-85 |
| Preventive Maintenance | 2-87 |
| General | 2-87 |
| Model 6 Procedures | 2-88 |
| Micro 14/16 Procedures (6-Slot Box – Cooler) | 2-88 |
| Micro 24/26/27*/29/99 Procedures (16-Slot Box – Micro/1000 package) | 2-88 |
| Model 24/26/27*/29/99 Procedures (20-Slot Box) | 2-89 |

Chapter 3 Configuration

| | |
|---|------|
| Operating Information | 3-1 |
| Virtual Control Panel (VCP) Characters | 3-1 |
| VCP Commands | 3-2 |
| Loader Commands | 3-3 |
| Firmware Revision Level | 3-4 |
| VCP Revision Level | 3-4 |
| Control Store Firmware Revision Level | 3-4 |
| Primary System | 3-5 |
| RTE-A Primary System Configuration, Rev. 5000 and 5010 | 3-5 |
| RTE-A Primary System Configuration, Rev. 5020 | 3-6 |
| RTE-A Primary System Configuration, Rev. 5270 | 3-7 |
| Primary Software Installation Procedures | 3-9 |
| CS/80 Cartridge or Magnetic Tape, Rev. 5000 and 5010 | 3-9 |
| CS/80 Cartridge or Magnetic Tape, Rev. 5012 | 3-11 |
| CS/80 Cartridge or Magnetic Tape, Rev. 5020 | 3-13 |
| CS/80 Cartridge, Magnetic, or DAT Tape, Rev. 5270 | 3-15 |
| 3.5-inch Diskettes | 3-16 |
| Sample RTE-A Boot Command File, Rev. 5020 (5.2) | 3-17 |
| Sample RTE-A Welcome File, Rev. 5020 (5.2) | 3-18 |
| Hard Disk Drive Configuration | 3-19 |
| Interface Configuration | 3-20 |
| HP 12005A*/B Async Serial Interface | 3-20 |
| HP 12006A Parallel Interface | 3-21 |
| Programmable Serial Interface (PSI) | 3-22 |
| Firmware Installation | 3-25 |
| PSI Test Hoods | 3-26 |
| HP 12008A PROM Storage Module | 3-26 |
| HP 12009A HP-IB Interface | 3-27 |
| Switch Configuration | 3-27 |
| HP-IB Cable Length Restrictions | 3-28 |
| HP-IB Loading/Cabling Guide | 3-29 |
| Device Equivalent Loads | 3-30 |
| HP 12016A SCSI Interface | 3-32 |
| HP 12021A* Mini-Disk Controller | 3-32 |
| HP 12022A* Integral Disk Controller | 3-34 |
| HP 12025A/B I/O Extender | 3-35 |
| I/O Extender Switches | 3-35 |
| I/O Extender Software Considerations | 3-35 |
| I/O Extender Restrictions | 3-36 |
| I/O Extender Firmware Requirements | 3-36 |
| Rack Mounting Instructions | 3-37 |
| Floor Mounting Instructions | 3-38 |
| HP 12040B*/C/D 8-Channel Asynchronous Multiplexer | 3-38 |
| HP 12040B*/C/D Jumper Positions vs. Manufacturer's Part No. | 3-39 |

| | |
|---|------|
| HP 12065A Color Video Output Interface | 3-39 |
| Switch Configuration | 3-39 |
| Display Parameters | 3-40 |
| HP 12076A LAN/1000 Interface Controller Card Switch Configuration | 3-41 |
| HP 12100A A400 On-Board I/O Interface | 3-42 |
| HP 12153A Writable Control Store for A700* | 3-42 |
| HP 12155A PROM Control Store for A700* | 3-42 |
| HP 12205A Control Store for A900 | 3-42 |

Chapter 4 Troubleshooting

| | |
|---|------|
| LED Indications | 4-1 |
| A400/A600+ Self-Test | 4-1 |
| A700* Self-Test | 4-5 |
| A900 Self-Test | 4-11 |
| A990 Self-Test | 4-16 |
| A400/A600+/A700* Memory Array Cards | 4-22 |
| A600+/A700* Error Correcting Memory Card | 4-23 |
| A700* WCS Card | 4-23 |
| A900/A990 Memory Array Card | 4-24 |
| A900 CS Card | 4-24 |
| I/O Extender IOC Card (12025-66001) | 4-24 |
| I/O Extender EXT Card (12025-60002) | 4-24 |
| PSI Cards | 4-25 |
| HP 12021A* Model 5 and 6 Internal Disk Controller LED Indications | 4-26 |
| Self-Test Initialization | 4-26 |
| EPROM Errors | 4-26 |
| Non-Fatal Errors | 4-27 |
| Drive Power Up Errors | 4-27 |
| Read Self-Test Errors | 4-28 |
| Read/Write Self-Test Errors | 4-28 |
| After Self-Test | 4-28 |
| HP 12076A LAN/1000 Interface Controller Card LED Display | 4-29 |
| HP 12016A SCSI Card Tests | 4-29 |
| Self-Test | 4-29 |
| Verification Program | 4-30 |
| Interactive Interface | 4-30 |
| Non-Interactive Interface | 4-32 |
| VCP Loader Errors | 4-34 |
| Cartridge Tape Loader Errors | 4-34 |
| PROM Card Loader Errors | 4-34 |
| DS/1000 Loader Errors | 4-35 |
| Disk Loader Errors | 4-35 |
| Magnetic Tape Loader Errors | 4-36 |
| HP 12022A Disk Interface Loader Error | 4-36 |
| Other | 4-37 |
| Halt Error Codes | 4-37 |
| Diagnostic Control System Error Indications | 4-39 |
| Primary and Secondary LED Error Codes | 4-39 |
| Diagnostic Program Error LED Indications | 4-41 |
| Diagnostic Driver Errors | 4-42 |
| RTE Device Driver Posted Status | 4-44 |
| ASCII/BYTES Table | 4-45 |
| Utilities | 4-47 |
| ASAVE and ARSTR | 4-47 |
| CSYS | 4-48 |
| COPYL | 4-49 |
| EDIT/1000 | 4-49 |
| ERTSH | 4-50 |
| FC | 4-51 |
| FORMA | 4-53 |

| | |
|--|------|
| FORMC | 4-54 |
| FORMF | 4-55 |
| FORMT | 4-56 |
| FOWN | 4-56 |
| FPACK | 4-57 |
| FPUT | 4-57 |
| FREES | 4-57 |
| FSCON | 4-58 |
| FST | 4-58 |
| FVERI | 4-60 |
| INSTL | 4-60 |
| LIF | 4-61 |
| LINDX | 4-62 |
| MERGE | 4-62 |
| METER | 4-63 |
| MPACK | 4-64 |
| OLDRE | 4-64 |
| PBV (PushButton Verify) | 4-64 |
| PRINT | 4-65 |
| RINFO (Reset Multiuser Accounting Information) | 4-66 |
| SAM (System Available Memory Reporting) | 4-67 |
| SINFO (Show Multiuser Accounting Information) | 4-67 |
| SPORT (Serial Port Analyzer) | 4-67 |
| TF | 4-68 |
| WH | 4-69 |
| BOOTEX Boot Extension | 4-70 |
| Purpose | 4-70 |
| BOOTEX Flowchart | 4-71 |
| Operation | 4-72 |
| Boot Program Commands | 4-72 |
| ECHO Command | 4-72 |
| System/Snap Commands | 4-72 |
| Mounting Cartridges | 4-72 |
| Scratch LU | 4-73 |
| Bad Pages | 4-73 |
| Memory Commands | 4-73 |
| Restore Program Commands: RP, ST, SZ, and PR | 4-74 |
| Reserved Partition Assignment | 4-74 |
| Reserved Partition Definition | 4-75 |
| Swap File Definition | 4-75 |
| Timeslicing, Swapping, Security Code, Session Accounting | 4-75 |
| END Command | 4-76 |
| Sample BOOTEX Command File | 4-76 |

Chapter 5 Diagnostics

| | |
|--|------|
| Diagnostic Control System | 5-1 |
| Diagnostic Welcome Message | 5-1 |
| Interface Card Octal Identification Codes | 5-2 |
| VCP AUTO Execution – Complete Test Series | 5-3 |
| VCP AUTO Execution – Single Test Execution | 5-5 |
| A-Series Diagnostic BOOT/LOAD Sequence | 5-8 |
| Operator Command Options | 5-9 |
| AUTO | 5-9 |
| SHOW | 5-10 |
| ASSIGN | 5-10 |
| LOG | 5-11 |
| FREEZE | 5-12 |
| RESET | 5-12 |
| COPY | 5-12 |
| CLEAR | 5-12 |

| | |
|---|------|
| EXIT | 5-12 |
| Diagnostic Design Language (DDL) | 5-13 |
| HP 24612A Diagnostic Media Allocation | 5-18 |
| BCM AUTO File Allocation, rev. 5000, 5010, and 5020 | 5-19 |
| BCM AUTO File Allocation, rev. 5270 | 5-20 |
| HP 24612A Diagnostic Media Options | 5-22 |
| Option 044, 3.5-Inch Floppies | 5-22 |
| Option 022, CS/80 Cartridge Tape | 5-22 |
| Option 051, 1600 bpi Magnetic Tape | 5-22 |
| Option AAH, SCSI DAT Tape | 5-22 |
| HP 24612A KERNEL Diagnostics | 5-24 |
| KERNEL Diagnostic Summary1 | 5-24 |
| Basic Instruction Diagnostic (CPU) | 5-24 |
| Memory Array Diagnostic (MAD) A400/A600/A700*; (MADMG) A900/A990 | 5-25 |
| Memory Controller Diagnostic (MCDXL*) | 5-26 |
| Memory Controller Diagnostic (MCD) | 5-27 |
| System Function Diagnostic (SFD) | 5-28 |
| I/O Master Diagnostic (IOM) | 5-29 |
| Expanded Instruction Diagnostic (EIG) | 5-30 |
| Floating Point Diagnostic (FPD) | 5-31 |
| Language Instruction Diagnostic (LIS) | 5-32 |
| Scientific Instruction Set (SIS) | 5-34 |
| CDS Basic Instruction Diagnostic (CDSBI) | 5-35 |
| CDS Procedural Call Diagnostic (CDSPC) | 5-36 |
| HP 24612A Interface Diagnostics | 5-37 |
| General Information | 5-37 |
| Diagnostic Test Hoods | 5-38 |
| General Diagnostic Operation | 5-38 |
| HP 12005A*/B Async Serial Interface (ASIC) | 5-39 |
| HP 12006A Parallel Interface (PIC) | 5-41 |
| Programmable Serial Interface (PSI) Diagnostics | 5-42 |
| HP 12008A PROM Storage Module (PROM) | 5-42 |
| HP 12009A HP-IB Interface (HPIB) | 5-43 |
| HP 12016A SCSI Interface (SCSI) | 5-45 |
| Single SCSI Card Automatic Mode Execution | 5-45 |
| Multiple SCSI Card Automatic Mode Execution | 5-46 |
| Interactive Mode Diagnostic Operation | 5-47 |
| SCSI Card Self-Test | 5-48 |
| TERMPWR Check | 5-48 |
| Firmware Timestamp Display | 5-49 |
| RAM Test | 5-50 |
| Loopback Test | 5-51 |
| HP 12022A* Disk Interface/Controller Diagnostic (DID) | 5-52 |
| Interactive Diagnostic Operation | 5-53 |
| Register Definitions | 5-54 |
| HP 12040A/B/C/D 8-Channel Asynchronous Multiplexer Diagnostic (MUX) | 5-57 |
| Common Errors, Rev. B and C | 5-57 |
| Common Errors, Rev. D | 5-58 |
| HP 12060A/B High Level Analog Input | |
| HP 12061A 31-Channel Expansion Multiplexer | 5-58 |
| HP 12062A 4-Channel Analog Output Card Diagnostic (AOUTD) | 5-59 |
| Interactive Diagnostics | 5-60 |
| Analog Output Calibration | 5-60 |
| Analog and Digital Output Program | 5-60 |
| HP 12063A Isolated Digital I/O Card Diagnostic (DIGIO) | 5-61 |
| Optional Diagnostics | 5-62 |
| HP 12072A Data Link Diagnostic (FDL) | 5-62 |
| HP 12072A Diagnostic Error Messages | 5-64 |
| HP 12100A A400 On-Board I/O (OBIO) | 5-68 |
| HP 12153A Writable Control Store (WCS) | 5-70 |
| HP 12205A Control Store Card (CSIC) | 5-71 |
| HP 24398B Diagnostic Media Options | 5-72 |
| Option 044, 3.5-Inch Floppies | 5-72 |

| | |
|---|-------|
| Option 022, CS/80 Cartridge Tape | 5-73 |
| Option 051, 1600 bpi Magnetic Tape | 5-75 |
| Option AAH, SCSI DAT Tape | 5-77 |
| Loading Diagnostics from 3.5-Inch Floppies | 5-77 |
| Loading Diagnostics from CS/80 Cartridge Tapes | 5-78 |
| Loading Diagnostics from 1600 bpi Magnetic Tape | 5-79 |
| Loading Diagnostics from SCSI DAT | 5-80 |
| HP 24398B Peripheral Diagnostics | 5-81 |
| CS/80 Disk Diagnostics | 5-81 |
| CS/80 Error Information | 5-85 |
| RTE-A DD*33 Error Decoding | 5-86 |
| Class of Errors | 5-87 |
| HP 7970E* HP-IB Verifier | 5-91 |
| ICD/MAC Disk* Diagnostics | 5-96 |
| HP 7974*, 7978*, 7980 Magnetic Tape Drive Exerciser | 5-99 |
| Systems Modem Diagnostic | 5-101 |
| Vector Instruction Set (VIS) Diagnostic | 5-104 |

Chapter 6 Adjustments

| | |
|--|-----|
| Model 6 Power Supply Adjustments | 6-1 |
|--|-----|

Chapter 7 Peripherals

| | |
|--|-----|
| Peripheral Installation | 7-1 |
| A600 Model 6 Terminal Installation | 7-1 |
| Peripheral Configuration | 7-2 |
| 2392A Terminal Configuration | 7-2 |
| 2393/97A and 150-I/150-II Terminal Configuration | 7-2 |
| 2621A Terminal Configuration | 7-3 |
| 2622/23/25/26/28A Terminal Configuration | 7-3 |
| 2624A Terminal Configuration | 7-4 |
| 293x Printer Configuration | 7-5 |

Chapter 8 Replacement Parts

| | |
|---|------|
| Replaceable Parts/Exchange Assemblies | 8-1 |
| Processors | 8-1 |
| A400 | 8-1 |
| A600/A600+ | 8-2 |
| A700 | 8-3 |
| A900 | 8-4 |
| A990 | 8-4 |
| Box-Specific Parts Lists | 8-5 |
| Model 6 (10-Slot Box) | 8-5 |
| Micro 14/16 (6-Slot Box) | 8-5 |
| Micro/1000 (16-Slot Box) | 8-6 |
| Model 26/27/29/99 (20-Slot Box) | 8-7 |
| I/O Extender (12025A/B) | 8-8 |
| I/O Interface Exchange Assemblies | 8-9 |
| HP-IB Cables | 8-9 |
| Power Supply History | 8-10 |
| 12040 Multiplexer Replaceable Parts (current) | 8-11 |
| 12040 MUX Assembly Revisions History | 8-11 |

| | |
|--|------|
| 12040 MUX Accessories History | 8-12 |
| 12076A LAN/1000 Replaceable Parts | 8-13 |
| Power Cord and Cordset Replaceable Parts | 8-13 |
| A-Series Firmware History | 8-14 |
| A400 Base Set Firmware | 8-14 |
| A400 OBIO Firmware | 8-14 |
| A400 VCP Firmware | 8-14 |
| A600 Minifloppy Controller | 8-15 |
| A600 Base Set Firmware | 8-15 |
| A600+ Base Set Firmware | 8-17 |
| A600/A600+ VCP Firmware | 8-18 |
| A700 Base Set Firmware | 8-19 |
| A700 Floating Point History | 8-20 |
| A700 VCP Firmware History | 8-20 |
| A900 Firmware History | 8-22 |
| A900 VCP Firmware History | 8-29 |
| A990 Firmware History | 8-31 |
| PSI Firmware History | 8-32 |
| 12007B 1000-1000 Modem Interface | |
| 12044A 1000-1000 Direct Connect Interface | 8-32 |
| 12042B OEM P.S.I | 8-32 |
| 12043A MRJE (download) | 8-32 |
| 12072A Data Link Slave firmware | 8-32 |
| 12073A 1000-3000 Modem Interface | |
| 12082A 1000-3000 Direct Connect Interface | 8-33 |
| 12075A X.25 (LAP-B) Modem Interface | 8-33 |
| 12092A Multipoint Master Modem Interface | 8-33 |
| 12016A SCSI Firmware History | 8-33 |
| 12040A/B/C MUX Firmware History | 8-34 |
| 12040D MUX Firmware History | 8-35 |
| 12076A LAN/1000 Interface Controller Card Firmware | 8-35 |
| 12041B 8-Channel MUX OEM Version | 8-35 |

Chapter 9 Diagrams

| | |
|---|------|
| A400 Board (12100-60001) | 9-1 |
| A600 Processor (12101-60001) | 9-2 |
| A600+ Processor (12105-60001) | 9-3 |
| A600/A600+ Parity Memory Controller (12102-60001/60002) | 9-4 |
| A600+ ECC Memory Controller (12110-60001/60002) | 9-5 |
| A700 Lower Processor (12152-60002) | 9-6 |
| A700 Memory Controller (12152-60003) | 9-7 |
| A700 Floating Point Processor (12156-60001) | 9-8 |
| A900 Cache Control (12203-60004) | 9-9 |
| A900 Data Path (12202-60001) | 9-10 |
| A900 Sequencer (12201-60001) | 9-11 |
| A900 Control Store (12205-60001) | 9-12 |
| A990 Board (12990-60102 or -60202*) | 9-13 |
| SCSI Interface Card (12016-60101) | 9-14 |
| LAN/1000 Interface Controller (12076-60001) | 9-15 |

Chapter 10 Reference

| | |
|----------------------------------|------|
| A-Series Reference Manuals | 10-1 |
| Hardware Manuals | 10-1 |
| Software Manuals | 10-2 |
| Interface Manuals | 10-2 |
| Diagnostic Manuals | 10-3 |

Table of Contents

Chapter 1 Product Information

| | |
|--|------|
| Board Computers, Box Computers, and System Processor Units | 1-1 |
| Product Number Summary by Processor Family | 1-1 |
| Backplane Slot Requirements by Processor Family | 1-4 |
| Maximum Main Memory by Processor Family | 1-7 |
| Processing Speed by Processor Family | 1-10 |
| Maximum Electrical Requirements and Availability by Product Number | 1-10 |
| Product – Option List by Number | 1-18 |
| Peripheral Devices | 1-31 |

Product Information

Board Computers, Box Computers, and System Processor Units

Product Number Summary by Processor Family

Table 1-1 contains a listing of HP product numbers by processor family number. This list includes current and discontinued products. The date shown in parentheses after the processor family number indicates the year in which the product first shipped. Discontinued products are indicated with an asterisk (*) after the product number (for example, 2484A*).

Table 1-1. HP Product Number Summary by Processor Family ¹

| Processor (CPU) Family | Level of Integration | Hewlett-Packard Product Number | | | | |
|------------------------|--|--------------------------------|-----------------------------------|---|---|-------------------------------------|
| | | Computer on a Card(s) | 6-slot Card Cage (Cooler Package) | 16-slot Card cage ² (Micro/1000 Package) | 20-slot Card Cage (20-slot Box Package) | 20-slot Card Cage (Cabinet Package) |
| A400 (1986) | Board Computer ³ | 12100A | | | | |
| | Box Computer ⁴ | | 2424A (Micro 14) | 2434A (Micro 24) | 2134A (Model 24) | |
| | System Processor Unit ⁵ (SPU) | | | 2484A*/B (Micro 24) | | |
| A600+ (1982) | Board Computer ⁶ | 2106AK*/BK*/CK/DK | | | | |
| | Box Computer ⁴ | | 2426E*/F*/G/H (Micro 16) | 2436A*/E*/G/H (Micro 26) | 2156A*/B*/C/D (Model 26) | |
| | System Processor Unit ⁵ (SPU) | | | 2486A*/B/C (Micro 26) | | 2196A*/B*/C*/D*/G/H (Model 26) |
| A700* (1982) | Board Computer ⁶ | 2107AK* | | | | |
| | Box Computer ⁷ | | | 2437A*/B* (Micro 27) | 2137A*/B* (Model 27) | |
| | System Processor Unit ⁵ (SPU) | | | 2487A*/B* (Micro 27) | 2197E* (Model 27) | 2197A*/B*/C*/D* (Model 27) |
| A900 (1982) | Box Computer ⁸ | | | 2439A*/B (Micro 29) | 2139A*/B (Model 29) | |
| | System Processor Unit ⁵ (SPU) | | | 2489A*/B (Micro 29) | | 2199A*/B*/C*/D*/E (Model 29) |
| A990 (1991) | Board Computer ⁹ | 12990C ¹⁰ | | | | |
| | Box Computer ⁴ | | | 2939A (Micro 99) | 2959A (Model 99) | |
| | System Processor Unit ⁵ (SPU) | | | 2989A (Micro 99) | | 2999A (Model 99) |

See notes next page

Table 1-1 notes:

- * Discontinued product; shown for reference only.
- 1. Data applies to currently available products only (except A700 processor family of products).
- 2. Includes one dedicated slot each for battery backup and 25 kHz power accessory cards. Two adjacent slots, in addition to the dedicated battery backup slot, are consumed if this accessory is used.
- 3. Board Computer: Single card computer includes processor and memory plus breakout panel containing four serial I/O ports.
- 4. Box Computer: Board Computer (same processor family) in a box card cage with dc power supply.
- 5. System Processor Unit: Box Computer (same processor family) plus HP-IB card (to system disk), RTE-A with VC+ and diagnostics.
- 6. Board Computer: CPU card and memory controller card (with memory).
- 7. Box Computer: Upper and lower CPU cards, memory controller card (without memory), and floating point processor card. All cards in a box card cage with dc power supply.
- 8. Box Computer: Floating point processor includes sequencer, data path, and cache control cards plus memory controller card (without memory). All cards in a box card cage with dc power supply.
- 9. Board Computer: Single card CPU includes writable control store, two level cache, floating point processor, and memory controller (without memory).
- 10. Upgrade Board: From A400, A600+, A700, or A900 processor configuration to equivalent A990 processor configuration. Plug compatible with these other processor family cards.

Backplane Slot Requirements by Processor Family

Table 1-2 contains a listing, by processor family number, of the number of backplane slots required for each of the most common cards used with each processor family.

NOTE

The sum total of all system and/or accessory cards listed per package type in table 1-2 cannot always be accommodated by the package type indicated. This limitation becomes more severe when considering I/O card slot requirements. Therefore, consult the *HP 1000 A-Series Computer Systems . . . Ordering Guide* (part no. 5952-1745D or prior edition part no.) when configuring a computer or system.

Table 1-2. Backplane Slot Requirements by Processor Family (Sheet 1 of 2) ¹

| Processor (CPU) Family | Level of integration | Package Type | Total Number of Slots per Package | Number of Backplane Slots Required For: | | | | | | | | | | | |
|------------------------|----------------------|---------------------|-----------------------------------|---|-------------------|-----------------|----------------|--------------------|-----------------|---------------------|-------------------------|------------------|---------------------------------|-----|-----|
| | | | | Mandatory Cards | | | | System Cards | | | | Accessory Cards | | | |
| | | | | Pro-cessor | Memory Controller | Mini-mum Memory | HP-IB Disk I/F | System Console I/F | Battery Back-up | 25 kHz Power Supply | Writ-able Control Store | PROM Stg. Module | Max. Mem-ory Array ² | | |
| A400 | Board | Card | 0 | 1 | (Note 3) | (Note 3) | n/a | n/a | n/a | n/a | n/a | n/a | n/a | n/a | n/a |
| | Box | Cooler | 6 | 1 | (Note 3) | (Note 3) | n/a | n/a | n/a | n/s | n/s | n/s | 1 | 4 | 4 |
| | Box | Micro/1000 | 16 | 1 | (Note 3) | (Note 3) | n/a | n/a | n/a | 3-4.7 | 1.7 | n/s | 1 | 4 | 4 |
| | Box | 20-slot box | 20 | 1 | (Note 3) | (Note 3) | n/a | n/a | n/a | (Note 5) | (Note 5) | n/s | 1 | 4 | 4 |
| | System | Micro/1000 | 16 | 1 | (Note 3) | (Note 3) | 1 | 1 | 1 | 3-4.7 | 1.7 | n/s | 1 | 4 | 4 |
| A600+ | Board | Card | 0 | 1 | (Note 6) | (Note 6) | n/a | n/a | n/a | n/a | n/a | n/a | n/a | n/a | n/a |
| | Box | Cooler ⁸ | 6 | 1 | (Note 6) | (Note 6) | n/a | n/a | n/a | n/s | n/s | n/s | 1 | 4 | 4 |
| | Box | Micro/1000 | 16 | 1 | (Note 6) | (Note 6) | n/a | n/a | n/a | 3-4.7 | 1.7 | n/s | 1 | 4 | 4 |
| | Box | 20-slot box | 20 | 1 | (Note 6) | (Note 6) | n/a | n/a | n/a | (Note 5) | (Note 5) | n/s | 1 | 4 | 4 |
| | System | Micro/1000 | 16 | 1 | (Note 6) | (Note 6) | 1 | 1 | 1 | 3-4.7 | 1.7 | n/s | 1 | 4 | 4 |
| | System | Cabinet | 20 | 1 | (Note 6) | (Note 6) | 1 | 1 | 1 | (Note 5) | (Note 5) | n/s | 1 | 4 | 4 |

Notes:

n/a = not applicable; n/s = not supported.

1. Data applies to currently available products only (except A700 processor family) and excludes I/O requirements.

2. Maximum number of memory array slots are shown after accounting for the number of mandatory cards and dedicated slots/slot sequence requirements. Consideration has *not* been given to slot and power requirements for accessory and system cards (shown in this table) or I/O cards.

3. Processor card includes memory controller with minimum (base) memory; see table 1-3.

4. Battery backup requires one slot but extends into the two adjacent slots above in Micro/1000 packages.

5. Battery backup and 25 kHz power are housed in main dc power supply in 20-slot boxes and cabinets.

6. Memory controller card contains minimum (base) memory; see table 1-3.

7. Requires dedicated slot.

8. The sum total of all mandatory and accessory cards shown for this package type cannot be accommodated due to insufficient slot capacity.

Table 1-2. Backplane Slot Requirements by Processor Family (Sheet 2 of 2) ¹

| Processor (CPU) Family | Level of Integration | Package Type | Total Number of Slots per Package | Number of Backplane Slots Required For: | | | | | | | | |
|------------------------|----------------------|--------------|-----------------------------------|---|----------------|----------------|--------------------|------------------|---------------------|-------------------------|------------------|--------------------------------|
| | | | | Mandatory Cards | | | System Cards | | Accessory Cards | | | |
| | | | | Pro-processor Memory Controller | Minimum Memory | HP-IB Disk I/F | System Console I/F | Battery Backup | 25 kHz Power Supply | Writ-able Control Store | PROM Stg. Module | Max. Memory Array ² |
| A700* | Box | Micro/1000 | 16 | 3 | 1 | n/a | n/a | 3 ^{4,7} | 1 ⁷ | 1 | 1 | 3 |
| | Box | 20-slot box | 20 | 3 | 1 | n/a | n/a | (Note 5) | (Note 5) | 1 | 1 | 4 |
| | System | Micro/1000 | 16 | 3 | 1 | 1 | 1 | 3 ^{4,7} | 1 ⁷ | 1 | 1 | 3 |
| | System | 20-slot box | 20 | 3 | 1 | 1 | 1 | (Note 5) | (Note 5) | 1 | 1 | 4 |
| | System | Cabinet | 20 | 3 | 1 | 1 | 1 | (Note 5) | (Note 5) | 1 | 1 | 4 |
| A900 | Box | Micro/1000 | 16 | 3 ⁷ | 1 ⁷ | n/a | n/a | 3 ^{4,7} | 1 ⁷ | 1 | 1 | 2 |
| | Box | 20-slot box | 20 | 3 ⁷ | 1 ⁷ | n/a | n/a | (Note 5) | (Note 5) | 1 | 1 | 8 |
| | System | Micro/1000 | 16 | 3 ⁷ | 1 ⁷ | 1 | 1 | 3 ^{4,7} | 1 ⁷ | 1 | 1 | 2 |
| | System | Cabinet | 20 | 3 ⁷ | 1 ⁷ | 1 | 1 | (Note 5) | (Note 5) | 1 | 1 | 8 |
| | Board | Upgrade Card | 0 | 1 | (Note 9) | n/a | n/a | n/a | n/a | (Note 10) | n/a | n/a |
| A990 | Box | Micro/1000 | 16 | 1 | (Note 9) | n/a | n/a | 3 ^{4,7} | 1 ⁷ | (Note 10) | 1 | 4 |
| | Box | 20-slot box | 20 | 1 | (Note 9) | n/a | n/a | (Note 5) | (Note 5) | (Note 10) | 1 | 4 |
| | System | Micro/1000 | 16 | 1 | (Note 9) | 1 | 1 | 3 ^{4,7} | 1 ⁷ | (Note 10) | 1 | 4 |
| | System | Cabinet | 20 | 1 | (Note 9) | 1 | 1 | (Note 5) | (Note 5) | (Note 10) | 1 | 4 |

Notes:

* Discontinued product; shown for reference only. n/a = not applicable.

1. Data applies to currently available products only (except A700 processor family) and excludes I/O requirements.
2. Maximum number of memory array slots are shown *after* accounting for the number of mandatory card and dedicated slots/slot sequence requirements. Consideration has *not* been given to slot and power requirements for accessory and system cards (shown in this table) or I/O cards.
4. Battery backup requires one slot but extends into two adjacent slots above in Micro/1000 packages.
5. Battery backup and 25 kHz power are housed in main dc power supply in 20-slot boxes and cabinets.
7. Requires dedicated slot.
9. Processor card includes memory controller without minimum (base) memory.
10. Processor card includes writable control store.

Maximum Main Memory by Processor Family

Table 1-3 contains a listing of maximum main memory capacity by processor family number. The data has been taken from the most recent HP 1000 A-Series Computer Systems . . . Ordering Guide (part no. 5952-1745D or prior edition part no.) in which the product number appears. Discontinued products are indicated with an asterisk (*) after the processor family number (for example, A700*).

NOTE

Maximum main memory values in table 1-3 are shown without regard for the slot and power requirements for system and accessory cards (shown in table 1-2), and I/O cards, consult the *HP 1000 A-Series Computer Systems . . . Ordering Guide*. (part no. 5952-1745D or prior edition part no.) when configuring a computer or system for maximum main memory.

Table 1-3. Maximum Main Memory by Processor Family ¹

| Processor (CPU) Family | Card Cage Size | Maximum Available Memory Array Slots ² | Size of Base Memory Maximum Size of Memory Array Cards Maximum Main Memory Capacity ² | | | | | | | | | | | | | |
|------------------------|------------------------------|---|--|------------------|-------------------|------------------|--|--------------------|----------------------------------|-------------------|------------------|------------|-------------|--|--------------|----------|
| | | | ECC | | Parity | | ECC | | | Parity | | ECC (MB) | Parity (MB) | | | |
| | | | 256 kbit RAMs (MB) | 1 Mbit RAMs (MB) | 64 kbit RAMs (MB) | 1 Mbit RAMs (MB) | 64 kbit RAMs (MB) | 256 kbit RAMs (MB) | 1 Mbit RAMs (MB) | 64 kbit RAMs (MB) | 1 Mbit RAMs (MB) | | | | | |
| A400 | 6-slot 16-slot 20-slot | 4 | | | | 0.5 | | | | 1.6 | | 8.3 | | | -- | 32.4 |
| A600+ | 6-slot 16-slot 20-slot | 4 | | 1.5 | | 0.5 | | | 2.5,6,7 | 1.6,7 | | 8.3,7 | | | 8 | 32.4 |
| A700* | 16-slot 20-slot | 3 ⁸ 4 | | | | | 0.5 ⁶ 0.5 ⁶ | | 2 ⁶ 2 ⁶ | 1.6 1.6 | | 8.3 8.3 | | | 6 8 | 24 32 |
| A900 | 16-slot 20-slot | 2 ⁹ 4 | | | | | 0.75 ¹⁰ 0.75 ¹⁰ | | 3 10 3 | | | | | | 16 32.4 | -- -- |
| A990 | 16-slot 20-slot | 4 ¹¹ 4 | | | | | 0.75 0.75 | | 3 ¹⁰ 3 | | | | | | 32.4 32.4 | -- -- |

See notes next page

Table 1-3 notes:

- * Discontinued product; shown for reference only.
- 1. Data applies to currently available products only (except A700 processor family of products).
- 2. Maximum values are shown *without* regard for system, I/O, and accessory card slot and power requirements.
- 3. HP 12103K/L/M array cards must be installed on a 512k-multiple boundary.
- 4. 32 MB is maximum *addressable* memory.
- 5. HP 12110A*/B controller card (with 0.5 KB*/1 MB ECC memory) is required to support ECC array cards in the A600+ processor family.

- 6. Each of the array cards listed below, must be added to the backplane in a sequence that will satisfy the equation:

$$\frac{\text{[Size of the existing, installed controller and/or array card(s)]}}{\text{[Size of the array card to be added]}} = \text{a whole integer.}$$

Applicable cards: HP 12103A*/B*/C/D, 12104A*, and 12111A*/B/C.

- 7. A 64 kbit and 1 Mbit parity card(s) can be mixed with a 256 kbit ECC card(s) in the A600+ processor family. The 256 kbit card(s), however, must be installed between the CPU card and 64 kbit card(s).
- 8. Maximum of three memory slots are available since the controller and array cards must be installed adjacent to one another in the right-hand half of the 16-slot card cage.
- 9. Maximum of two memory slots are available since array cards must be installed in the right-hand half of the 16-slot card cage, adjacent to the controller card. The four-card processor set (which includes the controller card) requires four dedicated slots (in the right-hand half of the card cage).
- 10. A 3 MB array card(s) must be installed closer to the controller card than a 0.75 MB card.
- 11. For an A990 that has been upgraded from an A900 in a 16-slot box, the maximum available memory array slots is 2. Therefore, the maximum main memory is 16 MB.

Processing Speed by Processor Family

Table 1-4 contains a listing of selected indicators of processing speed by processor family number.

Table 1-4. Processing Speed by Processor Family¹

| Processor (CPU) Family | Fastest Base Set Inst. Speed (MIPs) | Floating Pt. Speed (B1D Whet.) (kwips) | I/O Bandwidth (MB/sec) | | Memory Cycle Time (nsec) |
|------------------------|-------------------------------------|--|------------------------|------|--------------------------|
| | | | Out | In | |
| A400 | 1 | 122 | 4.27 | 4.27 | 454 |
| A600+ | 1 | 113 | 4.27 | 4.27 | 454 |
| A700* | 1 | 340 | 4.0 | 4.0 | 500 |
| A900 | 3 | 821 | 2.5 | 3.7 | 181 ² |
| A990 | 7 | 1,500 | 2.7 | 4.0 | 122 ³ |

Notes:

- * Discontinued product; shown for reference only.
- 1. Data applies to current active products only.
- 2. Average effective value at 88% cache hit rate.
- 3. Average effective value assuming 80% hit rate in the level 1 cache and a 97% hit rate in the level 2 cache.

Maximum Electrical Requirements and Availability by Product Number

Table 1-5 contains a listing of the following items by HP product number:

1. Size of base memory (MB), when included with product.
2. Whether an HP-IB card is included with product.
3. Ac current (A) and power (Watts) required from exterior line source.
4. Output current (A) and power (Watts) available from: (a) main dc power supply, and (b) 25 KHZ power supply.

Table 1-5. Maximum Electrical Requirements and Availability by HP Product Number (Sheet 1 of 7)

| Hewlett-Packard Product Number | Product Includes: | | | Input Required From: | | Output Available From: | | | | | | | | | |
|--------------------------------|----------------------|-------------|-----------------|-------------------------|-----------|------------------------|----------|---------------|---------------------|-----------|-----------|--------|-----|----------|-----|
| | Base Memory ECC (MB) | Parity (MB) | HP-IB Interface | Exterior Ac Line | | Main Dc Power Supply 1 | | | 25 KHz Power Supply | | | | | | |
| | | | | Oper. Current @115V (A) | @230V (A) | Maximum Power (W) 2 | @+5V (A) | @+5V(M) (A) 3 | @+12V (A) | @-12V (A) | Total (W) | (W) | (A) | @ (Vrms) | |
| | (MB) | (MB) | | (A) | (A) | (W) | (A) | (A) | (A) | (W) | (A) | (Vrms) | | | |
| 12100A | -- | 0.5 | No | n/a | n/a | n/a | 4.2 4 | 1.5 4 | 0.07 4 | n/a | 0.09 4 | 32 4 | n/a | n/a | n/a |
| 12990C | -- | -- | No | n/a | n/a | n/a | 6.3 4 | 1.2 4 | n/a | n/a | n/a | 40 4 | n/a | n/a | n/a |
| 2106BK* | - | 0.1 | No | n/a | n/a | n/a | 9.6 4 | 1.1 4 | -- | -- | -- | 53.5 4 | n/a | n/a | n/a |
| 2106CK | -- | 0.5 | No | n/a | n/a | n/a | 9.6 4 | 1.1 4 | -- | -- | -- | 53.5 4 | n/a | n/a | n/a |
| 2106DK | 1.0 | -- | No | n/a | n/a | n/a | 9.7 4 | 1.3 4 | -- | -- | -- | 55.0 4 | n/a | n/a | n/a |
| 2107AK* | - | 0.1 | No | n/a | n/a | n/a | 17.2 4 | 1.3 4 | -- | -- | -- | 92.5 4 | n/a | n/a | n/a |
| 2134A | -- | 0.5 | No | 6.0 | 3.0 | 700 | 55.8 5 | 8.3 5 | 5.5 | 3.4 | (Note6) | 50 | 1.5 | 39 | |
| 2136C* | -- | 0.1 | Yes | n/s | n/s | 300 | 12.6 | 4.8 | 2.5 | 1.4 | 1.75 | -- | -- | -- | -- |

Notes:

- * Discontinued product; shown for reference only. n/a = not applicable. n/s = not specified.
- 1. Values are listed under this category after subtracting processor and base memory/HP-IB card consumption (when included with product). Values flagged with notes 5, 9, 10, 11, and 12 are exceptions.
- 2. Maximum power required for any combination of HP interfaces and other HP plug-ins which can be accommodated by the product number indicated. Power factor (PF) is typically 0.75 with a range of 0.7 to 0.8. Use a PF of 0.7 to 0.72 to estimate ac input requirements in Volt-Amps (VA) from Watts (W) to ensure sufficient total input power (that is, VA=W/PF). To estimate ventilation or air conditioning requirements in BTU per hour, multiply W by 3.419. To determine heat dissipation requirements in kilogram-calories per hour, multiply W by 0.8598.
- 3. +5V(M) is voltage available to processor, memory controller, and memory array cards.
- 4. Requirement from external power supply.
- 5. Combined current consumption at +5.1 V and +5 V(M), including processor and base memory/HP-IB cards, when included with product, is limited to 70 W.
- 6. Main power supply provides enough current for any combination of HP interfaces and other HP plug-ins which can be accommodated by the product number indicated.

Table 1-5. Maximum Electrical Requirements and Availability by HP Product Number (Sheet 2 of 7)

| Hewlett-Packard Product Number | Product Includes: | | Input Required From: | | Output Available From: | | | | | | | | | |
|--------------------------------|-------------------|-----------------|----------------------|---------------|-----------------------------------|----------------------------|---------------------|---------------------|-----------|-----|----------|-----------------|------------------|-----------------|
| | Base Memory | HP-IB Interface | Exterior Ac Line | | Main Dc Power Supply ¹ | | | 25 KHz Power Supply | | | | | | |
| | | | Oper. Current | Maximum Power | @ +5V (A) | @ +5V (M) (A) ³ | @ +12V (A) | @ -12V (A) | Total (W) | (W) | (A) | @ (Vrms) | | |
| | ECC (MB) | Parity (MB) | @115V (A) | @230V (A) | | | | | | | | | | |
| 2136D* | — | 0.1 | No | n/s | n/s | 300 | 13.5 | 4.8 | 3.7 | 1.4 | 175 | -- | -- | -- |
| 2137A* | — | 0.1 | No | n/s | n/s | 700 | 42.8 ^{5,7} | 5.6 ^{5,7} | 5.6 | 3.5 | n/s | 50 ⁷ | 1.5 ⁷ | 39 ⁷ |
| 2137B* | — | -- | No | n/s | n/s | 700 | 39.9 ⁵ | 9.6 ^{5,7} | 5.6 | 3.5 | (Note 6) | 50 | 1.5 | 39 |
| 2139A* | 0.8 | -- | No | n/s | n/s | 800 | 41.8 | 7.0 | 5.5 | 3.5 | n/s | n/s | n/s | n/s |
| 2139B | — | -- | No | n/s | n/s | 800 | 42.8 ⁵ | 9.0 ⁵ | 5.5 | 3.5 | (Note 6) | 50 | 1.5 | 39 |
| 2156B* | — | 0.1 | No | n/s | n/s | 700 | 50.4 | 5.9 | 5.6 | 3.5 | n/s | 50 | 2.5 | 27 |
| 2156C | — | 0.5 | No | n/s | n/s | 700 | 50.4 | 8.7 | 5.6 | 3.5 | (Note 6) | 50 | 2.5 | 27 |
| 2156D | 1.0 | -- | No | n/s | n/s | 700 | 50.3 | 8.5 | 5.6 | 3.5 | (Note 6) | 50 | 2.5 | 27 |
| 2186C* | — | 0.5 | Yes | n/s | n/s | n/s | 12.6 | 4.8 | 2.5 | 1.4 | 175 | -- | -- | -- |

Notes:

* Discontinued product; shown for reference only. n/a = not applicable. n/s = not specified.

1. Values are listed under this category *after* subtracting processor and base memory/HP-IB card consumption (when included with product). Values flagged with notes 5, 9, 10, 11, and 12 are exceptions.
2. Maximum power required for any combination of HP interfaces and other HP plug-ins which can be accommodated by the product number indicated. Power factor (PF) is typically 0.75 with a range of 0.7 to 0.8. Use a PF of 0.7 to 0.72 to estimate ac input requirements in Volt-Amps (VA) from Watts (W) to ensure sufficient total input power (that is, VA=W/PF). To estimate ventilation or air conditioning requirements in BTU per hour, multiply W by 3.419. To determine heat dissipation requirements in kilogram-calories per hour, multiply W by 0.8598.
3. +5V(M) is voltage available to processor, memory controller, and memory array cards.
5. Combined current consumption at +5.1 V and +5V(M), including processor and base memory/HP-IB cards, when included with product, is limited to 70 W.
6. Main power supply provides enough current for any combination of HP interfaces and other HP plug-ins which can be accommodated by the product indicated.
7. Values apply only to computers or SPUs having a serial number prefix of 2648 or greater.

Table 1-5. Maximum Electrical Requirements and Availability by HP Product Number (Sheet 3 of 7)

| Hewlett-Packard Product Number | Product Includes: | | Input Required From: | | Output Available From: | | | | | | | | | |
|--------------------------------|-----------------------------|------------------|-------------------------|-----------------|------------------------|----------|---------------|---------------------|-----------|-----------|----------|-----------------|------------------|-----------------|
| | Base Memory ECC Parity (MB) | HP-IB Inter-face | Exterior Ac Line | | Main Dc Power Supply 1 | | | 25 KHz Power Supply | | | | | | |
| | | | Oper. Current @115V (A) | @230V (A) | Maximum Power (W) 2 | @+5V (A) | @+5V(M) (A) 3 | @+12V (A) | @-12V (A) | Total (W) | (W) | (A) | @ (Vrms) | |
| | 2186D* | -- | 0.5 | No | n/s | n/s | n/s | 13.5 | 4.8 | 3.7 | 1.4 | 175 | -- | -- |
| 2196C* | -- | 0.5 | Yes | 16 ⁸ | n/s | n/s | 46.3 | 5.8 | 5.3 | 3.4 | n/s | n/s | n/s | n/s |
| 2196D* | -- | 0.5 | Yes | 16 ⁸ | n/s | n/s | 46.3 | 5.8 | 5.3 | 3.4 | n/s | n/s | n/s | n/s |
| 2196G | -- | 0.5 | Yes | 16 ⁸ | n/s | n/s | 47.9 | 8.8 | 5.5 | 3.5 | (Note 6) | 50 | 2.5 | 27 |
| 2196H | 1.0 | -- | Yes | 16 ⁸ | n/s | n/s | 47.8 | 8.6 | 5.5 | 3.5 | (Note 6) | 50 | 2.5 | 27 |
| 2197C* | -- | 0.5 | Yes | 16 ⁸ | n/s | n/s | 35.1 | 5.5 | 5.3 | 3.4 | n/s | 50 ⁷ | 1.5 ⁷ | 39 ⁷ |
| 2197D* | -- | 0.5 | Yes | 16 ⁸ | n/s | n/s | 35.1 | 5.5 | 5.3 | 3.4 | n/s | 50 ⁷ | 1.5 ⁷ | 39 ⁷ |

Notes:

- * Discontinued product; shown for reference only. n/a = not applicable. n/s = not specified.
- 1. Values are listed under this category after subtracting processor and base memory/HP-IB card consumption (when included with product). Values flagged with notes 5, 9, 10, 11, and 12 are exceptions.
- 2. Maximum power required for any combination of HP interfaces and other plug-ins which can be accommodated by the product number indicated. Power factor (PF) is typically 0.75 with a range of 0.7 to 0.8. Use a PF of 0.7 to 0.72 to estimate ac input requirements in Volt-Amps (VA) from Watts (W) to ensure sufficient total input power (that is, VA = W/PF). To estimate ventilation or air conditioning requirements in BTU per hour, multiply W by 3.419. To determine heat dissipation requirements in kilogram-calories per hour, multiply W by 0.8598.
- 3. +5V(M) is voltage available to processor, memory controller, and memory array cards.
- 6. Main power supply provides enough current for any combination of HP interfaces and other HP plug-ins which can be accommodated by the product indicated.
- 7. Values apply only to computers or SPUs having a serial number prefix of 2648 or greater.
- 8. Current required per phase. HP 2196A*/C*/G/H and 2197C*/E*, with tall cabinet, require split phase; HP 2196B*/D* and 2197B*/D* require single phase.

Table 1-5. Maximum Electrical Requirements and Availability by HP Product Number (Sheet 4 of 7)

| Hewlett-Packard Product Number | Product Includes: | | Input Required From: | | Output Available From: | | | | | | | | |
|--------------------------------|-------------------------|----------------------|----------------------------|-----------|------------------------|-------------------|------------------|---------------------|-----------|--------------------|-----|-----|----------|
| | Base Memory ECC (MB) | HP-IB Inter- face | Exterior Ac Line | | Main Dc Power Supply 1 | | | 25 KHz Power Supply | | | | | |
| | | | Oper. Current @115V (A) | @230V (A) | Maximum Power (W) 2 | @+5V (A) | @+5V(M) (A) 3 | @+12V (A) | @-12V (A) | Total (W) | (W) | (A) | @ (Vrms) |
| 2197E | -- | -- | 16.8 | n/s | n/s | 37.8 ⁵ | 9.6 ⁵ | 5.5 | 3.5 | (Note 6) | 50 | 1.5 | 39.7 |
| 2199C* | 0.8 | -- | 16.8 | n/s | n/s | 38.1 ⁵ | 7.0 ⁵ | 5.2 | 3.4 | n/s | 50 | 1.5 | 39.7 |
| 2199D* | 0.8 | -- | 16.8 | n/s | n/s | 38.1 | 7.0 | 5.2 | 3.4 | n/s | 50 | 1.5 | 39.7 |
| 2199E | -- | -- | 16.8 | n/s | 700 | 40.7 | 9.0 | 5.4 | 3.5 | n/s | 50 | 1.5 | 39.7 |
| 2424A | -- | 0.5 | 2.5 | 1.3 | 216 | 17.3 | -- | 2.03 | 1.01 | 119.0 ⁹ | -- | -- | -- |
| 2426E* | -- | 0.5 | 2.5 | 1.3 | 216 | 12.2 | -- | 2.1 | 1.1 | 83.9 ¹⁰ | -- | -- | -- |
| 2426F* | 1.0 | -- | 2.5 | 1.3 | 216 | 11.9 | -- | 2.1 | 1.1 | 82.4 ¹⁰ | -- | -- | -- |

Notes:

- * Discontinued product; shown for reference only. n/a = not applicable. n/s = not specified.
- 1. Values are listed under this category *after* subtracting processor and base memory/HP-IB card consumption (when included with product). Values flagged with notes 5, 9, 10, 11, and 12 are exceptions.
- 2. Maximum power required for any combination of HP interfaces and other plug-ins which can be accommodated by the product number indicated. Power factor (PF) is typically 0.75 with a range of 0.7 to 0.8. Use a PF of 0.7 to 0.72 to estimate ac input requirements in Volt-Amps (VA) from Watts (W) to ensure sufficient total input power (that is, VA = W/PF). To estimate ventilation or air conditioning requirements in BTU per hour, multiply W by 3.419. To determine heat dissipation requirements in kilogram-calories per hour, multiply W by 0.8598.
- 3. +5V(M) is voltage available to processor, memory controller, and memory array cards.
- 5. Combined current consumption at +5.1 V and +5 V(M), *including* processor and base memory/HP-IB cards, when included with product, is limited to 70 W.
- 6. Main power supply provides enough current for any combination of HP interfaces and other HP plug-ins which can be accommodated by the product indicated.
- 7. Values apply only to computers or SPUs having a serial number prefix of 2648 or greater.
- 8. Current required per phase. HP 2197C*/E, and 2199A*/C*/E, with tall cabinet, require split phase; HP 2197B*/D* and 2199B*/D* require single phase.
- 9. Total main dc power supply consumption, *including* processor and base memory card(s), when included with product, is limited to 151 W.
- 10. Total main dc power supply consumption, *including* processor and base memory cards, when included with product, is limited to 157 W.

Table 1-5. Maximum Electrical Requirements and Availability by HP Product Number (Sheet 5 of 7)

| Hewlett-Packard Product Number | Product Includes: | | Input Required From: | | Output Available From: | | | | | | | | | |
|--------------------------------|--------------------------------|-----------------|-------------------------|-----------|-----------------------------------|--------------------------|-----------|---------------------|-----------|------|---------------------|------------------|-------------------|--------------------|
| | Base Memory ECC Parity (MB) | HP-IB Interface | Exterior Ac Line | | Main Dc Power Supply ¹ | | | 25 KHz Power Supply | | | | | | |
| | | | Oper. Current @115V (A) | @230V (A) | @+5V (A) | @+5V(M) (A) ³ | @+12V (A) | @-12V (A) | Total (W) | (W) | (A) | @ (Vrms) | | |
| | (MB) | (MB) | (A) | (A) | (A) | (A) | (A) | (W) | (W) | (A) | (Vrms) | | | |
| 2426G | -- | 0.5 | No | 2.5 | 1.3 | 216 | 12.3 | -- | 2.1 | 1.1 | 83.9 ⁹ | -- | -- | -- |
| 2426H | 1.0 | -- | No | 2.5 | 1.3 | 216 | 11.9 | -- | 2.1 | 1.1 | 82.4 ⁹ | -- | -- | -- |
| 2434A | -- | 0.5 | No | 6.0 | 3.0 | 500 | 38.8 | 5.4 | 6.93 | 2.91 | 268.0 ¹¹ | 30 ¹³ | 1.5 ¹³ | 19.5 ¹³ |
| 2436A* | -- | 0.1 | No | 6.0 | 3.0 | 500 | 33.4 | 5.9 | 7.0 | 3.0 | 246.5 ¹¹ | 30 ¹³ | 1.5 ¹³ | 19.5 ¹³ |
| 2436E* | -- | 0.5 | No | 6.0 | 3.0 | 500 | 33.4 | 5.8 | 7.0 | 3.0 | 246.0 ¹¹ | 30 ¹³ | 1.5 ¹³ | 19.5 ¹³ |
| 2436G | -- | 0.5 | No | 6.0 | 3.0 | 500 | 33.4 | 5.8 | 6.7 | 3.0 | 246.0 ¹¹ | 30 ¹³ | 1.5 ¹³ | 19.5 ¹³ |
| 2436H | 1.0 | -- | No | 6.0 | 3.0 | 500 | 33.4 | 5.7 | 6.7 | 3.0 | 245.5 ¹¹ | 30 ¹³ | 1.5 ¹³ | 19.5 ¹³ |
| 2437A* | -- | 0.1 | No | 6.0 | 3.0 | 500 | 25.9 | 5.6 | 7.0 | 3.0 | 207.5 ¹¹ | 30 ¹³ | 1.5 ¹³ | 19.5 ¹³ |

Notes:

- * Discontinued product; shown for reference only. n/a = not applicable. n/s = not specified.
- 1. Values are listed under this category after subtracting processor and base memory/HP-IB card consumption (when included with product). Values flagged with notes 5, 9, 10, 11, and 12 are exceptions.
- 2. Maximum power required for any combination of HP interfaces and other plug-ins which can be accommodated by the product number indicated. Power factor (PF) is typically 0.75 with a range of 0.7 to 0.8. Use a PF of 0.7 to 0.72 to estimate ac input requirements in Volt-Amps (VA) from Watts (W) to ensure sufficient total input power (that is, VA=W/PF). To estimate ventilation or air conditioning requirements in BTU per hour, multiply W by 3.419. To determine heat dissipation requirements in kilogram-calories per hour, multiply W by 0.8598.
- 3. +5V(M) is voltage available to processor, memory controller, and memory array cards.
- 9. Total main dc power supply consumption, including processor and base memory card(s), when included with product, is limited to 151 W.
- 11. Total main dc power supply consumption, including processor and base memory/HP-IB card(s), when included with product, is limited to 300 W.
- 13. Applicable only if HP 12159A card is installed. Value is split phase (measured from phase to common).

Table 1-5. Maximum Electrical Requirements and Availability by HP Product Number (Sheet 6 of 7)

| Hewlett-Packard Product Number | Product Includes: | | Input Required From: | | Output Available From: | | | | | | | | | |
|--------------------------------|--------------------------------|----------------------|----------------------------|--------------------------------|-----------------------------------|--------------------------|-----------|---------------------|-----------|------|-------|----------|-----|------|
| | Base Memory ECC Parity (MB) | HP-IB Inter- face | Exterior Ac Line | | Main Dc Power Supply ¹ | | | 25 KHz Power Supply | | | | | | |
| | | | Oper. Current @115V (A) | Maximum Power (W) ² | @+5V (A) | @+5V(M) (A) ³ | @+12V (A) | @-12V (A) | Total (W) | (W) | (A) | @ (Vrms) | | |
| 2437B* | -- | -- | No | 6.0 | 3.0 | 500 | 23.0 | 6.7 | 7.0 | 3.0 | 198.5 | 30 | 1.5 | 19.5 |
| 2439A* | 0.8 | -- | No | 6.0 | 3.0 | 500 | 27.9 | 3.0 | 7.0 | 3.0 | 222.5 | 30 | 1.5 | 19.5 |
| 2439B | -- | -- | No | 6.0 | 3.0 | 500 | 27.9 | 3.0 | 7.0 | 3.0 | 222.5 | 30 | 1.5 | 19.5 |
| 2484A* | -- | 0.5 | Yes | 6.0 | 3.0 | 500 | 36.7 | 5.4 | 6.83 | 2.91 | 256.3 | 30 | 1.5 | 19.5 |
| 2484B | -- | 0.5 | Yes | 6.0 | 3.0 | 500 | 36.7 | 5.4 | 6.83 | 2.91 | 256.3 | 30 | 1.5 | 19.5 |
| 2486A* | -- | 0.5 | Yes | 6.0 | 3.0 | 500 | 29.7 | 5.8 | 6.7 | 2.9 | 222.7 | 30 | 1.5 | 19.5 |
| 2486B | -- | 0.5 | Yes | 6.0 | 3.0 | 500 | 31.3 | 5.8 | 6.6 | 3.0 | 234.3 | 30 | 1.5 | 19.5 |
| 2486C | 1.0 | -- | Yes | 6.0 | 3.0 | 500 | 31.2 | 5.6 | 6.6 | 3.0 | 232.8 | 30 | 1.5 | 19.5 |

Notes:

- * Discontinued product; shown for reference only. n/a = not applicable. n/s = not specified.
- 1. Values are listed under this category *after* subtracting processor and base memory/HP-IB card consumption (when included with product). Values flagged with notes 5, 9, 10, 11, and 12 are exceptions.
- 2. Maximum power required for any combination of HP interfaces and other plug-ins which can be accommodated by the product number indicated. Power factor (PF) is typically 0.75 with a range of 0.7 to 0.8. Use a PF of 0.7 to 0.72 to estimate ac input requirements in Volt-Amps (VA) from Watts (W) to ensure sufficient total input power (that is, VA = W/PF). To estimate ventilation or air conditioning requirements in BTU per hour, multiply W by 3.419. To determine heat dissipation requirements in kilogram-calories per hour, multiply W by 0.8598.
- 3. +5V(M) is voltage available to processor, memory controller, and memory array cards.
- 11. Total main dc power supply consumption, *including* processor and base memory/HP-IB card(s), when included with product, is limited to 300 W.
- 12. Combined current consumption at +5.1 V and +5 V(M) *including* processor and base memory/HP-IB cards, when included with product, is limited to 50 W.
- 13. Applicable only if HP 12159A card is installed. Value is split phase (measured from phase to common).

Table 1-5. Maximum Electrical Requirements and Availability by HP Product Number (Sheet 7 of 7)

| Hewlett-Packard Product Number | Product Includes: | | Input Required From: | | | Output Available From: | | | | | | | | | | |
|--------------------------------|--------------------------------|-----------------|----------------------------|-----------|--------------------------------|-----------------------------------|---------------------------|-----------|---------------------|-----------|----------|-----|----------|-----|-----|------|
| | Base Memory ECC Parity (MB) | HP-IB Interface | Exterior Ac Line | | | Main Dc Power Supply ¹ | | | 25 KHz Power Supply | | | | | | | |
| | | | Oper. Current @115V (A) | @230V (A) | Maximum Power (W) ² | @+5V (A) | @+5V (M) (A) ³ | @+12V (A) | @-12V (A) | Total (W) | (W) | (A) | @ (Vrms) | | | |
| | | | | | | | | | | | | | | 6.0 | 3.0 | 500 |
| 2487A* | -- | 0.5 | Yes | 6.0 | 3.0 | 500 | 22.0 | 5.6 | 6.7 | 2.9 | 184.2 | 11 | 30 | 1.5 | 13 | 19.5 |
| 2487B* | -- | -- | Yes | 6.0 | 3.0 | 500 | 20.9 | 6.7 | 6.9 | 3.0 | 186.8 | 11 | 30 | 1.5 | 13 | 19.5 |
| 2489A* | 0.8 | -- | Yes | 6.0 | 3.0 | 500 | 23.1 | 1.0 | 6.7 | 2.9 | 165.7 | 11 | 30 | 1.5 | 13 | 19.5 |
| 2489B | -- | -- | Yes | 6.0 | 3.0 | 500 | 25.8 | 3.0 | 6.9 | 3.0 | 210.8 | 11 | 30 | 1.5 | 13 | 19.5 |
| 2939A | -- | -- | No | 6.0 | 3.0 | 500 | 36.7 | 5.7 | 7.0 | 3.0 | 260 | 11 | 30 | 1.5 | 13 | 19.5 |
| 2959A | -- | -- | No | 6.0 | 3.0 | 800 | 59.3 | 7.3 | 5.4 | 3.4 | (Note 6) | | 50 | 1.5 | 13 | 19.5 |
| 2989A | -- | -- | Yes | 6.0 | 3.0 | 500 | 34.6 | 5.7 | 6.9 | 3.0 | 248.3 | 11 | 30 | 1.5 | 13 | 19.5 |
| 2999A | -- | -- | Yes | 6.0 | 3.0 | 700 | 57.2 | 7.3 | 5.3 | 3.4 | (Note 6) | | 50 | 1.5 | 13 | 19.5 |

Notes:

* Discontinued product; shown for reference only. n/a = not applicable. n/s = not specified.

1. Values are listed under this category *after* subtracting processor and base memory/HP-IB card consumption (when included with product). Values flagged with notes 5, 9, 10, 11, and 12 are exceptions.

2. Maximum power required for any combination of HP interfaces and other plug-ins which can be accommodated by the product number indicated. Power factor (PF) is typically 0.75 with a range of 0.7 to 0.8. Use a PF of 0.7 to 0.72 to estimate ac input requirements in Volt-Amps (VA) from Watts (W) to ensure sufficient total input power (that is, VA = W/PF). To estimate ventilation or air conditioning requirements in BTU per hour, multiply W by 3.419. To determine heat dissipation requirements in kilogram-calories per hour, multiply W by 0.8598.

3. +5V(M) is voltage available to processor, memory controller, and memory array cards.

6. Main power supply provides enough current for any combination of HP interfaces and other HP plug-ins which can be accommodated by the product indicated.

11. Total main dc power supply consumption, *including* processor and base memory/HP-IB card(s), when included with product, is limited to 300 W.

13. Applicable only if HP 12159A card is installed. Value is split phase (measured from phase to common).

Product – Option List by Number

Below is a list of product and option numbers and product descriptions covering board and box computers and systems. This list includes currently available and discontinued products. The option list is *not* all-inclusive. The date shown in parentheses after the product name indicates when the product first appeared in the *HP 1000 A-Series Computer Systems Hardware, Software, Peripherals, and Support Ordering Guide* (part no. 5952-1745D or prior edition part no.). The descriptions have been taken from the *most recent* Ordering Guide in which the product/option number appeared. Descriptions generally are not available prior to 6/83. Discontinued products are indicated with an asterisk (*) after the date (for example, 11/87*).

12100A A400 BOARD COMPUTER (11/86): Single card computer with CPU and 512 KB parity memory. Four serial I/O ports are available from breakout panel connected to card.

12990C A400/A600+/A700/A900-TO-A990 UPGRADE KIT (11/90): A990 single card CPU, frontplane connectors for 1 to 4 memory array cards, and RTE-A upgrade tape.

022 CS/80 cartridge tape media.

044 Microdiskette media.

061 1600 cpi reel-to-reel tape media.

100 “A” software copy license upgrade.

200 Replace 1 to 4 frontplane memory card connectors with 5 to 8.

400 Return credit for A400 processor.

600 Return credit for A600+ processor with parity mem controller.

605 Return credit for A600+ processor with ECC mem controller.

700 Return credit for A700 processor.

900 Return credit for A900 processor.

905 A900 to A990 upgrade incentive.

2106AK A600+ BOARD COMPUTER (Before 6/83*): CPU card and memory controller card with 128 KB parity memory.

2106BK A600+ BOARD COMPUTER (6/83 or before*): CPU card and memory controller card with 128 KB parity memory.

014 Delete standard 128 KB memory controller card.

2106CK A600+ BOARD COMPUTER (11/87): CPU card and memory controller card with 512 KB parity memory.

2106DK A600+ BOARD COMPUTER (11/87): CPU card and memory controller card with 1 MB ECC memory.

2107AK A700 BOARD COMPUTER (6/83 or before*): CPU card and memory controller card with 128 KB parity memory.

001 Add floating point processor with scientific/vector instruction sets.

014 Delete standard 128 KB memory controller card.

2134A A400 (MODEL 24) 20-SLOT BOX COMPUTER (11/87): Single card computer with CPU and 512 KB parity memory. Four serial I/O ports are available from breakout panel connected to the card. Includes box with power supply.

010 Discount for upgrade from E/F-Series systems.

015 230 V ac/50 Hz power.

2136A/C A600 (MODEL 6) 8-SLOT BOX COMPUTER (Before 6/83*): CPU card, memory controller card with 128 KB parity memory, dual mini-flexible disk drive, async serial interface card, and HP-IB interface card.

2136B/D A600 (MODEL 6+) 8-SLOT BOX COMPUTER (6/83 or before*): CPU card, memory controller card with 128 KB parity memory, and RTE-A.

2137A A700 (MODEL 27) 20-SLOT BOX COMPUTER (6/83 or before*): 128 KB parity memory and floating point processor.

014 Delete standard 128 KB memory.

015 230 V ac/50 Hz power.

2137B A700 (MODEL 27) 20-SLOT BOX COMPUTER (11/87*): Upper and lower CPU cards, memory controller card (without memory), floating point processor card, and box with power supply.

015 230 V ac/50 Hz power.

2139A A900 (MODEL 29) 20-SLOT BOX COMPUTER (6/83 or before*): 768 KB ECC memory, cache memory, and floating point processor cards.

014 Delete standard 768 KB memory card.

015 230 V ac/50 Hz power.

2139B A900 (MODEL 29) 20-SLOT BOX COMPUTER (11/87): Sequencer card, data path card, cache control card, memory controller card (without memory), and box with power supply.

0CM Discount for upgrade from A400 computer or system.

0C1 Discount for upgrade from A600+ computer or system.

0C2 Discount for upgrade from A700 computer or system.

010 Discount for upgrade from E/F series system.

015 230 V ac/50 Hz power.

2156A A600+ (MODEL 26) 20-SLOT BOX COMPUTER (Before 6/83*)

2156B A600+ (MODEL 26) 20-SLOT BOX COMPUTER (6/83 or before*): CPU card and memory controller card with 128 KB parity memory.

014 Delete standard memory controller.

015 230 V ac/50 Hz power.

2156C A600 (MODEL 26) 20-SLOT BOX COMPUTER (11/87): CPU card, memory controller card with 512 KB parity memory, and box with power supply.

015 230 V ac/50 Hz power.

2156D A600+ (MODEL 26) 20-SLOT BOX COMPUTER (11/87): CPU card, memory controller card with 1 MB ECC memory, and box with power supply .

015 230 V ac/50 Hz power.

2186A A600 (MODEL 6+) 8-SLOT SPU (Before 6/83*): CPU card, memory controller card with 128 KB parity memory, dual mini-flexible disk drive, async serial interface card, HP-IB interface card, and RTE-A.

2186B A600 (MODEL 6+) 8-SLOT SPU (Before 6/83*): CPU card, memory controller card with 128 KB parity memory, async serial interface card, HP-IB interface card, and RTE-A.

2186C A600 (MODEL 6+) 8-SLOT SPU (6/83 or before*): CPU card, memory controller card with 512 KB parity memory, dual mini-flexible disk drive, async serial interface card, HP-IB interface card, and RTE-A.

012 Substitute 128 KB memory controller card for 512 KB card.

2186D A600 (MODEL 6+) 8-SLOT SPU (6/83 or before*): CPU card, memory controller card with 512 KB parity memory, and RTE-A.

012 Substitute 128 KB memory controller card for 512 KB card.

2196A A600+ (MODEL 26) SPU – TALL CABINET (Before 6/83*): Memory controller card with 128 KB parity memory, async serial interface card, HP-IB interface card (to system disk), and RTE-A.

2196B A600+ (MODEL 26) SPU – SHORT CABINET (Before 6/83*): Memory controller card with 128 KB parity memory, async serial interface card, HP-IB interface card (to system disk), and RTE-A.

2196C A600+ (MODEL 26) SPU – TALL CABINET (6/83 or before*): CPU card, memory controller card with 512 KB parity memory, async serial interface card, HP-IB interface card, (to system disk) and RTE-A.

- 005 Add 15 m (49 ft) fiber optic terminal cable.
- 006 Add 5 m (16.4 ft) wire terminal cable.
- 008 Delete HP 12005B Async Serial Interface Card.
- 010 Discount for upgrade from M-Series systems.
- 014 Delete standard memory controller card.
- 015 230 V ac/50 Hz power.
- 022 CS/80 cartridge tape media.
- 051 Upper door trim replacement (allows front-to-rear ventilation).
- 053 Lower door (with ventilation louvers instead of cutout).
- 061 1600 cpi reel-to-reel tape media.
- 070 Delete cabinet from SPU; add support rails and HP-IB card.

2196D A600+ (MODEL 26) 20-SLOT SPU – SHORT CABINET (6/83 or before*): CPU card, memory controller card with 512 KB parity memory, async serial interface card, HP-IB interface card (to system disk), and RTE-A.

- 005 Add 15 m (49 ft) fiber optic terminal cable.
- 006 Add 5 m (16.4 ft) wire terminal cable.
- 008 Delete HP 12005B Async Serial Interface Card.
- 010 Upgrade from M-Series systems.
- 014 Delete standard memory controller card.
- 015 230 V ac/50 Hz power.
- 022 CS/80 cartridge tape media.
- 061 1600 cpi reel-to-reel tape media.

2196G A600+ (MODEL 26) 20-SLOT SPU – SHORT OR TALL CABINET (11/87): CPU card, memory controller card with 512 KB parity memory, HP-IB interface card (to system disk), box with power supply, and RTE-A with VC+ and diagnostics.

- 010 Discount for upgrade from E/F-Series systems.
- 015 230 V ac/50 Hz power.
- 022 CS/80 cartridge tape media.
- 061 1600 cpi reel-to-reel tape media.

2196H A600+ (MODEL 26) 20-SLOT SPU – SHORT OR TALL CABINET (11/87); CPU card, memory controller card with 1 MB ECC memory, HP-IB interface card (to system disk), box with power supply and RTE-A with VC+ and diagnostics.

- 010 Discount for upgrade from E/F-Series systems.
- 015 230 V ac/50 Hz power.
- 022 CS/80 cartridge tape media.
- 061 1600 cpi reel-to-reel tape media.

2197A A700 (MODEL 27) 20-SLOT SPU – TALL CABINET (Before 6/83*).

2197B A700 (MODEL 27) 20-SLOT SPU – TALL CABINET (Before 6/83*).

2197C A700 (MODEL 27) 20-SLOT SPU – TALL CABINET (6/83 or before*): memory controller card with 512 KB parity memory, floating point processor card, async serial interface card, HP-IB interface card (to system disk), and RTE-A with VC+.

005 Add 15 m (49 ft) fiber optic terminal cable.

006 Add 5 m (16.4 ft) wire terminal cable.

008 Delete HP 12005B Async Serial Interface card.

010 Discount for upgrade from M-Series systems.

014 Delete standard memory controller card.

015 230 V ac/50 Hz power.

022 CS/80 cartridge tape media.

051 Upper door trim replacement (allows front-to-rear ventilation).

053 Lower door (with ventilation louvers instead of cutout).

061 1600 cpi reel-to-reel tape media.

070 Delete cabinet from SPU; add support rails and HP-IB card.

2197D A700 (MODEL 27) 20-SLOT SPU – SHORT CABINET (6/83 or before*): Memory controller card with 512 KB parity memory, floating point processor card, async serial interface card, HP-IB interface card (to system disk) and, RTE-A with VC+.

005 Add 15 m (49 ft) fiber optic terminal cable.

006 Add 5 m (16.4 ft) wire terminal cable.

008 Delete HP 12005B Async Serial Interface Card.

010 Discount for upgrade from M-Series systems.

014 Delete standard memory controller card.

015 230 V ac/50 Hz power.

022 CS/80 cartridge tape media.

061 1600 cpi reel-to-reel tape media.

2197E A700 (MODEL 27) 20-SLOT SPU (11/87*): Upper and lower CPU cards, memory controller card (without memory), floating point processor card, HP-IB card (to system disk), box with power supply, and RTE-A with VC+ and diagnostics.

010 Discount for upgrade from from E/F-Series systems.

015 230 V ac/50 Hz power.

022 CS/80 cartridge tape media.

061 1600 cpi reel-to-reel tape media.

2199A A900 (MODEL 29) 20-SLOT SPU (Before 6/83*)

2199B A900 (MODEL 29) 20-SLOT SPU (Before 6/83*).

2199C A900 (MODEL 29) 20-SLOT SPU – TALL CABINET (6/83 or before*): Memory controller card with 768 KB ECC memory, cache memory card, floating point processor card, async serial interface card, HP-IB interface card (to system disk), and RTE-A with VC+.

- 005 Add 15 m (49 ft) fiber optic terminal cable.
- 006 Add 5 m (16.4 ft) wire terminal cable.
- 008 Delete HP 12005B Async Serial Interface Card.
- 010 Discount for upgrade from M/E/F-Series systems.
- 014 Delete standard memory controller card.
- 015 230 V ac/50 Hz power.
- 022 CS/80 cartridge tape media.
- 051 Upper door trim replacement (allows front-to-rear ventilation).
- 053 Lower door (with ventilation louvers instead of cutout).
- 061 1600 cpi reel-to-reel tape media.
- 070 Delete cabinet from SPU; adds support rails, and HP-IB card.
- 100 Discount for upgrade from E/F-Series systems.
- 101 Add 0.75 MB memory on CS/80 cartridge tape media.
- 102 Add 2.25 MB memory on CS/80 cartridge tape media.
- 103 Same as option 101 except ads Basic/1000C instead of Pascal/1000.
- 104 Add 2.25 MB memory on CS/80 cartridge tape.
- 111 Add 0.75 MB memory on 1600 cpi reel-to-reel tape media.
- 112 Add 2.25 MB memory on 1600 cpi reel-to-reel tape media.
- 113 Add 0.75 MB memory on 1600 cpi reel-to-reel tape media.
- 114 Add 2.25 MB memory on 1600 cpi reel-to-reel tape media.

2199D A900 (MODEL 29) 20-SLOT SPU – SHORT CABINET (6/83 or before*): Memory controller card with 768 KB ECC memory, cache memory card, floating point processor card, async serial interface card, HP-IB interface card (to system disk), and RTE-A with VC+.

- 005 Add 15 m (49 ft) fiber optic terminal cable.
- 006 Add 5 m (16.4 ft) wire terminal cable.
- 008 Delete HP 12005B Async Serial Interface Card.
- 010 Discount for upgrade from M/E/F-Series systems.
- 014 Delete standard memory controller card.
- 015 230 V ac/50 Hz power.
- 022 CS/80 cartridge tape media.
- 061 1600 cpi reel-to-reel tape media.
- 100 Discount for upgrade from E/F Series systems.
- 101 Add 0.75 MB memory on CS/80 cartridge tape media.
- 102 Add 2.25 MB memory on CS/80 cartridge tape media.
- 103 Same as option 101 except add Basic/1000C instead of Pascal.
- 104 Add 2.25 MB memory on CS/80 cartridge tape media.
- 111 Add 0.75 MB memory on 1600 cpi reel-to-reel tape media.
- 112 Add 2.25 MB memory on 1600 cpi reel-to-reel tape media.

- 113 Add 0.75 MB memory on 1600 cpi reel-to-reel tape media.
- 114 Add 2.25 MB memory on 1600 cpi reel-to-reel tape media).

2199E A900 (MODEL 29) 20-SLOT SPU – SHORT OR TALL CABINET (11/87): Sequencer card, data path card, cache control card, memory controller card (without memory), HP-IB interface card (to system disk), box with power supply, and RTE-A with VC+ and diagnostics.

- 0CM Discount for upgrade from A400 computer or system.
- 0C1 Discount for upgrade from A600+ computer or system.
- 0C2 Discount for upgrade from A700 computer or system.
- 010 Discount for upgrade from E/F series system.
- 015 230 V ac/50 Hz power.
- 022 CS/80 cartridge tape media.
- 061 1600 cpi reel-to-reel tape media.

2424A A400 (MICRO 14) 6-SLOT BOX COMPUTER (11/86): Single card computer with CPU and 512 KB parity memory. Four serial I/O ports are available from breakout panel connected to card. Includes box with power supply

- 010 Discount for upgrade from E/F-Series systems..
- 015 230 V ac/50 Hz power.

2426E A600+ (MICRO 16) 6-SLOT BOX COMPUTER (4/86*): CPU card, memory controller card with 512 KB parity memory, and box with power supply.

- 015 230 V ac/50 Hz power..

2426F A600+ (MICRO 16) 6-SLOT BOX COMPUTER (4/86*): CPU card, memory controller card with 1 MB ECC memory.

- 015 230 V ac/50 Hz power, and box with power supply.

2426G A600+ (MICRO 16) 6-SLOT BOX COMPUTER (11/87): CPU card, memory controller card with 512 KB parity memory, and box with power supply.

- 015 230 V ac/50 Hz power.

2426H A600+ (MICRO 16) 6-SLOT BOX COMPUTER (11/87): CPU card, memory controller card with 1 MB ECC memory, and box with power supply .

- 015 230 V ac/50 Hz power.

2434A A400 (MICRO 24) 16-SLOT BOX COMPUTER (11/86): Single card computer with CPU and 512 KB parity memory. Four serial I/O ports are available from breakout panel connected to the card. Includes box with power supply.

- 010 Discount for upgrade from E/F-Series systems.

015 230 V ac/50 Hz power.

151 Preparation kit for HP 12122A Integrated Disks.

2436A A600+ (MICRO 26) 16-SLOT BOX COMPUTER (6/83 or before*): CPU card and memory controller card with 128 KB parity memory.

014 Delete standard 128 KB memory controller card.

111 Add integrated 14.5 MB fixed and 270 KB microflexible disk drives and interfaces.

2436E A600+ (MICRO 26) 16-SLOT BOX COMPUTER (6/85*): CPU card and memory controller card with 512 KB parity memory.

014 Delete standard memory controller card.

015 230 V ac/50 Hz power.

151 Preparation kit for HP 12120A/12121A Integrated Disks.

2436G A600+ (MICRO 26) 16-SLOT BOX COMPUTER (11/87): CPU card, memory controller card with 512 KB parity memory, and box with power supply.

015 230 V ac/50 Hz power.

151 Preparation kit for HP 12122A Integrated Disks.

2436H A600+ (MICRO 26) 16-SLOT BOX COMPUTER (11/87): CPU card, memory controller card with 1 MB ECC memory, and box with power supply .

015 230 V ac/50 Hz power.

151 Preparation kit for HP 12122A Integrated Disks.

2437A A700 (MICRO 27) 16-SLOT BOX COMPUTER (6/83 or before*): Memory controller card with 128 KB parity memory.

001 Add floating point processor card.

014 Delete standard memory controller card.

015 230 V ac/50 Hz power.

151 Preparation kit for HP 12120A/12121A Integrated Disks.

2437B A700 (MICRO 27) 16-SLOT BOX COMPUTER (11/87*): Upper and lower processor cards, memory controller card (without memory), floating point processor card, and box with power supply.

015 230 V ac/50 Hz power.

151 Preparation kit for HP 12122A Integrated Disks.

2439A A900 (MICRO 29) 16-SLOT BOX COMPUTER (6/83 or before*): Memory controller card with 768 KB ECC memory.

- 014 Delete standard memory controller card.
- 015 230 V ac/50 Hz power.
- 151 Preparation kit for HP 12120A/12121A Integrated Disks.

2439B A900 (MICRO 29) 16-SLOT BOX COMPUTER (11/87):
 Sequencer card, data path card, cache control card, memory controller card (without memory), and box with power supply.

- 0CM Discount for upgrade from A400 computer or system.
- 0C1 Discount for upgrade from A600+ computer or system.
- 0C2 Discount for upgrade from A700 computer or system.
- 010 Discount for upgrade from E/F-Series system.
- 015 230 V ac/50 Hz power.
- 151 Preparation kit for HP 12122A Integrated Disks.

2456A A600+ (MICRO 16 PLUS) 6-SLOT BOX COMPUTER BUNDLE (4/86*): CPU card, memory controller card with 512 KB parity memory, eight-channel MUX card, and HP-IB interface card.

- 001 Substitute 1 MB ECC memory for 512 KB parity memory.
- 002 Add 40 MB Winchester disk.
- 003 Add 55 MB Winchester disk.
- 004 Add 65 MB cartridge tape subsystem.
- 015 230 V ac/50 Hz power.

2459A A900 (MICRO 29 PLUS) 16-SLOT SPU BUNDLE (4/86*): 1.5 MB ECC memory card, eight-channel MUX card, 40 MB Winchester disk, 65 MB cartridge tape subsystem, and RTE-A with VC+.

- 001 Substitute 55 MB Winchester disk for 40 MB disk.
- 002 Substitute 132.1 MB Winchester disk for 40 MB disk.
- 003 Substitute 3 MB ECC memory on 1 card for 1.5 MB on 2 cards.
- 004 Add HP 12007B Modem Interface to another HP 1000 system.
- 005 Add HP 12044A Direct Connect Interface to HP 1000 system.
- 006 Add HP 12076A LAN/1000 Link Interface and HP 91790R Right-To-Copy NS/1000 software.
- 015 230 V ac/50 Hz power.
- 115 Add HP 7945A 55.5 MB CS/80 Fixed Disk (operates from option 015).
- 215 Add HP 7914CT, opt. 140 132.1 MB CS/80 Stand-Alone Disk (operates from option 015).

2484A A400 (MICRO 24) 16-SLOT SPU (Before 11/86*): Single card computer with CPU and 512 KB parity memory. Four serial I/O ports available from breakout panel connected to card. Also includes HP-IB card (to system disk) and RTE-A

- 015 230 V ac/50 Hz power.
- 022 CS/80 cartridge tape media.

- 044 Microdiskette disk media.
- 061 1600 cpi reel-to-reel tape media.
- 150 Preparation kit for HP 12120A Integrated Disks.
- 151 Preparation kit for HP 12121A Integrated Disks.

2484B A400 (MICRO 24) 16-SLOT SPU (11/87) Single card computer with CPU and 512 KB parity memory. Four serial I/O ports available from breakout panel connected to card. Also includes HP-IB card (to system disk), RTE-A with VC+ and diagnostics, and box with power supply.

- 015 230 V ac/50 Hz power.
- 022 CS/80 cartridge tape media.
- 044 Microdiskette media.
- 061 1600 cpi reel-to-reel tape media.
- 151 Preparation kit for HP 12122A Integrated Disk.

2486A A600+ (MICRO 26) SPU (6/83 or before*): Memory controller card with 512 KB parity memory, async serial I/O card, HP-IB interface card (to system disk), and RTE-A.

- 005 Add 15 m (49 ft) fiber optic terminal cable.
- 006 Add 5 m (16.4 ft) wire terminal cable.
- 014 Delete standard memory controller card.
- 015 230 V ac/50 Hz power.
- 022 CS/80 cartridge tape media.
- 044 Microdiskette media.
- 061 1600 cpi reel-to-reel tape media.
- 101 Add HP 12103C 512 KB Parity Memory Array Card, VC+, Basic/1000C, Image 1000, and Graphics 1000-II DGL on CS/80 cartridge tape media.
- 102 Option 101 with FORTRAN 77 and Symbolic Debug/1000.
- 103 Option 101 with Pascal 1000 in place of Basic/1000C.
- 121 Option 101 with software on 270 KB microdiskette media.
- 122 Option 121 with FORTRAN 77 and Symbolic Debug/1000.
- 123 Option 121 with Pascal 1000 in place of Basic/1000C.
- 131 Option 121 with software on 1600 cpi reel-to-reel tape media.
- 132 Option 122 with software on 1600 cpi reel-to-reel tape media.
- 133 Option 123 with software on 1600 cpi reel-to-reel tape media.
- 150 Preparation kit for HP 12120A Integrated Disks.
- 151 Preparation kit for HP 12121A Integrated Disks.

2486B A600+ (MICRO 26) 16-SLOT SPU (11/87): CPU card, memory controller card with 512 KB parity memory, HP-IB interface card (to system disk), box with power supply, and RTE-A with VC+ and diagnostics.

- 015 230 V ac/50 Hz power.
- 022 CS/80 cartridge tape media.
- 044 Microdiskette media.

- 061 1600 cpi reel-to-reel tape media.
- 151 Preparation kit for HP 12122A Integrated Disks.

2486C A600+ (MICRO 26) 16-SLOT ECC SPU (11/87): CPU card, memory controller card with 1 MB ECC memory, HP-IB interface card (to system disk), box with power supply, and RTE-A with VC+ and diagnostics.

- 015 230 V ac/50 Hz power.
- 022 CS/80 cartridge tape media.
- 044 Microdiskette media.
- 061 1600 cpi reel-to-reel tape media.
- 151 Preparation kit for HP 12122A Integrated Disks.

2487A A700 (MICRO 27) 16-SLOT SPU (6/83 or before*): Memory controller card with 512 KB parity memory, async serial interface card, HP-IB interface card (to system disk), box with power supply, and RTE-A .

- 001 Add floating point processor card.
- 005 Add 15 m (49 ft) fiber optic terminal cable.
- 006 Add 5 m (16.4 ft) wire terminal cable.
- 008 Delete HP 12005B Async serial Interface Card.
- 014 Delete standard memory controller card.
- 015 230 V ac/50 Hz power.
- 022 CS/80 cartridge tape media.
- 044 Microdiskette media.
- 061 1600 cpi reel-to-reel tape media.
- 101 Add HP 12103C 512 KB Parity Memory Array Card, VC+, Basic/1000C, Image 1000, and Graphics 1000-II DGL software on CS/80 cartridge tape media.
- 102 Option 101 with FORTRAN 77 and Symbolic Debug/1000.
- 103 Option 101 with Pascal 1000 in place of Basic/1000C.
- 121 Option 101 with software on 270 KB microdiskette media
- 122 Option 121 plus FORTRAN 77 and Symbolic Debug/1000.
- 123 Option 121 with Pascal 1000 in place of Basic/1000C.
- 131 Option 121 with software on 1600 cpi reel-to-reel tape media.
- 132 Option 122 with software on 1600 cpi reel-to-reel tape media.
- 133 Option 123 with software on 1600 cpi reel-to-reel tape media.
- 150 Preparation kit for HP 12120A Integrated Disks.
- 151 Preparation kit for HP 12121A Integrated Disks.

2487B A700 (MICRO 27) 16-SLOT SPU (11/87*): Upper and lower CPU cards, memory controller card (without memory), floating point processor card, HP-IB card (to system disk), box with power supply, and RTE-A with VC+ and diagnostics.

- 015 230 V ac/50 Hz power.
- 022 CS/80 cartridge tape media.
- 044 Microdiskette media.

- 061 1600 cpi reel-to-reel tape media.
- 151 Preparation kit for HP 12122A Integrated Disks.

2489A A900 (MICRO 29) 16-SLOT SPU (6/83 or before*): Memory controller card with 768 KB ECC memory, async serial interface card, HP-IB interface card (to system disk), box with power supply, and RTE-A.

- 005 Add 15 m (49 ft) fiber optic terminal cable.
- 006 Add 5 m (16.4 ft) wire terminal cable.
- 008 Delete HP 12005B Async serial Interface card.
- 014 Delete standard memory controller card.
- 015 230 V ac/50 Hz power.
- 022 CS/80 cartridge tape media.
- 044 Microdiskette media.
- 061 1600 cpi reel-to-reel tape media.
- 101 Add HP 12103C 512 KB Parity Memory Array Card, VC+, Basic/1000C, Image 1000, and Graphics 1000-II DGL software on CS/80 cartridge tape media.
- 102 Option 101 with FORTRAN 77 and Symbolic Debug/1000.
- 103 Option 101 with Pascal 1000 in place of Basic/1000C.
- 121 Option 101 with software on 270 KB microdiskette media.
- 122 Option 121 with FORTRAN 77 and Symbolic Debug/1000.
- 123 Option 121 with Pascal 1000 in place of Basic/1000C.
- 131 Option 121 with software on 1600 cpi reel-to-reel tape media.
- 132 Option 122 with software on 1600 cpi reel-to-reel tape media.
- 133 Option 123 with software on 1600 cpi reel-to-reel tape media.
- 150 Preparation kit for HP 12120A Integrated Disks.
- 151 Preparation kit for HP 12121A Integrated Disks.

2489B A900 (MICRO 29) 16-SLOT SPU (11/87): Sequencer card, data path card, cache control card, memory controller card (without memory), HP-IB card (to system disk), box with power supply, and RTE-A with VC+ with diagnostics.

- 0CM Discount for upgrade from A400 computer or system.
- 0C1 Discount for upgrade from A600+ computer or system.
- 0C2 Discount for upgrade from A700 computer or system.
- 010 Discount for upgrade from E/F series system.
- 015 230 V ac/50 Hz power.
- 022 CS/80 cartridge tape media.
- 044 Microdiskette media.
- 061 1600 cpi reel-to-reel tape media.
- 151 Preparation kit for HP 12122A Integrated Disks.

2939A A990 (MICRO 99) 16-SLOT BOX COMPUTER (11/90): Single card computer with CPU, writable control store, floating point processor, two-level cache, and memory controller (without memory). Also includes box with power supply.

015 230 V ac/50 Hz power.

151 Preparation kit for HP 12122A Integrated Disk.

2959A A990 (MODEL 99) 20-SLOT BOX COMPUTER (11/90): Single card computer with CPU, writable control store, floating point processor, two-level cache, and memory controller (without memory). Also includes box with power supply.

015 230 V ac/50 Hz power.

2989A A990 (MICRO 99) 16-SLOT SPU (11/90): Single card computer with CPU, writable control store, floating point processor, two-level cache, and memory controller (without memory). Also includes HP-IB card (to system disk), box with power supply, and RTE-A with VC+ and diagnostics.

015 230 V ac/50 Hz power.

022 CS/80 cartridge tape media.

044 Microdiskette media.

061 1600 cpi reel-to-reel tape media.

151 Preparation kit for HP 12122A Integrated Disks.

2999A A990 (MODEL 99) 20-SLOT SPU (11/90): Single card computer with CPU, writable control store, floating point processor, two-level cache, and memory controller (without memory) . Also includes HP-IB card (to system disk), box with power supply, and RTE-A with VC+ and diagnostics.

015 230 V ac/50 Hz power.

022 CS/80 cartridge tape media.

061 1600 cpi reel-to-reel tape media.

Peripheral Devices


Tables 1-6 through 1-11 list all supported peripherals on the A-Series. The peripherals are grouped into the tables as follows:

| | |
|------------|-----------------------|
| Table 1-6 | Terminals |
| Table 1-7 | Printers |
| Table 1-8 | Disk Drives |
| Table 1-9 | Tape Drives |
| Table 1-10 | Graphics Devices |
| Table 1-11 | Miscellaneous Devices |

Each table contains a diagram that separates the devices into categories based on the device and interface drivers for those peripheral devices. The peripheral devices are then listed by product number according to the category they fall into.

Driver sizes shown in the tables are for rev. 5000 or later. Driver sizes may vary from revision to revision.

Table 1-6. Terminals by Driver Type



See notes, next page.

Table 1-6. Terminals by Driver Type (continued)

| Category 1 Terminals | | Category 2 Terminals | |
|----------------------|--------------------------------|----------------------|--------------------------------|
| HP Product Number | Device Driver DDC00 or DDC01 | HP Product Number | Device Driver DD*00 |
| 2622A* | Display Terminal | 2382A* | Office Display Terminal |
| 2623A* ^ | Graphics Terminal | 2392A* | Display Terminal |
| 2624A*/B* | Display Terminal | 2393A ^ * | Monochrome Graphics Terminal |
| 2625A* ^ | Dual System Terminal | 2397A ^ * | Color Graphics Terminal |
| 2626A* | Display Station | 2621A*/B*/P* | Display Terminal |
| 2627A ^ | Color Graphics Terminal | 2645A*# | Display Station |
| 2628A* ^ | Word Processing Terminal | 2647A*# | Intelligent Graphics Terminal |
| 2642A* | Display Terminal w/CTU | 2648A*# | Graphics Terminal |
| 2645A*# | Display Station | 2649A* | OEM Terminal |
| 2647A*# | Intelligent Graphics Terminal | 3081A* | Rugged Industrial Terminal |
| 2648A*# | Graphics Terminal | 3082B* | Rugged Industrial Terminal |
| 2649A* | OEM Terminal | 45610B* | Touchscreen Terminal |
| 3081A* | Rugged Industrial Terminal | 45850/1A* | HP150 II Touchscreen Terminal |
| 3082B* | Rugged Industrial Terminal | 700/92 | Replacement Terminal for 2392A |
| 45850/1A* | HP150 II Touchscreen Terminal | 72425A* | Vectra Model 25 PC** |
| 700/92 | Replacement Terminal for 2392A | 72435A* | Vectra Model 35 PC** |
| | | 72445A* | Vectra Model 45 PC** |


* Discontinued product; shown for reference only.

Cartridge tape units in HP 2645A, HP 2647A, and HP 2648A Terminals require Device Driver DD*20 w/DD*00 or DDC01.

^ Supported by device handlers in the HP 92861A Graphics/1000I Device-Independent Graphics Library, version 2.0.

** HP 724xxA Vectra PCs require: (1) monochrome or color monitor connected via appropriate adapter card, (2) serial-parallel, or dual serial dual serial interface, (3) disk operating system, and (4) Advancelink 2392 software or equivalent to function as an HP 1000 A-Series terminal.

Table 1-7. Printers by Driver Type



See notes, next page.

Table 1-7. Printers by Driver Type (continued)

Category 1 Printers

| HP Product Number | Device Driver DD*00 |
|-------------------|--------------------------------------|
| 2225D ^ | 150 cps Thinkjet Printer |
| 2227A ^ | 192 cps Quietjet Plus Printer |
| 2228A ^ | 192 cps Quietjet Printer |
| 2235B/D ^ | 240/480 cps RuggedWriter 480 Printer |
| 2276A * | DeskJet Printer |
| 2277A * | DeskJet Plus Printer |
| HP Product Number | Device Driver DDC00 |
| 2562C* ^ | 420 lpm Line Printer |
| 2563A*/B*/C+049 ^ | 420 lpm Line Printer |
| 2564A*/B*/C+049 ^ | 840 lpm Line Printer |
| 2565A+049* ^ | 600 lpm Line Printer |
| 2566A*/B*/C+049 ^ | 1200 lpm Line Printer |
| 2631A*/B* | Printer |
| 2680A | 45 ppm Laser Printer |
| 2684A/D ^ | LaserJet/2000 Printer |
| 2686A* ^ | 8 ppm LaserJet Printer |
| 2686A+300* ^ | 8 ppm LaserJet Plus Printer |
| 2687A * | 12 ppm Laser Printer; Desktop |
| 2688A * | 12 ppm Laser Printer |
| 2932A* ^ | 200 cps General-Purpose Printer |
| 2933A * | Factory Data Printer |
| 2934A ^ | 67/100/200 cps Business Printer |
| 33049A | 8 ppm Laser Jet Series III Printer |
| 33440A* ^ | 8 ppm LaserJet Series II Printer |
| 3630A+001 ^ | PaintJet Printer |

Category 2 Printers


| HP Product Number | Device Driver DDC12 |
|-------------------|--------------------------------------|
| 2562C* ^ | 420 lpm Line Printer |
| 2563A*/B*/C+214 ^ | 420 lpm Line Printer |
| 2564A*/B*/C+214 ^ | 840 lpm Line Printer |
| 2565A+214* ^ | 600 lpm Line Printer |
| 2566A*/B*/C+214 ^ | 1200 lpm Line Printer |
| 2608S+214* | Line Printer |
| HP Product Number | Device Driver DD*12 |
| 2235B/D ^ | 240/480 cps RuggedWriter 480 Printer |
| 2631A*/B* | Printer |
| 2932A* ^ | 200 cps General-Purpose Printer |
| 2933A * | Factory Data Printer |
| 2934A ^ | 67/100/200 cps Business Printer |
| HP Product Number | (See Note A below) |
| 2671A * | Thermal Printer |
| 2671G * | 120 cps Graphics (thermal) Printer |
| 2673A*/G* | 120 cps Intelligent Graphics Printer |

* Discontinued product; shown for reference only.

^ Supported by device handlers in the HP 92861A Graphics/1000II Device-Independent Graphics Library, version 2.0.

Note A: HP 2671A*, HP 2671G*, and HP 2673A*/G* Printers are supported only by HP-IB interface driver ID*37 so all output to those printers must transfer character strings at the interface level.

Table 1-8. Disk Drives by Driver Type (Sheet 1 of 2)



(See Category 1, next pg.)

See notes, next page.

Table 1-8. Disk Drives by Driver Type (Sheet 1 of 2, continued)


Category 1 Disk Drives (continued)

| HP Product Number | Device Driver DD*33 | HP Product Number | Device Driver DD*33 |
|-------------------|--|-------------------|--|
| 12122A* | 20 MB Fixed Disk w/630 KB Microflexible Disk – for integration into Micro/1000 CPU/SPU | 7957A* | 81 MB Fixed Disk |
| C2200A | 335 MB Fixed Disk | 7957B* | 81 MB Winchester Disk |
| C2202A | 670 MB Fixed Disk w/cache | 7958A* | 130 MB Fixed Disk |
| C2203A | 670 MB Fixed Disk w/ two cache | 7958B* | 152 MB Winchester Disk |
| 7907A* | 20 MB Fixed/20 MB Removable Disk | 7959B* | 304 MB Winchester Disk |
| 7908P/R* | 16 MB Fixed Disk w/Cartridge Tape Drive | 7962B* | 304 MB Winchester Disk |
| 7911P/R* | 28 MB Fixed Disk w/Cartridge Tape Drive | 7963B* | (Dual 1, 42 MB) Flexible Disk |
| 7912P/R* | 65 MB Fixed Disk w/Cartridge Tape Drive | 9122D*/S* | Dual 630 KB Microflexible Disks |
| 7914C/T* | 131 MB Fixed Disk w/Cartridge Tape Drive | 9133D* | 15 MB Fixed Disk w/630 KB Microflexible Disk |
| 7914P/R* | 131 MB Fixed Disk w/Cartridge Tape Drive | 9133H* | 20 MB Fixed Disk w/630 KB Microflexible Disk |
| 7914ST* | 131 MB Fixed Disk w/1600 cpi Mag. Tape Unit** | 9133L* | 40 MB Fixed Disk w/630 KB Microflexible Disk |
| 7914TD* | 131 MB Fixed Disk w/1600 cpi Mag. Tape Unit | 9134D* | 15 MB Fixed Disk |
| 7933H*/XP* | 404 MB Fixed Disk | 9134H* | 20 MB Fixed Disk |
| 7935H/XP | 404 MB Removable Disk | 9134I* | 40 MB Fixed Disk |
| 7936H*/XP* | 307 MB Fixed Disk | 9153B* | 20 MB Fixed Disk w/630 KB Microflexible Disk |
| 7937H*/XP* | 571 MB Fixed Disk | 9153C* | 20/40 MB Winchester Disk |
| 7941A* | 24 MB Fixed Disk | 9154B* | 20 MB Fixed Disk |
| 7942A* | 24 MB Fixed Disk w/Cartridge Tape Drive | 9262B* | 152 MB Removable Disk |
| 7945A* | 55 MB Fixed Disk | 9263B* | 304 MB Removable Disk/7946A* |
| 7946A* | 55 MB Fixed Disk w/Cartridge Tape Drive | | |

* Discontinued product; shown for reference only.

** The 1600 cpi magnetic tape unit in the HP 7914ST product requires a separate HP 12009A HP-IB interface.

Table 1-8. Disk Drives by Driver Type (Sheet 2 of 2)




See notes, next page.

Table 1-8. Disk Drives by Driver Type (Sheet 2 of 2, continued)

| Category 2 Disk Drives | | Category 4 Disk Drives | |
|-------------------------------|---|-------------------------------|---|
| HP Product Number | Device Driver DDM30 | HP Product Number | No Device Driver |
| 7906M + 102* | 19 MB MAC Master Cartridge Disk | 12120A* | 20 MB Fixed Disk w/630 KB Microflexible Disk for integration in Micro/1000 CPU/SPU |
| 7920M + 102* | 50 MB MAC Master Disk | 12121A* | 20 MB Fixed Disk for integration into Micro/1000 CPU/SPU |
| 7925M + 102* | 120 MB MAC Master Disk | 263xA/E/248xA | Opt. 110* 10 MB Fixed Disk w/270 KB Microflexible for integration in Micro/1000 CPU/SPU |
| | | 263xA/E/248xA | Opt. 111* 15 MB Fixed Disk w/270 KB Microflexible for integration in Micro/1000 CPU/SPU |
| Category 3 Disk Drives | | Category 5 Disk Drives | |
| HP Product Number | Device Driver DD*30 | HP Product Number | Device Driver DDQ30 |
| 9121A* | Dual 270 KB Microflexible Disks | C1701A | 650 MB Rewritable Optical Disk |
| 9133A* | 4.6 MB Fixed Disk w/270 KB Microflexible Disk | C2212A | Mass Storage System w/330 MB Fixed Disk |
| 9133B* | 9.2 MB Fixed Disk w/270 KB Microflexible Disk | C2213A | Mass Storage System w/660 MB Fixed Disk |
| 9133V+004* | 4.5 MB Fixed Disk w/270 KB Microflexible Disk | C2212A/— | Add 332 MB Hard Disk |
| 9133XV+010* | 9.6 MB Fixed Disk w/270 KB Microflexible Disk | 2213A+001 | |
| 9134A* | 4.6 MB Fixed Disk | C2213A+002 | Add 664 MB Hard Disk |
| 9134B* | 9.2 MB Fixed Disk | C2212A/— | Add 650 Rewritable Optical Disk |
| 9134XV+010* | 9.6 MB Fixed Disk | 2213A+005 | |
| 9895A* | Dual 1.2 MB Flexible Disks | | |

* Discontinued product; shown for reference only.

Table 1-9. Tape Drives by Driver Type



See notes, next page.

Table 1-9. Tape Drives by Driver Type (continued)


| Category 1 Tape Drives | | Category 2 Tape Drives | |
|--|--|--|--|
| HP Product Number | Device Driver DD*23 | HP Product Number | Device Driver DD*33 |
| 7970E+626/636* 7971A+140/144** | 600 cpi Magnetic Tape Unit 600 cpi Magnetic Tape Unit | 35401A+100* 7908P/R* 7911P/R* 7912P/R* 7914CT* 7914P/R* 7942A* 7946A* 9144A 9145A | Autochanger Cartridge Tape Subsystem 16 MB Fixed Disk w/Cartridge Tape Drive 28 MB Fixed Disk w/Cartridge Tape Drive 65 MB Fixed Disk w/Cartridge Tape Drive 131 MB Fixed Disk w/Cartridge Tape Drive 131 MB Fixed Disk w/Cartridge Tape Drive 24 MB Fixed Disk w/Cartridge Tape Drive 55 MB Fixed Disk w/Cartridge Tape Drive 67 MB Cartridge Tape Subsystem 134 MB Cartridge Tape Subsystem |
| HP Product Number | Device Driver DD*24 | Category 3 Tape Drives | |
| C1511A* 7914ST* | 1.3 GB DDS HP-IB Tape Drive 131 MB Fixed Disk w/1600 cpi Magnetic Tape Unit** | HP Product Number | Device Driver DDQ24 |
| 7974A* 7978A* 7978B* 7979A 7980A 7980XC | 1600 cpi Magnetic Tape Unit 6250/1600 cpi Magnetic Tape Unit 6250/1600 cpi Magnetic Tape Unit 1600 cpi Autoloading Magnetic Tape Unit 6250/1600 cpi Autoloading Magnetic Tape Unit 6250/1600 cpi Autoloading Magnetic Tape Unit with data compression | C1512A* C2212A C2213A C2212A+003 C2213A+003 | 1.3 GB DDS SCSI Tape Drive Mass Storage System w/330 MB Fixed Disk ^ Mass Storage System w/660 MB Fixed Disk ^ Add 1.3 GB Digital Audio Tape Add 1.3 GB Digital Audio Tape |

* Discontinued product; shown for reference only.

^ Requires DDQ30 Device Driver

** The 1600 cpi magnetic tape unit in the HP 7914ST product requires a separate HP 12009A HP-IB interface and uses Device Driver DD*24.

Table 1-10. Graphics Devices by Driver Type



See notes, next page.

Table 1-10. Graphics Devices by Driver Type (continued)

| Category 1 Graphics Devices | | Category 2 Graphics Devices | |
|---|---|--|---|
| HP Product Number | Device Driver DD*00 (See Note A below) | HP Product Number | (See Notes A and B below) |
| 7440A+001 ^ 7470A+001* ^ | Eight – pen Colorpro Plotter, A-size Two – pen Plotter, A-size | 7225B* ^ 7440A+002* ^ 7475A+002 ^ 7510A* 7550A*/B ^ 7570A/B ^ | Plotter with 17501A HP-IB Interface Eight – pen Colorpro Plotter, A-size Six – pen Plotter, A/B-size Color Film Recorder, 35mm Eight – pen Auto Sheet Feed Plotter, A/B-size Draftpro Plotter w/17570A HP-IB I/F, C/D-size |
| HP Product Number | Device Driver DDC00 (See Note B below) | 7580A*/B*+060* ^ 7585A*/B*+060* ^ 7586B+060* ^ 7595A*/B ^ 7596A*/B ^ 7599A ^ 9111A* ^ 9872A*/B*/S* ^ 9872C*/T* ^ | Eight – pen Drafting Plotter, A-E size Eight – pen Drafting Plotter, A-E size Eight – pen Drafting Plotter, A-D size Eight – pen Drafting Plotter, A-E size Eight – pen Drafting Plotter, A – E size DraftMaster I Plotter, single sheet feed DraftMaster II Plotter, sgl. sheet or roll feed Draftmaster MX Multiuser sgl. sht. or roll feed Graphics Tablet Graphics Plotter Graphics Plotter |
| 7475A+001 ^ 7510A* ^ 7550A*/B ^ 7570A/B ^ 7580A*/B*+060* ^ 7585A*/B*+060* ^ 7586A*/B*+060* ^ 7595A*/B ^ 7596A*/B ^ 7599A ^ | Six – pen Plotter, A/B-size Color Film Recorder, 35mm Eight – pen Auto Sheet Feed Plotter, A/B-size Eight – pen Draftpro Plotter, C/D-size Eight – pen Drafting Plotter, A-D size Eight – pen Drafting Plotter, A-E size Eight – pen Drafting Plotter, A – E size DraftMaster I Plotter, single sheet feed DraftMaster II Plotter, sgl. sheet or roll feed Draftmaster MX Multiuser sgl. sht. or roll feed | | |

* Discontinued product; shown for reference only.

^ Supported by device handlers in the HP 92861A Graphics/1000II Device-Independent Graphics Library, version 2.0..

Note A: Device handlers for graphics devices are provided in the HP 92861A Version 2.0 Graphics/1000-II Device-Independent Graphics Library.

Note B: HP-IB connected plotters and other graphics devices are supported by HP-IB interface driver ID*37 and device handlers in the HP 92861A Version 2.0 Graphics/1000-II Device-Independent Graphics Library which is required for operation.

Table 1-11. Miscellaneous Devices by Driver Type




Table of Contents

Chapter 2 Environmental/Installation/PM

| | |
|---|------|
| Switch Settings | 2-1 |
| A400/A600+/A900/A990 CPU; A700* Frontplane Lower Byte | 2-1 |
| A400 On-Board I/O Switch (U1001) | 2-3 |
| A400 On-Board I/O Cable Switches | 2-4 |
| A700* Frontplane Upper Byte Switch Settings | 2-4 |
| A900 Sequencer Switch Settings | 2-4 |
| A700* Floating Point Processor | 2-5 |
| A700* Writable Control Store | 2-5 |
| A700* PROM Control Store | 2-6 |
| A900 Control Store | 2-7 |
| A400 Micro 14 (6-Slot) Factory Switch Settings | 2-8 |
| A400 Micro/1000 (16-Slot) Factory Switch Settings | 2-8 |
| A600+ Model 6* (8-Slot) Factory Switch Settings | 2-9 |
| A600+ Micro 16 (6-Slot) Factory Switch Settings | 2-9 |
| A600+ Micro/1000 (16-Slot) Factory Switch Settings | 2-10 |
| A600+ Model 26 (20-Slot) Factory Switch Settings | 2-10 |
| A700* Micro/1000 (16-Slot) Factory Switch Settings | 2-11 |
| A700* Model 27 (20-Slot) Factory Switch Settings | 2-11 |
| A900 Micro/1000 (16-Slot) Factory Switch Settings | 2-12 |
| A900 Model 29 (20-Slot) Factory Switch Settings | 2-12 |
| A990 Factory Switch Settings (16- and 20-Slot) | 2-13 |
| Typical Card Placement and Cabling | 2-14 |
| A400 6-Slot Computer Cards and Priority Diagram | 2-14 |
| A400 6-Slot Computer Cabling Diagram (With External CS/80 Disk) | 2-15 |
| A400 6-Slot Computer Cabling Diagram (With External SCSI Disk) | 2-16 |
| A400 16-Slot System Cards and Priority Diagram | 2-17 |
| A400 16-Slot System Cabling Diagram (With External CS/80 Disk) | 2-18 |
| A400 16-Slot System Cabling Diagram (With External SCSI Disk) | 2-19 |
| A400 16-Slot System Cabling Diagram (With Internal Disk - 12022A Interface) | 2-20 |
| A400 16-Slot System Cabling Diagram (With Internal Disk - 12009A Interface) | 2-21 |
| A400 20-Slot System Cards and Priority Diagram | 2-22 |
| A400 20-Slot System Cabling Diagram (With External CS/80 Disk) | 2-23 |
| A400 20-Slot System Cabling Diagram (With External SCSI Disk) | 2-24 |
| A600+ 6-Slot Computer Cards and Priority Diagram | 2-25 |
| A600+ 6-Slot Computer Cabling Diagram (With External CS/80 Disk) | 2-26 |
| A600+ 6-Slot Computer Cabling Diagram (With External SCSI Disk) | 2-27 |
| A600+ Model 6* (8-Slot) System Cards and Priority Diagram | 2-28 |
| A600+ Model 6* (8-Slot) System Cabling Diagram | 2-29 |
| A600+ 16-Slot System Cards and Priority Diagram | 2-30 |
| A600+ 16-Slot System Cabling Diagram (With External CS/80 Disk Drive) | 2-31 |
| A600+ 16-Slot System Cabling Diagram (With External SCSI Disk Drive) | 2-32 |
| A600+ 16-Slot System Cabling Diagram (With Internal Disk - 12022A Interface) | 2-33 |
| A600+ 16-Slot System Cabling Diagram (With Internal Disk - 12009A Interface) | 2-34 |
| A600+ 20-Slot System Cards and Priority Diagram | 2-35 |
| A600+ 20-Slot System Cabling Diagram (With External CS/80 Disk Drive) | 2-36 |
| A600+ 20-Slot System Cabling Diagram (With External SCSI Disk Drive) | 2-37 |
| A700* 16-Slot System Cards and Priority Diagram | 2-38 |
| A700* 16-Slot System Cabling Diagram (With External CS/80 Disk Drive) | 2-39 |

| | |
|--|------|
| A700* 16-Slot System Cabling Diagram (With External SCSI Disk Drive) . . . | 2-40 |
| A700* 16-Slot System Cabling Diagram (With Internal Disk – 12022A Interface) | 2-41 |
| A700* 16-Slot System Cabling Diagram (With Internal Disk – 12009A Interface) | 2-42 |
| A700* 20-Slot System Cards and Priority Diagram | 2-43 |
| A700* 20-Slot System Cabling Diagram (With External CS/80 Disk) | 2-44 |
| A700* 20-Slot System Cabling Diagram (With External SCSI Disk) | 2-45 |
| A900 16-Slot System Cards and Priority Diagram | 2-46 |
| A900 16-Slot System Cabling Diagram (With External CS/80 Disk) | 2-47 |
| A900 16-Slot System Cabling Diagram (With External SCSI Disk) | 2-48 |
| A900 16-Slot System Cabling Diagram (With Internal Disk - 12022A Interface) | 2-49 |
| A900 16-Slot System Cabling Diagram (With Internal Disk - 12009A Interface) | 2-50 |
| A900 20-Slot System Cards and Priority Diagram | 2-51 |
| A900 20-Slot System Cabling Diagram (With External CS/80 Disk) | 2-52 |
| A900 20-Slot System Cabling Diagram (With External SCSI Disk) | 2-53 |
| A990 16-Slot Upgrade from A400, A600+, or A700* - System Cards and Priority Diagram | 2-54 |
| A990 16-Slot Upgrade from A900 - System Cards and Priority Diagram | 2-55 |
| A990 20-Slot Upgrade from A400, A600+, or A700* - System Cards and Priority Diagram | 2-56 |
| A990 20-Slot Upgrade from A900 - System Cards and Priority Diagram | 2-57 |
| A990 16-Slot System Cabling Diagram (With External CS/80 Disk) | 2-58 |
| A990 16-Slot System Cabling Diagram (With External SCSI Disk) | 2-59 |
| A990 20-Slot System Cards and Priority Diagram | 2-60 |
| A990 20-Slot System Cabling Diagram (With External CS/80 Disk) | 2-61 |
| A990 20-Slot System Cabling Diagram (With External SCSI Disk) | 2-62 |
| I/O Extender Micro/1000 Box (HP 12025A) | 2-63 |
| I/O Extender 20-Slot Box (HP 12025B) | 2-63 |
| LAN/1000 Interface Controller Cabling | 2-64 |
| Memory Configurations | 2-65 |
| Memory Rules | 2-65 |
| Memory Products | 2-66 |
| A900 Control Store Placement | 2-68 |
| A700* WCS/PCS Placement | 2-68 |
| A400 Control Memory Map | 2-69 |
| A600 Control Memory Map | 2-70 |
| A600+ Control Memory Map | 2-70 |
| A700* Control Memory Map | 2-71 |
| A900 Control Memory Map | 2-72 |
| A990 Control Memory Map | 2-73 |
| A-Series Power-Up Sequence | 2-74 |
| Power Supply | 2-77 |
| 6-Slot Box (Cooler) Power Supply Test Points | 2-77 |
| 20-Slot Box Power Supply Test Points | 2-78 |
| 20-Slot Box Power Supply Connections | 2-79 |
| Model 6 115/230 Vac Strapping | 2-80 |
| Micro/1000 Power Supply Test Points | 2-81 |
| I/O Extender (12025A) Power Supply Test Points | 2-82 |
| I/O Extender (12025B) Power Supply Voltages | 2-82 |
| Battery Backup | 2-83 |
| 8-Slot Card Cages* (Model 6) | 2-83 |
| 16-Slot Card Cages | 2-84 |
| 20-Slot Card Cages | 2-84 |
| A600+ Processor | 2-85 |
| Switches and Connectors for 8-, 16- and 20-Slot Card Cages | 2-85 |
| Preventive Maintenance | 2-87 |
| General | 2-87 |
| Model 6 Procedures | 2-88 |
| Micro 14/16 Procedures (6-Slot Box – Cooler) | 2-88 |
| Micro 24/26/27*/29/99 Procedures (16-Slot Box – Micro/1000 package) | 2-88 |
| Model 24/26/27*/29/99 Procedures (20-Slot Box) | 2-89 |

Environmental/Installation/PM

Switch Settings

A400/A600+/A900/A990 CPU; A700* Frontplane Lower Byte

The following are the switch settings for the A400 Board U1601 switches, the A600/A600+ and A990 CPU switches, the lower 8 switches on the A700 frontplane, and the A900 Data Path switches.

Boot Sel Switches (see notes on following page)

| S1 | S2 | S3 | S4 | S5 | S6 | S7 | S8 | |
|----|----|----|----|----|----|----|----|--|
| C | C | C | C | z | y | x | M | Loop on self-test Test 2 regardless of error. |
| C | C | O | C | z | y | x | M | Loop on self-test Test 2 and stop on error. |
| C | O | O | C | z | y | x | M | Run VCP routine, for diagnostic purposes only, on completion of the microcoded selftest. |
| O | C | C | C | z | y | x | M | If memory lost (not sustained), run VCP; otherwise, restart program (JMP 4B). (See Note 2, 3, and 4.) |
| O | O | C | O | z | y | x | M | If memory lost (not sustained), speed sense and run VCP; otherwise, restart program (JMP 4B). (See Notes 2, 3, 4, and 6.) |
| O | C | O | C | z | y | x | M | If memory lost, boot from PROM PCA, otherwise, restart program (JMP 4B). (Note 3 and 4) (PROM sc=22; equivalent loader command is %brm) |
| O | O | C | C | z | y | x | M | If memory lost, boot from program from HDLC; otherwise restart prog (JMP 4B). (Note 3) (HDLC sc=24; equivalent loader command is %bds) |
| O | O | O | C | z | y | x | M | If memory lost, boot program from first file on disk (JMP 4B) via HPIB or SCSI; otherwise restart program (JMP4B). SCSI sc=27, addr=6. HPIB sc =27, addr=2. Equivalent loader cmd is %bdc. |
| O | C | C | O | z | y | x | M | If memory lost, boot program from first file on disk (HP 12022A), other wise, restart program (JMP 4B) (Note 3) (12022 sc=32, addr is 0; equivalent loader command is %bdi) |
| C | C | C | O | z | y | x | M | If memory lost, execute bootstring from time-of-day clock RAM on A990 card, other wise, restart program (JMP 4B). (Note 8) |

where: O = Open (up);
 C = Closed (down)
 x = Don't care; MUST be set in DOWN position for A990.
 y = C, system console uses ENQ-ACK handshake.
 y = O, system console does not use ENQ-ACK handshake.
 z = C, Normal Mode, BREAK Enabled on VCP console.
 z = O, BREAK disabled. (VCP console won't halt CPU).
 M = C, Disable Auto-restart, battery backup not installed.
 M = O, Enable Auto-restart, battery backup installed.

NOTES:

* Discontinued product; shown for reference only

1. All settings except speed sense option are true for the following VCP ROMs:
 A600/A600+ = 12102-80003/4 = 5180-4253/54 = 5180-4263/64
 A700 = 12152-80039/40/41/42 = 12152-80043/44/45/46
 = 12152-80058/59/60/61
 A900 ¹ = 12203-80007/8 = 12203-80009/10 = 12203-80012/13
 A900 ² = 5180-4253/4 = 5180-4263/4

¹ old cache control card (12203-60002)

² new cache control card (12203-60011) for I/O Extender support

Previous VCP ROMs had S5 = don't care and S4 = closed for BREAK enabled, open for BREAK disabled. Auto-boot from 12022A is not possible with earlier (prior to 4001) VCP ROMs.

2. Speed sense allows VCP to execute at any supported baud rate on the A400 on-board I/O or the 8-channel rev 'D' MUX (software rev 4010 or higher). The speed sense option can only be used with VCP rev 4020 or higher. Refer to the VCP firmware history for each CPU in Chapter 8 for ROM part numbers.

Speed sense and autoboot cannot be selected together

3. When a loader finishes an auto-boot, it starts execution of the loaded program at location 02.
4. If the auto-restart feature is disabled (switch S8 closed), the program cannot restart and the boot loader (or VCP routine) will execute.
5. Do not use any switch combination that is not shown above.
6. Use this switch configuration for normal computer operation.
7. The VCP command RS can be used to read all switch settings, except S7 and S8, as follows:

Bit: 15 14 13 12 11 10 9 8 7 6 5 4 3 2 1 0
 Boot Sel. Switch: S6 S5 S4 S3 S2 S1
 where: 0 = switch closed; 1 = switch open

8. This switch setting is only available on the A990.

A400 On-Board I/O Switch (U1001)

The on-board I/O is capable of communicating with RS-232, RS-422, or RS-423 protocol. Each of the four on-board I/O ports is capable of independent configuration selecting one of these standards. Modem control is supported on Ports B and C in either V.28 or RS-232 protocol.

All four ports communicate to the peripherals through the edge connector J2 via a 2-meter cable. At the end of the cable there are four 25-pin connectors on a breakout panel. Each of these connectors will support all three electrical standards, however, RS-422/423 requires an RS-449 connector. An adaptor cable with an RS-449 connector must be fabricated by the customer. Refer to the Installation and Service Manual for your computer for information on the adaptor cable.

The U1001 switches on the A400 board configure the ports for RS-232 or RS-422/RS-423 (switches S1 through S4), configure modem control for V.28 or RS-232 (switches S5 and S6), and determine if Port A will be the VCP interface (switch S7). Note that if modem control is desired, switches S2 and/or S3 (port B and C, respectively) must be configured as RS-232 in addition to setting switches S5 and S6 for V.28 or RS-232.

The select code of the four on-board I/O ports is 77 octal and cannot be changed.

A400 U1001 Switch Settings

| Switch | I/O Port Controlled | Definition |
|--|---------------------|---|
| S1 | A | Open = RS-422/RS-423; Closed = RS-232. |
| S2 | B | Open = RS-422/RS-423; Closed = RS-232. |
| S3 | C | Open = RS-422/RS-423; Closed = RS-232. |
| S4 | D | Open = RS-422/RS-423; Closed = RS-232. |
| S5 | C | Open = V.28; Closed = RS-232. You must also set switch S3 for RS-232 when using Port C for Modem control. |
| S6 | B | Open = V.28; Closed = RS-232. You must also set switch S2 for RS-232 when using Port B for Modem control. |
| S7 [†] | A | Open = does not operate as VCP; Closed = does operate as VCP. |
| [†] Note that only Port A can be used as the VCP interface. | | |

A400 On-Board I/O Cable Switches

There are two switches on the breakout panel of the A400 on-board I/O cable. One switch configures port B and the other switch configures port C. They should be set as follows (note that the two ports are independently configurable):

DCE position – when connecting a *terminal* to the port.

DTE position – when connecting a *modem* to the port.

These switches reverse the transmit and receive lines. Refer to the Installation and Service Manual for your computer for more information.

A700* Frontplane Upper Byte Switch Settings

The following are the switch settings for the upper eight switches on the A700* frontplane:

A700* Front Plane Upper Switch Settings

| Switch Setting | Meaning |
|---|---|
| C C C C C x x x | Normal mode, go to VCP pretest. |
| O x x x x x x x | Loop on Lower Processor selftest. |
| C O x x x x x x | Loop on Upper Processor selftest. |
| C C O x x x x x | Loop on Memory Controller selftest. |
| C C C O x x x x | Loop on Floating Point self-test (if installed) |
| C C C C O x x x | Enable diagnostic window. This setting is used for microcode debugging only. It reduces effective CPU speed by 70%. |
| where: O = Open C = Closed x = don't care | |

A900 Sequencer Switch Settings

The sequencer card switches are set to match the size of the base set PROMs installed on the sequencer card. The card currently has 2k PROMs and switches U204S1–S5 are all closed.

* Discontinued product; shown for reference only.

A700* Floating Point Processor

The following switch settings are for the 12156-60001 floating point processor:

| Switch | Meaning |
|----------------|---|
| 1 – 3 | User ROM 2k Address (open = 1, closed = 0) |
| 4 | User ROM enable – Closed to enable |
| 5 [†] | Jump table overlay enable – Closed to enable |
| 6 [†] | Fixed ROM (FPP/VIS/SIS) enable – Closed to enable |
| 7 – 8 | Don't care |

The factory switch setting for the card is as follows:

S1–8 = 0 0 0 0 C C 0 0

where O = Open, C = Closed

A700* Writable Control Store

The switch pack on the 12153-60001 Writable Control Store Card is used to set the select code of the card as follows:

| Switches | | | | | | | |
|----------|----|----|----|-------------|----|----|----|
| S1 | S2 | S3 | S4 | S5 | S6 | S7 | S8 |
| O | x | < | | select code | | | > |

where: O = Open (up) = logic 1
C = Closed (down) = logic 0
X = don't care

* Discontinued product; shown for reference only.

† These switches must be closed to enable use of the hardware floating point processor with the Floating Point/VIS/SIS firmware

A700* PROM Control Store

The 12155-60001 PROM Control Store card can be physically configured for 1k through 8k of PROM storage, installed in addressable banks of 1k each. At installation, each 1k bank must be address-mapped as a 1k logical module within the computer control store address scheme, using the eight PROM bank address switches located on the PCS card.

NOTE

All empty PROM banks must have switch 5 in the OFF position, which disables that bank. A loaded PROM bank can also be disabled by placing switch 5 in the OFF position.

A700* PROM Control Store Card Configuration Switch Settings

| Logical Module Number | Logical Module Address Blocks | | | PROM Bank Map Switch [†] | | | | |
|-----------------------|-------------------------------|-------------|-----------|-----------------------------------|---|---|---|---|
| | Decimal | Octal | Hex | 5 | 4 | 3 | 2 | 1 |
| 0 | 0-1023 | 0-1777 | 0-3FF | ON | ∅ | ∅ | ∅ | ∅ |
| 1 | 1024-2047 | 2000-3777 | 400-7FF | ON | ∅ | ∅ | ∅ | 1 |
| 2 | 2048-3071 | 4000-3777 | 800-BFF | ON | ∅ | ∅ | 1 | ∅ |
| 3 | 3072-4095 | 6000-7777 | C00-FFF | ON | ∅ | ∅ | 1 | 1 |
| 4 | 4096-5119 | 10000-11777 | 1000-13FF | ON | ∅ | 1 | ∅ | ∅ |
| 5 | 5120-6143 | 12000-13777 | 1400-17FF | ON | ∅ | 1 | ∅ | 1 |
| 6 | 6144-7167 | 14000-15777 | 1800-1BFF | ON | ∅ | 1 | 1 | ∅ |
| 7 | 7168-8191 | 16000-17777 | 1C00-1FFF | ON | ∅ | 1 | 1 | 1 |
| 8 | 8192-9215 | 20000-21777 | 2000-23FF | ON | 1 | ∅ | ∅ | ∅ |
| 9 | 9216-10239 | 22000-23777 | 2400-27FF | ON | 1 | ∅ | ∅ | 1 |
| 10 | 10240-11263 | 24000-25777 | 2800-2BFF | ON | 1 | ∅ | 1 | ∅ |
| 11 | 11264-12287 | 26000-27777 | 2C00-2FFF | ON | 1 | ∅ | 1 | 1 |
| 12 | 12288-13311 | 30000-31777 | 3000-33FF | ON | 1 | 1 | ∅ | ∅ |
| 13 | 13312-14335 | 32000-33777 | 3400-37FF | ON | 1 | 1 | ∅ | 1 |
| 14 | 14336-15359 | 34000-35777 | 3800-3BFF | ON | 1 | 1 | 1 | ∅ |
| 15 | 15360-16383 | 36000-37777 | 3C00-3FFF | ON | 1 | 1 | 1 | 1 |

† On = 0 = closed
Off = 1 = open

* Discontinued product; shown for reference only.

A900 Control Store

The following are the switch settings for the 12205-60001 Control Store card:

| U1 Switches | | | | | | | |
|-------------|----|----|-------------|----|----|----|----|
| S1 | S2 | S3 | S4 | S5 | S6 | S7 | S8 |
| x | x | < | select code | | | | > |

where: Open (up) = logic 1
Closed (down) = logic ∅
X = don't care

If you have installed PROMs on the CS card, it is necessary to select a bank address for the PROMs. The PROM bank address is set by switches U0201S1-S8 on the CS card, and the address must be appropriate for the microprogram addresses in the PROMs.

PCS Address Select for 2k PROMs

| Module Number | Control Store Addresses | | | U0201 Switch [†] | | | |
|---------------|-------------------------|---------------|-----------|---------------------------|----|----|----|
| | Decimal | Octal | Hex | S4 | S5 | S6 | S8 |
| 0 | 0-2047 | 000000-003777 | 0-7FF | 0 | 0 | 0 | 0 |
| 1 | 2048-4095 | 004000-007777 | 800-FFF | 0 | 0 | 0 | 1 |
| 2 | 4096-6143 | 010000-013777 | 1000-17FF | 0 | 0 | 1 | 0 |
| 3 | 6144-8191 | 014000-017777 | 1800-1FFF | 0 | 0 | 1 | 1 |
| 4 | 8192-10239 | 020000-023777 | 2000-27FF | 0 | 1 | 0 | 0 |
| 5 | 10240-12287 | 024000-027777 | 2800-2FFF | 0 | 1 | 0 | 1 |
| 6 | 12288-14335 | 030000-033777 | 3000-37FF | 0 | 1 | 1 | 0 |
| 7 | 14336-16383 | 034000-037777 | 3800-3FFF | 0 | 1 | 1 | 1 |
| 8 | 16384-18431 | 040000-043777 | 4000-47FF | 1 | 0 | 0 | 0 |
| 9 | 18432-20479 | 044000-047777 | 4800-4FFF | 1 | 0 | 0 | 1 |
| 10 | 20480-22527 | 050000-053777 | 5000-57FF | 1 | 0 | 1 | 0 |
| 11 | 22528-24575 | 054000-057777 | 5800-5FFF | 1 | 0 | 1 | 1 |
| 12 | 24576-26623 | 060000-063777 | 6000-67FF | 1 | 1 | 0 | 0 |
| 13 | 26624-28671 | 064000-067777 | 6800-6FFF | 1 | 1 | 0 | 1 |
| 14 | 28672-30719 | 070000-073777 | 7000-77FF | 1 | 1 | 1 | 0 |
| 15 | 30720-32767 | 074000-077777 | 7800-7FFF | 1 | 1 | 1 | 1 |

†₁ = open (up)

0 = closed (down)

Notes: Switches U0201S1-S2 must be open; and switches U0201S3 and S7 must be closed.

Switch U0201S9 must be closed to enable the PCS, and open to disable the PCS.

Switch U0201S10 may be set to either position (don't care)

A400 Micro 14 (6-Slot) Factory Switch Settings

HP 2424A

| Card | Switch Settings |
|---|--|
| A400 Board 12100-60001 | U1601 = OOCOCCCC U1001 = all closed |
| HP-IB Interface 12009-60020 [†] • | U16S1-8 = all closed U1 = OCCOC000 |
| SCSI Interface 12016-60101 [†] • | SW1 = OCCOC000 SW2 = CCCCC000 |
| where: O = Open (up) C = Closed (down) | |
| [†] This interface not included with Micro 14 product. | |
| • No two cards can have same sc when used in same system; boot sc is shown for both SCSI and HP-IB. | |

A400 Micro/1000 (16-Slot) Factory Switch Settings

HP 2484B

| Card | Switch Settings |
|---|--|
| A400 Board 12100-60001 | U1601 = OOCOCCCM [‡] U1601 = OCCOCCCM [‡] U1001 = all closed |
| Disk Drive Interface 12022-60008 ^{*†} (optional) | U1 = CCCOOCOC U1605 = CCCOCCCO (10 Mb) CCCOCCOC (15 Mb) CCCOCCCO (20 Mb) |
| HP-IB Interface 12009-60020 • | U16S1-8 = all closed (down) U1 = OCCOC000 |
| SCSI Interface 12016-60101 [†] • | SW1 = OCCOC000 SW2 = CCCCC000 |
| where: M = C if battery backup not installed; O if battery backup installed. O = Open (up) C = Closed (down) | |
| [†] This interface not included with Micro 24 product. | |
| [‡] With optional internal disk | |
| • No two cards can have same sc when used in same system; boot sc is shown for both SCSI and HP-IB card. | |
| * Discontinued product; replaced by 12009-60020 HPIB card. | |

A600+ Model 6* (8-Slot) Factory Switch Settings

HP 2186B*

| Card | Switch Settings |
|--|--|
| Memory Controller HP 12102A*/B | S1 = NORM † |
| Processor HP 12101A or HP 12105A | U1 = OCCCCCM |
| Minifloppy Drive Controller HP 12021A | S2 = CCCOCOC |
| HP-IB Interface 12009-60020 • | U1651-8 = all closed (down) U1 = OCCOCOOO |
| SCSI Interface 12016-60101 † • | SW1 = OCCOCOOO SW2 = CCCCCOOO |
| Async Serial IF 12005-60012 | U21 = OOOOCCCX U1 = CCCOCCCC |
| Battery Backup HP 12013A | S1 = ON |
| <p>where: M = C if battery backup not installed; O if battery backup installed. O = Open (up) C = Closed (down) X = Don't Care</p> <p>† This interface not included with Model 6 product. ‡ Memory Controller switch set to BATT if Battery Backup option is installed, NORM if not installed.</p> <p>• No two cards can have same sc when used in same system; boot sc is shown for both SCSI and HP-IB card.</p> | |

A600+ Micro 16 (6-Slot) Factory Switch Settings

HP 2426E*/F*

| Card | Switch Settings |
|--|---|
| Processor HP 12105A | U1 switches = OCCCCCCC |
| Memory Controller HP 12102 or 12110 | S1 = NORM † |
| Async Serial IF 12005-60012 † | U21 switches = OOOOCCCX U1 switches = CCCOCCCC |
| HP-IB Interface 12009-60020 † • | U16S1-8 = all closed (down) U1 = OCCOCOOO |
| SCSI Interface 12016-60101 † • | SW1 = OCCOCOOO SW2 = CCCCCOOO |
| MUX Card HP 12040B*/C/D | U1 switches = COCOCCOO |
| <p>where: O = Open (up) C = Closed (down) X = Don't Care</p> <p>† This interface not included with Micro 16 product. ‡ Battery Backup not available on Micro 16 product.</p> <p>• No two cards can have same sc when used in same system; boot sc is shown for both SCSI and HP-IB card.</p> | |

* Discontinued product; shown for reference only.

A600+ Micro/1000 (16-Slot) Factory Switch Settings

HP 2486C

| Card | Switch Settings |
|---|-----------------------------|
| Mem Controller HP 12102A*/B or 12110A*/B | S1 = NORM † |
| Processor HP 12105A | U1 = OCCCCCM |
| | U1 = OCCOCCCM ** |
| Disk Drive Interface 12022-60008* † (optional) | U1 = CCCOOCOC |
| | U1605 = CCCOCCCO (10 Mb) |
| | = CCCOCCOC (15 Mb) |
| | = CCCOCCCO (20 Mb) |
| HP-IB Interface 12009-60020* • | U16S1-8 = all closed (down) |
| | U1 = OCCOCCOO |
| SCSI Interface 12016-60101† • | SW1 = OCCOCCOO |
| | SW2 = CCCCCOOO |
| Async Serial IF 12005-60012† | U21 = OOOOCCCX |
| | U1 = CCCOCCCC |
| MUX Card HP 1240B*/C/D | U1 = COCCOCCO |

where: M = C if battery backup not installed;
 O if battery backup installed.

 O = Open (up)
 C = Closed (down) ** With optional internal disk
 X = Don't Care

† This interface not included with Micro 26 product.
‡ Mem Controller switch set to BA† if Battery Backup is installed, NORM if not.

• No two cards can have same sc when used in same system; boot sc is shown for both SCSI and HP-IB card.

A600+ Model 26 (20-Slot) Factory Switch Settings

HP 2196D*

| Card | Switch Settings |
|---|-----------------------------|
| Mem Controller HP 12102A*/B or HP 12110A*/B | S1 = BAT |
| Processor 12105A | U1 = OCCCCCM |
| HP-IB Interface 12009-60020* • | U16S1-8 = all closed (down) |
| | U1 = OCCOCCOO |
| Async Serial IF 12005-60012 | U21 = OOOOCCCX |
| | U1 = CCCOCCCC |
| SCSI Interface 12016-60101† • | SW1 = OCCOCCOO |
| | SW2 = CCCCCOOO |

where: M = C if battery backup not installed;
 O if battery backup installed.

 O = Open (up)
 C = Closed (down) † This interface not included with Model 26 product.
 X = Don't Care

• No two cards can have same sc when used in same system; boot sc is shown for both SCSI and HP-IB card.

* Discontinued product; shown for reference only.

A700* Micro/1000 (16-Slot) Factory Switch Settings

HP 2487B*

| Card | Switch Settings |
|---|---|
| Frontplane 12160-60001 | Boot Sel & M = OCCCCCM † Boot Sel & M = OCCOCCM ‡ SLFTST = all closed |
| Disk Drive Interface (optional) 12022-60008*† | U1 = CCCOCCOC U1605 = CCCOCCCO (10 Mb) CCCOCCOC (15 Mb) CCCOCCCO (20 Mb) |
| HP-IB Interface 12009-60020 * | U16S1-8 = all closed (down) U1 = OCCOCOOO |
| SCSI Interface 12016-60101 † * | SW1 = OCCOCOOO SW2 = CCCCCOOO |
| Async Serial IF 12005-60012 † | U21 = OOOOCCX U1 = CCCOCCOC |
| MUX Card HP 12040B*/C/D | U1 = COCOCCOO |
| where: M = C if battery backup not installed; O if battery backup installed. O = Open (up) † This interface not included with Micro 27 product. C = Closed (down) ‡ With optional internal disk. * No two cards can have same sc when used in same system; boot sc is shown for both SCSI and HP-IB card. | |

A700* Model 27 (20-Slot) Factory Switch Settings

HP 2197C*/D*

| Card | Switch Settings |
|--|---|
| Frontplane 12156-60002 | Boot Sel & M = OCCCCCM SLFTST = all closed |
| Floating Point 12156-60001 | OOOUJF = OOOOCC |
| HP-IB Interface 12009-60020 * | U16S1-8 = all closed (down) U1 = OCCOCOOO |
| SCSI Interface 12016-60101 † * | SW1 = OCCOCOOO SW2 = CCCCCOOO |
| Async Serial IF 12005-60012 | U21 = OOOOCCX U1 = CCCOCCOC |
| where: M = C if battery backup not installed; O if battery backup installed. O = Open (up) C = Closed (down) † This interface not included with Model 27 product. X = Don't Care ‡ * No two cards can have same sc when used in same system; boot sc is shown for both SCSI and HP-IB card. | |

* Discontinued product; shown for reference only.

A900 Micro/1000 (16-Slot) Factory Switch Settings

HP 2489B

| Card | Switch Settings |
|---|---|
| Data Path 12202-60001 | Boot Sel & M = OCCOCCCM † Boot Sel & M = OCCCCCCM |
| Sequencer 12201-60001 | U0204S1-5 = CCCCC |
| Disk Drive Interface 12022-60008 (optional) | U1 = CCCOOCOC U1605 = CCCOCCCO (10 Mb) = CCCOCCOC (15 Mb) = CCCOOCOC (20 Mb) |
| HP-IB Interface 12009-60020* | U16S1-8 = all closed (down) U1 = OCCOCOOO |
| SCSI Interface 12016-60101 † * | SW1 = OCCOCOOO SW2 = CCCCCOOO |
| Async Serial IF 12005-60012 † | U21 = OOOOCCCX U1 = CCCOCCCC |
| MUX Card HP 12040B*/C/D | U1 = COCOCCOO |
| <p>where: M = C if battery backup not installed; O if battery backup installed.</p> <p>O = Open (up) C = Closed (down) † This interface not included with Micro 29 product. X = Don't Care ‡ With optional interface disk</p> <p>* No two cards can have same sc when used in same system; boot sc is shown for both SCSI and HP-IB card.</p> <p>* Discontinued product; shown for reference only</p> | |

A900 Model 29 (20-Slot) Factory Switch Settings

HP 2199E

| Card | Switch Settings |
|---|--|
| Data Path 12202-60001 | Boot Sel & M = OCCCCCCM |
| Sequencer 12201-60001 | U0204S1-5 = CCCCC |
| HP-IB Interface 12009-60020 * | U16S1-8 = all closed (down) U1 = OCCOCOOO |
| SCSI Interface 12016-60101 † * | SW1 = OCCOCOOO SW2 = CCCCCOOO |
| Async Serial IF 12005-60012 † | U21 = OOOOCCCX U1 = CCCOCCCC |
| <p>where: M = C if battery backup not installed; O if battery backup installed.</p> <p>O = Open (up) C = Closed (down) † This interface not included with Model 29 product. X = Don't Care ‡ With optional interface disk</p> <p>* No two cards can have same sc when used in same system; boot sc is shown for both SCSI and HP-IB card.</p> | |

A990 Factory Switch Settings (16- and 20-Slot)

HP 29x9A

| Card | | Switch Settings |
|------------------------|--|--------------------------------------|
| Processor | 12990-60202 or 12990-60102 [†] | SW2 = OOCZYCM |
| HP-IB Interface | 12009-60020 • | U16S1-8= All closed U1 = OCCOCCOO |
| SCSI Interface | 12016-60101 [†] • | SW1 = OCCOCCOO SW2 = CCCOCCOO |
| Async Serial Interface | 12005-60012 [†] | U21 = OOOOCCCX U1 = CCCOCCOO |
| Multiplexer | HP 12040B*/C/D [†] | U1 = COCOCCOO |

where: O = Open (up).
C = Closed (down).

M = C if battery backup not installed.
= O if battery backup installed.

Y = C when system console uses ENQ-ACK handshaking (normal mode).
= O when system console does not use ENQ-ACK handshaking.

Z = C normal mode, break enabled.
= O break enabled (but not halts).

[†] This interface not included with Micro 99 or Model 99 product.



• No two cards can have same sc when used in same system; boot sc is shown for both SCSI and HP-IB card.

[‡] Standard processor card (and upgrade processor card from A400, A600+, and A700) part no. is 12990-60202. Upgrade, from A900, processor card part no. is 12990-60102.

* Discontinued product: shown for reference only

Typical Card Placement and Cabling

A400 6-Slot Computer Cards and Priority Diagram




Notes:

- 1 Up to four memory array cards are supported.

A400 6-Slot Computer Cabling Diagram (With External CS/80 Disk)


HP 2424A Computer System



Notes:

- * Portions or all of this product line are discontinued; shown for reference only
- ① As additional memory is added, larger frontplane connectors are required. HP 12038-60005 through -60008 connect one through four memory cards respectively.
- ② This diagram may not indicate the proper priority placement of cards in the card cage; see applicable "...Computer Cards and Priority Diagram" for this information.



A400 6-Slot Computer Cabling Diagram (With External SCSI Disk)



Notes:

- * Portions or all of this product line are discontinued; shown for reference only
- 1 As additional memory is added, larger frontplane connectors are required. HP 12038-60005 through -60008 connect one through four memory cards respectively.
- 2 This diagram may not indicate the proper priority placement of cards in the card cage; see applicable "...Computer Cards and Priority Diagram" for this information.
- 3 Cable part no. 12016-60002 is for single-ended SCSI devices. Single-ended and differential devices cannot be connected to the same SCSI interface card (i.e. SCSI bus). Use cable part no. 12016-60003 for differential devices.

A400 16-Slot System Cards and Priority Diagram




Notes:

- 1 Slot 8 is reserved for the optional HP 12159A 25 kHz Power Module. If not installed, this slot must remain unoccupied.
- 2 Slot 15 is the lowest priority I/O card if optional HP 12154A Battery Backup Card is not installed. If the battery backup card is installed, see note 3.
- 3 Slot 16 is reserved for the HP 12154A Battery Backup Card which, when used, extends into the space occupied by slots 14 and 15. This makes slot 13 the lowest priority I/O card slot. If the battery backup card is not installed, a voltage jumper card (part no. 02430-60009) must be installed in slot 16.
- 4 Up to four memory array cards are supported.

A400 16-Slot System Cabling Diagram (With External CS/80 Disk)

HP 2484B System Processor Unit




Notes:

- * Portions or all of this product line are discontinued; shown for reference only
- ① As additional memory is added, larger frontplane connectors are required. HP 12038-60005 through -60008 connect one through four memory cards respectively.
- ② This diagram may not indicate the proper priority placement of cards in the card cage; see applicable "...System Cards and Priority Diagram" for this information.

A400 16-Slot System Cabling Diagram (With External SCSI Disk)


HP 2484B System Processor Unit



Notes:

- * Portions or all of this product line are discontinued; shown for reference only
- 1 As additional memory is added, larger frontplane connectors are required. HP 12038-60005 through -60008 connect one through four memory cards respectively.
- 2 This diagram may not indicate the proper priority placement of cards in the card cage; see applicable "...System Cards and Priority Diagram" for this information.
- 3 Cable part no. 12016-60002 is for single-ended SCSI devices. Single-ended and differential devices cannot be connected to the same SCSI interface card (i.e. SCSI bus). Use cable part no. 12016-60003 for differential devices.

A400 16-Slot System Cabling Diagram (With Internal Disk - HP 12022A** Interface)




Alternate System Console Configurations

Notes:

- * Portions or all of this product line are discontinued; shown for reference only
 - ** Replaced by HP 12009A interface (HP 12122A disk subsystem); see next page.
 - ① The flexible disk drive ribbon cable must be connected to the HP 12022A Card (part no. 12022-60008) so that its red stripe is on the right side as you face the rear of the computer.
 - ② The hard disk drive ribbon cable must be connected to the HP 12022A Card (part no. 12022-60008) so that its red stripe is on the right side as you face the rear of the computer.
 - ③ The flexible disk drive ribbon cable must be connected to the HP 12120A Disk Drive so that its red stripe is on the right as you face the front of the computer
 - ④ The hard disk drive ribbon cables must be connected to the HP 12120A Disk Drive so that its red stripe is on the left as you face the front of the computer
- As additional memory is added, larger frontplane connectors are required.
- ⑤ HP 12038-60005 through -60008 connect one through four memory cards respectively.
 - ⑥ This diagram may not indicate the proper priority placement of cards in the card cage; see applicable "...System Cards and Priority Diagram" for this information.
 - ⑦ HP 12120A is a 20 MB hard disk drive (with flexible disk drive included). A 15 MB and 10 MB hard disk drive device (both with flexible disk drive included) also existed as HP 2484A*, opt. 111 and opt 110 respectively



A400 16-Slot System Cabling Diagram (With Internal Disk - HP 12009A Interface)



Notes:

- * Portions or all of this product line are discontinued; shown for reference only
- ① The HB-IB ribbon cable must be connected to the HP 12009A Card (part no. 12009-60020) so that its red stripe is on the right side as you face the rear of the computer.
- ② When connecting the ribbon cable to the connector on the disk controller card, make sure that you line up the triangle on the side of the connector
- ③ As additional memory is added, larger frontplane connectors are required. HP 12038-60005 through -60008 connect one through four memory cards respectively.
- ④ This diagram may not indicate the proper priority placement of cards in the card cage; see applicable "...System Cards and Priority Diagram" for this information.

A400 20-Slot System Cards and Priority Diagram




Notes:

- ① Up to four memory array cards are supported.

A400 20-Slot System Cabling Diagram (With External CS/80 Disk)


HP 2134A Computer System



Notes:

- * Portions or all of this product line are discontinued; shown for reference only
- ① As additional memory is added, larger frontplane connectors are required. HP 12038-60005 through -60008 connect one through four memory cards respectively.
- ② This diagram may not indicate the proper priority placement of cards in the card cage; see applicable "...System Cards and Priority Diagram" for this information.



A400 20-Slot System Cabling Diagram (With External SCSI Disk)



Notes:


- * Portions or all of this product line are discontinued; shown for reference only
- 1 As additional memory is added, larger frontplane connectors are required. HP 12038-60005 through -60008 connect one through four memory cards respectively.
- 2 This diagram may not indicate the proper priority placement of cards in the card cage; see applicable "...System Cards and Priority Diagram" for this information.
- 3 Cable part no. 12016-60002 is for single-ended SCSI devices. Single-ended and differential devices cannot be connected to the same SCSI interface card (i.e. SCSI bus). Use cable part no. 12016-60003 for differential devices.

A600+ 6-Slot Computer Cards and Priority Diagram



A600+ 6-Slot Computer Cabling Diagram (With External CS/80 Disk)

HP 2426H Computer System




Notes:

- * Portions or all of this product line are discontinued; shown for reference only
- 1 Memory array cards must be located directly above the memory controller card. A second 12038-60005 frontplane connector must be used to connect the first memory array card to the memory controller card. As additional memory array cards are added, the appropriate frontplane connector must be used. HP 12038-60006 through -60008 connect two through four memory array cards respectively.
- 2 Connect gray connectors to gray transmitters; connect blue connectors to blue receivers.
- 3 If HP 12040 MUX card is installed in lieu of 12005-60012 ASIC card, refer to MUX manual (part no. 12040-90123) for cabling information. Note that rev. B or C of the HP 12040 MUX sets a baud rate of 9600 at port 0 for the system console. Rev D of the MUX senses and sets the baud rate to match that of the terminal. To configure the MUX ports, follow the directions in the Welcome file (rev. 4010 or later of RTE-A).
- 4 This diagram may not indicate the proper priority placement of cards in the card cage; see applicable "...Computer Cards and Priority Diagram" for this information.

A600+ 6-Slot Computer Cabling Diagram (With External SCSI Disk)

HP 2426H Computer System



Notes:

* Portions or all of this product line are discontinued; shown for reference only

1 Memory array cards must be located directly above the memory controller card. A second 12038-60005 frontplane connector must be used to connect the first memory array card to the memory controller card. As additional memory array cards are added, the appropriate frontplane connector must be used. HP 12038-60006 through -60008 connect two through four memory array cards respectively.



2 Connect gray connectors to gray transmitters; connect blue connectors to blue receivers.

3 If HP 12040 MUX card is installed in lieu of 12005-60012 ASIC card, refer to MUX manual (part no. 12040-90123) for cabling information. Note that rev. B or C of the HP 12040 MUX sets a baud rate of 9600 at port 0 for the system console. Rev D of the MUX senses and sets the baud rate to match that of the terminal. To configure the MUX ports, follow the directions in the Welcome file (rev. 4010 or later of RTE-A).

4 This diagram may not indicate the proper priority placement of cards in the card cage; see applicable "...Computer Cards and Priority Diagram" for this information.

5 Cable part no. 12016-60002 is for single-ended SCSI devices. Single-ended and differential devices cannot be connected to the same SCSI interface card (i.e. SCSI bus). Use cable part no. 12016-60003 for differential devices.

A600+ Model 6* (8-Slot) System Cards and Priority Diagram




Notes:

* Discontinued product; shown for reference only


☐ See the "A600+ 20-slot System Cards and Priority Diagram" (With Memory Array Card) for an additional memory array card configuration.

A600+ Model 6* (8-Slot) System Cabling Diagram

HP 2186A*/C* System Processor Unit





HP 2186B*/D* System Processor Unit



Notes:

- * Portions or all of this product line are discontinued; shown for reference only
- ① Memory array cards must be located directly above the memory controller card. A second 12038-60005 frontplane connector must be used to connect the first memory array card to the memory controller card. As additional memory array cards are added, the appropriate frontplane connectors must be used. HP 12038-60006 through -60008 connect two through four memory array cards respectively.
- ② If you have a hard disk (for example, HP 7908) as the system disk, it is recommended that the HP-IB interface card be placed above all other I/O cards. (For the HP 2186A/C SPU, the HP 12021 card should always be the lowest card in the card cage.)
- ③ This diagram may not indicate the proper priority placement of cards in the card cage; see preceding "...System Cards and Priority Diagram" for this information.

A600+ 16-Slot System Cards and Priority Diagram




Notes:

- ① Slot 8 is reserved for the optional HP 12159A 25 kHz Power Module. If not installed, this slot must remain unoccupied.
- ② Slot 15 is the lowest priority I/O card if optional HP 12154A Battery Backup Card is not installed. If the battery backup card is installed, see note 3.
- ③ Slot 16 is reserved for the HP 12154A Battery Backup Card which, when used, extends into the space occupied by slots 14 and 15. This makes slot 13 the lowest priority I/O card slot. If the battery backup card is not installed, a voltage jumper card (part no. 02430-60009) must be installed in slot 16.
- ④ Up to four memory array cards are supported.

L8500-45A

A600+ 16-Slot System Cabling Diagram (With External CS/80 Disk Drive)

HP 2486C System Processor Unit



Notes:

* Portions or all of this product line are discontinued; shown for reference only

1 Memory array cards must be located directly above the memory controller card. A second 12038-60005 frontplane connector must be used to connect the first memory array card to the memory controller card. As additional memory array cards are added, the appropriate frontplane connector must be used. HP 12038-60006 through -60008 connect two through four memory array cards respectively.


2 Connect gray connectors to gray transmitters; connect blue connectors to blue receivers.

3 When installing the optional HP 12040 MUX card, refer to the card manual (part no. 12040-90123) for cabling information. Note that rev. B or C of the HP 12040 MUX sets a baud rate of 9600 at Port 0 for the system console. Rev D of the MUX senses and sets the baud rate to match that of the terminal. To configure the MUX ports, follow the directions in the Welcome file (rev. 4010 or later of RTE-A).

4 This diagram may not indicate the proper priority placement of cards in the card cage; see applicable "...System Cards and Priority Diagram" for this information.

A600+ 16-Slot System Cabling Diagram (With External SCSI Disk Drive)

HP 2486C System Processor Unit



Notes:

* Portions or all of this product line are discontinued; shown for reference only

[1] Memory array cards must be located directly above the memory controller card. A second 12038-60005 frontplane connector must be used to connect the first memory array card to the memory controller card. As additional memory array cards are added, the appropriate frontplane connector must be used. HP 12038-60006 through -60008 connect two through four memory array cards respectively.

[2] Connect gray connectors to gray transmitters; connect blue connectors to blue receivers.


[3] When installing the optional HP 12040 MUX card, refer to the card manual (part no. 12040-90123) for cabling information. Note that rev. B or C of the HP 12040 MUX sets a baud rate of 9600 at Port 0 for the system console. Rev D of the MUX senses and sets the baud rate to match that of the terminal. To configure the MUX ports, follow the directions in the Welcome file (rev. 4010 or later of RTE-A).

[4] This diagram may not indicate the proper priority placement of cards in the card cage; see applicable "...System Cards and Priority Diagram" for this information.

[5] Cable part no. 12016-60002 is for single-ended SCSI devices. Single-ended and differential devices cannot be connected to the same SCSI interface card (i.e. SCSI bus). Use cable part no. 12016-60003 for differential devices.

A600+ 16-Slot System Cabling Diagram (With Internal Disk - HP 12022A** Interface)


HP 2486C System Processor Unit



Notes:

- * Portions or all of this product line are discontinued; shown for reference only
 - ** Replaced by HP 12009A Interface (HP 12122A disk subsystem); see next page.
- 1 The flexible disk drive ribbon cable must be connected to the HP 12022A Card (part no. 12022-60008) so that its red stripe is on the right side as you face the rear of the computer.
 - 2 The hard disk drive ribbon cable must be connected to the HP 12022A Card (part no. 12022-60008) so that its red stripe is on the right side as you face the rear of the computer.
 - 3 The flexible disk drive ribbon cable must be connected to the HP 12120A Disk Drive so that its red stripe is on the right as you face the front of the computer
 - 4 The hard disk drive ribbon cables must be connected to the HP 12120A Disk Drive so that its red stripe is on the left as you face the front of the computer
 - 5 Connect gray connectors to gray transmitters. Connect blue connectors to blue receivers.
 - 6 When installing the optional HP 12040 MUX card, refer to the card manual (part no. 12040-90123) for cabling information. Note that rev. B or C of the HP 12040 MUX sets a baud rate of 9600 at Port 0 for the system console. Rev D of the MUX senses and sets the baud rate to match that of the terminal. To configure the MUX ports, follow the directions in the Welcome file (rev. 4010 or later of RTE-A).
 - 7 Memory array cards must be located directly above the memory controller card. A second 12038-60005 frontplane connector must be used to connect the first memory array card to the memory controller card. As additional memory array cards are added, the appropriate frontplane connectors must be used. HP 12038-60006 through -60008 connect two through four memory array cards respectively.
 - 8 This diagram may not indicate the proper priority placement of cards in the card cage; see applicable "...System Cards and Priority Diagram" for this information.
 - 9 HP 12120A is a 20 MB hard disk drive (with flexible disk drive included). A 15 MB and 10 MB hard disk drive device (both with flexible disk drive included) also existed as HP 2486A*, opt. 111 and opt. 110 respectively

A600+ 16-Slot System Cabling Diagram (With Internal Disk - HP 12009A Interface)





Notes:

* Portions or all of this product line are discontinued; shown for reference only

- 1 The HB-IB ribbon cable must be connected to the HP 12009A Card (part no. 12009-60020) so that its red stripe is on the right side as you face the rear of the computer.
- 2 When connecting the ribbon cable to the connector on the disk controller card, make sure that you line up the triangle on the side of the connector
- 3 Connect gray connectors to gray transmitters. Connect blue connectors to blue receivers.
- 4 When installing the optional HP 12040 MUX card, refer to the card manual (part no. 12040-90123) for cabling information. Note that rev. B or C of the HP 12040 MUX sets a baud rate of 9600 at Port 0 for the system console. Rev D of the MUX senses and sets the baud rate to match that of the terminal. To configure the MUX ports, follow the directions in the Welcome file (rev. 4010 or later of RTE-A).
- 5 Memory array cards must be located directly above the memory controller card. A second 12038-60005 frontplane connector must be used to connect the first memory array card to the memory controller card. As additional memory array cards are added, the appropriate frontplane connectors must be used. HP 12038-60006 through -60008 connect two through four memory array cards respectively.
- 6 This diagram may not indicate the proper priority placement of cards in the card cage; see applicable "...System Cards and Priority Diagram" for this information.

A600+ 20-Slot System Cards and Priority Diagram




Notes:

- ¹ Up to four memory array cards are supported.

A600+ 20-Slot System Cabling Diagram (With External CS/80 Disk Drive)

HP 2196G/H System Processor Unit



Notes:

* Portions or all of this product line are discontinued; shown for reference only

1 Memory array cards must be located directly to the right of the memory controller card. A second 12038-60005 frontplane connector must be used to connect the first memory array card to the memory controller card. As additional memory array cards are added, the appropriate frontplane connector must be used. HP 12038-60006 through -60008 connect two through four memory array cards respectively.


2 Connect gray connectors to gray transmitters; connect blue connectors to blue receivers.

3 When installing the optional HP 12040 MUX card, refer to the card manual (part no. 12040-90123) for cabling information. Note that rev. B or C of the HP 12040 MUX sets a baud rate of 9600 at Port 0 for the system console. Rev D of the MUX senses and sets the baud rate to match that of the terminal. To configure the MUX ports, follow the directions in the Welcome file (rev. 4010 or later of RTE-A).

4 This diagram may not indicate the proper priority placement of cards in the card cage; see applicable "...System Cards and Priority Diagram" for this information.

A600+ 20-Slot System Cabling Diagram (With External SCSI Disk Drive)

HP 2196G/H System Processor Unit



Notes:

* Portions or all of this product line are discontinued; shown for reference only

1 Memory array cards must be located directly to the right of the memory controller card. A second 12038-60005 frontplane connector must be used to connect the first memory array card to the memory controller card. As additional memory array cards are added, the appropriate frontplane connector must be used. HP 12038-60006 through -60008 connect two through four memory array cards respectively.


2 Connect gray connectors to gray transmitters; connect blue connectors to blue receivers.

3 When installing the optional HP 12040 MUX card, refer to the card manual (part no. 12040-90123) for cabling information. Note that rev. B or C of the HP 12040 MUX sets a baud rate of 9600 at Port 0 for the system console. Rev D of the MUX senses and sets the baud rate to match that of the terminal. To configure the MUX ports, follow the directions in the Welcome file (rev. 4010 or later of RTE-A).

4 This diagram may not indicate the proper priority placement of cards in the card cage; see applicable "...System Cards and Priority Diagram" for this information.

5 Cable part no. 12016-60002 is for single-ended SCSI devices. Single-ended and differential devices cannot be connected to the same SCSI interface card (i.e. SCSI bus). Use cable part no. 12016-60003 for differential devices.

A700* 16-Slot System Cards and Priority Diagram




Notes:

* Discontinued product; shown for reference only.

- ① Slot 8 is reserved for the optional HP 12159A 25 kHz Power Module. If not installed, this slot must remain unoccupied.
- ② Slot 15 is the lowest priority I/O card if optional HP 12154A Battery Backup Card is not installed. If the battery backup card is installed, see note 3.
- ③ Slot 16 is reserved for the HP 12154A Battery Backup Card which, when used, extends into the space occupied by slots 14 and 15. This makes slot 13 the lowest priority I/O card slot. If the battery backup card is not installed, a voltage jumper card (part no. 02430-60009) must be installed in slot 16.
- ④ Up to four memory array cards are supported.

A700* 16-Slot System Cabling Diagram (With External CS/80 Disk Drive)


HP 2487B* System Processor Unit



Notes:

- * Portions or all of this product line are discontinued; shown for reference only
- As additional memory is added, larger frontplane connectors are required.
- 1 HP 12038-60005 through -60008 connect one through four memory cards respectively.
- 2 If optional floating point card (part no. 12156-60001) is installed between the upper and lower processor, the 12156-60002 front-plane must be used.
- 3 Connect gray connectors to gray transmitters; connect blue connectors to blue receivers.
- 4 When installing the optional HP 12040 MUX card, refer to the card manual (part no. 12040-90123) for cabling information. Note that rev. B or C of the HP 12040 MUX sets a baud rate of 9600 at Port 0 for the system console. Rev D of the MUX senses and sets the baud rate to match that of the terminal. To configure the MUX ports, follow the directions in the Welcome file (rev. 4010 or later of RTEA).
- 5 This diagram may not indicate the proper priority placement of cards in the card cage; see applicable "...System Cards and Priority Diagram" for this information.

A700* 16-Slot System Cabling Diagram (With External SCSI Disk Drive)




Notes:

- * Portions or all of this product line are discontinued; shown for reference only
- As additional memory is added, larger frontplane connectors are required.
- 1 HP 12038-60005 through -60008 connect one through four memory cards respectively.
- 2 If optional floating point card (part no. 12156-60001) is installed between the upper and lower processor, the 12156-60002 frontplane must be used.
- Connect gray connectors to gray transmitters; connect blue connectors to blue receivers.
- 3
- 4 When installing the optional HP 12040 MUX card, refer to the card manual (part no. 12040-90123) for cabling information. Note that rev. B or C of the HP 12040 MUX sets a baud rate of 9600 at Port 0 for the system console. Rev D of the MUX senses and sets the baud rate to match that of the terminal. To configure the MUX ports, follow the directions in the Welcome file (rev. 4010 or later of RTEA).
- 5 This diagram may not indicate the proper priority placement of cards in the card cage; see applicable "...System Cards and Priority Diagram" for this information.
- 6 Cable part no. 12016-60002 is for single-ended SCSI devices. Single-ended and differential devices cannot be connected to the same SCSI interface card (i.e. SCSI bus). Use cable part no. 12016-60003 for differential devices.

A700* 16-Slot System Cabling Diagram (With Internal Disk – HP 12022A** Interface)

HP 2487B* System Processor Unit




Notes:

- * Portions or all of this product line are discontinued; shown for reference only
- ** Replaced by HP 12009A Interface (HP 12122A disk subsystem); see next page.
- ① The flexible disk drive ribbon cable must be connected to the HP 12022A Card (part no. 12022-60008) so that its red stripe is on the right side as you face the rear of the computer.
- ② The hard disk drive ribbon cable must be connected to the HP 12022A Card (part no. 12022-60008) so that its red stripe is on the right side as you face the rear of the computer.
- ③ The flexible disk drive ribbon cable must be connected to the HP 12120A Disk Drive so that its red stripe is on the right as you face the front of the computer
- ④ The hard disk drive ribbon cables must be connected to the HP 12120A Disk Drive so that its red stripe is on the left as you face the front of the computer
- ⑤ Connect gray connectors to gray transmitters. Connect blue connectors to blue receivers.
- ⑥ When installing the optional HP 12040 MUX card, refer to the card manual (part no. 12040-90123) for cabling information. Note that rev. B or C of the HP 12040 MUX sets a baud rate of 9600 at Port 0 for the system console. Rev D of the MUX senses and sets the baud rate to match that of the terminal. To configure the MUX ports, follow the directions in the Welcome file (rev. 4010 or later of RTE-A).
- ⑦ As additional memory is added, larger frontplane connectors are required. HP 12038-60005 through -60008 connect one through four memory cards respectively.
- ⑧ This diagram may not indicate the proper priority placement of cards in the card cage; see applicable "...System Cards and Priority Diagram" for this information.
- ⑨ HP 12120A is a 20 MB hard disk drive (with flexible disk drive included). A 15 MB and 10 MB hard disk drive device (both with flexible disk drive included) also existed as HP 2487A*, opt. 111 and opt. 110 respectively
- ⑩ If optional floating point card (part no. 12156-60001) is installed between the upper and lower processor, the 12156-60002 front-plane must be used.

A700* 16-Slot System Cabling Diagram (With Internal Disk – HP 12009A Interface)

HP 2487B* System Processor Unit




Alternate System Console Configurations

Notes:

- * Portions or all of this product line are discontinued; shown for reference only
- 1 The HB-IB ribbon cable must be connected to the HP 12009A Card (part no. 12009-60020) so that its red stripe is on the right side as you face the rear of the computer.
- 2 When connecting the ribbon cable to the connector on the disk controller card, make sure that you line up the triangle on the side of the connector
- 3 Connect gray connectors to gray transmitters. Connect blue connectors to blue receivers.
- 4 When installing the optional HP 12040 MUX card, refer to the card manual (part no. 12040-90123) for cabling information. Note that rev. B or C of the HP 12040 MUX sets a baud rate of 9600 at Port 0 for the system console. Rev D of the MUX senses and sets the baud rate to match that of the terminal. To configure the MUX ports, follow the directions in the Welcome file (rev. 4010 or later of RTE-A).
- 5 As additional memory is added, larger frontplane connectors are required. HP 12038-60005 through -60008 connect one through four memory cards respectively.
- 6 This diagram may not indicate the proper priority placement of cards in the card cage; see applicable "...System Cards and Priority Diagram" for this information.
- 7 If optional floating point card (part no. 12156-60001) is installed between the upper and lower processor, the 12156-60002 front-plane must be used.

A700* 20-Slot System Cards and Priority Diagram




Notes:

* Discontinued product; shown for reference only

① Up to four memory array cards are supported.

A700* 20-Slot System Cabling Diagram (With External CS/80 Disk)

HP 2197E* System Processor Unit




Notes:

- * Portions or all of this product line are discontinued; shown for reference only
- As additional memory is added, larger frontplane connectors are required.
- 1 HP 12038-60005 through -60008 connect one through four memory cards respectively.
- 2 If optional floating point card (part no. 12156-60001) is installed between the upper and lower processor, the 12156-60002 front-plane must be used.
- 3 Connect gray connectors to gray transmitters; connect blue connectors to blue receivers.
- 4 When installing the optional HP 12040 MUX card, refer to the card manual (part no. 12040-90123) for cabling information. Note that rev. B or C of the HP 12040 MUX sets a baud rate of 9600 at Port 0 for the system console. Rev D of the MUX senses and sets the baud rate to match that of the terminal. To configure the MUX ports, follow the directions in the Welcome file (rev. 4010 or later of RTEA).
- 5 This diagram may not indicate the proper priority placement of cards in the card cage; see applicable "...System Cards and Priority Diagram" for this information.

A700* 20-Slot System Cabling Diagram (With External SCSI Disk)


HP 2197E* System Processor Unit



Notes:

- * Portions or all of this product line are discontinued; shown for reference only
- As additional memory is added, larger frontplane connectors are required.
- 1 HP 12038-60005 through -60008 connect one through four memory cards respectively.
- 2 If optional floating point card (part no. 12156-60001) is installed between the upper and lower processor, the 12156-60002 front-plane must be used.
- 3 Connect gray connectors to gray transmitters; connect blue connectors to blue receivers.
- 4 When installing the optional HP 12040 MUX card, refer to the card manual (part no. 12040-90123) for cabling information. Note that rev. B or C of the HP 12040 MUX sets a baud rate of 9600 at Port 0 for the system console. Rev D of the MUX senses and sets the baud rate to match that of the terminal. To configure the MUX ports, follow the directions in the Welcome file (rev. 4010 or later of RTE-A).
- 5 This diagram may not indicate the proper priority placement of cards in the card cage; see applicable "...System Cards and Priority Diagram" for this information.
- 6 Cable part no. 12016-60002 is for single-ended SCSI devices. Single-ended and differential devices cannot be connected to the same SCSI interface card (i.e. SCSI bus). Use cable part no. 12016-60003 for differential devices.

A900 16-Slot System Cards and Priority Diagram




Notes:

- ❶ Slot 8 is reserved for the optional HP 12159A 25 kHz Power Module. If not installed, this slot must remain unoccupied.
- ❷ Slot 15 is the lowest priority I/O card if optional HP 12154A Battery Backup Card is not installed. If the battery backup card is installed, see note 3.
- ❸ Slot 16 is reserved for the HP 12154A Battery Backup Card which, when used, extends into the space occupied by slots 14 and 15. This makes slot 13 the lowest priority I/O card slot. If the battery backup card is not installed, a voltage jumper card (part no. 02430-60009) must be installed in slot 16.
- ❹ One or two memory array cards are supported.

A900 16-Slot System Cabling Diagram (With External CS/80 Disk)

HP 2489B System Processor Unit




Notes:

- * Portions or all of this product line are discontinued; shown for reference only
- [1] If a second memory array card is added, use memory frontplane connector part no. 12222-60002.
- [2] Connect gray connectors to gray transmitters; connect blue connectors to blue receivers.
- [3] If HP 12040 MUX card is installed in lieu of 12005-60012 ASIC card, refer to MUX manual (part no. 12040-90123) for cabling information. Note that rev. B or C of the HP 12040 MUX sets a baud rate of 9600 at port 0 for the system console. Rev D of the MUX senses and sets the baud rate to match that of the terminal. To configure the MUX ports, follow the directions in the Welcome file (rev. 4010 or later of RTE-A).
- [4] This diagram may not indicate the proper priority placement of cards in the card cage; see applicable "...System Cards and Priority Diagram" for this information.

A900 16-Slot System Cabling Diagram (With External SCSI Disk)

HP 2489B System Processor Unit



Alternate System Console Configurations

Notes:

* Portions or all of this product line are discontinued; shown for reference only

1 If a second memory array card is added, use memory frontplane connector part no. 12222-60002.

2 Connect gray connectors to gray transmitters; connect blue connectors to blue receivers.


3 If HP 12040 MUX card is installed in lieu of 12005-60012 ASIC card, refer to MUX manual (part no. 12040-90123) for cabling information. Note that rev. B or C of the HP 12040 MUX sets a baud rate of 9600 at port 0 for the system console. Rev D of the MUX senses and sets the baud rate to match that of the terminal. To configure the MUX ports, follow the directions in the Welcome file (rev. 4010 or later of RTE-A).

4 This diagram may not indicate the proper priority placement of cards in the card cage; see applicable "...System Cards and Priority Diagram" for this information.

5 Cable part no. 12016-60002 is for single-ended SCSI devices. Single-ended and differential devices cannot be connected to the same SCSI interface card (i.e. SCSI bus). Use cable part no. 12016-60003 for differential devices.

A900 16-Slot System Cabling Diagram (With Internal Disk - HP 12022A** Interface)


HP 2489B System Processor Unit



Notes:

- * Portions or all of this product line are discontinued; shown for reference only
- ** Replaced by HP 12009A Interface (HP 12122A disk subsystem); see next page.
- 1 The flexible disk drive ribbon cable must be connected to the HP 12022A Card (part no. 12022-60008) so that its red stripe is on the right side as you face the rear of the computer.
- 2 The hard disk drive ribbon cable must be connected to the HP 12022A Card (part no. 12022-60008) so that its red stripe is on the right side as you face the rear of the computer.
- 3 The flexible disk drive ribbon cable must be connected to the HP 12120A Disk Drive so that its red stripe is on the right as you face the front of the computer
- 4 The hard disk drive ribbon cables must be connected to the HP 12120A Disk Drive so that its red stripe is on the left as you face the front of the computer
- 5 Connect gray connectors to gray transmitters. Connect blue connectors to blue receivers.
- 6 When installing the optional HP 12040 MUX card, refer to the card manual (part no. 12040-90123) for cabling information. Note that rev. B or C of the HP 12040 MUX sets a baud rate of 9600 at Port 0 for the system console. Rev D of the MUX senses and sets the baud rate to match that of the terminal. To configure the MUX ports, follow the directions in the Welcome file (rev. 4010 or later of RTE-A).
- 7 If a second memory array card is added, use memory frontplane connector part no. 12222-60002.
- 8 This diagram may not indicate the proper priority placement of cards in the card cage; see applicable "...System Cards and Priority Diagram" for this information.
- 9 HP 12120A is a 20 MB hard disk drive (with flexible disk drive included). A 15 MB and 10 MB hard disk drive device (both with flexible disk drive included) also existed as HP 2489A*, opt. 111 and opt. 110 respectively


A900 16-Slot System Cabling Diagram (With Internal Disk - HP 12009A Interface)



Notes:

- * Portions or all of this product line are discontinued; shown for reference only
- 1 The HB-IB ribbon cable must be connected to the HP 12009A Card (part no. 12009-60020) so that its red stripe is on the right side as you face the rear of the computer.
- 2 When connecting the ribbon cable to the connector on the disk controller card, make sure that you line up the triangle on the side of the connector
- 3 Connect gray connectors to gray transmitters. Connect blue connectors to blue receivers.
- 4 When installing the optional HP 12040 MUX card, refer to the card manual (part no. 12040-90123) for cabling information. Note that rev. B or C of the HP 12040 MUX sets a baud rate of 9600 at Port 0 for the system console. Rev D of the MUX senses and sets the baud rate to match that of the terminal. To configure the MUX ports, follow the directions in the Welcome file (rev. 4010 or later of RTEA).
- 5 If a second memory array card is added, use memory frontplane connector part no. 12222-60002.
- 6 This diagram may not indicate the proper priority placement of cards in the card cage; see applicable "...System Cards and Priority Diagram" for this information.

A900 20-Slot System Cards and Priority Diagram




Notes:

- 1 Up to four memory array cards are supported.

A900 20-Slot System Cabling Diagram (With External CS/80 Disk)

HP 2199E System Processor Unit




Notes:

- * Portions or all of this product line are discontinued; shown for reference only
- [1] As additional memory is added, larger frontplane connectors are required. HP 12222-60001 through -60004 connect one through four memory cards respectively.
- [2] Connect gray connectors to gray transmitters; connect blue connectors to blue receivers.
- [3] If HP 12040 MUX card is installed in lieu of 12005-60012 ASIC card, refer to MUX manual (part no. 12040-90123) for cabling information. Note that rev. B or C of the HP 12040 MUX sets a baud rate of 9600 at port 0 for the system console. Rev D of the MUX senses and sets the baud rate to match that of the terminal. To configure the MUX ports, follow the directions in the Welcome file (rev. 4010 or later of RTE-A).
- [4] This diagram may not indicate the proper priority placement of cards in the card cage; see applicable "...System Cards and Priority Diagram" for this information.

A900 20-Slot System Cabling Diagram (With External SCSI Disk)

HP 2199E System Processor Unit




Notes:

Alternate System Console Configurations

- * Portions or all of this product line are discontinued; shown for reference only
- ① As additional memory is added, larger frontplane connectors are required. HP 12222-60001 through -60004 connect one through four memory cards respectively.
- ② Connect gray connectors to gray transmitters; connect blue connectors to blue receivers.
- ③ If HP 12040 MUX card is installed in lieu of 12005-60012 ASIC card, refer to MUX manual (part no. 12040-90123) for cabling information. Note that rev. B or C of the HP 12040 MUX sets a baud rate of 9600 at port 0 for the system console. Rev D of the MUX senses and sets the baud rate to match that of the terminal. To configure the MUX ports, follow the directions in the Welcome file (rev. 4010 or later of RTE-A).
- ④ This diagram may not indicate the proper priority placement of cards in the card cage; see applicable "...System Cards and Priority Diagram" for this information.
- ⑤ Cable part no. 12016-60002 is for single-ended SCSI devices. Single-ended and differential devices cannot be connected to the same SCSI interface card (i.e. SCSI bus). Use cable part no. 12016-60003 for differential devices.

A990 16-Slot Upgrade from A400, A600+, or A700* - System Cards and Priority Diagram




For *internal* disk drive cabling information, refer to the applicable processor and disk configuration cabling diagram *preceding* this page.

For *external* disk drive cabling information, refer to the applicable A990 disk configuration cabling diagram *following* this page.

Notes:

- * Discontinued product; shown for reference only.
- ① Up to four memory array cards are supported.
- ② Slot 8 is reserved for the optional HP 12159A 25 kHz Power Module. If not installed, this slot must remain unoccupied.
- ③ Slot 15 is the lowest priority I/O card if optional HP 12154A Battery Backup Card is not installed. If battery backup card is installed, see note 4.
- ④ Slot 16 is reserved for the HP 12154A Battery Backup Card which, when used, extends into the space occupied by slots 14 and 15. This makes slot 13 the lowest priority I/O card slot. If the battery backup card is not installed, a voltage jumper card (part no. 02430-60009) must be installed in slot 16.
- ⑤ As additional memory is added, larger frontplane connectors are required. HP 12230-60001 through -60004 connect one through four memory cards respectively.

A990 16-Slot Upgrade from A900 - System Cards and Priority Diagram




For *internal* disk drive cabling information, refer to the applicable A900 processor disk configuration cabling diagram *preceding* this page.

For *external* disk drive cabling information, refer to the applicable A990 disk configuration cabling diagram *following* this page.

Notes:

- ① One or two memory array cards are supported.
- ② Slot 8 is reserved for the optional HP 12159A 25 kHz Power Module. If not installed, this slot must remain unoccupied.
- ③ Slot 15 is the lowest priority I/O card if optional HP 12154A Battery Backup Card is not installed. If battery backup card is installed, see note 4.
- ④ Slot 16 is reserved for the HP 12154A Battery Backup Card which, when used, extends into the space occupied by slots 14 and 15. This makes slot 13 the lowest priority I/O card slot. If the battery backup card is not installed, a voltage jumper card (part no. 02430-60009) must be installed in slot 16
- ⑤ Frontplane connector part no. 12230-60001 connects one memory array card. If a second memory array card is added, use memory frontplane connector part no. 12230-60002.
- ⑥ Backplane jumper connector (part no. 12990-60020) plugs into slots 3 and 4 and covers slot 2.

A990 20-Slot Upgrade from A400, A600+, or A700* - System Cards and Priority Diagram



For disk drive cabling information, refer to the applicable A990 disk configuration cabling diagram following this page.


Note:

* Portions or all of this product line are discontinued; shown for reference only

1 Up to four memory array cards are supported.

2 As additional memory is added, larger frontplane connectors are required. HP 12230-60001 through -60004 connect one through four memory cards respectively.

A990 20-Slot Upgrade from A900 - System Cards and Priority Diagram



For disk drive cabling information, refer to the applicable A990 disk configuration cabling diagram following this page.


Note:

Up to four memory array cards are supported.

- 1 Backplane jumper connector (part no. 12990-60020) plugs into slots 3 and 4 and covers slot 2.
- 2

A990 16-Slot System Cabling Diagram (With External CS/80 Disk)

HP 2989A System Processor Unit




Notes:

* Portions or all of this product line are discontinued; shown for reference only

- 1 As additional memory is added, larger frontplane connectors are required. HP 12230-60001 through -60004 connect one through four memory cards respectively.
- 2 Connect gray connectors to gray transmitters; connect blue connectors to blue receivers.
- 3 When installing the optional HP 12040 MUX card, refer to the card manual (part no. 12040-90123) for cabling information. Note that rev. B or C of the HP 12040 MUX sets a baud rate of 9600 at Rpt 0 for the system console. Rev D of the MUX senses and sets the baud rate to match that of the terminal. To configure the MUX ports, follow the directions in the Welcome file (rev. 4010 or later of RTE-A).
- 4 This diagram may not indicate the proper priority placement of cards in the card cage; see applicable "...System Cards and Priority Diagram" for this information.

A990 16-Slot System Cabling Diagram (With External SCSI Disk)


HP 2989A System Processor Unit



Notes:

- * Portions or all of this product line are discontinued; shown for reference only
- 1 As additional memory is added, larger frontplane connectors are required. HP 12230-60001 through -60004 connect one through four memory cards respectively.
- 2 Connect gray connectors to gray transmitters; connect blue connectors to blue receivers.
- 3 When installing the optional HP 12040 MUX card, refer to the card manual (part no. 12040-90123) for cabling information. Note that rev. B or C of the HP 12040 MUX sets a baud rate of 9600 at Port 0 for the system console. Rev D of the MUX senses and sets the baud rate to match that of the terminal. To configure the MUX ports, follow the directions in the Welcome file (rev. 4010 or later of RTE-A).
- 4 This diagram may not indicate the proper priority placement of cards in the card cage; see applicable "...System Cards and Priority Diagram" for this information.
- 5 Cable part no. 12016-60002 is for single-ended SCSI devices. Single-ended and differential devices cannot be connected to the same SCSI interface card (i.e. SCSI bus). Use cable part no. 12016-60003 for differential devices.

A990 20-Slot System Cards and Priority Diagram




Note:

Up to four memory array cards are supported.

1

A990 20-Slot System Cabling Diagram (With External CS/80 Disk)

HP 2999A System Processor Unit




Notes:

- * Portions or all of this product line are discontinued; shown for reference only
- 1 As additional memory is added, larger frontplane connectors are required. HP 12230-60001 through -60004 connect one through four memory cards respectively.
- 2 Connect gray connectors to gray transmitters; connect blue connectors to blue receivers.
- 3 When installing the optional HP 12040 MUX card, refer to the card manual (part no. 12040-90123) for cabling information. Note that rev. B or C of the HP 12040 MUX sets a baud rate of 9600 at Port 0 for the system console. Rev D of the MUX senses and sets the baud rate to match that of the terminal. To configure the MUX ports, follow the directions in the Welcome file (rev. 4010 or later of RTE-A).
- 4 This diagram may not indicate the proper priority placement of cards in the card cage; see applicable "...System Cards and Priority Diagram" for this information.

A990 20-Slot System Cabling Diagram (With External SCSI Disk)


HP 2999A System Processor Unit



Notes:

- * Portions or all of this product line are discontinued; shown for reference only
- 1 As additional memory is added, larger frontplane connectors are required. HP 12230-60001 through -60004 connect one through four memory cards respectively.
- 2 Connect gray connectors to gray transmitters; connect blue connectors to blue receivers.
- 3 When installing the optional HP 12040 MUX card, refer to the card manual (part no. 12040-90123) for cabling information. Note that rev. B or C of the HP 12040 MUX sets a baud rate of 9600 at Port 0 for the system console. Rev D of the MUX senses and sets the baud rate to match that of the terminal. To configure the MUX ports, follow the directions in the Welcome file (rev. 4010 or later of RTE-A).
- 4 This diagram may not indicate the proper priority placement of cards in the card cage; see applicable "...System Cards and Priority Diagram" for this information.
- 5 Cable part no. 12016-60002 is for single-ended SCSI devices. Single-ended and differential devices cannot be connected to the same SCSI interface card (i.e. SCSI bus). Use cable part no. 12016-60003 for differential devices.


I/O Extender Micro/1000 Box (HP 12025A)



Notes:


- ① Slot 8 is reserved for the optional HP 12159A 25 kHz Power Module. If not installed, this slot must remain unoccupied.
- ② Slot 16 is reserved for the Interrupt Chain Jumper Card).

I/O Extender 20-Slot Box (HP 12025B)




LAN/1000 Interface Controller Cabling

Refer to the *HP 12076A LAN/1000 Link Local Area Network Interface Controller (LANIC) Installation Manual* (part no. 12076-90001) for detailed information.



L8700-11

Typical IEEE 802.3 Type 10 Base 5 LAN Using the LAN/1000 Interface Controller



Note that all node hardware must conform to a single standard.

L8700-08

Examples of Thick Cable LAN Compatibility

Memory Configurations

The following rule should be followed when installing memory arrays in an A400, A600+, or A700* System. The only exception to this rule is HP 12103K/L/M arrays (2, 4, and 8 Mbyte arrays respectively).

Arrange memory array cards such that the size of memory (including the A400 on-board memory or A600+ memory controller) installed in the backplane beneath any array card satisfies the following equation:

$$\frac{\text{Memory Size Now in Backplane}}{\text{Size of Array Card to be Added}} = \text{An Integer}$$

General rule is to place the largest array closest to the controller and install the remaining arrays in decreasing size order. The A400 and A600+ are special cases because you must consider the memory that is already included on the board or memory controller card.

For A900/A990 systems, the general rule is to install the largest memory card closest to the CPU.

Refer to power requirement/availability information to ensure on-line power requirements and battery backup capabilities are met.

Memory Rules




1. The A400 and A600 can never use ECC memory array cards.
2. In the A600+, an ECC controller must be installed if ECC memory is installed. (A600+ can only use the HP 12111 ECC array cards, not the HP 12104* ECC array cards.)
3. In the A700*, the HP 12111 ECC array cards can be mixed with the HP 12104* ECC array cards and the HP 12103 parity array cards.
4. In the A600+, the HP 12111 ECC array cards can be mixed with the HP 12103 parity array cards provided that the memory controller is an ECC memory controller.
5. A900 and A990 memory array cards cannot be used in an A400, A600+, or A700* system and vice versa.
6. The 16-slot A900 supports only 2 memory arrays.
7. The 16-slot A990 Upgrade from an A900 supports only 2 memory arrays.
8. HP 12154A battery backup card for 16-slot (Micro/1000) SPU or computer supports a maximum of four memory arrays.
9. HP 12157A*/B battery backup system for 20-slot SPU or computer supports a maximum of four memory arrays.

* Discontinued product; shown for reference only.

Memory Products

| Product | Size (bytes) | Part No. | 400 | 600 | 600+ | 700 | 900 | 990 |
|---------------------------------|--------------|--------------|-----|-----|------|-----|-----|-----|
| A600/600+ parity mem controller | 128K | 12102-60001* | NO | OK | OK | NO | NO | NO |
| A600/600+ parity mem controller | 512K | 12102-60010 | NO | OK | OK | NO | NO | NO |
| A600+ ECC mem controller | 512K | 12110-60001* | NO | NO | OK | NO | NO | NO |
| A600+ ECC mem controller | 1M | 12110-60004 | NO | NO | OK | NO | NO | NO |
| A700* mem controller | 0 | 12152-60003* | NO | NO | NO | OK | NO | NO |
| A900 ECC mem controller | 0 | 12204-60003 | NO | NO | NO | NO | OK | NO |
| A600(+)/700 par mem array | 128K | 12103-60015 | NO | OK | OK | OK | NO | NO |
| A700* parity mem array | 256K | 12103-60002* | NO | NO | NO | OK | NO | NO |
| A400/600(+)/700 par mem array | 512K | 12103-60016 | OK | OK | OK | OK | NO | NO |
| A400/600(+)/700 par mem array | 1M | 12103-60004 | OK | OK | OK | OK | NO | NO |
| A400/600(+)/700 par mem array | 2M | 12103-66001 | OK | OK | OK | OK | NO | NO |
| A400/600(+)/700 par mem array | 4M | 12103-66002 | OK | OK | OK | OK | NO | NO |
| A400/600(+)/700 par mem array | 8M | 12103-66003 | OK | OK | OK | OK | NO | NO |
| A700* ECC mem array | 512K | 12104-60001* | NO | NO | NO | OK | NO | NO |
| A600+/700 ECC mem array | 512K | 12111-60001 | NO | NO | OK | OK | NO | NO |
| A600+/700 ECC mem array | 1M | 12111-60002* | NO | NO | OK | OK | NO | NO |
| A600+/700 ECC mem array | 2M | 12111-60003* | NO | NO | OK | OK | NO | NO |
| A900/990 ECC mem array | 768K | 12220-60001 | NO | NO | NO | NO | OK | OK |
| A900/990 ECC mem array | 3M | 12221-60001 | NO | NO | NO | NO | OK | OK |
| A900/990 ECC mem array | 8M | 12221-66001 | NO | NO | NO | NO | OK | OK |

* Discontinued product; shown for reference only..




* Discontinued product; shown for reference only.


A900 Control Store Placement

Install the Control Store Card in the highest I/O priority slot (slot 1) of the computer card cage (next to the Sequencer Card).

A700* WCS/PCS Placement



Frontplane Connections



* Discontinued product; shown for reference only.

A400 Control Memory Map

Note that user microprogramming on the A400 computer is **not** supported by HP.

| Control Memory Module Allocation | Module No. | Address | | Software Entry Point |
|---|------------|-----------|-------------|----------------------|
| | | Hex | Decimal | |
| HP Base Set | 0k | 0-3FF | 00000-01023 | YES † |
| | 1k | 400-7FF | 01024-02047 | YES † |
| | 2k | 800-BFF | 02048-03071 | YES † |
| Reserved for User | 3k | C00-FFF | 03072-04095 | YES ‡ |
| Reserved for User | 4k | 1000-13FF | 04096-05119 | YES ‡ |
| | 5k | 1400-17FF | 05120-06143 | YES ‡ |
| Reserved for User | 6k | 1800-1BFF | 06144-07167 | NO |
| | 7k | 1C00-1FFF | 07168-08191 | NO |
| Reserved for User | 8k | 2000-23FF | 08192-09215 | YES ‡ |
| | 9k | 2400-27FF | 09216-10239 | NO |
| Reserved for User | 10k | 2800-2BFF | 10240-11263 | YES ‡ |
| | 11k | 2C00-2FFF | 11264-12287 | NO |
| Reserved for User | 12k | 3000-33FF | 12288-13311 | YES |
| | 13k | 3400-37FF | 13312-14335 | YES |
| Reserved for User | 14k | 3800-3BFF | 14336-15359 | NO |
| | 15k | 3C00-3FFF | 15360-16383 | NO |
| † HP use only ‡ May be used for HP future firmware package | | | | |

A600 Control Memory Map

| Control Memory Module Allocation | Module No. | Address | | Software Entry Point |
|----------------------------------|------------|---------|-------------|----------------------|
| | | Hex | Decimal | |
| HP Base Set | 0k | 0-3FF | 00000-01023 | YES † |
| † HP use only | | | | |

A600+ Control Memory Map

| Control Memory Module Allocation | Module No. | Address | | Software Entry Point |
|----------------------------------|------------|---------|-------------|----------------------|
| | | Hex | Decimal | |
| HP Base Set | 0k | 0-3FF | 00000-01023 | YES † |
| | 1k | 400-7FF | 01024-02047 | YES † |
| HP Reserved | 2k | 800-BFF | 02048-03071 | YES † |
| | 3k | C00-FFF | 03072-04095 | YES † |
| † HP use only | | | | |

A700* Control Memory Map

| Control Memory Module Allocation | Module No. | Address | | Software Entry Point |
|---|------------|-----------|-------------|----------------------|
| | | Hex | Decimal | |
| HP Base Set | 0k | 0-3FF | 00000-01023 | YES † |
| | 1k | 400-7FF | 01024-02047 | YES † |
| HP Reserved | 2k | 800-BFF | 02048-03071 | YES † |
| | 3k | C00-FFF | 03072-04095 | YES † |
| SIS, VIS, FPP | 4k | 1000-13FF | 04096-05119 | YES † |
| | 5k | 1400-17FF | 05120-06143 | YES † |
| HP Reserved | 6k | 1800-1BFF | 06144-07167 | NO |
| | 7k | 1C00-1FFF | 07168-08191 | NO |
| HP Reserved/User | 8k | 2000-23FF | 08192-09215 | YES ‡ |
| | 9k | 2400-27FF | 09216-10239 | NO |
| HP Reserved/User | 10k | 2800-2BFF | 10240-11263 | YES ‡ |
| | 11k | 2C00-2FFF | 11264-12287 | NO |
| Reserved for User | 12k | 3000-33FF | 12288-13311 | YES |
| | 13k | 3400-37FF | 13312-14335 | YES |
| Reserved for User | 14k | 3800-3BFF | 14336-15359 | NO |
| | 15k | 3C00-3FFF | 15360-16383 | NO |
| † HP use only ‡ May be used for HP future firmware package | | | | |

* Discontinued product; shown for reference only.


A900 Control Memory Map

| Control Memory Module Allocation | Module No. | Address | | Software Entry Point |
|---|------------|-----------|-------------|----------------------|
| | | Hex | Decimal | |
| HP Base Set | 0k | 0-3FF | 00000-01023 | YES † |
| | 1k | 400-7FF | 01024-02047 | YES † |
| HP Base Set | 2k | 800-BFF | 02048-03071 | YES † |
| | 3k | C00-FFF | 03072-04095 | YES † |
| SIS, VIS, FPP | 4k | 1000-13FF | 04096-05119 | YES † |
| | 5k | 1400-17FF | 05120-06143 | YES † |
| HP Reserved | 6k | 1800-1BFF | 06144-07167 | NO |
| | 7k | 1C00-1FFF | 07168-08191 | NO |
| HP Reserved/User | 8k | 2000-23FF | 08192-09215 | YES ‡ |
| | 9k | 2400-27FF | 09216-10239 | NO |
| HP Reserved/User | 10k | 2800-2BFF | 10240-11263 | YES ‡ |
| | 11k | 2C00-2FFF | 11264-12287 | NO |
| Reserved for User | 12k | 3000-33FF | 12288-13311 | YES |
| | 13k | 3400-37FF | 13312-14335 | YES |
| Reserved for User | 14k | 3800-3BFF | 14336-15359 | NO |
| | 15k | 3C00-3FFF | 15360-16383 | NO |
| † HP use only ‡ May be used for HP future firmware package | | | | |


A990 Control Memory Map

| Control Memory Module Allocation | Module No. | Address Hex | Software Entry Point |
|----------------------------------|--|-------------|----------------------|
| HP Instruction Set | 0k 1k 2k 3k 4k 5k | 0-17FF | Yes |
| Boot Memory (VCP) | 6k 7k | 1800 - 1FFF | No |
| HP Reserved/User | 8k 9k 10k 11k 12k 13k 14k 15k | 2000 - 3FFF | No |
| HP Reserved | 16k 17k 18k 19k 20k 21k 22k 23k | 4000 - 5FFF | No |
| Reserved for User | 24k 25k 26k 27k 28k 29k 30k 31k | 6000 – 7FFF | Yes |


A-Series Power-Up Sequence



A-Series Power-Up Sequence (Continued)




A-Series Power-Up Sequence (Continued)



Power Supply

6-Slot Box (Cooler) Power Supply Test Points

The following voltages should be present at the power supply test points on the backplane of the 6-slot box. The front cover must be removed to access the test points. Refer to the *Micro 14/16 Computer Installation and Service Manual*, part no. 02420-90001, for a detailed description on troubleshooting the power supply.



The following voltage ranges are produced depending on the load to the power supply:



| Nominal | With Cards Installed Fan Connected | No Cards Installed, Fan Disconnected |
|---------|---------------------------------------|---|
| +5V | 5.00 - 5.20 V | 4.59 - 5.61 V |
| +12V | 11.64 - 12.72 V | 10.92 - 13.20 V |
| -12V | -11.52 - -12.72 V | -10.92 - -13.44 V |

20-Slot Box Power Supply Test Points

The following voltages should be present at the power supply test point connector on the back of the 20-slot box. See Test Point Location diagram below. Note that for testing the battery, the white lead is positive (+) and the black lead is negative (-).


| Test Point | Nominal Voltage |
|-------------------------------------|---|
| +5 | +5.0 to +5.2V |
| +12 | +11.64 to +12.72V |
| -12 | -11.28 to -12.72V |
| +5M | +4.98 to +5.202V (Sustained when battery backup option is installed and enabled and power is removed.) |
| PON+ (Power On) | +2.4 to +5.0V |
| PFW- (Power Fail Warning) | +2.4 to +5.0V (Drops as soon as power fail is detected.) |
| MLT- (Memory Lost) | +2.4 to 5.0V if memory can be (or was) sustained. 0V if memory cannot be (or was not) sustained. MLT- is always 0V if battery option is not installed. |
| $\phi 1, \phi 2$ (25 kHz installed) | 19.5 Vrms +1.95, -2.3 Vrms (at 0 to .02 Amps) 19.5 Vrms ± 1.6 Vrms (at .02 to 1.5 Amps) |

Test Point Location



† Positive external battery: white lead
‡ Negative external battery: black lead


20-Slot Box Power Supply Connections



Front of Power Supply
(Toward Fan Panel and Front Panel)


| Connector | Description |
|---|--|
| P1 | DC Output Connectors |
| P2 | DC Output Connectors |
| P5 | Battery Switch Connector |
| P6 | Test Points and External Battery Connector |
| P7 | 230 Vac Line Configuration Connector |
| P8 | 115 Vac Line Configuration Connector |
| P9 | AC Line Input Connector |
| P10* | Battery Backup Connector |
| P11* | 25 kHz Sine Wave Connector |
| * Discontinued connector; shown for reference only. | |

Model 6 115/230 Vac Strapping



Micro/1000 Power Supply Test Points

Test points are on Voltage Jumper Card or optional Battery Backup Card.




| Voltage Point | Voltage Range [†] | | |
|---------------|----------------------------|---|--------------------------|
| MLOST- | 2.4 | - | 5.2 |
| PFW- | 2.4 | - | 5.2 |
| +12V | 11.6 | - | 12.7 |
| PON+ | 2.4 | - | 5.2 |
| -12V | -11.2 | - | -12.7 |
| +5.1V | 4.99 | - | 5.2 |
| +5.1VM | 4.99 | - | 5.2 |
| AC φ1 | 17.9 | - | 21.1 (Vrms) [‡] |
| AC φ2 | 17.9 | - | 21.1 (Vrms) [‡] |
| +28V | 22.4 | - | 33.6 |

[†] Under normal load conditions.
[‡] Phase to common at 0.02 to 1.5 A

I/O Extender (12025A) Power Supply Test Points

Test points are on the ICJ/12 Card.



| Voltage Point | Voltage Range † | |
|---------------|-----------------|---------------|
| PFW- | 4.9 | 5.2 |
| +12V | 11.6 | 12.7 |
| PON+ | 4.9 | 5.2 |
| -12V | -11.2 | -12.7 |
| +5.1V | 4.99 | 5.2 |
| AC ϕ 1 | 17.9 | 21.1 (Vrms) ‡ |
| AC ϕ 2 | 17.9 | 21.1 (Vrms) ‡ |
| +28V | 22.4 | 33.6 |

† Under normal load conditions.
 ‡ Phase to common at 0.02 to 1.5 A

I/O Extender (12025B) Power Supply Voltages

| Test Connector Pin Number | Voltage Point | Nominal Voltage |
|---------------------------|---------------|---------------------|
| 1 | +5 | 5.1V +/- 0.10V |
| 2 | +12 | 12.0V +0.72V/-0.36V |
| 3 | -12 | -12.0V +/- 0.72V |
| 4 | +5M | Not Valid |
| 5 | PON+ | 5.1V +/- 0.10V |
| 6 | PFW- | 5.1V +/- 0.10V |
| 7 | MLT- | Not Valid |
| 8 | ϕ 1 | 27.0 Vrms +/- 2.16V |
| 9 | ϕ 2 | 27.0 Vrms +/- 2.16V |
| 12 | Common | |


Battery Backup

CAUTION

Set the battery backup switch to **DISABLE (OFF)** before installing the battery backup card or module in the computer or system. Damage may occur to either the battery backup card or module or memory card. Once installed, set the switch to the desired position. See the following figures and the section titled “Switches and Connectors for 8-, 16-, and 20-Slot Card Cages” for location of this switch.

8-Slot Card Cages* (Model 6)

Battery backup is contained on the optional HP 12013A* card which is installed in the dedicated battery backup slot on the computer or system backplane. The battery backup switch is located on the battery backup card as shown below.



Model 6 Battery Backup Card Switch

Set the switches and connectors (when applicable) as indicated under the following section titled “Switches and Connectors for 8-, 16-, and 20-Slot Card Cages)” depending on whether battery backup is or is not installed.

* Discontinued product; shown for reference only.

CAUTION

Do not set the battery backup card on a conductive surface or on top of another PCA.

16-Slot Card Cages

Battery backup is contained on the optional HP 12154A card which is installed in the dedicated battery backup slot on the computer or system backplane.

CAUTION

Do not set the battery backup card on a conductive surface or on top of another PCA.

Set the switches and connectors (when applicable) as indicated under the following section titled “Switches and Connectors for 8-, 16-, and 20-Slot Card Cages)” depending on whether battery backup is or is not installed.


20-Slot Card Cages

Battery backup consists of the optional HP 12157B Battery Backup Module which is installed in the main dc power supply.

Set the switches and connectors (when applicable) as indicated under the following section titled “Switches and Connectors for 8-, 16-, and 20-Slot Card Cages)” depending on whether battery backup is or is not installed.

A600+ Processor

An additional backup switch, S1, must be set on the A600+ computer or system. This switch is located on the 12102A*/B or 12110A*/B Memory Controller card as indicated below.



A600+ Memory Controller Cards

Switches and Connectors for 8-, 16- and 20-Slot Card Cages

Set the switches and connectors (when applicable) as indicated in the following figure depending on whether battery backup is or is not installed.

Note that the batteries on the battery backup card or battery backup module are partially discharged before shipping. When fully discharged, they must be charged for 14 hours (16-slot box) or 24 hours (20-slot box) in order to sustain memory for one hour (full charge).

Corrosion may form on the batteries when they are fully discharged. This corrosion can be removed with a dampened cloth in a mild solution of baking soda and water.

* Discontinued product; shown for reference only.

Battery Backup Switches and Connectors for 8-, 16-, and 20-Slot Card Cages¹

| Switch or Connector | Battery Backup (BB) | Processor Family | | | |
|--|---------------------|---|--------------------------|--------------------------|--------------------------|
| | | A400 | A600/A600+ | A700* | A900 |
| Battery Backup Switch (Location) ➔ | Installed | Enable | Enable | Enable | Enable |
| | Not Installed | Disable ³ | Disable ³ | Disable ³ | Disable ³ |
| Strapping Connector ² (Location) ➔ | Installed | B.B. card of 8-slot cage; front panel of 16-slot cage; back panel of 20-slot cage | | | |
| | Not Installed | To B.B. On | To B.B. On | To B.B. On | To B.B. On |
| Memory Lost (M) Switch S8 ¹ (Location) ➔ | Installed | To B.B. Off | To B.B. Off | To B.B. Off | To B.B. Off |
| | Not Installed | ➔ | ➔ | ➔ | ➔ |
| Backup Switch S1 (Location) ➔ | Installed | Open (up) ⁴ | Open (up) ⁴ | Open (up) ⁴ | Open (up) ⁴ |
| | Not Installed | Closed (dn) ⁵ | Closed (dn) ⁵ | Closed (dn) ⁵ | Closed (dn) ⁵ |
| Processor Card | Processor Card | Processor Card | Processor Card | Front Plane | Data Path Card |
| | Bat | | | | |
| | Norm | | | | |
| Mem. Ctr. Card | Mem. Ctr. Card | | | | |
| | Not Installed | N/A | N/A | N/A | N/A |

Notes:

- * Discontinued product; shown for reference only. N/A = Not Applicable.
- 1. Battery backup is not supported on 6-slot card cages; set switch S8 closed for any CPU in 6-slot box.
- 2. Old model 20-slot boxes which contain the discontinued Boschert power supply do not have a strapping connector. When these units were supplied without battery backup, a jumper board was factory-inserted into the empty battery module slot in the Boschert power supply. This jumper board must be removed if battery backup is to be installed.
- 3. Set switch to disable if: (1) power is turned off and memory backup is not required (avoids draining the battery), or (2) memory or battery backup cards are to be inserted or withdrawn from the backplane. Note that batteries are still charged in the disable position when power is on.
- 4. Set switch open if: (1) battery backup is installed, enabled, and (2) auto-restart is desired.
- 5. Set switch closed if: (1) battery backup is not installed, or (2) auto-restart is not desired.

Preventive Maintenance

General

Periodic maintenance schedules should be set up according to the quality of the environment in which the system is operating. A system in a clean and air-conditioned atmosphere requires much less care than one which is located in an atmosphere with an unusual amount of dust, smoke, moisture, or other foreign matter. Consult the service manual for the optional disk drive and peripherals for the procedures required for a preventive maintenance schedule.

NOTE

When operating in a dusty or humid environment, the flexible disk drives will accumulate dust and dirt on heads and other moving surfaces such as the spindle and head positioner. Cleaning should be increased to match the rate of dirt accumulation. Avoid using high-velocity vacuum cleaners which may bend or distort head mechanisms. For specific information refer to disk drive service manuals.

On all computers perform the following steps as necessary:

1. Clean cabinet exterior and interior.
2. Check fans for proper operation.

Model 6 Procedures

On the Model 6, the ventilating fan filters for the optional disk drive cabinet should be cleaned monthly to ensure that the equipment remains free of dust. The ventilation fans in the equipment base have sealed bearings and require no lubrication.

Periodically check the batteries on the optional battery backup card for corrosion which may form on the batteries when they are fully discharged. This corrosion can be removed with a cloth dampened in a mild solution of baking soda and water.

Micro 14/16 Procedures (6-Slot Box – Cooler)

1. Clean the Box interior and exterior with a damp cloth.
2. Check fans for proper operation. Remove front cover and filter. While observing the fan spin, set the Power switch to off. The fan should continue to spin for at least 12 seconds. If the fan spins for less than 12 seconds, replace the fan.
3. Remove the box air filter from the inside of the front cover and vacuum its intake surface or wash it in mild detergent and warm water.

Micro 24/26/27*/29/99 Procedures (16-Slot Box – Micro/1000 package)

1. Clean the Box interior and exterior with a damp cloth.
2. Check fans for proper operation. While observing the fan spin, set the Power switch to off. The fan should continue to spin for at least 22 seconds. If a fan spins for less than 22 seconds, replace it.
3. Remove the front cover of the box by grasping it at both sides and pulling it away from the box. Remove the air filter by sliding it out of the box. Vacuum the filter's intake surface or wash it in mild detergent and warm water.
4. Filters for the ventilating fans in the optional disk drive cabinet should be cleaned monthly to ensure that the equipment remains free of dust. These fans have sealed bearings and require no lubrication.

5. Periodically check the batteries on the optional battery backup card for corrosion which may form on the batteries when they are fully discharged. This corrosion can be removed with a cloth dampened in a mild solution of baking soda and water.

Model 24/26/27*/29/99 Procedures (20-Slot Box)

On Models 24, 26, 27, 29, and 99, the ventilating fans in the computer have sealed bearings and require no lubrication.

The air filter in the computer should be cleaned monthly to ensure that the computer remains free of dust. Clean the air filter in a solution of warm water and mild soap. Thoroughly dry the filter before reinstalling it into the computer.

NOTE

Cleaning the air filter is the customer's responsibility. However, if you are at the customer's site, you should check the air filter and clean it if necessary.

* Discontinued product; shown for reference only.

Table of Contents

Chapter 3 Configuration

| | |
|---|------|
| Operating Information | 3-1 |
| Virtual Control Panel (VCP) Characters | 3-1 |
| VCP Commands | 3-2 |
| Loader Commands | 3-3 |
| Firmware Revision Level | 3-4 |
| VCP Revision Level | 3-4 |
| Control Store Firmware Revision Level | 3-4 |
| Primary System | 3-5 |
| RTE-A Primary System Configuration, Rev. 5000 and 5010 | 3-5 |
| RTE-A Primary System Configuration, Rev. 5020 | 3-6 |
| RTE-A Primary System Configuration, Rev. 5270 | 3-7 |
| Primary Software Installation Procedures | 3-9 |
| CS/80 Cartridge or Magnetic Tape, Rev. 5000 and 5010 | 3-9 |
| CS/80 Cartridge or Magnetic Tape, Rev. 5012 | 3-11 |
| CS/80 Cartridge or Magnetic Tape, Rev. 5020 | 3-13 |
| CS/80 Cartridge, Magnetic, or DAT Tape, Rev. 5270 | 3-15 |
| 3.5-inch Diskettes | 3-16 |
| Sample RTE-A Boot Command File, Rev. 5020 (5.2) | 3-17 |
| Sample RTE-A Welcome File, Rev. 5020 (5.2) | 3-18 |
| Hard Disk Drive Configuration | 3-19 |
| Interface Configuration | 3-20 |
| HP 12005A*/B Async Serial Interface | 3-20 |
| HP 12006A Parallel Interface | 3-21 |
| Programmable Serial Interface (PSI) | 3-22 |
| Firmware Installation | 3-25 |
| PSI Test Hoods | 3-26 |
| HP 12008A PROM Storage Module | 3-26 |
| HP 12009A HP-IB Interface | 3-27 |
| Switch Configuration | 3-27 |
| HP-IB Cable Length Restrictions | 3-28 |
| HP-IB Loading/Cabling Guide | 3-29 |
| Device Equivalent Loads | 3-30 |
| HP 12016A SCSI Interface | 3-32 |
| HP 12021A* Mini-Disk Controller | 3-32 |
| HP 12022A* Integral Disk Controller | 3-34 |
| HP 12025A/B I/O Extender | 3-35 |
| I/O Extender Switches | 3-35 |
| I/O Extender Software Considerations | 3-35 |
| I/O Extender Restrictions | 3-36 |
| I/O Extender Firmware Requirements | 3-36 |
| Rack Mounting Instructions | 3-37 |
| Floor Mounting Instructions | 3-38 |
| HP 12040B*/C/D 8-Channel Asynchronous Multiplexer | 3-38 |
| HP 12040B*/C/D Jumper Positions vs. Manufacturer's Part No. | 3-39 |
| HP 12065A Color Video Output Interface | 3-39 |
| Switch Configuration | 3-39 |
| Display Parameters | 3-40 |
| HP 12076A LAN/1000 Interface Controller Card Switch Configuration | 3-41 |
| HP 12100A A400 On-Board I/O Interface | 3-42 |
| HP 12153A Writable Control Store for A700* | 3-42 |
| HP 12155A PROM Control Store for A700* | 3-42 |
| HP 12205A Control Store for A900 | 3-42 |

Configuration

Operating Information

Virtual Control Panel (VCP) Characters

| Character Entry | Response (octal) | Meaning |
|----------------------|------------------|---|
| A [†] | xxxxxx | A-Register contents |
| B [†] | xxxxxx | B-Register contents |
| E [†] | x | E-Register contents |
| G [†] | x000xx | Global Reg (GR) bit 15=0 if enabled |
| I [†] | x | Interrupt system status |
| M [†] | 0xxxxx | Memory address (pointer for T and Ln cmd) |
| O [†] | x | O-Register contents |
| P [†] | 0xxxxx | Program execution address |
| Q [†] | xxxxxx | C and Q-Register contents (C=bit 15) |
| RS | xxxxxx | Switch register contents |
| T | 0xxxxx xxxxxx | Memory contents pointed to by M |
| V | xxxxxx | Violation register (memory protect) |
| X [†] | xxxxxx | X-Register contents |
| Y [†] | xxxxxx | Y-Register contents |
| Z [†] | 0xxxxx | Z-Register contents |
| RC | 0000xx | Central Interrupt Register contents |
| RD [‡] | xxxxxx xxxxxx | Data for I/O diagnose modes 1 and 2 |
| RF [‡] | xxxxxx | I/O flags; Flags 20-24, 30 |
| RI [‡] | xxxxxx | Interrupt mask register |
| RP | xxxxxx xxxxxx | Parity violation register contents |
| RW [†] | xxxxxx | Working map set (WMAP) |
| R20 [‡] | xxxxxx | DMA Self-configuration register |
| R21 [‡] | xxxxxx | DMA Control register |
| R22 [‡] | xxxxxx | DMA Address register |
| R23 [‡] | xxxxxx | DMA Count register |
| R24-26 [‡] | xxxxxx | I/O Scratch register |
| R30 [‡] | xxxxxx | I/O Card Data Register |
| R31/R32 [‡] | xxxxxx | Optional I/O Card register |

[†] Registers that are maintained in the VCP save area of boot RAM.
[‡] Applies only to the card whose select code equals the GR.

VCP Commands

| Command | Meaning |
|---------|--|
| %B | Load and go (boot). Execute a specified loader routine and start program execution at completion of load. |
| %C | Clear memory. Set all memory to zero and perform a preset. |
| %E | Execute. Start execution of program at location P=2 (A-Reg → all 1's and B-Reg → 0). |
| %F | Fill memory. Set all memory locations to value in A-Register and perform a preset. (VCP rev. 4023 or later) |
| %L | Load. Similar to %B but do not start execution. |
| %M | Memory test. Execute destructive extended memory test. Tests addressing logic. The test will optionally loop on error. Returns amount of memory found. If an error is found, the error type, error address, and the data written and read are displayed. |
| %P | Preset. Generate a control reset (CRS) signal to all interface PCAs. |
| %R | Run. Set all registers to the appropriate value in the save area and start execution at address specified by the P-Register. |
| %S | Parity error set. Places a parity error in addressable memory to test the parity interrupt handler and to verify proper functioning of the parity error interrupt logic. this command cannot be used on the A900. |
| %T | Test. Initiate the selftest and return to VCP (memory is sustained but I/O is reset). |
| %W | Write. Write from memory to a selected device. |
| D | Decrement. Decrement memory pointer and display contents of the M- or TRegisters. |
| Ln | List. List n blocks of eight memory locations starting with the location pointed to by the M-Register |
| Sn | Show. List boot memory. (VCP rev. 4023 or later) |
| N | Next. Same as D except increment the pointer |
| RMxx | List the 32 map registers in the DMS map set specified by xx. |
| RMxxPyy | Show the value of register yy in map set xx. If a number is input after the command, the register is changed to the new value. |
| ? | Output HELP screen. |

Loader Commands

Loader Command Format

%BdvffbusctextSS BOOT String
 %Ldvffbusc LOAD String
 %Wdvffbusc WRITE String

where:

- dv – device type as follows;
 - DC disk (cartridge or flexible) via HPIB or SCSI
 (SCSI boot supported with VCP rev 4021 or later)
 - DI HP 12022A Integral Disk/Controller (VCP rev 4001 or later)
 - CT cartridge tape (HP 264x)
 - RM PROM Card
 - DS DS computer network link
 - MT SCSI DAT tape or HP-IB magnetic tape (MT added at VCP rev 4001;
 SCSI DAT support added at 4021)

ff – file number (octal 0 to 77777 only)

b – (BOOT/LOAD) HP-IB or SCSI bus address
 (WRITE) 4K word memory block number when writing
 to CTUs. For HP 12022A*, 0 is fixed disk, 3 is diskette.

u – unit number (0 to 7); for HP 7906/9134* # ➔ head number.
 for CS/80 0 ➔ disk drive.
 1 ➔ tape device.
 for HP 9144/45* 0 ➔ stand-alone tape drive.
 for CTUs 0 ➔ left CTU.
 1 ➔ right CTU.
 for HP 9121* 0 ➔ left drive.
 1 ➔ right drive.

sc – Select code of the interface card to be used.

text – File name or ASCII string passed to the program after it is loaded.

SS – Load but do not execute; return to VCP

* Discontinued product; shown for reference only

Note that spaces cannot be used in the command entry; also leading zeroes in the numeric value are optional. The following is acceptable:

| | | | | |
|----------------|--|--------------------|----|--------|
| %Bdv | where the default values are as follows: | | | |
| | DC | 002027 (for HP-IB) | RM | 000022 |
| | | 006027 (for SCSI) | DS | 000024 |
| | DI | 000032 | MT | 004027 |
| | CT | 000020 | | |
| %Bdvtext | Device parameters defaulted; text cannot be a number | | | |
| %Bdvffbusc | No text passed. | | | |
| %Bdvffbusctext | Text passed. | | | |

Firmware Revision Level

VCP Revision Level

The revision level of the VCP firmware installed in a system is shown in the B-Register at power-up. The A-Register contains the number of I/O masters installed in the system. The revision level can also be obtained with the VCP command %T.

Control Store Firmware Revision Level

The following procedure can be used, through the VCP, to find the revision level of the control store firmware (base set, floating point) installed in a system.

A-Reg → 0 B-Reg → XX

where XX is the 1K block of control store to be accessed, for example:

0-1K XX → 0
1-2k XX → 1
 ⋮
5-6K XX → 5

Execute the following:

| Instruction: | Opcode: |
|--------------|---------|
| FWID | 105301 |
| HLT 77B | 102077 |

A-Register upper byte – Firmware revision level.
A-Register lower byte – package # (1 = Base Set, 2 = FPP).

All 1's will be returned if the firmware addressed is not installed.

The B-Register is ignored for the A600 (Base Set only).

Primary System

RTE-A Primary System Configuration, Rev. 5000 and 5010

| LU | Select Code | HP-IB Addr. | HP Device |
|--|-------------|-------------|--|
| HP-IB #1 | | | |
| 15 | 27 | 36B | HP-IB Controller LU |
| 16,17 | " | 0 | HP 7908* CS/80 disk |
| 18 | " | 0 | HP 7907* CS/80 disk, fixed |
| 19 | " | 0 | HP 7941* CS/80 disk |
| 20 | " | 0 | HP 7911* CS/80 disk |
| 21 | " | 0 | HP 7945* CS/80 disk |
| 22 | " | 0 | HP 7912* CS/80 disk |
| 23 | " | 0 | HP 7914* CS/80 disk |
| 24 | " | 0 | CS/80 compatible cartridge tape cache |
| 25,26 | " | 0 | HP 7933* CS/80 disk |
| 29-31 | " | 0 | HP 7907* CS/80 disk, removable |
| 32,33 | " | 6 | HP 7902/9121* 3.5 in. flexible disk drives |
| 50-52 | " | 2 | HP 12122A or 9153B* hard disk |
| 53 | " | 2 | HP 12122A or 9153B* sgl-side flex disk drive |
| 54 | " | 2 | HP 12122A or 9153B* dbl-side flex disk drive |
| 7 | " | 3 | HP 7974*/7978A* streaming mag tape drive |
| 8 | " | 4 | HP 7970 mag tape drive |
| 9 | " | 1 | HP 9144 CS/80 cartridge tape drive |
| HP-IB #2 | | | |
| 40 | 26 | 36 | HP-IB Controller LU |
| 41-43 | " | 7 | HP 9133*/3H* 5.25 in. fixed disk |
| 44-47 | " | 0 | HP 9134* CS/80 disk |
| 12 | " | 1 | HP 9144* CS/80 cartridge tape drive |
| 34,35 | " | 2 | HP 7902*/9122* 3.5 in. flexible disk drives |
| 61 | " | 7 | HP 9133H* 3.5 in. flexible disk drive |
| 85 | " | 3 | HP 2563/66A/2608 line printer |
| 6 | " | 6 | HP 2932A* line printer |
| Micro/1000 Integrated Disks | | | |
| 55,62 | 32 | | HP 248x Computer with 15 MB hard disk |
| 59,60 | " | | HP 248x Computer with 20 MB hard disk |
| 39 | " | | HP 248x Computer with sgl-side flex disk |
| 63 | " | | HP 248x Computer with dbl-side flex disk |
| Network Links | | | |
| 79,80 | 24 | | DS/1000 Read and Write Ports |
| 81,82 | " | | DS/1000 LU mapping |
| * Discontinued product; shown for reference only | | | |

| LU | Select Code | HP-IB Addr. | HP Device |
|--|-------------|-------------|---|
| HP 12122A LUs | | | |
| 50-52 | 27 | 2 | Hard disks, unit 0 |
| 53 | " | 2 | SS flexible, unit 1 |
| 54 | " | 2 | DS flexible, unit 1 |
| ASIC #1 | | | |
| 1 | 20 | | HP 26xx* default system console |
| ASIC #2 | | | |
| 100 | 40 | | HP 26xx* terminal |
| HP 12100A, A400 OBIO | | | |
| 110 | 77 | | A400 On-Board I/O Port A Terminal |
| 111 | " | | A400 On-Board I/O Port B Terminal |
| 112 | " | | A400 On-Board I/O Port C Terminal |
| 113 | " | | A400 On-Board I/O Port D Terminal |
| HP 12040D | | | |
| 120-127 | 30 | | 8-channel MUX, ports 0 - 7 respectively |
| HP 12040B*/C | | | |
| 130-137 | 23 | | 8-channel MUX, ports 0 - 7 respectively |
| * Discontinued product; shown for reference only | | | |

RTE-A Primary System Configuration, Rev. 5020

At Rev. 5020, the only change to the Primary System LU Configuration was that LUs 50 and 51 were merged into just LU 51.

Therefore, for the Rev. 5020 configuration, refer to the previous table (Rev. 5000/5010), but note that the disk LUs for the HP 12122A/9153B are 51, 52 instead of 50, 51, 52.

RTE-A Primary System Configuration, Rev. 5270

At Rev. 5270 (5.27) there was a major change in the Primary configuration due to the addition of SCSI boot support and the creation of a SCSI Primary.

| Select Code | LU | ADDR | SCSI | HP-IB |
|-------------|---|---|---|---|
| 25b | 22-2 344 20-21 | 2 5 6 | -- -- -- | SCSI MO Disk SCSI DAT Tape SCSI Hard Disk |
| 26b | 26-27/28* 29 54 39 37 38 36 25 | 0 0 0 1 3 4 7 36b | HP-IB Disk HP-IB Floppy Disk HP-IB Cartridge 9144/45 Cartridge 7974/78 Tape 7970 Tape 2392A Printer HP-IB Controller | -- -- -- -- -- -- -- -- |
| 27b | 16-17/18* 19 24 9 12-13 7 8 14 10-11 6 15 | 0 0 0 1 2 3 4 5 6 7 36b | -- -- -- -- SCSI MO Disk -- -- -- SCSI DAT Tape SCSI Hard Disk -- -- | HP-IB Disk HP-IB Floppy Disk HP-IB Cartridge 9144/45 Cartridge -- 7974/78 Tape 7970 Tape -- -- 2392A Printer HP-IB Controller |
| 24b | 41-42 46-47 48 49 85 45 | 0 2 2 2 3 36 | HP-IB Disk 9153 Fixed Disk 9153 Sgl-Side Flex Disk 9153 Dbl-Side Flex Disk 2563/66 A/26085 Printer HP-IB Controller | (same) |

* You may use either LU 17 or 18, but not both. You may also use either LU 27 or 28.

| Select Code | LU | ADDR | Device |
|--|---|------|--|
| The following devices have same configuration for both HP-IB and SCSI systems. | | | |
| 20b | ASIC #1 1 | | HP 26xx Default System Console |
| 77b | 12100A A400 OBIO 110 111 112 113 | | A400 On-Board I/O Port A Terminal A400 On-Board I/O Port B Terminal A400 On-Board I/O Port C Terminal A400 On-Board I/O Port D Terminal |
| 30b | 12040D MUX 120 – 127 | | HP 12040 Rev. D 8-Channel MUX, Ports 0 – 7, respectively |
| 23b | 12040B/C MUX 130 – 137 | | HP 12040 Rev. B or C, 8-Channel MUX, Ports 0 – 7, respectively |

Primary Software Installation Procedures

This section is intended to briefly describe the boot process and to list the bootstrings for several different media. Refer to the *RTE-A Primary System Software Installation Manual* (part no. 92077-90038), for more information.

CS/80 Cartridge or Magnetic Tape, Rev. 5000 and 5010

Primary System installation is identical with software revisions 5000 and 5010 unless specifically indicated otherwise.

The Primary System, when supplied on CS/80 cartridge or 1600 bpi magnetic tape, consists of two tapes. One tape contains the Primary in ASAVE format. The second contains the bootable subsystem ARSTR needed to restore the Primary tape.

Note: After the Rev. 5000 release, CS/80 tape part no. 24999-13641 was created for Primary installation to the HP 12122A disk subsystem. It is an ASAVE version of LUs 50 and 51. This tape was distributed only on internal subscription services. (At Rev. 5012, an extra tape was shipped with the Primary (to customers) for the installation of LUs 50 and 51.)

Proceed with the following steps to install the Primary System:

1. Boot ARSTR[†] from the VCP prompt, with one of the following commands:

CS/80 tape:

%bdc441027 (for the HP 9144/45* tape drive)

%bdc440127 (for other C S/80 tape drives)

Magnetic tape:

%bmt23027 (for the HP 7974*/78*/79 /80 tape drive)

%bmt24027 (for the HP 7970* magnetic tape drive)

* Discontinued product; shown for reference only.

† Only revision 2536 or later of the ARSTR utility can be used to restore the primary system to a 20 MB integrated hard disk in a Micro/1000 system.

‡ In order to boot from the HP 7979, the tape drive must have the model ID configured as 7974. Refer to the HP 7979 CE Handbook for information about configuring the HP 7979.

2. After ARSTR is booted, the prompt “ARSTR:” is displayed. Remove the ARSTR tape and insert the tape labeled RTE-A Primary/Master or Primary/Diags/Master. The Primary can now be restored from the tape using one of the following commands:

CS/80 tape:

ARSTR: ta,9 (for the HP 9144/45 tape drive)

ARSTR: ta,24 (for other C S/80 tape drives)

Magnetic tape:

ARSTR: ta,7 (for the HP 7974*/78*/79/80 magnetic tape drive)

ARSTR: ta,8 (for the HP 7970* magnetic tape drive)

3. Copy the software to the hard disk with one of the following commands:

CS/80 hard disk:

ARSTR: re,1:16,2:17|rw

This command restores files 1 and 2 to disk volume L Us 16 and 17 respectively and rewinds the tape.

Micro/1000 hard disk (20 MB):

ARSTR: re,3:59,4:60|rw

This command restores files 3 and 4 to disk volume L Us 59 and 60 respectively and rewinds the tape.

4. Boot the Primary System from the hard disk with one of the following commands:

CS/80 hard disk:

VCP> %bdc27

HP 12122A disk subsystem:

VCP> %bdc

Micro/1000 hard disk (except HP 12122A):

VCP> %bdi32

CS/80 Cartridge or Magnetic Tape, Rev. 5012

The Primary System, when supplied on either CS/80 or 1600 bpi media, consists of the following three tapes.

- The Primary, in ASAVE format, to be restored to LUs 16/17 for HP 79xx* disks or LUs 50/51 for the HP 12122A disk subsystem.
- The Primary, in ASAVE format, to be restored to LUs 59/60 for the Micro/1000 disk subsystem with HP 12022A* controller interface.
- The bootable ARSTR needed to restore the Primary tape.

Proceed with the following steps to install the Primary System:

1. Boot ARSTR with one of the following commands:

CS/80 tape:

VCP> %bdc451027 (for HP 9144/45 tape drives)

VCP> %bdc450127 (for other C S/80 tape drives)

Magnetic tape:

VCP> %bmt23027 (for the HP 7974*/78*/79 †80 tape drive)

VCP> %bmt24027 (for the 7970* magnetic tape drive)

2. After ARSTR is booted, the prompt "ARSTR:" is displayed. Remove the tape and insert one of the tapes labeled RTE-A Primary (or Primary/Diag if the system came with diagnostics) depending on the LU number to be restored. Use the following guide.

| <u>Tape</u> <u>Label No.</u> | <u>Restores</u> <u>LUs</u> | <u>For the following Disks</u> |
|---------------------------------|-------------------------------|--|
| Primary #1 | 16 and 17 | HP 7907*/08*/11*/12*/14*/33*/41*/45* |
| Primary #1 | 50 and 51 | HP 9153 or Micro/1000 with HP 12122A integrated disk subsystem |
| Primary #2 | 59 and 60 | Micro/1000 with integrated disk using HP 12022A* interface |

* Portions or all of this product line are discontinued; shown for reference only.

† In order to boot from the HP 7979, the tape drive must have the model ID configured as 7974. Refer to the HP 7979 CE Handbook for information about configuring the HP 7979.

3. The Primary can now be restored from tape using one of the following commands:

CS/80 hard disk:

ARSTR: ta,9 (for the HP 9144/45 tape drive)

ARSTR: ta,24 (for other C S/80 tape drives)

Magnetic tape:

ARSTR: ta,7 (for the HP 7974*/78*/79/80 magnetic tape drive)

ARSTR: ta,8 (for the HP 7970* magnetic tape drive)

4. Copy the software to the hard disk with one of the following commands:

HP 79xx* hard disks:

ARSTR: re,1:16,2:17|rw

This command restores files 1 and 2 to disk volume L Us 16 and 17 respectively and rewinds the tape.

HP 9153 hard disk or Micro/1000 with HP 12122A integrated disk:

ARSTR: re,3:50,4:51|rw

This command restores files 3 and 4 to disk volume L Us 50 and 51 respectively and rewinds the tape.

Micro/1000 integrated disk (20 MB) using HP 12022A* controller:

ARSTR: re,1:59,2:60|rw

This command restores file 1 and 2 to disk volume L Us 59 and 60 respectively and rewinds the tape.

5. Boot the Primary System from the hard disk with one of the following commands:

HP 79xx* hard disks:

VCP> %bdc27

HP 9153 hard disk or Micro/1000 with HP 12122A integrated disk:

VCP> %bdc2027

Micro/1000 integrated disk (20 MB) using HP 12022A* controller:

VCP> %bdi32

* Portions or all of this product line discontinued; shown for reference only.

CS/80 Cartridge or Magnetic Tape, Rev. 5020

The Primary System, when supplied on either CS/80 or 1600 bpi media, consists of the following four tapes.

- The Primary, in ASAVE format, to be restored to LUs 16 and 17 for HP 79xx* disks or LU 51 for the HP 12122A disk subsystem.
- The Primary, in ASAVE format, to be restored to LU 59 for the Micro/1000 disk subsystem with HP 12022A* controller interface.
- The bootable ARSTR needed to restore the Primary tape.
- RTE-A relocatables for the system gen and program linking.

Proceed with the following steps to install the Primary System:

1. Boot ARSTR with one of the following commands:

CS/80 tape:

VCP> %bdc451027 (for HP 9144/45 tape drives)

VCP> %bdc450127 (for other C S/80 tape drives)

Magnetic tape:

VCP> %bmt23027 (for the HP 7974*/78*/79 /80 tape drive)

VCP> %bmt24027 (for the 7970* magnetic tape drive)

2. After ARSTR is booted, the prompt “ARSTR:” is displayed. Remove the tape and insert one of the tapes labeled RTE-A Primary (or Primary/Diag if the system came with diagnostics) depending on the LU number to be restored. Use the following guide.

| <u>Tape</u> <u>Label No.</u> | <u>Restores</u> <u>LUs</u> | <u>For the following Disks</u> |
|---------------------------------|-------------------------------|--|
| Primary #1 | 16 and 17 | HP 7907*/08*/11*/12*/14*/33*/41*/45* |
| Primary #1 | 51 | HP 9153 or Micro/1000 with HP 12122A integrated disk subsystem |
| Primary #2 | 59 | Micro/1000 with integrated disk using HP 12022A* interface |

* Portions or all of this product line are discontinued; shown for reference only.

‡ In order to boot from the HP 7979, the tape drive must have the model ID configured as 7974. Refer to the HP 7979 CE Handbook for information about configuring the HP 7979.

3. The Primary can now be restored from tape using one of the following commands:

CS/80 hard disk:

ARSTR: ta,9 (for the HP 9144/45 tape drive)

ARSTR: ta,24 (for other C S/80 tape drives)

Magnetic tape:

ARSTR: ta,7 (for the HP 7974*/78*/79/80 magnetic tape drive)

ARSTR: ta,8 (for the HP 7970* magnetic tape drive)

4. Copy the software to the hard disk with one of the following commands:

HP 79xx* hard disks:

ARSTR: re,1:16,2:17|rw

This command restores files 1 and 2 to disk volume L Us 16 and 17 respectively and rewinds the tape.

HP 9153 hard disk or Micro/1000 with HP 12122A integrated disk:

ARSTR: re,3:51|rw

This command restores file 3 to disk volume L U 51 and rewinds the tape.

Micro/1000 integrated disk (20 MB) using HP 12022A* controller:

ARSTR: re,1:59|rw

This command restores file 1 to disk volume L U 59 and rewinds the tape.

5. Boot the Primary System from the hard disk with one of the following commands:

HP 79xx* hard disks:

VCP> %bdc27

HP 9153 hard disk or Micro/1000 with HP 12122A integrated disk:

VCP> %bdc2027

Micro/1000 integrated disk (20 MB) using HP 12022A* controller:

VCP> %bdi32

* Portions or all of this product line discontinued; shown for reference only.

CS/80 Cartridge, Magnetic, or DAT Tape, Rev. 5270

The Primary System, when supplied on CS/80, 1600 bpi Magnetic, or SCSI DAT Tape media, consists of the following three tapes.

- The primary, in ASAVE format.
- The bootable ARSTR needed to restore the primary tape.
- RTE-A relocatables for the system gen and program linking.

Proceed with the following steps to install the Primary System:

1. Boot ARSTR with one of the following commands:

To copy from HP-IB tape to HP-IB disk (HP-IB card = sc 27):

```
VCP> %bdc401027      (for the HP 9144*/45* tape drive)
VCP> %bdc400127      (for other CS/80 tape drives)
VCP> %bmt23027       (for the HP 7974*/78*/79‡/80 tape drive)
VCP> %bmt24027       (for the HP 7970* tape drive)
```

To copy from SCSI tape to SCSI disk (SCSI card = sc 27):

```
VCP> %bmt25027       (for the SCSI DAT tape drive)
```

To copy from HP-IB tape to SCSI disk (HP-IB card = sc 26 and SCSI card = sc 25):

```
VCP> %bdc401026      (for the HP 9144*/45* tape drive)
VCP> %bdc400126      (for other CS/80 tape drives)
VCP> %bmt23026       (for the HP 7974*/78*/79/80 tape drive)
VCP> %bmt24026       (for the HP 7970* tape drive)
```

To copy from SCSI tape to HP-IB disk (SCSI card = sc 25 and HP-IB card = sc 26):

```
VCP> %bmt25025       (for the SCSI DAT tape drive)
```

* Portions or all of this product line are discontinued; shown for reference only.

‡ In order to boot from the HP 7979, the tape drive must have the model ID configured as 7974. Refer to the HP 7979 CE Handbook for information about configuring the HP 7979.

2. After ARSTR is booted, the prompt “ARSTR:” is displayed. Remove the tape and insert the ASAVE tape. The primary can now be restored from tape using one of the following commands:

To copy from HP-IB tape to HP-IB disk (HP-IB card = sc 27):

ARSTR: ta,9|re,1:16|rw (from 9144/45 tape drive to CS/80 disk)
ARSTR: ta,24|re,1:16|rw (from other CS/80 tape drives to CS/80 disk)
ARSTR: ta,7|re,1:16|rw (from 7974/78 tape drive to CS/80 disk)
ARSTR: ta,8|re,1:16|rw (from 7970 tape drive to CS/80 disk)

To copy from SCSI tape to SCSI disk (SCSI card = sc 27):

ARSTR: ta,14|re,2:10|rw (from SCSI DAT tape to SCSI hard disk)
ARSTR: ta,14|re,2:12|rw (from SCSI DAT tape to SCSI MO disk)

To copy from HP-IB tape to SCSI disk (HP-IB card = sc 26 and SCSI card = sc 25):

ARSTR: ta,39|re,2:20|rw (from 9144/45 tape drive to SCSI hard disk)
ARSTR: ta,54|re,2:20|rw (from other CS/80 tape drives to SCSI disk)
ARSTR: ta,37|re,2:20|rw (from 7974/78 tape drive to SCSI hard disk)
ARSTR: ta,38|re,2:20|rw (from 7970 tape drive to SCSI hard disk)
ARSTR: ta,39|re,2:22|rw (from 9144/45 tape drive to SCSI MO disk)
ARSTR: ta,54|re,2:22|rw (from other CS/80 tapes to SCSI MO disk)
ARSTR: ta,37|re,2:22|rw (from 7974/78 tape drive to SCSI MO disk)
ARSTR: ta,38|re,2:22|rw (from 7970 tape drive to SCSI MO disk)

To copy from SCSI tape to HP-IB disk (SCSI card = sc 25 and HP-IB card = sc 26):

ARSTR: ta,44|re,1:26|rw (from SCSI DAT tape drive to CS/80 disk)

3. Boot from the hard disk with one of the following commands:

VCP> %bdc27 (for CS/80 disk)
VCP> %bdc2027 (for SCSI MO disk)
VCP> %bdc6027 (for SCSI hard disk)

3.5-inch Diskettes

Installing the RTE-A Primary System from diskettes consists of booting the primary, initializing the hard disk, and then copying the remainder of the primary to the hard disk. Due to the number of steps and commands required, refer to the *Primary Installation Manual* (part no. 92077-90038) for installation procedures.

Sample RTE-A Boot Command File, Rev. 5020 (5.2)

As the system is brought into memory, the following messages appear on the screen. Note that you are prompted to enter the current date and time.

```
* SOURCE: 92077-17293 REV.5020 <901205.1442>
* JCR
* FHP,MCN – size up the swap file (2048 blocks)
* Primary system boot up command file (boot.cmd) for primary system
ec
* Define system and snap files
sy,primary.sys
sn,primary.snp
*
* Note: No FMGR cartridges are mounted. If needed, mount cartridge
      16 for CS-80 systems (MC,16) or mount cartridge 60 for micro-
      1000 systems (MC,60) to mount the appropriate FMGR cartridge.
*
* Define initially RP'ed programs
rp,drtr,d.rtr
rp,derr,d.err
*
rp,ci,cm
rp,cix
*
* RP the powerfail routine and DDC00/DDC01 modem handler
rp,autor
*
* Configure the system console
rp,ci,ci.s
*
* Note: the following line is used for the primary system only.
*   Remove it when you generate your system with a system
      console gen'd in.
*
* Map VCP terminal to LU1
rp,lucfg,prhlp
*
* Use Welcome1.cmd
st,,1
end
*
* End RP phase
* Define swap file
* sw,swap.swp::system::2048
*
end
```

Sample RTE-A Welcome File, Rev. 5020 (5.2)

Note that the following example involves an HP 12040D, 8-port MUX card with ports 0 through 7 and device driver DDC00 enabled. LU 1 is an Async port. This example will be different for a different system configuration.

```
*/SYSTEM/WELCOME1.CMD:
* This file is designed to be edited according to your system
* configuration. See RTE-A System Generation and Installation
* Manual concerning the functions of the WELCOME file. This
* reflects the terminals configured in the primary system
* (using #ANS), and should be modified according to your system
* configuration.
*
* remove the initializing program which dynamically configures
* LU 1 to the VCP port
of PRIHP id
*
* Update /system/snp.snp for LINK program. Note that if
* SNAP::0 exists, LINK will search there first. Be sure you
* do not have a SNAP on your FMGR cartridges.
*
co /system/snp.snp /system/snp.snp d
*
wd /programs
set log = off
* The following lines give the typical enabling sequences for
* standard terminals. If you desire to connect up a RS-232
* printer, enable it according to the RTE-A Driver Reference
* Manual.
*
* If you are using VC+, be sure to RP PROMT in your boot.cmd
* file, and do not perform the "rp ci ciNNN" and "cn LU 20b
* ciNNN" commands. The VC+ primary program ("cn LU 20b prompt")
* is performed automatically upon first init to the interface
* driver and is not necessary.
*
* Remove the "*"s before the lines which pertain to your system
* using EDIT (see RTE-A EDIT/1000 User's Guide). Do not remove
* the comment if the particular card is not physically in your
* system.
*
* Section 1: ENABLE ASIC (12005B) card (LU 100, select code 21b)
*
* echo 'Enabling LU 100, ASIC'
* rp ci ci100
* cn 100 20b ci100
*
* Section 2: ENABLE A400/OBIO 4-MUX (12100A) card (LUs 110 -
* 113)
* note: If you want to perform speed sensing, use only the
* command "CN <lu> 34b 2" (a dummy entry to the card) instead
* of the "CN <lu> 30b 13xB" command.
*
* Echo 'Enabling LU 110, OBIO 4-MUX port A'
* cn 110 30b 130b
* cn 110 34b 2
```

```

* rp ci ci100
* cn 110 20b ci110
.
* Echo 'Enabling LU 113, OBIO 4-MUX port D'
* cn 113 30b 133b
* cn 113 34b 2
* rp ci ci113
* cn 113 20b ci113
*
*
* Section 3: ENABLE DDC00 compatible 8-MUX (12040D) card (LUs
* 120 - 127 Select Code 30b)
* note: If you want to perform speed sensing, use only the
* command "CN <lu> 34B 2" (a dummy entry to the card) instead
* of the "CN <lu> 30b 13xB" command.
*
*
echo 'Enabling LU 120, REV.D 8-MUX port 0'
cn 120 30b 130b
cn 120 34b 2
rp ci ci120
cn 120 20b ci120
.
*
echo 'Enabling LU 127, REV.D 8-MUX port 7'
cn 127 30b 137b
cn 127 34b 2
rp ci ci127
cn 127 20b ci127
*
*
* Enable CI.RUN as primary program on LU 1
*
echo 'Enabling system console LU 1
set log = on
rp ci ci.01
cn 1 20b ci.01
co "mess.txt::system 1
rp link
ws link 32
*
* Set the time: tm <mon> <day> <year> <hr>:<min>:<sec>: <am/pm>
*
set log = off
ex

```

Hard Disk Drive Configuration

When using internal jumpers or switches to configure any HP 9133 or HP 9153 hard disk drive, strap the drive for 256-byte sector size and single-volume operation. Refer to the appropriate disk drive manual for instructions on internal strapping.

Interface Configuration

HP 12005A*/B Async Serial Interface

Switch Configuration

U1 Switches

S1 S2 S3 S4 S5 S6 S7 S8

- O X < – Select Code – > HP 12005 will not operate as the VCP interface.
- C X < – Select Code – > HP 12005 will operate as the VCP interface. A BREAK character will HALT the computer and enter this code. NOTE: The VCP Interface Select Code must be set for 20B. Early revisions of VCP ROMs allow disabling VCP Break by setting bit 4 on the CPU. Later revisions (4001 and later) use bit 5 for this purpose.

U21 Switches

S1 S2 S3 S4 S5 S6 S7 S8

- < baud rate > S P X X S7/S8 switch setting for 12005-60001
- < baud rate > S P O C S7/S8 switch setting for 12005-60007[†]
- < baud rate > S P O C S7/S8 switch setting for 12005-60010[†]
- < baud rate > S P ● X S7/S8 switch setting for 12005-60011/12[‡]

where:

- O = Open (up) = 1
- C = Closed (down) = 0
- X = don't care
- S = O; Two stop bits
- S = C; One stop bit
- P = O; Even parity
- P = C; Odd parity

- * Discontinued product; shown for reference only.
- S7 is used to select 19.2k baud (see next page).
- ‡ HP 12005B includes fiber optics.
- † When switch S7 is Closed (down) and switch S8 is Open (up), a 16 X baud rate (set by switches S1–S4) signal will be available on pin 23. This signal is necessary for the HP 25590 Diagnostic Interface Unit, DIU (part of the HP 2250 Measurement and Control Product). When switch S7 is Open (up) and switch S8 is Closed (down), normal baud rate operation is regained. The other two possible switch settings for S7 and S8 (i.e., both Open or both Closed) must not be used. If used, these settings will result in self-test errors and/or diagnostic errors.

| Baud Rate | S1 | S2 | S3 | S4 | S7 [▪] |
|-----------|----|----|----|----|-----------------|
| ext clk | C | C | C | C | C |
| 50 | C | C | C | O | C |
| 75 | O | C | C | C | C |
| 110 | O | C | C | O | C |
| 134.5 | C | O | C | C | C |
| 150 | C | O | C | O | C |
| 300 | O | O | C | C | C |
| 600 | O | O | C | O | C |
| 900 | C | C | O | C | C |
| 1200 | C | C | O | O | C |
| 1800 | O | C | O | C | C |
| 2400 | O | C | O | O | C |
| 3600 | C | O | O | C | C |
| 4800 | C | O | O | O | C |
| 7200 | O | O | O | C | C |
| 9600 | O | O | O | O | C |
| 19200 | O | O | O | O | O |

▪ For 12005-60011/12

HP 12006A Parallel Interface

Switch Configuration

U1 Switches

S1 S2 S3 S4 S5 S6 S7 S8

- O Y < – Select Code – > HP 12006 will not operate as the VCP interface.
 C Y < – Select Code – > HP 12006 will operate as the VCP interface if a suitable VCP ROM is used (currently non-HP supplied).

where:

O = Open (up) = 1

C = Closed (down) = 0

Y = O; Active high Device Command (for diagnostic)

Y = C; Active low Device Command

Note:

Cable (shielded, twisted pair) is grounded at CPU end only

Programmable Serial Interface (PSI)

Switch Configuration

HP 12007A*/B, HP 12042A*/B, HP 12043A/44A/73A/75A/82A/92A

The PSI Interface is the PCA that is used with specific ROMs to create the various data communications interfaces. The PSI PCA is available in two basic versions, a Modem PSI card or a Direct Connect PSI card. The following tables show the many data communications interfaces, the required ROMs, and specific strapping requirements.

PSI Part Numbers

| | Modem | Direct Connect (DC) |
|---------------------|-----------|--|
| PCA (new part) | 5061-4940 | 5061-4938 |
| PCA (exchange part) | 5061-4941 | 5061-4939 |
| Cable | 5061-4914 | 5061-3422 (male) 5061-4908 (female) |

Product Descriptions and ROM Locations

| Description | HP Product | PSI Version | ROMs | Location |
|---|------------|-------------|----------------------------|------------|
| HDLC, †1000 to 1000 Link | 12007A*/B | Modem | 5180-7233** | U24 |
| | 12044A | DC | 5180-7233** | U93 |
| Bisync, ‡1000 to 3000 Link | 12073A | Modem | 91750-80016 91750-80017 | U24 U44 |
| | 12082A | DC | 91750-80016 91750-80017 | U93 U73 |
| X.25 1000 to Packet Network | 12075A | Modem | 5180-7260 | U24 |
| OEM Version | 12042A*/B | Modem | 5180-1951 | U24 |
| MRJE, 1000 to IBM | 12043A | Modem | 5180-1966 | U24 |
| Data Link Master Multipoint | 12092A | Modem | 5180-1966 | U24 |
| † HDLC = High level Data Link Control, uses full duplex protocol. ‡ Bisync = Binary Synchronous communication, uses half duplex protocol. ** Or newer part number 5181-6113 | | | | |

* Discontinued product; shown for reference only.

U1 Switches[†] on PSI (All Products)

- S1** = O PSI will not operate as the VCP Interface.
 C PSI will operate as the VCP Interface. A remote BREAK command (via DS/NS software) will halt the computer and enter the VCP mode if the PSI is used as the VCP interface. The select code must be 24B.
- S2** = O If card cage door is closed and the spring clip on the hood connector will contact the cage door with a metal to metal connection. (This is true for Model 6 systems and LSeries systems.)
 C If the spring clip on the hood connector is not touching card cage ground. (This is true for all 20-slot boxes and Micro/1000 systems.)
- S3** }
S4 } Select code
S5 }
S6 }
S7 }
S8 }

U15 Switches[†] S6, S7, S8 on PSI (Baud Rate) for Bisync and HDLC

| S6 | S7 | S8 | Clock Rate (bps) |
|----|----|----|------------------|
| O | O | O | 300 |
| C | O | O | 1.2k |
| O | C | O | 2.4k |
| C | C | O | 4.8k |
| O | O | C | 9.6k |
| C | O | C | 19.2k |
| O | C | C | 57.6k |
| C | C | C | 230.0k |

HP 12007A*/B, HP 12044A (HDLC)

- S1** = X
S2 = C 128 Byte information field (recommended for Modems)
 O 1024 Byte information field (recommended for Direct Connects)
 Both ends of link must have S2 in same position.
- S3** = X
S4 = X
S5 = X
S6 }
S7 } Refer to U15 Switches (Baud Rate).
S8 }

* Discontinued product, shown for reference only

[†] O = open (UP) = logic 1, C = closed (down) = logic 0, X = don't care

HP 12042A*/B (OEM Version)

S1 → S8 Depends on OEM ROM code.

HP 12043A (MRJE)

S1 → S8 = X The PSI is programmatically configured by software requirements.

HP 12073A, HP 12082A (Bisync)

- S1 = X
- S2 = C External clock
O No external clock
- S3 = C Ring detect
O Auto answer, Direct Connect
- S4 = C Modem, 20 second time-out
O Direct Connect, requires internal clock, no time-out.
- S5 = X
- S6 } Refer to U15 Switches (Baud Rate), 57.6k bps maximum.
- S7 }
S8 }

HP 12075A (X.25)

- S1 = O Always open to use bps selected by S5 thru S8
- S2 = X
- S3 = X
- S4 = X

U15 Switches[†] (Baud Rate) for X.25 only

| S8 | S7 | S6 | S5 | Clock Rate (bps) |
|----|----|----|----|------------------|
| O | O | O | O | 300 |
| O | O | O | C | 1.2k |
| O | O | C | O | 2.4k |
| O | O | C | C | 4.8k |
| O | C | O | O | 9.6k |
| O | C | O | C | 19.2k |
| O | C | C | O | 38.4k |
| O | C | C | C | 48.0k |
| C | O | O | O | 57.6k |

[†] O = open (off, up), C = closed (on, down), X = don't care

* Discontinued product; shown for reference only.

Firmware Installation

A set of jumpers on the interface card provides the option of using different ROM parts in the future. The set consists of a 14-pin socket that houses seven removable jumpers (XW1A through XW1G), and two hard-wired jumpers on the interface card itself. XW1A through XW1G should be configured as described in the following tables. Hard-wired jumpers W5 (not installed) and W6 (installed) are factory configured.

| ROM Category | HP Part No. [†] | Part Type |
|--|---|--|
| A | 1818-0762 | TI 2532 |
| B | 1818-0498 | TI 2516 Intel 2716 |
| C | 1818-0850 1818-1633 (No HP P/N) 1818-1747 1818-3384 | Intel 2732 Intel 2732A Intel 2332 Intel 2764 Intel 2764A |
| [†] HP Part No. refers to the unprogrammed part; typically a separate sticker is applied with the firmware part no. (i.e., the contents of the programmed ROM). | | |

| ROM Category | | | Modem and Direct Connect | | | | | | | Direct Connect Only | | | |
|----------------|-----|------|--------------------------|---|---|---|---|---|---|---------------------|----|----|----|
| Modem | U24 | U44 | XW1A through XW1G | | | | | | | XW2D through XW2A | | | |
| Direct Connect | U93 | U203 | A | B | C | D | E | F | G | D | C | B | A |
| | C | C | | | | | x | | | dc | dc | dc | dc |
| | C | A | | | | x | x | | | x | | dc | dc |
| | A | A | | | | | x | x | x | x | | dc | dc |
| | C | A | | | x | | x | x | | x | | dc | dc |
| | B | A | | | x | | x | x | x | x | | dc | dc |
| | B | B | | | x | | x | x | x | x | | dc | dc |
| | A | B | x | | | | x | x | | x | | dc | dc |
| | C | C | x | | | | x | x | x | x | | dc | dc |
| | A | B | x | | x | | x | x | | x | | dc | dc |
| | B | C | x | | x | | x | | x | x | | dc | dc |

where: x = a required jumper in place
dc = don't care

PSI Test Hoods

| Direct-Connect | Modem | Purpose |
|------------------------|---|---|
| 5061-3421 5061-3460 | 5061-3425 5061-4916 5061-3453 5061-4915 5061-3441 | loopback verifier diagnostic hood diagnostic hood RS-449 loopback RS-449 loopback |

Both the loopback verifier and the diagnostic hood will perform a loopback function, but the diagnostic hood allows checking all the signal lines to the edge connector. The 1000-3000 link cannot loopback since it is defined as half-duplex. Therefore, the diagnostic hood is shipped for BISYNC while the loopback hood is shipped for HDLC or X.25.

HP 12008A PROM Storage Module

Switch Configuration

U1 Switches

S1 S2 S3 S4 S5 S6 S7 S8

X X < - Select Code - > The Select Code is the only configuration required.

where:

- O = Open (up) = logic 1
- C = Closed (down) = logic 0
- X = don't care

Refer to *HP 12008A PROM Storage Module Interface Reference Manual* (part no. 12008-90001), for information about ROMs suitable for this card as well as programming information.

HP 12009A HP-IB Interface

Switch Configuration

U1 Switches

| S1 | S2 | S3 | S4 | S5 | S6 | S7 | S8 | |
|----|----|----|----|-------------|----|----|----|---|
| C | Y | < | - | Select Code | - | > | | HP 12009 will not operate as the bus controller—in-charge. |
| O | Y | < | - | Select Code | - | > | | HP 12009 will operate as the bus controller in-charge. [†] |

where:

- O = Open (up) = logic 1
- C = Closed (down) = logic 0

Y = O; the delay between the assertion of data on the bus and the assertion of DAV is 500 ns.

Y = C; the delay between the assertion of data on the bus and the assertion of DAV is 350 ns (satisfies IEEE Standard 488-1978 for fast settling time required for high speed operation).

U16 Switches[‡]

| S1 | S2 | S3 | S4 | S5 | S6 | S7 | S8 | |
|----|----|----|----|------------|----|----|----|--|
| C | C | C | < | HP-IB adrs | > | | | Determines the HP-IB address to which the PHI chip will respond. |
| O | C | C | < | HP-IB adrs | > | | | Puts PHI chip online. |
| C | O | C | < | HP-IB adrs | > | | | Puts PHI chip into "TALK ALWAYS" mode. |
| C | C | O | < | HP-IB adrs | > | | | Puts PHI chip into "LISTEN ALWAYS" mode. |

where:

- O = Open (up) = logic 1
- C = Closed (down) = logic 0

Note that diagnostics will not pass unless jumper W1 is installed

[†] When U1S1 is open, U16S1-S8 should all be closed for typical applications.

[‡] U144 or later. U16S1-S3 should be open in special applications only

HP-IB Cable Length Restrictions

Standard/Low-Speed Operation (Switch U1S2 Open)

1. All devices on the bus must be the same speed.
2. The total length of the cable permitted to be used with one interface card must be less than or equal to two times the number of devices connected together. The HP-IB card is considered *one* device.
3. The total maximum cable length must not exceed 20 meters.

High-Speed Operation (Switch U1S2 Closed)

1. All devices expected to talk at higher rates must use a settling time of 350 ns or less.
2. All devices expected to operate at higher rates should use 48 mA tri-state drivers.
3. The device capacitance on each lead (except REN and IFC) should be less than 50 pF per device.
4. Interconnecting cable links should be as short as possible with a maximum of 15 meters total length per system.
5. Normally, the optional load resistor pack must be installed for high-speed operation. It is installed at the factory at location U79, a storage socket, and should be installed in U119 when in use. Pin one of the resistor pack goes in the receptacle just above the “U” of “U119” silk-screened on the board.

| <u>Number of External Devices</u> | <u>Maximum Total Cable Length (meters)</u> |
|---|--|
| 1 | 9 |
| 2 | 10 |
| 3 | 11 |
| 4 | 12 |
| 5 | 13 |
| 6 | 14 |
| 7 (max, see below) | 15 |

6. Normally, no more than eight high-speed devices are allowed in the system (the HP-IB card counts as one device). A normal maximum system is composed of the HP-IB card with its high-speed resistor pack and up to 7 peripherals.

HP-IB Loading/Cabling Guide

HP 12009 (Instrument or Computer) 1 or 8 loads (1 standard + 7 loads in optional pack = 8 loads).

There are two simple rules to follow when configuring controllers to control peripheral devices and resulting cable layout and length restrictions.

Rule 1 – Loading

For mass storage devices, a controller can support a maximum of four HP-IB loads. For best performance, it is recommended that one interface card not have both disk and mag tapes connected to it. However, if this is the case you need to change your answer file and regen the system.

Rule 2 – Cable Lengths

The cable length (in meters) cannot exceed the total HP-IB loads associated with the computer speed controller (internal and external HP-IB loads). For example, if the controller is “preloaded” to 8 HP-IB loads and only one disk drive is connected to it with an HP-IB load of 1, then the maximum cable length is 9 meters (8 internal + 1 external). All internal device cable lengths must be included in the total cable length computation. The best “rule of thumb” is to measure HP-IB cable lengths from controller PCA edge connector to device PCA edge connector. A summary of known internal HP-IB cable lengths is included in this section. For standard speed operation, 2 meters of cable per device is allowed.

Another point to remember is to add up all pieces of cable, especially if a complex “T” cabling arrangement is used.

Site Preparation Flexibility

The only way to alter the layout of an HP 1000 system when HP-IB cabling restrictions develop is to, when possible, increase the number of HP-IB loads per device. The HP 2608S* printer can have loads adjusted on the interface within the printer (8 loads maximum). The HP 7974*/78* tape drives also have adjustable load resistors.

* Discontinued product; shown for reference only.

HP 1000 Series HP-IB Summary Chart

| HP Device | # Loads | Internal Cable |
|---------------|---------|----------------|
| 59310B* | 1 | 0M |
| 12821A* | 7 | 0M |
| 12009 | 1 or 8 | 0M |
| 7933*/35* | 1 | 0M |
| 792XM* | 1 | 0.75M |
| 7906M* | 1 | 0.75M |
| 7906H* | 2 | 0.75M |
| 7970E* | 1 | 0M |
| 7974* | 1-6 | 1M |
| 7978* | 1-7 | 0M |
| 7908* | 1 | 0M |
| 7911*/12*Disk | 1 | 1.0M |
| 7911*/12*Tape | 1 | 0.5M |
| 2608* | 1 | 0M |
| 293x* | 1 | 0M |
| 256x* | 1 to 8 | 0M |
| 9895* | 1 | 0M |
| Plotters* | 1 | 0M |
| 2608S* | 1 to 8 | 0M |
| 12009-60007* | | 2M |
| 10833A | | 1M |
| 10833B | | 2M |
| 10833C | | 4M |
| 10833D | | 0.5M |

Special Conditions:

HP 12009A can support an HP 2631B* and two HP 2608Ss*.

Device Equivalent Loads

There must be one equivalent load for each meter of cable. Optional resistor packs for the HP12009 provide seven additional loads for a total of eight loads for the card.

* Portions or all of this product line are discontinued; shown for reference only.

m = meters of cable
 load = device load
 equivalents

(Refer to the appropriate peripheral Installation/Service Manual for individual device loads.)

Case 1. $m - \text{load} = N \leq 0$ As long as N remains less than or equal to 0, the optional load resistor packs are not required.

Case 2. $m - \text{load} = N > 0$ and less than 8 devices. Install the optional load resistor packs in the sockets provided. See Note.

Case 3. $m - \text{load} = N > 0$ and more than 8 devices. The optional resistors provided with the card will not meet the system requirements. The following formulas must be used to determine the correct values of the load resistors to be used.

$$R_{12/14} = \frac{2.3k \text{ ohms}}{N}$$

$$R_{11/13} = \frac{4.7k \text{ ohms}}{N}$$

If power applied to the HP-IB Interface card is lost while the optional load resistors are being used, the HP-IB bus will be pulled down to ground. This is also true for devices connected to the bus. All devices (e.g., disks) on the bus should be powered on for high speed operation. Half of the devices plus the farthest device should be powered on for standard/low speed operation.

| NOTE: | Part No. | Location | Value |
|--------------|-----------------|-----------------|------------------|
| | 1810-0272 | R12,R14 | 330 ohms |
| | 1810-0270 | R11,R13 | 680 ohms |
| | 1810-0018 | U119 | Resistor package |

Pin 1 is identified by a dot, a round depression in the resistor pack, or by pin numbers printed on the package. The HP 12009 identifies pin 1 in conjunction with the part reference (i.e., 1R12 = R12 pin 1).

The 12009-60020 card has changed the four SIP resistor sets to a single DIP package (part no. 1810-0018). You must move the package from the shipping (storage) socket U79 to the load position socket U119 where the resistor acts as an additional seven loads (for a total preload of eight).

HP 12016A SCSI Interface

Switch Configuration

SW1 Switches

S1 S2 S3 S4 S5 S6 S7 S8

O C < – Select Code – >

S2 = C enables SCSI TERMPWR (terminal power)

SW2 Switches

S1 S2 S3 S4 S5 S6 S7 S8

C C C C C O O O

S1 - S5 = C (reserved)

S6 - S8 = 0 determines address (7 shown and recommended)

where:

O = Open (up) = logic 1

C = Closed (down) = logic 0

HP 12021A* Mini-Disk Controller

The following are the switch settings for the Model 6* Mini-Disk Controller:

Switch

S1 S2 S3 S4 S5 S6 S7 S8

O C X X Y <HP-IB adrs> Loop on Controller selftest only.

C O X X Y <HP-IB adrs> Loop on self-test.

where:

O = Open (up) = logic 1


C = Closed (down) = logic 0

X = don't care

Y = C; sets HP-IB timing to Slow (500 ns between DATA & DAV).


Y = O; sets HP-IB timing to Fast (350 ns between DATA & DAV).

* Discontinued product; shown for reference only.



- Note:
1. Switch S3-5 in up position enables compatibility with high-speed HP-IB operation.
 2. Switches S3-6 through S3-8 set HP-IB address (up position equals "1").

Unit jumpers for the flexible mini-disk drives (found on the electronics PCA for each drive) are as follows.



HP 12022A* Integral Disk Controller

U1 Switches

| | | | | | | | |
|----|----|----|-----------------|----|----|----|----|
| S1 | S2 | S3 | S4 | S5 | S6 | S7 | S8 |
| X | X | < | - Select Code - | | | | > |

U1605 Switches

| S1 | S2 | S3 | S4 | S5 | S6 | S7 | S8 | Disk Drive Type* |
|--|----|----|----|----|----|----|----|--|
| C | C | C | C | C | C | C | O | 10 Mbyte fixed, address 0 . With flexible disk drive, address 3. (Micro 2x SPU option 110) |
| C | C | C | O | C | C | C | O | |
| C | C | C | C | C | C | O | C | 15 Mbyte Fixed, Address 0 . With flexible disk drive, address 3. (Micro 2x SPU option 111) |
| C | C | C | O | C | C | O | C | |
| C | C | C | C | O | C | C | O | 20 Mbyte Fixed, Address 0 . (Micro 2x SPU Opt. 151) |
| C | C | C | O | O | C | C | O | With flex. disk drive, address 3. (Micro 2x SPU Opt. 150) |
| <p>Note: The switch settings for flexible disk drives are valid for both single-sided and double-sided 3-1/2 inch microdiskettes.</p> <p>where: O = Open (up) = logic 1 C = Closed (down) = logic 0 X = don't care</p> | | | | | | | | |

To configure a 15 MB disk to look like a 10 MB disk, strap the HP 12022A* card for 10 MB, then format the disk with the FORMF bootable system microdiskette supplied with a 10 MB system. Use LU 36 when formatting the disk as a 10 MB disk.

The following jumpers should be inserted on the HP 12022A* card as indicated. They are used for factory tests and they apply for all integrated hard disk sizes.

- W1, 2, 4, 6, 7 = IN
- W3, 5 = OUT
- J6 = all OUT
- J5 = all OUT except pin 23 tied to pin 24

Seagate has put a green sticker on the outside of the drive designating which drive it is.

- 10 MB = ST-412
- 15 MB = ST-419
- 20 MB = ST-225

* Discontinued product; shown for reference only.

HP 12025A/B I/O Extender

I/O Extender Switches

The I/O extender has two switches, either on the front of the box (HP 12025A) or the rear of the box (HP 12025B). The switches are:

- a. **BATTERY or BACKUP.** This two-position switch has no function when the extender box is used for the extender and may be set to either position. (When the +5VM voltage is activated the box is used for computers.)
- b. **LINE.** When this switch is set to the ON position, it applies AC line power to the extender power supply and fans. When this switch is set to OFF, it removes AC power from the power supply and fans.

I/O Extender Software Considerations

Previously, RTE-A only supported 24 select codes. This limitation was based on the fact that there were 24 available map sets in the A-Series and each map set was used for a unique select code. With the additional select codes needed by the I/O Extender, changes were made to the operating system to dynamically allocate and deallocate map sets.

One word has been added to the Interface Table (IFT) to store mapping information for a particular I/O channel. Therefore, a change was made to the IFT definition in the generation.

| | |
|-------|------------------------------|
| AL:LO | Look to a map set |
| AL:DY | Dynamically allocate map set |

Example: IFT,%ID*50::RELOC,SC:26B,AL:DY

For more information refer to the *RTE-A System Generation and Installation Manual* (part no. 92077-90034).

I/O Extender Restrictions

1. I/O Extenders are supported only in A600+, A700*, A900, and A990 16- and 20-slot card cages.
2. The EXT card goes in the first slot of the extender box.
3. The I/O Control (IOC) card goes in the CPU backplane. The slot location is dependent upon its priority.
4. If the Interrupt Chain Jumper (ICJ) card is used, the card goes in the first slot after the last card in the extender box.
5. You need to allocate additional space in the answer file for the I/O extender.
6. To use more than 24 I/O cards, you need Rev. 2440 software. However, the extender is compatible back to Rev. 2340 software.
7. The I/O extender will not support battery backup in the I/O extender box. The 12151-80004 battery backup jumper card must be installed in the power supply of the HP 12025B 20-slot box.

I/O Extender Firmware Requirements

If an A900 computer with serial prefix less than 2500 is used with the I/O extender, the following is needed:

1. A 12203-60011 or newer cache control card. (Older cards will cause a self-test machine check error.)
2. The following PROM part numbers (or higher) for the 12201 Sequencer Card.

| PROM Part No. | Designation | ROM |
|---------------|-------------|-----|
| 12201-80084 | U0803 | 0 |
| 12201-80085 | U0802 | 1 |
| 12201-80086 | U0801 | 2 |
| 12201-80087 | U1103 | 3 |
| 12201-80088 | U1102 | 4 |
| 12201-80089 | U1101 | 5 |

* Discontinued product; shown for reference only.

If an A700* computer with serial prefix less than 2500 is used with the I/O Extender, the following PROMS for the 12152 Lower Processor Card are needed.

| PROM Part No. | Reference Designation |
|---------------|-----------------------|
| 12152-80053 | U91 |
| 12152-80054 | U101 |
| 12152-80055 | U111 |
| 12152-80056 | U121 |

Rack Mounting Instructions

The I/O Extenders can be installed:

1. In place of an HP 791xR* Disk. In an A-Series system that does not use an HP 791xR* CS/80 Disk, an HP 12025B I/O Extender can be installed in the HP 219xC* cabinet space normally occupied by the HP 791xR* Disk. This requires the replacement of the standard disk computer door, which is cut out for access to the disk, with an HP 219xC*/D* Option 053 door, which has louvers instead of the cut out for the disk. A set of 12679 Support Rails is also required.

NOTE

Because it does not use front-to-rear ventilation, the HP 12025A I/O Extender cannot be installed in the HP 791xR* Disk mounting space in HP 219xC* + 053 SPU cabinets.

2. In the upper compartment of the HP 219xC* cabinet. One or two HP 12025A or 12025B I/O Extenders can be installed in the upper compartment of the HP 219xC* (29431G) SPU Cabinet, provided that:
 - a. Only HP 12025A or only HP 12025B I/O Extenders are installed in the upper compartment. A HP 12025A I/O Extender cannot be installed in the same compartment with a HP 12025B because they differ with respect to direction of ventilation air flow. One set of 12679 Support Rails is required for each I/O extender.

* Discontinued product; shown for reference only.

- b. The upper front door of the cabinet is deleted for installation of HP 12025B I/O Extenders (but not for HP 12025A I/O Extenders) by ordering HP 219xC* Option 051. This permits the front-to-rear air flow required for self-ventilation of the HP 12025B I/O Extenders. For details of trim installation, see the *HP 40027A Door Trim Kit Installation Manual* (part no. 40027-90002).
- c. All unoccupied vertical front mounting space is covered by filler panels.

Floor Mounting Instructions

The HP 40025A Vertical Floor Mount must be used for vertical floor mounting of an HP 12025A I/O Extender box. Install the HP 12025A box in a HP 40025A by following the instructions provided with the HP 40025A.

HP 12040B*/C/D 8-Channel Asynchronous Multiplexer

The MUX select code and VCP enabling are controlled by the settings of switch U1.

Switch U1

S1 S2 S3 S4 S5 S6 S7 S8

C X < – Select Code – > Port 0 is enabled as VCP
 O X < – Select Code – > Port 0 is disabled as VCP

where: O = Open (up) = logic 1
 C = Closed (down) = logic 0
 X = Don't care

Note that the BOOT SEL switches for each processor can be set to enable VCP to do speed sensing and enable ENQ/ACK on Rev. D of the HP 12040 MUX. Refer to Chapter 2 for the CPU switch settings.

* Discontinued product; shown for reference only.

HP 12040B*/C/D Jumper Positions vs. Manufacturer's Part No.

| Manufacturer's Part Number | Install Jumper | Size (bytes) |
|--|---------------------|--------------|
| TI 2532 | W2, W5 | 4K |
| MOT MCM68A332 | W2, W5 | 4K |
| Intel 2732, 2332 | W4, W7 [†] | 4K |
| MK36000, AMI 54264 | W3, W5 | 8K |
| MOT MCM68A364, MCM68764 | W3, W5 | 8K |
| Intel 2764 | W4, W7 [†] | 8K |
| MK2764 | W4, W6 | 8K |
| MBM 2764 | W4, W7 | 8K |
| [†] Jumper W7 continuously enables the EPROM and is used in normal operation. Jumper W6 selectively enables the EPROM and may be used instead of Jumper W7 for custom applications. | | |

HP 12065A Color Video Output Interface

Switch Configuration

The switch settings for the HP 12065A card are as follows:

Switch SW1 Positions

SW1 contains eight positions, numbered 1 through 8; position 1 (SW1-1) is the most significant bit (bit 7). Positions SW1-3 through SW1-8 (bits 5 through 0) establish the video card's select code. Set these switches to the select code that you have chosen for the video card.

Positions SW1-1 and SW1-2 (bits 7 and 6) select the video pattern that is displayed at the end of self-test. These switches are read by the firmware when the card has finished testing its onboard electronics, and the appropriate test pattern is displayed. Self-test modes can be reconfigured in software. The mode definitions are as follows:

* Discontinued product; shown for reference only.

| Mode | Description |
|-------------|--|
| 0 0 | Displays the Graphics/1000-II 15 default colors in vertical bands and the default highlight mode. The first six colors are black, white, red, green, yellow, and blue. |
| 0 1 | Displays 15 vertical bands in increasing levels of gray. Because the gray scale represents a uniform ramp of intensity data, this mode is useful for testing the video signal without the monitor, such as with an oscilloscope. Alternatively, a monitor can be properly tested and adjusted for proper color tracking; there should be gradual steps in the gray scale without color hues in the vertical bands. |
| 1 0 | Displays a grid pattern for adjusting monitor convergence, and horizontal and vertical linearity. Convergence refers to the quality of the blue, green, and red electron beams converging to the same point. |
| 1 1 | Repeats self-test continuously. This is useful for the diagnosis of intermittent hardware problems. Note that changing the switches during continuous self-test will automatically reconfigure the self-test mode to the new switch setting selected. |

Switch SW2 Positions

The second switch, SW2, configures the monitor drive signal and display format.

| | Switches | | | |
|------|-----------------|---|---|---|
| | 1 | 2 | 3 | 4 |
| bits | 3 | 2 | 1 | 0 |

There are 16 possible configurations. These are shown with their respective parameter values in the table following. On power-up and self-test, the configuration indicated by the display switch positions is implemented.

Display Parameters

The monitor drive signal and display format are configured by hardware switch SW2, or in software using the Write Card Configuration video card request. There are 16 possible configurations which are shown by the display codes below. As shown by the range of horizontal sweep frequencies available, the video output card will operate with most monitors.

| Display Code | Resolution (h: horizontal) (v: vertical) | Horizontal Sweep Frequency | Vertical Scan Frequency |
|--------------|--|----------------------------|-------------------------|
| 0000 | 576h x 455v | 29.4 kHz | 60.0 Hz |
| 0001 | 512h x 512v | 31.5 kHz | 57.5 Hz |
| 0010 | 576h x 455v | 28.1 kHz | 57.4 Hz |
| 0011 | 512h x 512v | 30.8 kHz | 56.1 Hz |
| 0100 | 576h x 455v | 27.0 kHz | 55.1 Hz |
| 0101 | 512h x 512v | 29.4 kHz | 53.6 Hz |
| 0110 | 576h x 455v | 25.9 kHz | 52.9 Hz |
| 0111 | 512h x 512v | 28.1 kHz | 51.4 Hz |
| 1000 | 576h x 455v | 25.0 kHz | 50.9 Hz |
| 1001 | 512h x 512v | 27.0 kHz | 49.3 Hz |
| 1010 | 576h x 455v | 24.0 kHz | 49.1 Hz |
| 1011 | 512h x 512v | 25.9 kHz | 47.3 Hz |
| 1100 | 576h x 455v | 23.2 kHz | 47.4 Hz |
| 1101 | 512h x 512v | 25.0 kHz | 45.5 Hz |
| 1110 | 576h x 455v | 22.4 kHz | 45.7 Hz |
| 1111 | 512h x 512v | 24.0 kHz | 43.9 Hz |

HP 12076A LAN/1000 Interface Controller Card Switch Configuration

Switch U1

S1 S2 S3 S4 S5 S6 S7 S8

O X < – Select Code – > VCP and FCL (Forced Cold Load) are disabled

C X < – Select Code – > VCP is enabled

where: O = Open (up) = logic 1
C = Closed (down) = logic 0
X = don't care

HP 12100A A400 On-Board I/O Interface

Refer to the A400 On-Board I/O Switch (U1001) section in Chapter 2 for information.

HP 12153A Writable Control Store for A700*

The switch on the 12153-60001 Writable Control Store Card is used to set the select code of the card.

| Switch | | | | | | | |
|--------|----|----|----|-------------|----|----|----|
| S1 | S2 | S3 | S4 | S5 | S6 | S7 | S8 |
| O | X | < | - | Select Code | - | > | |

where: O = Open (up) = logic 1
C = Closed (down) = logic 0
X = don't care

HP 12155A PROM Control Store for A700*

Refer to the A700* PROM Control Store section in Chapter 2 for information on this card.

HP 12205A Control Store for A900

Refer to the A900 Control Store section in Chapter 2 for information on this card.

* Discontinued product; shown for reference only.

Table of Contents

Chapter 4 Troubleshooting

| | |
|---|------|
| LED Indications | 4-1 |
| A400/A600+ Self-Test | 4-1 |
| A700* Self-Test | 4-5 |
| A900 Self-Test | 4-11 |
| A990 Self-Test | 4-16 |
| A400/A600+/A700* Memory Array Cards | 4-22 |
| A600+/A700* Error Correcting Memory Card | 4-23 |
| A700* WCS Card | 4-23 |
| A900/A990 Memory Array Card | 4-24 |
| A900 CS Card | 4-24 |
| I/O Extender IOC Card (12025-66001) | 4-24 |
| I/O Extender EXT Card (12025-60002) | 4-24 |
| PSI Cards | 4-25 |
| HP 12021A* Model 5 and 6 Internal Disk Controller LED Indications | 4-26 |
| Self-Test Initialization | 4-26 |
| EPROM Errors | 4-26 |
| Non-Fatal Errors | 4-27 |
| Drive Power Up Errors | 4-27 |
| Read Self-Test Errors | 4-28 |
| Read/Write Self-Test Errors | 4-28 |
| After Self-Test | 4-28 |
| HP 12076A LAN/1000 Interface Controller Card LED Display | 4-29 |
| HP 12016A SCSI Card Tests | 4-29 |
| Self-Test | 4-29 |
| Verification Program | 4-30 |
| Interactive Interface | 4-30 |
| Non-Interactive Interface | 4-32 |
| VCP Loader Errors | 4-34 |
| Cartridge Tape Loader Errors | 4-34 |
| PROM Card Loader Errors | 4-34 |
| DS/1000 Loader Errors | 4-35 |
| Disk Loader Errors | 4-35 |
| Magnetic Tape Loader Errors | 4-36 |
| HP 12022A Disk Interface Loader Error | 4-36 |
| Other | 4-37 |
| Halt Error Codes | 4-37 |
| Diagnostic Control System Error Indications | 4-39 |
| Primary and Secondary LED Error Codes | 4-39 |
| Diagnostic Program Error LED Indications | 4-41 |
| Diagnostic Driver Errors | 4-42 |
| RTE Device Driver Posted Status | 4-44 |
| ASCII/BYTES Table | 4-45 |
| Utilities | 4-47 |
| ASAVE and ARSTR | 4-47 |
| CSYS | 4-48 |
| COPYL | 4-49 |
| EDIT/1000 | 4-49 |
| ERTSH | 4-50 |
| FC | 4-51 |
| FORMA | 4-53 |
| FORMC | 4-54 |
| FORMF | 4-55 |

| | |
|--|------|
| FORMT | 4-56 |
| FOWN | 4-56 |
| FPACK | 4-57 |
| FPUT | 4-57 |
| FREES | 4-57 |
| FSCON | 4-58 |
| FST | 4-58 |
| FVERI | 4-60 |
| INSTL | 4-60 |
| LIF | 4-61 |
| LINDX | 4-62 |
| MERGE | 4-62 |
| METER | 4-63 |
| MPACK | 4-64 |
| OLDRE | 4-64 |
| PBV (PushButton Verify) | 4-64 |
| PRINT | 4-65 |
| RINFO (Reset Multiuser Accounting Information) | 4-66 |
| SAM (System Available Memory Reporting) | 4-67 |
| SINFO (Show Multiuser Accounting Information) | 4-67 |
| SPORT (Serial Port Analyzer) | 4-67 |
| TF | 4-68 |
| WH | 4-69 |
| BOOTEX Boot Extension | 4-70 |
| Purpose | 4-70 |
| BOOTEX Flowchart | 4-71 |
| Operation | 4-72 |
| Boot Program Commands | 4-72 |
| ECHO Command | 4-72 |
| System/Snap Commands | 4-72 |
| Mounting Cartridges | 4-72 |
| Scratch LU | 4-73 |
| Bad Pages | 4-73 |
| Memory Commands | 4-73 |
| Restore Program Commands: RP, ST, SZ, and PR | 4-74 |
| Reserved Partition Assignment | 4-74 |
| Reserved Partition Definition | 4-75 |
| Swap File Definition | 4-75 |
| Timeslicing, Swapping, Security Code, Session Accounting | 4-75 |
| END Command | 4-76 |
| Sample BOOTEX Command File | 4-76 |

Troubleshooting

LED Indications

A400/A600+ Self-Test

Self-test consists of two test programs (Test 1 and Test 2) that automatically execute each time the computer is powered up. The tests provide a quick, convenient check of basic computer operation. Self-test can also be executed on the A600+ by pressing the RESET switch on the processor board. If there is a failure during the self-test, the computer may or may not operate depending on what part of the self-test failed. Successful completion of the self-test is followed immediately by execution of a bootstrap loader or the Virtual Control Panel (VCP) program. These functions are selected by setting the processor BOOT SEL switches.

Test 1. Test 1 is a microprogram stored in the base set PROMs of each processor and executes immediately upon power-up. This test will execute in all configurations in which +5V power is present, including the case when the A600+ processor board or the A400 board is the only assembly plugged into the backplane. All of the LEDs are turned on when power is initially applied to the computer or (for the A600+ only) when the RESET switch is pressed. Test 1 then begins execution. Test 1 is different for each processor. The following is a description of Test 1 for each processor:

A400 – Test 1 checks the basic functioning of the VLSI chip (that is, the CPU) and does a checksum of the VCP code in PROMs. If Test 1 fails, the processor loops on an instruction in location 04 of main memory.

A600+ – Test 1 checks the CPU, the backplane data paths, the control store sequencer, and the interrupt vector logic. If Test 1 fails, the processor loops on microcode that writes a galloping one through the CPU and backplane data paths, simplifying data path troubleshooting.

Failure is indicated by all the LEDs remaining on. If Test 1 completes successfully, it extinguishes the rightmost LED. Upon successful completion, Test 2 begins execution. Test 1 execution time is negligible. The following table shows the LED failure indicators for Test 1 and the first phase of Test 2.

Test 1/Test 2 Failure Indicators

| Failure Pattern † | Meaning |
|------------------------------|--|
| 11111111 | Microcode self-test failed. Short or power supply fault if PON is low. Processor fault if PON high. (Backplane or processor data bus problem.) |
| 11111110 | Microcode self-test passed but first memory fetch failed. First check frontplane cabling and memory controller, then check processor. |
| 11111100 | Basic instruction test failed. Check processor. |
| 11111000 | Boot memory access failed. Check memory controller and VCP/Loader/Self-Test PROMs. |
| 11110000 | Time Base Generator (TBG) tick or interrupt failed. Check processor. |
| 10111111 | No VCP found. |
| † 1 = lit LED; 0 = unlit LED | |

Test 2. Test 2 is an assembly language program stored in VCP PROM (located on the memory controller card for the A600+) and executes upon successful completion of Test 1. Test 2 can also be initiated by an operator command (%T) from the Virtual Control Panel (VCP). It has a maximum execution time of ten seconds. Test 2 consists of two phases.

The first phase checks the computer's basic instruction set, several internal flags, and Boot RAM. Boot RAM addressing is tested by writing the address of each location into that location and reading it back. Then the complement of each address is written and read back. Finally, zeroes are written and read back. When the entire 1k of Boot

RAM is tested successfully, each location of Boot RAM contains zeroes.

The second phase tests main memory, the I/O Master of each interface to ensure that data transfer, flag, interrupt, and direct memory access (DMA) functions are processed correctly, and checks the computer configuration. Phase 2 tests main memory by writing all ones to each memory location, and reading back the data. Then all zeroes are written and read back. (Main memory is cleared.)

The LED indication on successful completion of Test 2 depends on the computer action selected by the Start-Up (BOOT SEL) switches. (The first two switch settings are used for troubleshooting. The remaining switch settings are used for configuring the processor.) If Test 2 detects a failure, it stops executing and the processor LEDs indicate a failure code. If there is a VCP console and the failure does not hinder VCP operation, the VCP program is entered and the failure code is displayed on the VCP console.

If Test 2 detects a failure during phase 1, it stops execution so that booting of the system does not occur. The processor LEDs indicate the type of failure. If the basic instruction test, or the Time Base Generator (TBG) tick and the interrupt flag test fails, the processor is probably faulty.

If Test 2 detects a failure during phase 2, VCP can still run if the VCP interface is functioning properly and if a VCP console is installed. The failure will cause the LEDs to flash once. The VCP console then displays PTEST ERROR xxxxxx xxxxxx. The first word is the main error code and the second word is the flashing subcode. The following table shows the LED failure indications for memory and I/O errors. The octal number to the left of the LED codes are displayed in the PTEST ERROR fields. The number in the left field specifies the primary category of error: main memory error, I/O interface error, or interrupt error. The number in the right field identifies the specific error. For example, error code 000300 000203 indicates that an I/O error (300) has occurred and that the error was caused by duplicate select codes (203). An error code of 000340 000200 indicates a memory error (340) in the first 32 KWord block of memory.

At revision 4020 of VCP, a new parity error message was added. A memory test failure will result in the following message display:

PAR ERR xxxxxx zzzzzz

where xxxxxx is the octal page number where the failure occurred and zzzzzz is the octal word address within the page. (Don't forget to convert the page number to decimal and KWords to Kbytes to identify the failure location.)

Test 2 Error Codes

| Octal Code | LED Display † | Definition |
|---|----------------------|---|
| 340 2xx | 11100000 10xxxxxx | Main memory failure. The right field indicates the 32 KWord block of memory that is bad. If xxxxxx is zero, the memory controller could be bad. |
| 300 2xx | 11000000 10yyyyyy | I/O interface failure. The right field displays the interface select code or the error code. If yyyyyy is greater than 17B, yyyyyy is the failing select code. If yyyyyy is less than 20B, an interface error is indicated. |
| The values for yyyyyy are listed below. | | |
| 200 | 10000000 | No I/O cards. |
| 201 | 10000001 | More than one interface has VCP Enabled (switch U1S1 closed). |
| 202 | 10000010 | Priority chain broken or duplicate VCP select code. |
| 203 | 10000011 | Duplicate select code. The duplicate select code is contained in the B-Register. |
| 204 | 10000100 | An I/O card has a select code less than 20B or broken priority chain. |
| 205 | 10000101 | Terminal not connected for VCP. Check the cable, and VCP Enable (switch U1S1) or the VCP interface. |
| 206 | 10000110 | Unexpected time base generator interrupt. |
| 207 | 10000111 | Unexpected memory protect interrupt. |
| 210 | 10001000 | Unexpected unimplemented instruction trap (UIT) interrupt. |
| 211 | 10001001 | Invalid sc for A400 on-board I/O. |
| 212 | 10001010 | Invalid ID Number for A400 on-board I/O. |
| 213 | 10001011 | Speed sensing failure on A400 on-board I/O or HP 12040D 8-channel MUX. |
| † 1 = lit LED; 0 = unlit LED | | |

Self-Test Pass Indicators

| LED Display † | Definition |
|------------------------------|--|
| 00000111 | VCP program is running. |
| 00000001 | A boot loader is running. |
| 00000000 | User software is running. |
| 10000000 | Loader error. Probably a checksum error; change media on loading device. |
| 00001111 | Running Basic Control Module (BCM) Program. |
| 00010000 | Running Diagnostic Design Language (DDL) program. |
| † 1 = lit LED; 0 = unlit LED | |

A700* Self-Test

Self-Test consists of two test programs (Test 1 and Test 2) that automatically execute each time the computer is powered up. The tests provide a quick, convenient check of basic computer operation. Self-test can also be executed by pressing the RESET switch on the frontplane. If either self-test program fails, the computer will not operate. Successful completion of the self-test is followed immediately by execution of a bootstrap loader, the Virtual Control Panel (VCP) program, or a program sustained in memory by an optional battery pack. These functions are selected by setting the frontplane switches.

Test 1 is a microprogram stored in the base set PROMs on the lower processor card and executed immediately upon power up. It checks logic and registers on the processor cards and checks the VCP/Loader/Test 2 PROMs on the memory controller card. If the floating point processor card is installed, it is also checked by Test 1. On successful completion, Test 2 is started. If Test 1 detects a failure of a processor card or the memory controller, it stops executing and the frontplane LEDs indicate a failure code. If a floating point processor error is detected, it is indicated by the LEDs and the test stops executing. Test 1 execution time is negligible. Each processor card test and the memory controller test can be looped for troubleshooting by setting the frontplane switches.

* Discontinued product; shown for reference only.

Test 2 is part of the VCP program stored in PROM on the memory controller card and executes automatically upon successful completion of Test 1. Test 2 checks the computer's basic instruction set, several internal flags, and all the memory. If memory is sustained by the optional battery pack, Test 2 checks it in a non-destructive manner by reading each memory location and making a parity check on the data. If a parity error occurs, the location is read again. Soft errors (defined as a parity error only on the first of two reads of a memory location) are reported to the VCP (if present). If memory is not sustained, Test 2 writes all ones to each memory location, and reads back the data. Test 2 then writes all zeros and reads back the data. (The memory is cleared.) Test 2 also checks the I/O Master logic on each interface card to ensure that data transfer, flag, interrupt, and direct memory access (DMA) functions are processed correctly. If Test 2 detects a failure, it stops executing and the frontplane LEDs indicate a failure code. If a VCP is in the system and the failure does not hinder VCP operation, the VCP program is entered and the failure code is displayed on the VCP. The LED indication on successful completion of Test 2 depends on the computer action selected by the Start-Up (BOOT SEL) switches on the frontplane. Test 2 has a maximum execution time of five seconds.

Test 1. Test 1 sequentially tests the lower processor, upper processor, memory controller, and the floating point processor cards. The results of Test 1 are displayed on the LEDs on the frontplane. On power-up, all of the frontplane LEDs are turned on. The LEDs are then turned off, beginning with the high-order LED, to indicate the progress of Test 1. Test 1 accepts troubleshooting options specified by the frontplane switches. The switches should be set open only when troubleshooting hardware faults or when debugging microcode.

The following table shows the Test 1 switch options.

Test 1 Switch Options

| Switch Setting † | Meaning |
|--|--|
| CCCCCxxx xxxxxxxx | Normal mode, go to Test 2. |
| Oxxxxxxx xxxxxxxx | Loop on Lower Processor Test. |
| COxxxxxx xxxxxxxx | Loop on Lower Processor and Upper Processor Tests. |
| CCOxxxxx xxxxxxxx | Loop on Lower Processor, Upper Processor, and Memory Controller Tests. |
| CCCOxxxx xxxxxxxx | Loop on Lower Processor, Upper Processor, Memory Controller, and Floating Point Tests. |
| CCCCOxxx xxxxxxxx | Enable Diagnostic window (microcode debug utility). |
| † C = Closed = logic 0 O = Open = logic 1 x = don't care | |

Only one switch should be set open at any time. If a switch is set open, the test specified by the switch and all of the previous tests will be executed. For example, if SLFTST switch 3 is set open, the Lower Processor test, the Upper Processor test, and the Memory Controller test will be executed. If no faults occur, these tests will continue to execute in a loop. If a failure is detected in any of the tests, the micromachine enters a one-instruction loop and sets the appropriate LEDs on. The following table shows the error codes that are displayed.

Test 1 Failure Indicators

| Failure Pattern [†] | Meaning |
|---|---|
| 11111111 11111111 | A700* Lower processor card failed. |
| 01111111 11111111 | A700* Upper Processor card failed. |
| 00111111 11111111 | A700* Memory Controller or VCP PROMs failed. |
| 00011111 11111111 | A700* CPU passed and no Floating Point card installed, or Floating Point card failed. |
| 00011111 11111110 | A700* Floating Point card failed. |
| [†] 1 = lit LED; 0 = unlit LED * Discontinued product; shown for reference only | |

NOTE

The frontplane Diagnostic Window (DW) switch must be closed during normal operation. This switch is used to enable the Diagnostic Window. If the Diagnostic Window is enabled, various registers useful in debugging microcode are enabled on the CPU internal data bus after the execution of each instruction. Enabling this feature increases the execution time of each instruction by approximately two microseconds.

LEDs 15, 14, 13, and 0 will be set off if the computer passes all Test 1 tests. LED 12 will be set off if the Floating Point board is installed and if it passes the Floating Point test.

Test 2. Test 2 begins execution when Test 1 has completed successfully. Test 2 can also be initiated by an operator command (%T) from the Virtual Control Panel (VCP). If Test 2 detects a failure during phase 1, it stops execution so that booting or restarting of the system will not occur. The frontplane LEDs indicate the type of failure. Phase 1 of Test 2 retests the Upper and Lower Processor boards and the Memory Controller board.

The following table shows the LED failure indicators for the first phase of Test 2. If the basic instruction test fails, the Lower Processor board is probably faulty. If the Time Base Generator (TBG) tick and interrupt flag test fails, the Upper Processor board is probably faulty.

Test 2 Failure Indicators

| Failure Pattern [†] | Meaning |
|------------------------------|--|
| 000x1111 11111110 | Microcode test passed but first memory fetch failed. First check memory controller, then check upper processor and floating point processor. |
| 000x1111 11111100 | Basic instruction test failed. Check lower processor, then upper processor. |
| 000x1111 11111000 | Boot memory access failed. Check memory controller and VCP/Loader/Self-test PROMs. |
| 000x1111 11110000 | Time Base Generator (TBG) tick or interrupt flags failed. Check lower processor, then upper processor. |

† 1 = lit LED; 0 = unlit LED

The second phase of Test 2 tests main memory, the I/O master of all installed I/O boards, and the computer configuration. Any failure after this point will still allow the VCP to run if the VCP interface is functioning properly and if a VCP terminal is installed. The failure will cause the LEDs to flash once. The VCP then displays PTEST ERROR xxxxxx xxxxxx. The first word is the main error code and the second word is the flashing subcode. The following table shows the LED failure indicators for memory and I/O errors. The octal numbers to the left of the LED codes are displayed in the PTEST ERROR fields. The number in the left field specifies the primary category of error – main memory error, I/O interface error, or interrupt error. The number in the right field identifies the specific error. For example, error code 000300 000203 indicates that an I/O error (300) has occurred and that the error was caused by duplicate select codes (203). An error code of 000340 000200 indicates a memory error (340) in the first 32 KWord block of memory.

At revision 4020 of VCP, a new parity error message was added. A memory test failure will result in the following message display:

PAR ERR xxxxxx zzzzzz

where xxxxxx is the octal page number where the failure occurred and zzzzzz is the octal word address within the page. (Don't forget to convert the page number to decimal and KWords to Kbytes to identify the failure location.)

If no VCP is present, any error that occurs during Test 1 or Test 2 must be corrected before the computer can be booted up.

Test 2 Error Codes

| Octal Code | LED Display [†] | Definition |
|--|--------------------------|---|
| 340 2xx | 11100000 10xxxxxx | <p>Main memory failure. The right field indicates the 32 KWord block of memory that is bad.</p> <p>If xxxxxx is zero, the memory controller could be bad.</p> |
| 300 2xx | 11000000 10yyyyyy | <p>I/O interface failure. The right field displays the interface select code or the error code.</p> <p>If yyyyyy is greater than 17B, yyyyyy is the failing select code.</p> <p>If yyyyyy is less than 20B, an interface error is indicated.</p> <p>The values for yyyyyy are listed below.</p> |
| 200 | 10000000 | No I/O cards. |
| 201 | 10000001 | More than one interface has VCP Enabled (switch U1S1 closed). |
| 202 | 10000010 | Priority chain broken or duplicate VCP select code. |
| 203 | 10000011 | Duplicate select code. The duplicate select code is contained in the B-Register. |
| 204 | 10000100 | An I/O card has a select code less than 20B or broken priority chain. |
| 205 | 10000101 | Check the cable and VCP Break Enable (Switch U1S1) or the VCP interface. |
| 206 | 10000110 | Unexpected time base generator interrupt. |
| 207 | 10000111 | Unexpected memory protect interrupt. |
| 210 | 10001000 | Unexpected unimplemented instruction trap (UIT) interrupt. |
| 213 | 10001011 | Speed sense failed on 12040D card. Check ENQ/ACK enabled on terminal. |
| <p>[†] 1 = lit LED; 0 = unlit LED</p> | | |

Self-Test Pass Indicators

| LED Display † | Definition |
|---------------|--|
| 00000111 | VCP program is running. |
| 00000001 | A boot loader is running. |
| 00000000 | User software is running. |
| 10000000 | Loader error. Probably a checksum error; change media on loading device. |
| 00001111 | Running Basic Control Module (BCM) program. |
| 00010000 | Running Diagnostic Design Language (DDL) program. |

† 1 = lit LED; 0 = unlit LED

A900 Self-Test

The self-test consists of two test programs (Test 1 and Test 2) that automatically execute each time the computer is powered up and which provide a quick, convenient check of basic computer operation. (Also, the self-test can be executed by pressing the Reset switch on the sequencer card.) Test 1 tests the processor at the level of individual circuits, and Test 2 tests the processor at a functional level. (For example, Test 1 tests the hardware associated with an LIA instruction to ensure that it works correctly, and Test 2 executes an LIA instruction and checks the result.) If either test program fails, the computer may not operate. Successful completion of the self-test is followed immediately by execution of either a bootstrap loader, the Virtual Control Panel program, or a program sustained in memory by an optional battery card, as preselected by the user.

Test 1. Test 1 is a microprogram stored in PROM on the sequencer card. It executes immediately upon power up and makes checks for all four processor cards, including a check of the microcode PROMs on the sequencer card and the VCP/Test 2 PROMs on the cache control card. On successful completion, Test 2 is started. If Test 1 detects a failure it stops executing and the LEDs on the sequencer card indicate an error code. (Test 1 error codes are listed in the following table.) Test 1 execution time is negligible.

Test 2. Test 2 is part of the VCP program stored in PROM on the cache control card and executes upon successful completion of Test 1. Test 2 can also be initiated by an operator command (%T) from the Virtual Control Panel (VCP). It has a maximum execution time of ten seconds. Test 2 consists of two phases.

The first phase checks the computer's basic instruction set, several internal flags, and Boot RAM. Boot RAM addressing is tested by writing the address of each location into that location and reading it back. Then the complement of each address is written and read back. Finally, zeroes are written and read back. When the entire 1k of Boot RAM is tested successfully, each location of Boot RAM contains zeroes.

The second phase tests main memory, the I/O Master of each interface card, and the computer configuration. The I/O Master of each interface is checked to ensure that data transfer, flag, interrupt, and direct memory access (DMA) functions are processed correctly. If main memory was sustained by the optional battery pack, phase 2 tests main memory in a non-destructive manner by reading each memory location, thus making a parity check on the data. If a parity error does occur, the location is reported to the VCP console (if present). If memory was not sustained, phase 2 writes all ones to each memory location, and reads back the data; and then writes all zeroes and reads back. (Main memory is cleared.)

The LED indication on successful completion of Test 2 depends on the computer action selected by the Start-Up (BOOT SEL) switches on the data path card. If Test 2 detects a failure, it stops executing and the sequencer card LEDs indicate a failure code. If there is a VCP console and the failure does not hinder VCP operation, the VCP program is entered and the failure code is displayed on the VCP console as a PTEST ERROR.

If Test 2 detects a failure during phase 1, it stops execution so that booting of the system does not occur. The processor LEDs indicate the type of failure.

If Test 2 detects a failure during phase 2, VCP can still run if the VCP interface is functioning properly and if a VCP console is installed. The failure will cause the LEDs to flash the error code once. The VCP console then displays PTEST ERROR xxxxxxxx xxxxxxxx. The first word is the main error code and the second word is the subcode (the main error code and the subcode are displayed alternately on the LEDs). The octal number to the left of the LED codes are displayed in the PTEST ERROR fields. The number in the left field specifies the primary category of error: main memory error, I/O interface error, or interrupt error. The number in the right field identifies the specific error. For example, error code 000300 000203 indicates that an I/O error (300) has occurred and that the error was caused by duplicate select codes (203). An error code of 000340 000201 indicates a memory error (340) in the first 32k block of memory. Table 2-2 also shows the LED displays that indicate the self-test passed.

At revision 4020 of VCP, a new parity error message was added. A memory test failure will result in the following message display:

PAR ERR xxxxxx zzzzzz

where *xxxxxx* is the octal page number where the failure occurred and *zzzzzz* is the octal word address within the page. (Don't forget to convert the page number to decimal and KWords to Kbytes to identify the failure location.)

Execute the self-test by turning on the computer power. Troubles detected by the self-test are indicated by the sequencer card LEDs (A900) or processor card LEDs (A990) as listed in the following tables. The last table shows the LED displays that indicate that the self-test passed.

Test 1 Error Codes

| Error* Code | Meaning |
|---|---|
| <p>Note: LEDs 2, 3, 4, and 5 represent the sequencer, data path, cache control, and memory controller cards, respectively. A fully bright LED indicates the card primarily suspected of failure; a half-bright LED indicates the secondary suspect.</p> | |
| 111111111 | Unknown. Self-test did not begin execution. Check sequencer, cache control, memory controller, data path cards. |
| 110000000 | Sequencer card failure. |
| 110h00000 | Sequencer card failure. |
| 1100h0000 | Sequencer card or memory controller card failure. |
| 101000000 | Data path card failure. |
| 1h1000000 | Data path card or sequencer card failure |
| 1010h0000 | Data path card or memory controller card failure. |
| 100100000 | Cache control card failure. |
| 1h0100000 | Cache control card or sequencer card failure. |
| 10h100000 | Cache control card or data path card failure. |
| 100010000 | Memory controller card failure. |
| 1h0010000 | Memory controller card or sequencer card failure. |
| 100h10000 | Memory controller card or cache control card failure. |
| 10001h000 | Memory controller card or first memory array card failure. |
| 100000100 | Failure of floating point chip U0807, U0905, or U1106 on data path card. |

Test 1 Error Codes (Continued)

| Error* Code | Meaning |
|--|--|
| 10h000100 | Failure of floating point chips (see above) or data path. |
| 11000000b | Control store Bank Zero failure. Check PROMs U0801, U0802, U0803, U1101, U1102, and U1103 on sequencer card. |
| 1100000bb | Control store Bank One failure. Check PROMs U0701, U0702, U0703, U1001, U1002, and U1003 on sequencer card. |
| 110000bbb | Control store Bank Two failure. Check PROMs U0601, U0602, U0603, U0901, U0902, and U0903 on sequencer card. |
| The following error codes are not self-test codes but are detected by microcode and displayed on the LEDs. | |
| 100000010 | Fatal microcode error during the execution of software. Not necessarily a hardware failure. |
| 100000001 | Fatal hardware error during execution of software. Cycle the LINE switch; the self-test will execute and identify the failed card. |
| * 1 = lit LED 0 = unlit LED h = half-bright LED b = blinking | |

Test 2 Error Codes

| Octal Code | LED* Display | Definition |
|-------------------|---------------------|---|
| 376 | 011111110 | First instruction fetch of Test 2 failed. Check sequencer, cache control, memory controller, data path cards. |
| 374 | 011111100 | Basic instruction test failed. Check sequencer, data path, cache control, memory controller cards. |
| 370 | 011111000 | Boot memory access failed. Check cache control, memory controller, sequencer, data path cards. |

Test 2 LED Indications (Continued)

| Octal Code | LED Display [†] | Definition |
|---|--------------------------|---|
| 360 | 011110000 | TBG tick or interrupt flags failed. Check memory controller, sequencer, data path, cache control cards. |
| 340 2xx | 011100000 010xxxxxx | Main memory failure. The right field indicates the 32 KWord block of memory that is bad. If xxxxxx is zero, the memory controller card or memory frontplane could be bad. |
| 300 2xx | 011000000 010yyyyyy | I/O interface failure. The right field displays the interface select code or the error code. If yyyyyy is greater than 17B, yyyyyy is the failing select code. If yyyyyy is less than 20B, an interface error is indicated. |
| The values for yyyyyy are listed below. | | |
| 200 | 010000000 | No I/O Cards. |
| 201 | 010000001 | More than one interface has Break Enable. |
| 202 | 010000010 | Priority chain broken, or two terminals set for VCP. |
| 203 | 010000011 | Duplicate select code. The duplicate select code is contained in the B-Register. |
| 204 | 010000100 | An I/O card has a select code less than 20B. |
| 205 | 010000101 | Terminal not connected for VCP. Check the cable, select code, and Break Enable for the VCP interface. |
| 206 | 010000110 | Unexpected time base generator interrupt. |
| 207 | 010001000 | Unexpected memory protect interrupt. |
| 210 | 010001000 | Unexpected unimplemented instruction trap (UIT) interrupt. |
| 213 | 010001011 | Speed sense failed on HP 12040D. Check ENQ/ACK enabled on terminal. |
| [†] 1 = lit LED; 0 = unlit LED | | |

Self-Test Pass Indicators

| LED* Display | Definition |
|-----------------------------|--|
| 00000111 | VCP program is running. |
| 00000001 | A boot loader is running. |
| 00000000 | User software is running. |
| 10000000 | Loader error. Probably a checksum error; change media on loading device. |
| 00001111 | Running Basic Control Module (BCM) Program. |
| 00010000 | Running Diagnostic Design Language (DDL) program. |
| *1 = lit LED; 0 = unlit LED | |

A990 Self-Test

The A990 self-test consists of two test programs (Test 1 and Test 2) that automatically execute each time you turn on the computer. You also can initiate these tests by pressing Reset Switch SW1 on the A990 CPU card. Test 1 (microcoded self-test) tests the processor at the circuit level. Test 2 (VCP pretest) tests the processor at the functional level.

Successful completion of the tests is followed by execution of either a bootstrap loader, the Virtual Control Panel (VCP) program, or a program sustained in memory by optional battery backup. (Refer to the *A990 Computer Reference Manual*, part number 02959-90001, for information on bootstrap loaders and the VCP.) Which of these occurs depends on how the BOOT SELECT switches are configured.

Test 1. Test 1 is stored as a microprogram in the firmware EPROM on the A990 CPU card. It executes immediately on power-up and checks all of the hardware on the card. On successful completion of Test 1, Test 2 is started. If Test 1 detects a failure, it stops executing and the LEDs on the CPU card display an error code.

The bank of four LEDs on the bottom of the CPU card displays a code that indicates which field replaceable unit failed. When Test 1 is finished, all four LEDs are extinguished. The bank of eight LEDs on the top of the CPU card is not used by Test 1 to indicate defective field replaceable units. Any pattern that is displayed on the bank of eight LEDs during Test 1 should be ignored.

Test 1 Error Codes

| Error Code * | | Meaning |
|----------------|----------------|--|
| Bank of 4 LEDs | Bank of 8 LEDs | |
| 1111 | 11111111 | Initial power-on condition. All LEDs are turned on when PON signal is low. Incorrect indication may be caused by microcode load or execution problem, an A990 board failure, EPROM failure, or power system failure. |
| 0001 | XXXXXXXX | Failure caused by bad EPROM or bad A990 board. |
| 0010 | XXXXXXXX | Base set fatal error (also known as machine check error) has occurred after VCP was started. See LED indications next page for fatal base set error codes. |
| 0011 | XXXXXXXX | Failure caused by bad jumper board. |
| 0100 | XXXXXXXX | Failure caused by bad memory frontplane connector. |
| 0101 | XXXXXXXX | Failure caused by bad memory array card. |
| 0110 | XXXXXXXX | Failure caused by bad time-of-day clock chip or bad A990 board. |
| 0111 | XXXXXXXX | Failure caused by bad A990 board (possibly caused by a bad processor ASIC chip). |
| 1000 | XXXXXXXX | Failure caused by bad A990 board (possibly caused by a bad cache ASIC chip). |
| 1001 | XXXXXXXX | Failure caused by bad A990 board. |
| 1010 | XXXXXXXX | Failure caused by bad A990 board. |
| 1011 | XXXXXXXX | Failure caused by bad A990 board. |
| 1100 | XXXXXXXX | Failure caused by bad A990 board. |
| 1101 | XXXXXXXX | Failure caused by bad A990 board. |
| 1110 | XXXXXXXX | Failure caused by bad A990 board. |
| 1111 | 0000XXXX | Failure caused by bad EPROM or A990 board (board failure possibly caused by a bad processor ASIC chip). |

* 1 = lit LED; 0 = unlit LED; X = don't care

Test 1 Error Codes (Continued)

| Error Code * | | Meaning |
|--|-------------------|---|
| Bank of 4 LEDs | Bank of 8 LEDs | |
| The following LED indications are caused by fatal base set errors after the VCP program has started: | | |
| 0010 | 00000001 | Control store parity error. May have been caused by bad hardware. |
| | 00000010 | Microcode stack overflow or underflow. May have been caused by an error in the base set microcode. |
| | 00000100 | Zap counter interrupt. May have been caused by an error in the base set microcode. |
| | 00001000 | Two consecutive micro-interrupts. May have been caused by bad hardware. |
| | 00010000 | A micro-interrupt occurred, but the micro-interrupt register didn't have a known error pattern. May have been caused by bad hardware. |
| * 1 = lit LED; 0 = unlit LED | | |

Test 2. Test 2 is part of the VCP program also stored in the firmware EPROM on the A990 CPU card. It begins execution upon successful completion of Test 1. Test 2 can also be initiated by an operator command (%T) from VCP. Test 2 executes in two phases, and may take as long as 20 seconds to run, depending on the amount of memory installed.

The first phase of Test 2 checks the computer's basic instruction set, several internal flags, and the Boot RAM. When the entire Boot RAM has been successfully tested, each location of Boot RAM contains zeros.

The second phase of Test 2 tests main memory, the I/O Master of each interface card, and the computer configuration. The I/O Master of each interface card is checked to ensure that data transfer, flag, interrupt, and Direct Memory Access (DMA) functions are correctly processed. If battery backup sustained main memory, phase two of Test 2 tests main memory in a non-destructive manner. If main memory is not sustained by battery backup, a destructive memory test is performed and main memory is effectively cleared (memory contains all zeros). On successful completion of Test 2, the LEDs will be lit with a specific pattern. This pattern depends on the startup configuration as selected by the BOOT SELECT switches (SW2).

If Test 2 detects a failure, the error code is displayed on the upper 8 LEDs (the lower 4 LEDs are all off). If a failure is detected during *phase one* of Test 2, test execution stops and the LEDs indicate the type of failure by displaying a 1-byte static error code (see table next page). If a failure is detected during *phase two* of Test 2, the VCP can still run if the VCP interface is functioning properly and a VCP console is installed. The failure causes the LEDs to flash the error code (in binary format) as well as display the error code in octal format in the message “Pretest Error xxx.xxx.xxx.xxx” on the VCP console.

Each error message for *phase two* of Test 2 consists of four bytes of information. The information is displayed on the LEDs using the scheme described in the figure on the next page. The first byte of the error code is the main error code (memory error, I/O interface error, or interrupt error) and the second byte is the subcode. Some of the error codes give additional information in bytes 3 and 4. For example, error code 300 203 000 022 indicates that an I/O error (300) has occurred and that the error was caused by duplicate select codes (203) and the duplicate select code was 22 (000 022). An error code of 340 201 000 000 indicates a memory error (340 201) in the first 32k block of memory (000 000).

Self-Test Pass Indications





| Octal Code | LED Display | Definition |
|--|-------------|--|
| 007±005 | 000001 *1 | VCP program is running; VCP console connected and waiting for user input. |
| 002±000 | 000000 *0 | VCP program is running; VCP console is not connected, that is, VCP is waiting for the VCP console to respond to the first ENQ-ACK handshake. |
| 001 | 00000001 | A boot loader is running. |
| 000 | 00000000 | User software is running. |
| 200 | 10000000 | Loader error. Probably a checksum error; change media on loading device. |
| 020 | 00010000 | Running Diagnostic Design Language (DDL) Program. |
| 1 = lit LED; 0 = unlit LED; * = flashing LED | | |

Test 2 (phase 1) Error Codes

| Error Code * | | Meaning |
|--|--|--|
| Bank of 4 LEDs | Bank of 8 LEDs | |
| 0000 | 11111110 11111100 11111000 11110000 | Microcoded self-test (Test 1) passed but first memory fetch failed. Bad A990 board. Basic instruction test failed. Bad A990 board. Boot memory access failed. Bad EPROM or A990 board. TBG test failed. Bad A990 board. |
| * 1 = lit LED; 0 = unlit LED; X = don't care | | |

Sample Display of Test 2 (phase 2) Error Code

Revision 4022 and later of VCP uses the following scheme to display the four-byte long error code on the 8 LEDs. Preceding each byte of information a "travelling" LED pattern is displayed to indicate which byte of information is going to be displayed. For example, the following LED sequence is displayed for the error code 302 201 023 021. See NO TAG for a definition of all the error codes.

| Octal Code | LED Display |
|------------|--|
| 302 |  One travelling LED is displayed, then First byte of error message is displayed |
| 201 |  Two travelling LEDs are displayed, then Second byte of error message is displayed |
| 023 |  Three travelling LEDs are displayed, then Third byte of error message is displayed |
| 021 |  Four travelling LEDs are displayed, then Fourth byte of error message is displayed |

Test 2 (phase 2) Error Codes

| Octal Code * | Definition |
|--|--|
| Byte | |
| 1 2 3 4 | |
| 360 360 xxx xxx | TBG test failed. 3rd and 4th bytes (xxx xxx) indicate address in VCP where error was detected. |
| 340 ----- -- - | When LEDs are in this static pattern, memory test is running; this is not an error condition. |
| 340 200 000 000 | No memory found or missing frontplane connector. |
| 340 2nn xxx xxx | Main memory failed. nn = 01b to 12b depending on where in VCP code the error was detected. 3rd and 4th bytes indicate 32-KB blk of failed memory. |
| 341 000 377 377 | ECC memory detected in A400/A600; ECC memory is not supported in an A400/A600. (This error should never occur on an A990.) |
| 300 200 000 000 | No I/O cards in the card cage. |
| 300 201 0yy 0xx | More than one card has VCP enabled; yy and xx are the select codes of the enabled cards. |
| 300 202 0yy 0xx | Broken I/O chain; yy is the number of I/O cards found by polling; xx is the number found by priority scan; the break will usually be found at slot xx+1. |
| 300 203 000 0xx | Duplicate select codes; more than one card has the select code xx. |
| 300 204 000 0xx | An I/O card at select code xx has a select code of less than 20b. |
| 300 205 000 000 | No I/O card has been enabled as VCP interface. |
| 300 206 000 000 | Unexpected TBG interrupt. |
| 300 207 000 000 | Unexpected Memory Protect interrupt. |
| 300 210 000 000 | Unexpected UIT interrupt. |
| 300 211 000 000 | Invalid ID number or select code for A400 OBIO. (This error should never occur on an A990.) |
| 300 213 000 000 | VCP Speed Sense failed. |
| 300 220 xxx xxx . . | } I/O card at sc 20 thru 77 failed self-test. xxx xxx is the address in VCP where error was detected. |
| 300 277 xxx xxx | |
| * Error codes for phase 2 of Test 2 are displayed on upper 8 LEDs as 4 bytes of information using scheme illustrated in previous figure. | |

NOTE

If any HP 1000 fails the self-test only when it is cabled to an A-Series I/O extender, make sure that the extender is powered on, and verify that the A900 Cache card has part number 12203-60011 or higher, and U803 on the Sequencer card has part number 12201-80084 or higher.

A400/A600+/A700* Memory Array Cards

The green LED on the A-Series memory arrays (HP 12103A*/B*/C/D and K/L/M) will be extinguished when a parity error occurs on the board. The A400 board (HP 12100A), the A600+ memory controller (HP 12102A*/B), A600+ ECC memory controller (HP 12110A/B), and the A600+/A700 ECC memory arrays (HP 12111A*/B*/C*) also contain a parity LED.


A parity error indication (LED off) can be cleared by cycling the power switch, by pressing the Reset switch on the processor card or frontplane, or by entering the %T or %P command from VCP. Frequently recurring parity errors can be eliminated by replacing the memory card with the extinguished LED.

* Discontinued product; shown for reference only.

A600+/A700* Error Correcting Memory Card

The following LEDs are present on the HP 12104A* memory array and the HP 12110A*/B* A600+ memory controller. The green LED will be extinguished when a double bit error occurs on the array (double bit errors are not corrected). The red LEDs indicate the location of the last single-bit error on the array (single bit errors are corrected).

ECC LED Display



| Error Syndrome Code | Bit in Error | Error Syndrome Code | Bit in Error | Error Syndrome Code | Bit in Error |
|---------------------|--------------|---------------------|--------------|---------------------|--------------|
| 64 | DB 0 | 34 | DB 8 | 76 | CB 0 |
| 62 | DB 1 | 32 | DB 9 | 75 | CB 1 |
| 61 | DB 2 | 26 | DB 10 | 73 | CB 2 |
| 54 | DB 3 | 25 | DB 11 | 67 | CB 3 |
| 52 | DB 4 | 23 | DB 12 | 57 | CB 4 |
| 51 | DB 5 | 16 | DB 13 | 37 | CB 5 |
| 45 | DB 6 | 15 | DB 14 | 00 | no error |
| 43 | DB 7 | 13 | DB 15 | | |

where: DB is a Data Bit
CB is a Check Bit

A700* WCS Card

The green LED on the HP 12153A Writable Control Store card is lit when the WCS card is ON, which means the card has been enabled for control store operation through the system software.

* Discontinued product; shown for reference only.

A900/A990 Memory Array Card

The green LED is extinguished on HP 12220A*, 12221A, and 12221B memory array cards when a multibit, uncorrectable error has occurred. Multiple bit errors cause the computer to execute a jump to memory location 05.

A900 CS Card

The LED labeled RAM on the HP 12205A Control Store card is lit when the WCS bank is enabled; the LED labeled PROM is lit when the PCS bank is enabled.

I/O Extender IOC Card (12025-66001)

The red LED is lit under the following conditions:

- a. DC power in the CPU box is not within regulation.
- b. DC power in the extender is not within regulation.
- c. Processor is being manually reset.
- d. Extender is powered down.
- e. IOC to EXT cabling is damaged or is not connected.

The green LED is lit only when both the IOC and EXT are properly powered up and the interconnecting cable is properly connected.

I/O Extender EXT Card (12025-60002)

The red LED is lit under the following conditions:

- a. DC power in the CPU box is not within regulation.
- b. DC power in the extender is not within regulation.
- c. Processor is being manually reset.
- d. IOC to EXT cabling is damaged or is not connected.
- e. Processor is powered down.

The green LED is lit whenever the red LED is off. This indicates that the extender box is in an operating state.

* Discontinued product; shown for reference only.

PSI Cards

If a self-test failure is detected by the firmware, the indication on the LEDs is as follows:

| Condition | LEDs | Notes |
|-----------------|-----------------------|---|
| PRESET | all on | all on as long as PRESET is true |
| self-test | 0 = off 1,2,3 = on | true during the self-test for about 3.5 seconds. Anything else = error. |
| end self-test | all on | all on for 10ms |
| protocol start | varies | for HDLC, all off for BISYNC, 0,1,2 = on = on/off depending on internal switch for int/ext clock for X.25, all off for Multipoint A-Series, all off for MRJE and other download firmware, all on |
| protocol active | varies | for HDLC, LED 0 = on, logical connect has occurred; LED 1 = on, DMA transfer is active; LED 2 and 3 = off always. for BISYNC, no change from above. for X.25, LEDs 0 and 1 are the same as HDLC; LED 2 = on, msg frame timeout recovery is active; LED 3 toggles with each msg frame received. for Multipoint A-Series, LEDs 0 and 1 are the same as HDLC. for MRJE and other download firmware, the downloaded firmware will control the LEDs. |

HP 12021A* Model 5 and 6 Internal Disk Controller LED Indications

0 = LED off
 1 = LED on
 f = LED flashing
 ? = LED may be in any of the above states

Self-Test Initialization

| Green LED | T | I | Red LEDs | | | | | | Symptoms |
|-----------|---|---|----------|---|---|---|---|---|---|
| LED | T | I | A | B | C | D | E | F | |
| 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | No +5V or GND |
| ? | ? | ? | 1 | 1 | 1 | 1 | 1 | 1 | A problem with the EPROMs A problem with the Z80A chip (U22) No 4 MHz clock signal No reset pulse at U15 |

EPROM Errors

| Green LED | T | I | Red LEDs | | | | | | Symptoms |
|-----------|---|---|----------|---|---|---|---|---|-------------------------------|
| LED | T | I | A | B | C | D | E | F | |
| 0 | 0 | 0 | 0 | 0 | 0 | 0 | 1 | 0 | U73 ROM 1 HP-IB communication |
| 0 | 0 | 0 | 0 | 0 | 0 | 0 | 1 | 1 | U63 ROM 2 HP-IB communication |
| 0 | 0 | 0 | 0 | 0 | 0 | 1 | 0 | 0 | U43 ROM 3 Self-test |
| 0 | 0 | 0 | 0 | 0 | 0 | 1 | 0 | 1 | U93 RAM chip, lower bytes |
| 0 | 0 | 0 | 0 | 0 | 0 | 1 | 1 | 0 | U83 RAM chip, upper bytes |
| 0 | 0 | 0 | 0 | 0 | 0 | 1 | 1 | 1 | U12 GPIB chip |

* Discontinued product; shown for reference only.

Non-Fatal Errors

| Green LED | | | Red LEDs | | | | | | Symptoms |
|-----------|---|---|----------|---|---|---|---|---|---------------------------|
| | T | I | A | B | C | D | E | F | |
| 0 | 0 | 0 | 0 | 0 | 1 | 0 | 0 | 0 | LED register test |
| 0 | 0 | 0 | 0 | 0 | 1 | 0 | 0 | 1 | LED register test |
| 0 | 0 | 0 | 0 | 0 | 1 | 0 | 1 | 0 | Select register test |
| 0 | 0 | 0 | 0 | 0 | 1 | 0 | 1 | 1 | Select register test |
| 0 | 0 | 0 | 0 | 0 | 1 | 1 | 0 | 0 | Controller register test |
| 0 | 0 | 0 | 0 | 0 | 1 | 1 | 0 | 1 | Controller chip test |
| 0 | 0 | 0 | 0 | 0 | 1 | 1 | 1 | 0 | Controller register test |
| 0 | 0 | 0 | 0 | 0 | 1 | 1 | 1 | 1 | Controller chip test |
| 0 | 0 | 0 | 0 | 1 | 0 | 0 | 0 | 0 | Index pulse test |
| 0 | 0 | 0 | 0 | 1 | 0 | 0 | 0 | 1 | Spin one-shot test |
| 0 | 0 | 0 | 0 | 1 | 0 | 0 | 1 | 0 | Index pulse test |
| 0 | 0 | 0 | 0 | 1 | 0 | 0 | 1 | 1 | Spin one-shot test |
| 0 | 0 | 0 | 0 | 1 | 0 | 1 | 0 | 0 | Controller chip direction |
| 0 | 0 | 0 | 0 | 1 | 0 | 1 | 0 | 1 | Controller chip direction |

Drive Power Up Errors

| Green LED | | | Red LEDs | | | | | | Drive | Symptoms |
|-----------|---|---|----------|---|---|---|---|---|-------|-----------------------------|
| | T | I | A | B | C | D | E | F | | |
| 0 | ? | ? | 0 | 1 | 0 | 1 | 1 | 0 | 3 | Track 0 not set, spin set |
| 0 | 1 | f | 0 | 1 | 0 | 1 | 1 | 1 | 3 | Disc spins too slow |
| 0 | 1 | f | 0 | 1 | 1 | 0 | 0 | 0 | 3 | Disc spins too fast |
| 0 | 1 | ? | 0 | 1 | 1 | 0 | 0 | 1 | 3 | Track 0 on after step in |
| 0 | 1 | ? | 0 | 1 | 1 | 0 | 1 | 0 | 3 | Disc pulled out during test |
| 0 | ? | ? | 0 | 1 | 1 | 0 | 1 | 1 | 2 | Track 0 not set, spin set |
| 0 | 1 | f | 0 | 1 | 1 | 1 | 0 | 0 | 2 | Disc spins too slow |
| 0 | 1 | f | 0 | 1 | 1 | 1 | 0 | 1 | 2 | Disc spins too fast |
| 0 | 1 | ? | 0 | 1 | 1 | 1 | 1 | 0 | 2 | Track 0 on after step in |
| 0 | 1 | ? | 0 | 1 | 1 | 1 | 1 | 1 | 2 | Disc pulled out during test |
| 0 | ? | ? | 1 | 0 | 0 | 0 | 0 | 0 | 1 | Track 0 not set, spin set |
| 0 | 1 | f | 1 | 0 | 0 | 0 | 0 | 1 | 1 | Disc spins too slow |
| 0 | 1 | f | 1 | 0 | 0 | 0 | 1 | 0 | 1 | Disc spins too fast |
| 0 | 1 | ? | 1 | 0 | 0 | 0 | 1 | 1 | 1 | Track 0 on after step in |
| 0 | 1 | ? | 1 | 0 | 0 | 1 | 0 | 0 | 1 | Disc pulled out during test |
| 0 | ? | ? | 1 | 0 | 0 | 1 | 0 | 1 | 0 | Track 0 not set, spin set |
| 0 | 1 | f | 1 | 0 | 0 | 1 | 1 | 0 | 0 | Disc spins too slow |
| 0 | 1 | f | 1 | 0 | 0 | 1 | 1 | 1 | 0 | Disc spins too fast |
| 0 | 1 | ? | 1 | 0 | 1 | 0 | 0 | 0 | 0 | Track 0 on after step in |
| 0 | 1 | ? | 1 | 0 | 1 | 0 | 0 | 1 | 0 | Disc pulled out during test |
| 0 | ? | ? | 1 | 0 | 1 | 0 | 1 | 0 | ALL | No drives attached |

Read Self-Test Errors

| Green LED | | | Red LEDs | | | | | | Symptoms |
|-----------|---|---|----------|---|---|---|---|---|--------------------------------------|
| | T | I | A | B | C | D | E | F | |
| 0 | ? | ? | 1 | 0 | 1 | 0 | 1 | 1 | No disc/no index pulse/door open |
| 0 | 0 | f | 1 | 0 | 1 | 1 | 0 | 0 | Track 0 not set |
| 0 | ? | f | 1 | 0 | 1 | 1 | 0 | 1 | Retry exhausted on seek to track |
| 0 | ? | f | 1 | 0 | 1 | 1 | 1 | 0 | Read sector failed, record not found |
| 0 | ? | f | 1 | 0 | 1 | 1 | 1 | 1 | Read failed, data error |
| 0 | ? | f | 1 | 1 | 0 | 0 | 0 | 0 | Read failed, lost data byte |
| 0 | ? | f | 1 | 1 | 0 | 0 | 0 | 1 | No drives attached |

Read/Write Self-Test Errors

| Green LED | | | Red LEDs | | | | | | Symptoms |
|-----------|---|---|----------|---|---|---|---|---|----------------------------------|
| | T | I | A | B | C | D | E | F | |
| 0 | 1 | f | 1 | 1 | 0 | 0 | 1 | 0 | Disc is write protected |
| 0 | ? | ? | 1 | 1 | 0 | 0 | 1 | 1 | No disc/not spinning/door open |
| 0 | 0 | f | 1 | 1 | 0 | 1 | 0 | 0 | Track 0 not set |
| 0 | ? | f | 1 | 1 | 0 | 1 | 0 | 1 | Retry exhausted on seek to track |
| 0 | ? | f | 1 | 1 | 0 | 1 | 1 | 0 | Lost data during format |
| 0 | ? | f | 1 | 1 | 0 | 1 | 1 | 1 | Lost data during read operation |
| 0 | ? | f | 1 | 1 | 1 | 0 | 0 | 0 | Record not found after read |
| 0 | ? | f | 1 | 1 | 1 | 0 | 0 | 1 | CRC data error after read |
| 0 | ? | f | 1 | 1 | 1 | 0 | 1 | 0 | Buffer miscompare after read |

After Self-Test

(Operation controlled by host computer)

| | | | | | | | | | |
|---|--|--|---|---|---|---|---|---|------------------|
| 1 | | | 0 | 0 | 0 | 0 | 0 | 1 | Self-Test Passed |
| 1 | | | 0 | 0 | 0 | 0 | 1 | 0 | Seek |
| 1 | | | 0 | 0 | 0 | 1 | 1 | 0 | Read |
| 1 | | | 0 | 0 | 0 | 1 | 1 | 1 | Write |
| 1 | | | 0 | 0 | 1 | 0 | 0 | 0 | Request status |
| 1 | | | 0 | 0 | 1 | 0 | 0 | 1 | Request address |
| 1 | | | 0 | 0 | 1 | 0 | 1 | 0 | Format |
| 1 | | | 1 | 1 | 0 | 0 | 0 | 0 | Verify |

HP 12076A LAN/1000 Interface Controller Card LED Display

The green LED is on when power is available to the Medium Attachment Unit (MAU) or the transceiver. If the green LED is off, check the on-board fuse for a possible blown fuse. If the fuse is blown, check the node cabling and/or the MAU for a short circuit. (Note that pin 13 on the 15-pin D connector or pin L on the 48-pin hood connector is the +12 V line.) If an electrical short is isolated to the LANIC card, the card must be replaced.

Upon power-up the red LED should light indicating the self-test is in progress, and after approximately 5 seconds, turn off. If the red LED never turns on after power is applied, or if the light turns on and stays on continuously, then self-test failed indicating a faulty card.

HP 12016A SCSI Card Tests

Self-Test

When you turn computer power on, reset the computer, or execute the %P or %T commands from the VCP prompt, the SCSI (Small Computer System Interface) microprocessor executes a self-test on:

1. The firmware in PROM.
2. The SCSI card's on-board memory.
3. The ability of the SCSI protocol interface chip to communicate with the SCSI card microprocessor.

The self-test does *not* test the SCSI card-to-device cable or the ability of the card to communicate with the computer. (The computer processor's self-test checks for backplane communication between the SCSI card and computer.)

Four LEDs, located on the SCSI card, display card status and report errors (if any) that result from the self-test. The following table shows the possible self-test LED patterns and their definitions. A frozen LED pattern (pattern does not change and some LEDs are in a steady "on" condition) denotes a self-test failure. When the card passes the self-test, all of the LEDs briefly turn off and then LED #1 begins to blink. This indicates a normally functioning SCSI card.

SCSI LED Self-Test Status

| LED #1 | LED #2 | LED #3 | LED #4 | STATUS |
|--------|--------|--------|--------|--------------------------|
| OFF | ON | ON | ON | Card PROM checksum error |
| OFF | ON | ON | OFF | RAM test failed |
| OFF | ON | OFF | ON | Reserved |
| OFF | ON | OFF | OFF | DMA test failed |
| OFF | OFF | ON | ON | Timer test failed |
| OFF | OFF | ON | OFF | SCSI chip test failed |
| OFF | OFF | OFF | ON | Reserved |
| OFF | OFF | OFF | OFF | Passed test † |
| BLINK | OFF | OFF | OFF | Normal operation ‡ |

† The all-LEDs-off condition only exists briefly; LED #1 reverts to continuous blinking which indicates a normal functioning SCSI card.

‡ The rate at which LED #1 blinks indicates the activity of the card; a rate as low as several seconds between blinks is normal.

Verification Program

The SCSI online verification program, VSCSI, is an RTE-A application program which verifies that the SCSI card is functioning correctly. VSCSI provides two user interfaces, interactive and non-interactive.

You can get help on the verification program, at the CI prompt, without specifying any other parameters, simply by entering:

```
CI> vscsi
```

Interactive Interface

An interactive interface permits you to enter commands that run specific verification tests, one at a time. You can also specify the number of times to run each test. The test results are displayed on the screen after you run each test. After a test runs, the command prompt, vscsi, reappears on the screen and you can run another test or exit from the program. To call the interactive verification program, enter the following run string at the CI prompt:

```
CI> vscsi [scsilu] [nontest param1 [nontest param2 [...]]]
```

where:

`vscsi`: calls the verification program.

`scsilu`: is the Logical Unit (LU) number of (one of) the SCSI device(s) associated with the SCSI card you are testing. This parameter is optional. That is, you can still invoke the verification program, in the interactive mode, without specifying an LU number if you specify one or more of the following nontest parameters. If you specify one or more test commands (listed on the next page), you will invoke the non-interactive mode as described in the next subsection of this chapter.

`nontest param`: is one of the following four optional parameters:

- `-HP` Indicates a non-HP terminal.
- `-V` Specifies verbose mode.
- `-I` Ignores errors and continues test.
- `-L <logfile>` Produces log file to record test results.

After entering one or more of the optional nontest parameters, the command prompt, `vscsi`, will appear on the screen. You can now execute any of the following commands:

- | | |
|-------------------------------------|---|
| <code>? or ?? or HELP</code> | Any of these three commands displays a list of all valid commands with brief descriptions of each. |
| <code>LU [scsilu]</code> | Defines the card to be tested where <code>scsi</code> is defined above. |
| <code>FORMAT</code> | Formats the disk associated with the current SCSI LU. |
| <code>DISPLAY or DI</code> | Displays a list of the LUs associated with the SCSI card including the address, the device's vendor and model, and current status of the LUs. |
| <code>UP <lu></code> | Notifies the system that an LU is available. <code><lu></code> is any valid SCSI LU number. |
| <code>VERBOSE or VE [on/off]</code> | Turns verbose mode on or off. [on/off] |

LOOP [n] or REPEAT [n] Defines how many times to execute the following eight *test* commands.

| | | |
|---------------|---------------------|---|
| Test Commands | SELFTEST or SE | Issues a hard reset command to the SCSI card to force it to execute the SCSI self-test. |
| | FMP | Issues FMP calls to the SCSI LU to check the overall functioning of the card, disk, and cables. |
| | ID or REVCODE | Displays the ID and revision code of the SCSI card. |
| | DEVFLAG or DE | Checks device flag operation. |
| | TERMPWR or TE | Displays the status of the TERMPOWER status bit. |
| | TIMESTAMP and or TS | Displays the SCSI card's firmware timestamp address. |
| | RAMTEST or RAM | Tests SCSI card RAM. |
| | LOOPBACK | Loops the test data back from the output of the SCSI card to the input. |

EXIT or QUIT Exits the interactive verification program.
or ABORT

For a detailed description of the interactive test parameters, commands, and error/information messages, refer to the *HP 12016A SCSI Host Bus Adapter Card Installation and Reference Manual*, part no. 12016-90001.

Non-Interactive Interface

A non-interactive interface allows you to specify both the tests you want to execute and the number of times to execute the tests in the VSCSI run string. You can run all tests or just selected tests. As VSCSI runs, the tests results appear on screen and the programs terminates back to the CI prompt. Unless you tell the program to ignore errors, it will terminate on the first failure leaving an error message on the screen. (For a detailed explanation of error messages, refer to the *HP 12016A SCSI Host Bus Adapter Card Installation and Reference Manual*, part no. 12016-90001.)

You can invoke the non-interactive verification program from a CI command file or enter the following run string at the CI prompt:

```
CI> vscsi <scsilu> [param1 [param2 [...]]]
```

where:

vscsi: calls the verification program.

scsilu: is the Logical Unit (LU) number of (one of) the SCSI device(s) associated with the SCSI card you are testing.

param: is one of the following optional parameters or test commands. (Omitting all test commands from the run string invokes the interactive mode as described in the above subsection of this chapter.)

- HP Indicates non-HP terminal.
- V Specifies verbose mode.
- I Ignores errors and continues test.
- L <logfile> Produces log file to record test results.
- LOOP [n] Defines how many times to execute any of the following 10 parameters.

For a detailed description of the non-interactive test parameters, commands, and error/information messages, refer to the *HP 12016A SCSI Host Bus Adapter Card Installation and Reference Manual*, part no. 12016-90001.

VCP Loader Errors

The following are the error codes in response to errors in the loader commands %B and %L.

- LDER ERR 0 Unrecognizable load/bootstring.
- LDER ERR 2 Select code less than 20B.
- LDER ERR 3 No card with that select code.
- LDER ERR 4 Product ID not found in EPROM (A990 only).

Cartridge Tape Loader Errors

Test Commands

- SELFTEST Issues a hard reset command to the SCSI card to force it to execute the SCSI self-test.
or -SE
- FMP Issues FMP calls to the SCSI LU to check the overall functioning of the card, disk, and cables.
- ID Displays the ID and revision code of the card.
- DEVFLAG Checks device flag operation.
or -DE
- TERMPWR Displays the status of the TERMPOWER status bit.
or -TE
- TIMESTAMP Displays the SCSI card's firmware timestamp and address.
or -TS
- RAMTEST Tests SCSI card RAM.
or -RAM
- LOOPBACK Loops the test data back from the output of the SCSI card to the input.
- DISPLAY Displays a list of LUs associated with the SCSI card.
or -DI
- ALL Runs all of the verification program tests except the self-test and loopback test.

- LDER ERR 110 File Forward Error; status in B-Register.
- LDER ERR 111 Checksum Error.
- LDER ERR 112 No data before EOF.
- LDER ERR 113 Bad length word.
- LDER ERR 120 Write Error; status in B-Register.

PROM Card Loader Errors

- LDER ERR 211 End of Program.
- LDER ERR 212 Bad Format.
- LDER ERR 213 System larger than 32k; must start on card boundary .
- LDER ERR 214 Write not allowed to ROM.
- LDER ERR 215 Timeout reading data.

DS/1000 Loader Errors

(TO = Timeout)

- LDER ERR 310 TO after CLC 0; is SC a DS Card?
- LDER ERR 311 Checksum Error; is P file absolute binary?
- LDER ERR 312 TO after download request.
- LDER ERR 313 TO after file number.
- LDER ERR 314 Bad Transfer (cntrl request); status in B-Register.
- LDER ERR 315 TO after buffer request.
- LDER ERR 316 TO after count echo.
- LDER ERR 317 TO waiting for data.
- LDER ERR 320 TO after VCP mode request DS write.
- LDER ERR 321 Remote node will not accept data; status in B-Register.
- LDER ERR 325 Record out of sequence. (Ensure central file is a memory image file.)

Disk Loader Errors

(TO = Timeout)

- LDER ERR 411 TO reading disc type or error in initialization process; check HP-IB adrs, card, cable; or, for SCSI check condition after inquiry command.
- LDER ERR 412 TO reading status; is device a disc?
- LDER ERR 413 Status error; status in B-Register.
- LDER ERR 414 TO during file mask.
- LDER ERR 415 TO during seek.
- LDER ERR 416 TO during read/write command.
- LDER ERR 417 TO during DMA of data.
- LDER ERR 418 Parity error during DMA transfer.
- LDER ERR 420 Parity error during DMA transfer.
- LDER ERR 421 TO during FIFO flush.
- LDER ERR 422 TO during DSJ command.
- LDER ERR 423 Bad DSJ return; returned value in B-Register.
- LDER ERR 460 Disc not identifiable; disc ID in B-Register.

Magnetic Tape Loader Errors

(TO = Timeout)

- LDER ERR 510 TO during initialization/read ID. For DAT tape, check condition after inquiry command.
- LDER ERR 511 TO when issuing end/select unit.
- LDER ERR 512 Mag tape off-line.
- LDER ERR 513 No write ring. For DAT tape, check condition after read/write, parity error/TO during DMA transfer.
- LDER ERR 514 TO during End command.
- LDER ERR 515 TO waiting for rewind completion.
- LDER ERR 517 TO waiting for DMA transfer.
- LDER ERR 520 Parity error during DMA transfer.
- LDER ERR 521 TO doing a PHI flush.
- LDER ERR 522 TO waiting for DSJ.[†]
- LDER ERR 523 Bad DSJ response.[†]
- LDER ERR 525 TO waiting for Mag Tape Not Busy.
- LDER ERR 530 TO after issuing a command.
- LDER ERR 531 Parallel Poll time-out after issuing a command.
- LDER ERR 535 Bad status after read/write command.
- LDER ERR 550 No data transfer (read only).
- LDER ERR 560 Not mag tape ID. For DAT tape, check condition after rewind command.

[†] DSJ = Device Specified Jump

HP 12022A Disk Interface Loader Error

(TO = Timeout)

- LDER ERR 610 TO after Sector Drive Head (SDH) for read/write.
- LDER ERR 611 TO after cylinder high.
- LDER ERR 612 TO after cylinder low.
- LDER ERR 613 TO after sector.
- LDER ERR 614 TO after sector count.
- LDER ERR 615 TO after read/write command.
- LDER ERR 616 TO after DMA read/write transfer.
- LDER ERR 617 Parity error during transfer.
- LDER ERR 620 Fixed disc not ready.
- LDER ERR 630 TO after request status register.
- LDER ERR 631 TO after read status register.
- LDER ERR 632 TO after waiting for not busy.
- LDER ERR 633 TO after request error register.
- LDER ERR 634 TO after read error register.
- LDER ERR 635 Status error: A-Register = status register [‡]
B-Register = error register [‡]
- LDER ERR 650 TO after SDH register for restore.
- LDER ERR 651 TO after restore.
- LDER ERR 660 Disc not defined.

[‡] Refer to the HP 12022A Disk Interface/Controller Diagnostic in chapter 5 for descriptions of the status register and error register.

Other

LDER ERR 1024/1025

Possible meanings:

1. Booting from CS/80 disc that has just been push button restored from a CTD tape or booting diagnostics directly from the tape. The CTD tape may not have been certified/formatted before data was stored to it.
2. Booting from a CTD tape in ASAVE format.
3. Booting from the CS/80 disc was not successful. Bootex may be corrupted.
4. Faulty tape control board in the CS/80 disc.
5. Incorrect VCP file number in the runstring.

The B-Register will give the following status:

- 0 = Ready for data; normal mode. Should not get 0 with this loader error.
- 1 = Status word should be read from drive. Indicates an error, or a new media could have been inserted.
- 2 = Power up has occurred; no activity in the disc has occurred yet.
- 3 = Parity error on command.

Halt Error Codes

When a halt is executed, the VCP is invoked. It displays the message:

Pxxxxx Axxxxx Bxxxxx Mxxxxx T1020zz

where:

P, A, B, M, T are registers.

xxxxxx are the contents of the registers.

zz is the halt number, meaning:

- 00 The generated system has not been initialized by the BOOTEX program. Also displays the following message:

INITIALIZE SYSTEM BY RUNNING BOOTEX/
BUILD

- 01 The system has not been initialized by the BOOTEX program. Can't mount disk; can't open boot command file; illegal use of shared partition for SHEMA. BOOTEX will usually try to print an error message prior to HLT 1.
- 02 A privileged routine has executed location 2. This can occur if data is executed or a link is set to 0. Problem with snap or system file (can't open, read/write error).
- 03 A group II or III error has occurred when no program was executing. The A register will usually indicate either a 046520 (memory protect) or 052511 (unimplemented instruction) error. This can be determined by converting the A register into two ASCII characters as follows:

046520 = MP = Memory Protect
052511 = UI = Unimplemented Instruction

Note: Older revision A900 memory controllers and almost any intermittent problem on the A900 can cause this symptom. In the A600, the processor is most likely to be the problem.

- 04 A CPU power failure has occurred and the power fail driver was not included in the system.
- 05 A CPU parity error has occurred in the system or system common areas of memory.
- 11 - 17 (octal)
An interrupt has occurred from one of the select codes 11B to 17B.
- 23 Possible corrupt system. Try restoring the operating system.

Diagnostic Control System Error Indications

When DCS first runs, a confidence check is made of the host CPU and I/O. The error is usually shown on the console CRT, but for systems without a console, or where the error prevents using the display, the LEDs can be used to determine the error code.

Primary and Secondary LED Error Codes

The Primary and Secondary LED error codes will alternate if an error is encountered.

P = Primary LED error code (bit 6 = 0). Displays for 2 seconds then becomes Secondary LED error code.

S = Secondary LED error code (bit 6 = 1). Displays for 2 seconds then becomes Primary LED error code.

0 = LED off

1 = LED on

X = Variable LED state; must be collectively converted to octal/decimal, including bit 6.

Examples:

S 0 1 0 1 0 1 1 0 = Select Code = octal 26

S 0 1 0 1 0 0 1 0 = Error Number = octal 22/decimal 18

S 0 0 0 1 1 0 1 0 = primary number = octal 32 = EIG

S 0 1 0 0 1 0 0 1 = subtest number = octal 11/decimal 9

| | <u>bit</u> | | | | | | | | |
|---|------------|---|---|---|---|---|---|---|--|
| | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 | (lower 8 bits on A700) |
| P | 0 | 0 | 0 | 0 | 1 | 0 | 0 | 0 | = Pretest CPU Base page |
| S | 0 | 1 | 0 | 0 | 0 | 0 | 0 | 0 | = 0 |
| P | 0 | 0 | 0 | 0 | 1 | 0 | 0 | 1 | = Pretest Memory |
| S | 0 | 1 | 0 | 0 | 0 | 0 | 0 | 0 | = 0 |
| P | 0 | 0 | 0 | 0 | 1 | 0 | 1 | 0 | = Pretest CPU Current page |
| S | 0 | 1 | 0 | 0 | 0 | 0 | 0 | 0 | = 0 |
| P | 0 | 0 | 0 | 0 | 1 | 0 | 1 | 1 | = Pretest CPU Shift Rotate |
| S | 0 | 1 | 0 | 0 | 0 | 0 | 0 | 0 | = 0 |
| P | 0 | 0 | 0 | 0 | 1 | 1 | 0 | 0 | = Pretest I/O Master |
| S | 0 | 1 | X | X | X | X | X | X | = Select Code (octal) |
| P | 0 | 0 | 0 | 0 | 1 | 1 | 0 | 1 | = Pretest Illegal Interrupt |
| S | 0 | 1 | X | X | X | X | X | X | = Select Code (octal) |
| P | 0 | 0 | 0 | 0 | 1 | 1 | 1 | 0 | = BCM Configuration |
| P | 0 | 0 | 0 | 0 | 1 | 1 | 1 | 1 | = BCM Execution or Error (flashes with 0 for active loading) |
| S | 0 | 1 | 0 | X | X | X | X | X | = Error Number (decimal) (See Appendix B, HP 1000 A/L- Series Computer Diagnostic Operating and Troubleshooting Manual, part no. 24612-90001.) |
| P | 0 | 0 | 0 | 1 | 0 | 0 | 0 | 0 | = DDL Input Mode |
| P | 0 | 0 | 0 | 1 | 0 | 0 | 0 | 1 | = DDL Run Mode |
| P | 0 | 0 | X | X | X | X | X | X | = Primary code of executing Kernal/ Interface program (see section below) |
| P | 0 | 0 | 0 | 1 | 0 | 0 | 1 | 0 | = DDL Error |
| S | 0 | 1 | 0 | X | X | X | X | X | = Error number in DDL (see DDL manual) |
| P | 0 | 0 | 0 | 1 | 0 | 0 | 1 | 1 | = DDL User |
| S | 0 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | = 177 |
| P | 0 | 0 | 0 | 1 | 0 | 1 | 0 | 0 | = DDL I/O Routine A |
| P | 0 | 0 | 0 | 1 | 0 | 1 | 0 | 1 | = DDL I/O Routine B |
| P | 0 | 0 | 0 | 1 | 0 | 1 | 1 | 0 | = DDL I/O Routine C |
| P | 0 | 0 | 0 | 1 | 0 | 1 | 1 | 1 | = DDL I/O Routine D |

Diagnostic Program Error LED Indications

| | <u>bit</u> | | | | | | | | |
|---|------------|---|---|---|---|---|---|---|---|
| | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 | (lower 8 bits on A700) |
| P | 0 | 0 | 0 | 1 | 1 | 0 | 0 | 0 | = CPU Base Set |
| S | 0 | 1 | X | X | X | X | X | X | = test that failed (decimal) |
| P | 0 | 0 | 0 | 1 | 1 | 0 | 0 | 1 | = MAD Memory Array |
| S | 0 | 1 | X | X | X | X | X | X | = failed card number (memory card with parity LED not lit) |
| P | 0 | 0 | 0 | 1 | 1 | 0 | 1 | 0 | = EIG Extended Instructions |
| S | 0 | 1 | X | X | X | X | X | X | = subtest that failed |
| P | 0 | 0 | 0 | 1 | 1 | 0 | 1 | 1 | = FPD Floating Point |
| S | 0 | 1 | X | X | X | X | X | X | = subtest that failed |
| P | 0 | 0 | 0 | 1 | 1 | 1 | 0 | 0 | = LIS Language Instructions |
| S | 0 | 1 | X | X | X | X | X | X | = subtest that failed |
| P | 0 | 0 | 0 | 1 | 1 | 1 | 0 | 1 | = SIS Language Instructions |
| S | 0 | 1 | X | X | X | X | X | X | = subtest that failed |
| P | 0 | 0 | 0 | 1 | 1 | 1 | 1 | 0 | = MCD Memory Controller |
| S | 0 | 1 | X | X | X | X | X | X | = subtest that failed (decimal for A-Series, octal for XL) |
| | | | | | | | | | 0-17 (octal) data error |
| | | | | | | | | | 40 XLD, XST failed |
| | | | | | | | | | 41 XST with MPT on failed |
| | | | | | | | | | 42 Map enable failed |
| | | | | | | | | | 43 DMA error |
| P | 0 | 0 | 1 | 0 | 0 | 0 | 0 | 0 | = SFD System Functions |
| S | 0 | 1 | X | X | X | X | X | X | = subtest that failed |
| P | 0 | 0 | 1 | 0 | 0 | 0 | 0 | 1 | = IOM I/O Master |
| S | 0 | 1 | X | X | X | X | X | X | = select code |
| P | 0 | 0 | 1 | 0 | 0 | 0 | 1 | 0 | = Interface Diagnostics |
| S | 0 | 1 | X | X | X | X | X | X | = select code |
| P | 0 | 0 | 1 | 0 | 1 | 0 | 0 | 0 | = CDSBI CDS Basic Instruction |
| S | 0 | 1 | X | X | X | X | X | X | = subtest that failed (decimal) |
| P | 0 | 0 | 1 | 0 | 1 | 0 | 0 | 1 | = CDSPC CDS Procedure Call |
| S | 0 | 1 | X | X | X | X | X | X | = subtest that failed (decimal) |
| P | 0 | 0 | 1 | 0 | 1 | 0 | 1 | 0 | = A990D, A990 Instruction Diagnostic |
| S | 0 | 1 | X | X | X | X | X | X | = subtest that failed |

Diagnostic Driver Errors

Driver Name (As Linked) Errors – where dnam is one of the following:

DCDVR when loading from disc
CTDVR when loading from CTU

dnam ERROR 0 = DEVICE UNDEFINED

A request to a driver was made for a non-existent device. Example: if during reset, the driver reported a configuration error and corrective action was not taken before access was attempted through that driver. Using an HP-IB address for a nonexistent disc.

dnam ERROR 1 = FILE ALREADY OPEN

A driver file was left open (no call for release), and another call was made to open a file to that driver. If necessary, enter RESET command.

dnam ERROR 2 = FILE 0 NOT ALLOWED

Access to file is not allowed because it is usually BCM, and is not in any specific format.

dnam ERROR 3 = FILE NOT OPENED

An attempt to release a driver was made, and there was no file open to that driver.

dnam ERROR 4 = COMMAND (EOF/FF)

A driver request of a device was made and the device returned an error. Usually this is a request to the cartridge tape when there is no tape in the drive.

dnam ERROR 5 = WRITE (PROTECTED)

A write request to a device returned an error. This is usually a request to the cartridge tape or flexible disc when it is write protected.

dnam ERROR 6 = TIMED OUT

During a transfer of data or command, the time allowed for correct operation was exceeded and the operation aborted. Usually disc related.

dnam ERROR 7 = BAD DSJ

The last request of an HP-IB device has been aborted because of an error. This can be any type of operation, command or data. DSJ (Device Specified Jump is a single byte status check for HP-IB devices only) is abnormal indicating a device error.

dnam ERROR 8 = USER ABORTED

The driver requested another data media, and the operator struck a key other than the RETURN key.

dnam ERROR 9 = READ/WRITE CONFLICT

A driver was requested for read or write, and a transfer was requested for the opposite.

dnam ERROR 10 =STATUS

A device reported an error status condition.

dnam ERROR 11 =DMA PARITY

During a DMA transfer out of memory, a parity error occurred.

RTE Device Driver Posted Status

Posted Status Bits

| Device Driver | | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 |
|---------------|-------|-----|-----|-----|-----|-----|----|-----|---|
| Terminals | DDC00 | EOF | BR | EOM | LD | OF | PF | TO | E |
| Terminals | DD.00 | D | — | D | — | — | — | — | E |
| Line Printers | DD.12 | — | — | EOM | — | — | — | — | E |
| CTUs | DD.20 | EOF | DB | EOM | BOM | SE | WP | OFF | E |
| Mag Tapes | DD.23 | EOF | DB | EOM | BOM | SE | WP | OFF | E |
| ICD Discs | DD.30 | — | — | — | EOM | SE | — | — | E |
| CS/80 | DD.33 | WP | UND | EOV | UNM | FLT | NR | CE | E |

- BOM – Beginning of Medium; tape currently positioned at Load Point
- BR – Break character detected on received data line.
- CE – Channel Errors; CS/80 set for any reject error or DMA length error.
- D – End of Transmission, set by a CNTRL D from keyboard.
- DB – Device Busy; performing a function that prevents other operations from starting.
- E – Error; set by system if driver sets any error code. For DDC00: Set to 1 if any DVT16 error bits are set and bits 6, 5, 3, 2, and 1 are cleared on each read request.
- EOF – End of File (set by CTU drivers only).
- EOM – End of Medium; printer out of paper; tape is currently positioned at the end-of-tape; a request made for more sectors than are available.
- EOV – End of Volume; CS/80.
- FLT – Fault.
- LD – Line down, valid for modem lines after first connect. Also indicates speed sensing failure for ID400/800/801.
- NR – Not Ready.
- OF – Overflow error, the application is losing data.
- OFF – Off Line; tape not installed.
- PF – Parity or Framing error, there was a bit error in the data.
- SE – Soft Error; recovered from read/write error.
- TO – Time-out by the device driver.
- UND – Unrecoverable data; CS/80 set for unrecoverable or marginal errors.
- UNM – Uninitialized Medium.

WP – Write Protected; no write ring; record tab set to protect; CS/80 write protected volume.

ASCII/BYTES Table

| Byte Position | | | | Byte Position | | | |
|---------------|--------|--------|-----|---------------|--------|--------|-----|
| CHAR | Left | Right | Dec | CHAR | Left | Right | Dec |
| NUL | 000000 | 000000 | 0 | CAN | 014000 | 000030 | 24 |
| SOH | 000400 | 000001 | 1 | EM | 014400 | 000031 | 25 |
| STX | 001000 | 000002 | 2 | SUB | 015000 | 000032 | 26 |
| ETX | 001400 | 000003 | 3 | ESC | 015400 | 000033 | 27 |
| EOT | 002000 | 000004 | 4 | FS | 016000 | 000034 | 28 |
| ENQ | 002400 | 000005 | 5 | GS | 016400 | 000035 | 29 |
| ACK | 003000 | 000006 | 6 | RS | 017000 | 000036 | 30 |
| BEL | 003400 | 000007 | 7 | US | 017400 | 000037 | 31 |
| BS | 004000 | 000010 | 8 | SPACE | 020000 | 000040 | 32 |
| HT | 004400 | 000011 | 9 | ! | 020400 | 000041 | 33 |
| LF | 005000 | 000012 | 10 | ” | 021000 | 000042 | 34 |
| VT | 005400 | 000013 | 11 | = | 021400 | 000043 | 35 |
| FF | 006000 | 000014 | 12 | \$ | 022000 | 000044 | 36 |
| CR | 006400 | 000015 | 13 | % | 022400 | 000045 | 37 |
| SO | 007000 | 000016 | 14 | & | 023000 | 000046 | 38 |
| SI | 007400 | 000017 | 15 | ‘ | 023400 | 000047 | 39 |
| DLE | 010000 | 000020 | 16 | (| 024000 | 000050 | 40 |
| DC1 | 010400 | 000021 | 17 |) | 024400 | 000051 | 41 |
| DC2 | 011000 | 000022 | 18 | * | 025000 | 000052 | 42 |
| DC3 | 011400 | 000023 | 19 | + | 025400 | 000053 | 43 |
| DC4 | 012000 | 000024 | 20 | , | 026000 | 000054 | 44 |
| NAK | 012400 | 000025 | 21 | - | 026400 | 000055 | 45 |
| SYN | 013000 | 000026 | 22 | . | 027000 | 000056 | 46 |
| ETB | 013400 | 000027 | 23 | / | 027400 | 000057 | 47 |

ASCII/BYTES Table (Cont.)

| Byte Position | | | | Byte Position | | | |
|---------------|--------|--------|-----|---------------|--------|--------|-----|
| CHAR | Left | Right | Dec | CHAR | Left | Right | Dec |
| 0 | 030000 | 000060 | 48 | X | 054000 | 000130 | 88 |
| 1 | 030400 | 000061 | 49 | Y | 054400 | 000131 | 89 |
| 2 | 031000 | 000062 | 50 | Z | 055000 | 000132 | 90 |
| 3 | 031400 | 000063 | 51 | [| 055400 | 000133 | 91 |
| 4 | 032000 | 000064 | 52 | \ | 056000 | 000134 | 92 |
| 5 | 032400 | 000065 | 53 |] | 056400 | 000135 | 93 |
| 6 | 033000 | 000066 | 54 | ^ | 057000 | 000136 | 94 |
| 7 | 033400 | 000067 | 55 | ␣ | 057400 | 000137 | 95 |
| 8 | 034000 | 000070 | 56 | ␣ | 060000 | 000140 | 96 |
| 9 | 034400 | 000071 | 57 | a | 060400 | 000141 | 97 |
| : | 035000 | 000072 | 58 | b | 061000 | 000142 | 98 |
| : | 035400 | 000073 | 59 | c | 061400 | 000143 | 99 |
| < | 036000 | 000074 | 60 | d | 062000 | 000144 | 100 |
| = | 036400 | 000075 | 61 | e | 062400 | 000145 | 101 |
| > | 037000 | 000076 | 62 | f | 063000 | 000146 | 102 |
| ? | 037400 | 000077 | 63 | g | 063400 | 000147 | 103 |
| @ | 040000 | 000100 | 64 | h | 064000 | 000150 | 104 |
| A | 040400 | 000101 | 65 | i | 064400 | 000151 | 105 |
| B | 041000 | 000102 | 66 | j | 065000 | 000152 | 106 |
| C | 041400 | 000103 | 67 | k | 065400 | 000153 | 107 |
| D | 042000 | 000104 | 68 | l | 066000 | 000154 | 108 |
| E | 042400 | 000105 | 69 | m | 066400 | 000155 | 109 |
| F | 043000 | 000106 | 70 | n | 067000 | 000156 | 110 |
| G | 043400 | 000107 | 71 | o | 067400 | 000157 | 111 |
| H | 044000 | 000110 | 72 | p | 070000 | 000160 | 112 |
| I | 044400 | 000111 | 73 | q | 070400 | 000161 | 113 |
| J | 045000 | 000112 | 74 | r | 071000 | 000162 | 114 |
| K | 045400 | 000113 | 75 | s | 071400 | 000163 | 115 |
| L | 046000 | 000114 | 76 | t | 072000 | 000164 | 116 |
| M | 046400 | 000115 | 77 | u | 072400 | 000165 | 117 |
| N | 047000 | 000116 | 78 | v | 073000 | 000166 | 118 |
| O | 047400 | 000117 | 79 | w | 073400 | 000167 | 119 |
| P | 050000 | 000120 | 80 | x | 074000 | 000170 | 120 |
| Q | 050400 | 000121 | 81 | y | 074400 | 000171 | 121 |
| R | 051000 | 000122 | 82 | z | 075000 | 000172 | 122 |
| S | 051400 | 000123 | 83 | { | 075400 | 000173 | 123 |
| T | 052000 | 000124 | 84 | | 076000 | 000174 | 124 |
| U | 052400 | 000125 | 85 | } | 076400 | 000175 | 125 |
| V | 053000 | 000126 | 86 | ~ | 077000 | 000176 | 126 |
| W | 053400 | 000127 | 87 | DEL | 077400 | 000177 | 127 |

Utilities

The following utility programs are available on RTE-A and are run from the CI (Command Interpreter) system prompt.

ASAVE and ARSTR

Purpose: Save or restore one disk LU, a group of disk LUs, or an entire disk unit to a tape.

Operation: ASAVE [command [|command ...|]]
ARSTR [command [|command ...|]]

where:

command is one of the following (or its first two letters).
Default = interactive mode.

EXIT|END|ABORT
Terminate ASAVE.

HELP|?|??
On-line help.

LH [fileNum]
List header record for file specified by fileNum or closest file to it on current tape.

Default = next save file. If save file for disk LU crosses tapes, it has same fileNum.

LL [fileDescriptor|lu]
Open list file or LU for log information (in addition to terminal); close previous one.

Default = If no file descriptor|lu is specified, then any open list file or device is closed.

RE fileNum:lu [fileNum:lu ...][VE]
(ARSTR only) Restore a file from tape to disk.

Default fileNum = 1 for first disk lu specified, 2 for second disk lu specified, and so forth.

Default lu = lu used during ASAVE.

Options:

VE Verify

SAVE, lu1 [,lu2 ,...] [,UN] [,AP] [,VE] [,NL] [,NC]

Save a disk to tape. Options:

UN Save entire disk unit containing lu1.

AP Append files to current ASAVE tape.

VE Verify.

NL Do not lock disk LUs during save operation. NC
Do not checksum the data records on the
tape.

TAPE [lu]

Specify tape LU. Default = display tape LU.

TITLE [text]

(ASAVE only) Specify title (<=40 characters) for save operation. Default = no title.

UE [ON|OFF]

Specify user error-handling mode (initially on). Default = display current mode.

CSYS

Purpose: Copy Type 1 (memory image) file from a CS/80 disk to a cartridge tape, in a memory-based system. CSYS runs only with the HP 7908/11/12/14 disk drives and CTD drive.

NOTE – CSYS does not acknowledge the system BReak command; once invoked, it continues to completion or until aborted by an error.

Operation: CSYS [,system file namr][,tape lu][,file no],[SA]

where:

system file namr

Name of type 1 file on disk.

tape lu

LU of the CTD to be copied.

file no

Specifies the file number that the VCP will use to boot
the system from the tape.

SA

Adds ASAVE file header so bootable ARSTR can be on same tape as backup.

COPYL

Purpose: Copy one disk LU to another, ignoring file structure.

Note: Disk LUs must be same type and size.

Operation: COPYL [sourceLu destinationLu]

where:

sourceLu

LU of disk to be copied.

destinationLu

LU of disk to receive data.

Default = interactive mode.

EDIT/1000

Purpose: Edit an ASCII file.

Operation: EDIT [file [commandList]]

where:

file

File descriptor of file to be edited.

commandList

List of EDIT commands, separated by vertical bars (|). The commands H and ? display information about EDIT commands.

ERTSH

Purpose: Used with FORMA to find, verify and spare faulty disk sectors (on a Micro/1000 system).

Note: For successful operation, at least 256 KB of system memory, for a memory-based system, is required.

Operation: ERTSH [;command;...]

where:

command is any of the following (command parameters are separated by blanks or commas; default = interactive mode):

BP [word] ... [word]
Define or display the user definable test data pattern (1 to 6 words long). Default = Display the test data patterns and specify those that are currently in use.

CY [low cylinder] [high cylinder]
Define a subrange of disk cylinders for error rate test. Default = all cylinders within the current test LU.

EX or /E
Exit ERTSH after performing necessary cleanup. ERTSH will not respond to a BREAK command during the cleanup process.

HD [low head] [high head]
Define a subrange of disk heads for error rate test. Default = all disk heads within the current test LU.

LL [lu]
Display the current extra log device or set up an extra log device. Setting the LU to zero terminates the use of the extra log device.

LU [lu]
Select the disk LU for testing. The LU does not have to be mounted to the file system. Default = display all disk LUs which can be tested and the currently selected LU.

P# [number]
Define the number of passes (0 to 32767) over the disk range for an error rate test. Zero indicates an infinite

number of passes. Default = display the current pass count.

RO [SQ/RN]

Execute a read-only error rate test over the specified disk range. The sequential (SQ) access test covers the entire disk range in a uniform manner. The random (RN) access test accesses random disk locations.

SC [low sector] [high sector]

Define a subrange of disk sectors for an error rate test. Default = all disk sectors.

SS [HD/AL]

Spare all defective sectors found during a test pass. AL causes all sectors with defects to be spared, while HD spares only those sectors which contain defects that cannot be corrected.

TH [,pattern number] ... [pattern number]

Select one or more of the 19 defined test data patterns for the write-then-read error rate test. If no parameters are specified, then the test data patterns are displayed in addition to the current pattern choices.

WR [SQ/RN]

Execute a write-then-read error rate test over the specified disk range. The LU cannot be mounted to the file system when this test is executed. The sequential (SQ) access test covers the entire disk range in a uniform manner. The random (RN) access test accesses random disk locations.

?? [,command mnemonic]

Display specific help information for the command mnemonic. Default = display all commands.

FC

Purpose: Back up and restore files from FMGR file addressing space to magnetic tape.

Note: FC cannot back up and/or restore CI directories.

Operation: FC [command]

where:

command is one of the following (default = interactive mode):

? List commands and their syntax.

LL Set list device or file.

TITLE

Set title for tape header file.

CF Set namr for tape comment file.

ECHO

Turn ON or OFF echoing of commands to list device.

SCRATCH

Specify disk cartridge for internal scratch files.

COPY

Copy files as specified by parameters.

DEFAULT

Set default source, destination, and options for subsequent COPY commands.

GROUP, COPY EG, AG

Group multiple copy commands into a single operation.

DL Compile directory list of FC tape.

CL List FMP cartridge list, or cartridges included on tape.

LC List comment file from FC tape.

LH List header file from FC tape.

TR Transfer to or from FC command file.

EX Exit FC. If a group COPY is active, it will be completed first.

AB Abort FC, including any active group COPY.

* Comment.

FORMA

Purpose: Provides initialize and spare functions for Micro/1000 systems with internal disks using the HP 12022A* interface card.

Note: For successful operation, at least 256 KB of system memory, for a memory-based system, is required.

Operation: FORMA [command]

where:

command is one of the following (default = interactive mode):

IM lu spareAction

where:

lu Disk LU.

spareAction

 p for save the primary;

 s for save the primary and secondary

 n for save neither.

Note: If you are using a new or replacement disk drive when initializing media that was *not* previously initialized using FORMA, always choose “n”. (If you choose “p” or “s”, the operation will take 16 hours.)

SS diskLu r s/b ccc h ss/bbbbb [p] [o/u]

where:

diskLu Disk LU (1 to 63).

r Retain data (answer y or n).

s/b Logical (sector) or physical (byte) addressing.

ccc Cylinder number of the defect.

h Head number.

* Discontinued product; shown for reference only.

ss/bbbbb Logical sector or physical byte count since index.

p Primary spare.

o/u Override old spare or unspare.

FORMC

Purpose: Verify integrity of CS/80 disk and tape drives, spare a disk block, or format a disk volume or tape. May also be used with stand alone HP 9153B*/C, integrated HP 9153B* (“Nighthawk”) Winchester disk drives, and Micro/1000 Internal Disk Drives using the HP 12122A interface card.

Operation: FORMC [logLu] [command]

where:

logLu LU of log device; default = 1, user terminal

command is one of the following, or its first two letters (default = interactive mode):

? List FORMC commands.

END|EXIT|/EXIT
End FORMC.

ABORT|/ABORT
Abort FORMC.

VERIFY mediaLu [start number]
Verify integrity of CS/80 disk or tape.

mediaLu
LU of CS/80 disk or tape to be verified.

start
Number of disk track or tape block at which verify is to begin. Default = entire disk or tape.

* Discontinued product; shown for reference only.

number
Decimal number of disk tracks or tape blocks to be verified.

SPARE mediaLu track
Spare blocks on specified track.

mediaLu
LU of CS/80 disk or CTD (cache tracks) to be spared.

track
Number of logical RTE (not physical) track containing blocks to be spared.

FORMAT mediaLu [interleave]
Format specified disk or tape.

mediaLu
LU of CS/80 disk or tape to be formatted. Note that entire disk is formatted; it is not possible to format single LUs.

interleave
Disk sector interleave factor. Decimal number between 1 and 32 (Default = 1).

FORMF

Purpose: Verify integrity of and format a flexible disk.

Operation: FORMF [logLu [command lu [interleave]]]

where:

logLu
LU of log device.

command
VE (verify disk integrity) or FO (format disk).

lu
LU of disk.

interleave
disk sector interleave factor.

Exit FORMF with EX, EN, or /E; abort it with AB or /A.

FORMT

Purpose: Format a flexible disk, initialize a hard disk, spare a track on a hard disk, verify data on a disk LU, or reformat a hard disk. Will not run online. System must be memory-based with one ID segment generated.

Operation: FORMT [logLu] [command diskLu [pram]]

where:

logLu

LU of device from which FORMT queries are answered. Default is user terminal.

command is one of the following:

FO Format flexible disk.

IN Initialize hard disk.

SP Spare track on hard disk.

VE Verify data on disk LU (read-only verify).

RE Reformat hard disk.

diskLu

LU of disk.

pram

For command = FO, pram = sector fill number; for command = SP, pram = track to spare; for other commands, pram is empty.

FOWN

Purpose: Displays owners of and disk space used by files specified.

Operation: FOWN [mask]

where:

mask

File mask. Default = all CI files.

FPACK

Purpose: Rearrange files on file system volume, increasing largest free space on volume. See also MPACK.

Operation: FPACK lu

where:

lu LU of volume to be packed.

FPUT

Purpose: Install bootable systems and diagnostics in space reserved by IN command.

Operation: FPUT file lu [offset]

where:

file File descriptor of file to be installed.

lu LU of disk volume where file is to be installed.

offset

Bootable file number.

FREES

Purpose: Report total free space and size of largest free space on CI file system volume.

Operation: FREES [lu]

where:

lu LU of CI file system volume. Default = all CI volumes.

FSCON

Purpose: Convert FMGR cartridge to CI (hierarchical) structure.

Operation: FSCON lu

where:

lu LU of FMGR cartridge to be converted.

FST

Purpose: Back up and restore files from the disk to magnetic or CS/80 cartridge tape. Supports streaming.

Operation: FST [command | command | ... | command]

where:

command is one of the following (default = interactive mode):

? or HE

List commands and their syntax.

/ Display command stack (10 lines).

BA Select files to back up.

DF Specify a non-default directory file.

DL Display the mounted tape's directory file.

EX Exit FST.

GO Begin executing backup/restore.

LC List the mounted tape's comment file.

LH List the mounted tape's header.

LI List the files selected for backup/restore.

LL Set log device or file for FST activities.

LN List the non-selected files (restore only).

- MT Set the magnetic tape LU.
- NE Advance the tape to another append.
- PO Position the tape to a specific append.
- PR Rewind the tape to a previous append.
- RE Select files to restore.
- RU Run an external program.
- SC Select the tape's comment file (backup only).
- SD Set the tape density (HP 7974/78 only).
- SE Lock the tape LU and check the tape status.
- SH Display the DF, MT, TI, SC, LL, and option settings.
- TI Specify a title for the tape (backup only).
- TR Begin executing a transfer file.
- UN Unselect files.
- * Comment.

FST Options:

FST> option [option]...[option] [ON/OFF] ...

where:

option is one of the following (specify ON or OFF for each group of options, the default is ON):

- A Append this backup to the data already on the tape.
- B Only show errors and status messages.
- C Clear the disk file's backup bits.
- D Replace duplicate files.
- K Keep tape on-line when backup/restore is complete.
- L Lock any disk LUs used.
- O Restore files to their original main size.

- P Purge the disk files after backing up the files.
- Q Report messages only to the log device/file.
- U Replace duplicate file if file has been updated.
- V Verify the files during the backup/restore.
- W Backup all the blocks reserved for the file.
- Y Write over the tape without asking.

FVERI

Purpose: Verify that data within a hierarchical file system volume is consistent.

Operation: FVERI [lu|mask] [options]

where:

lu LU of volume to be verified. Default = all volumes.

mask
mask describing a set of files to be verified.

options
one or more of the following:

+B verify bit map only, illegal if mask is also specified.

+L,file|lu
list file or device for errors.

?? On-line help.

INSTL

Purpose: Initialize boot extension (BOOTEX) file for disk LU.

Operation: INSTL [snap] [system] bootDest lu [bootSource],[NC]

where:

- snap
Snapshot file of target system. Default = same as host system.
- system
System file of target system. Default = same as host system.
- bootDest
File to contain new boot extension, or number which is an offset into reserved space on LU.
- lu Disk LU (on target system) containing target system and snap file.
- NC
No Console option. BOOTEK will not send message to console.
- bootSource
Name of boot extension file on host system. Default is bootDest, if it is a file.

LIF

Purpose: Interchanges files between an HP 1000 system and other HP computer systems. Translates files from the RTE FMP format to a standard Logical Interchange Format (LIF) and vice versa.

Operation: LIF [command]

where:

command is one of the following (default = interactive mode):

CO Copy files from one medium to another.

DL Directory list.

EX Exit.

HE Help.

IN Initialize the LIF medium.

LI List files on the list device.
LL Logical list, specifies the list device.
MC Mount cartridge.
PK Pack cartridge (LIF medium).
PU Purge files from LIF medium.
RN Rename LIF file.
ST Store files to and from LIF medium.
SV Severity level.
TR Transfer to a LIF command file.

LINDEX

Purpose: Index library files for faster searching.

Operation: LINDEX inputFile outputFile

where:

inputFile
File to be indexed.

outputFile
Indexed library (different from inputFile).

MERGE

Purpose: Combine two or more input files into a single output file.

Operation: MERGE [mergeList] [file|lu]

where:

mergeList
File containing names of files to be merged.

file|lu
Output file name or LU.

METER

Purpose: Displays information about system and user processes. Meter updates the information approximately once every five seconds.

Operation: METER

When the cursor is at the bottom of the list, you can enter one of the following single key commands:

- I Sort in increasing order
 - D Sort in decreasing order
 - H Sort by histogram order
 - L Sort by LU (Session number)
 - N Sort by name
 - O Sort by owner
 - P Sort by priority
 - S Sort by state
 - T Sort by total CPU
 - A Display all processes
 - U Display only user processes (non-system)
 - ? Display a help screen
 - E Exit
- space
Exit

Uppercase or lowercase does not make any difference to METER except for the commands H, L, P, and S. For these commands there can be both a primary and a secondary sort key. Indicate primary sort keys by typing an uppercase character. Indicate secondary sort keys by lowercase.

Use the BR command, not the OF command, to stop execution of METER.

MPACK

Purpose: Consolidate free space on disk by moving files. The LU to be packed must be inactive.

Operation: MPACK lu [option]

where:

lu
LU of volume to be packed.

option
+P = Pack disk LU

?
List options and their syntax.

OLDRE

Purpose: Change extended relocatable record formats to non-extendable formats.

Operation: OLDRE namr

where:

namr
Name of type 5 file. Begins with %.

PBV (PushButton Verify)

Purpose: Verifies that the data copied in a CS/80 PushButton Save or a CS/80 PushButton Restore operation is correct.

Operation: PBV sourceLu destinationLu

where:

sourceLu
If verifying a save operation, LU must be a CS/80 disk.
If verifying a restore operation, LU must be a CS/80 CTD.

destinationLu

If verifying a save operation, LU must be a CS/80 CTD. If verifying a restore operation, LU must be a CS/80 disk.

Refer to the RTE-A Utilities Manual (part no. 92077-90004) for additional information.

PRINT

Purpose: Print one or more files to a printer or a file.

Operation: PRINT [file] [lu],[option1 [option2 [...]]]

PRINT options can be placed anywhere in the runstring provided a plus sign precedes each option. PRINT understands file masks. PRINT options are as follows:

Options:

+A:filename

Directs output to the specified filename and appends to the current file if it exists.

+B:banner

Prints a large letter, user-defined banner.

+C:ON/OFF

Sets the carriage control option on or off.

+F:#

Advances paper the specified number of pages after all files are printed.

+I:#

Indents each line by the specified number of spaces.

+M:#

Merge consecutive files with the specified number of blank lines between them.

+N

Produces a numbered listing for each file in the runstring.

- +O:filename
Directs output to the specified filename and overwrites the current file if it exists.
- +P[:OK]
Purges printed files that have been sent to the line printer. PRINT prompts you before purging the files unless you qualify the command with the word OK.
- +Q Suppresses file mask verification. If this option is not used, PRINT shows all files that match the runstring and asks if it is OK to print them.
- +X:#
Prints all files contained in the runstring a specified number of times.
- +W:workingdir
Prints the files that follow relative to the given working directory.
- +? Returns an explanation of available options.

RINFO (Reset Multiuser Accounting Information)

Purpose: Resets the multiuser accounting information to zero for cumulative connect time and cumulative CPU usage. Only the superuser can run this utility.

Operation: RINFO [UserMask1 [UserMask2 [...]]]

where:

UserMask

is the name or file mask for the user(s) whose accounting information is to be reset. Defaults to the current user.

SAM (System Available Memory Reporting)

Purpose: Prints out information concerning the status of System Available Memory (SAM).

Operation: SAM [AL]

where:

AL complete listing of all SAM blocks

SINFO (Show Multiuser Accounting Information)

Purpose: Displays the multiuser accounting information found in the user configuration file for the user(s) specified. The information shown is last logoff time, cumulative connect time, and cumulative CPU usage.

Operation: SINFO [UserMask1 [UserMask2 [...]]]

where:

UserMask

is the name or file mask for the users whose accounting information is to be displayed. Defaults to the current user.

SPORT (Serial Port Analyzer)

Purpose: Troubleshooting serial ports. Displays the status of serial ports driven by DDC00. Verifies that a port was set up in the desired manner.

Operation SPORT [port_lu [,display_lu [,waitflag]]]

where:

port_lu

Serial port LU for which current status is requested.

display_lu

LU to which the output is directed.

waitflag

Non-zero value to force a wait for a busy port. Permits

SPORT to “hang” on the port until current request completes.

TF

Purpose: Back up and restore files to magnetic or CS/80 cartridge tape.

Operation: TF [command]

where:

command is one of the following (default = interactive mode):

? List commands and their syntax.

COPY

Copy files as specified by parameters.

TITLE

Set title for tape header file.

DEFAULT

Set default source, destination, and options for subsequent COPY commands.

GROUP, EG, AG

Group multiple COPY commands into a single operation.

LL Set list device or file for LH or DL.

LH List header file from TF tape.

DL Compile directory list of TF tape.

TR Transfer to or return from TF command file.

EX Exit TF.

* Comment.

WH

Purpose: Display system status information.

Operation: WH [option]

where:

option is one of the following:

AC Active programs.

AL Active and dormant programs.

CL Class number.

PA Partition status.

SE All sessions (VC+ only).

SH Shareable EMA areas.

ST System status.

US All user programs.

none

All programs in current session.

??|HE

On-line help.

BOOTEX Boot Extension

Purpose


The boot process consists of three phases: initial boot extension load, modification of system file, and loading of the system file and system start-up.

Initial Load – In the initial load, the boot ROM loader brings into memory the boot extension, BOOTEX. BOOTEX resides on the disk starting at cylinder 0, sector 0. BOOTEX is a file that contains a boot program. The boot loader passes a string to BOOTEX which contains the name of a file. The file can either be a BOOTEX command file (Type 4) or an actual system file to be booted into memory (Type 1).

If the file is a type 4, BOOTEX assumes it is a boot command file. The command file contains the names of the system to be booted and its associated snapshot file, the names of any type 6 program files to be restored, and the reserved partition definitions for the system. BOOTEX restores each program file, then modifies the system file by setting up the memory descriptors and creating ID segments for those programs to be RP'd, and sets up the swap file and the swap area descriptors.

System Load and Start-up – The modified system file is now loaded into memory and, if a program has been specified as the start-up program, it begins to execute.

BOOTEX Flowchart



Operation

BOOTEX can be run either interactively or from a command file. The name of the BOOTEX command file is specified in the boot string (i.e., %BDCbuscNAME). The BOOTEX command file must be on the disk LU from which you are booting (same LU where BOOTEX is found). If the file is not found, or the file is a Type 0 file for the terminal, BOOTEX goes into interactive mode. In most cases, BOOTEX can be rescheduled for interactive execution with the BOOTEX string %BDCffbuscxx (where xx are don't cares).

Boot Program Commands

BOOTEX performs several functions: system and snapshot file initialization, cartridge mounting, memory specification, reserved partition definition, program RP, swap file initialization, set up of timeslice and priority swapping boundaries.

ECHO Command

Echoes all commands to the terminal. This command is usually found in the BOOTEX command file and not necessary for interactive mode.

EC

System/Snap Commands

The first phase of BOOTEX is system and snapshot file initialization. The following two commands must be entered prior to all other commands and must be found on the boot cartridge.

SY,filename

– where filename is the name of the system file.

SN,filename

– where filename is the name of the snapshot file.

Mounting Cartridges

BOOTEX will mount any cartridges you would like to have in the cartridge directory upon system start-up. This command should be entered before the command to relink or RP is given. The cartridge that contains the files to be relinked and/or RP'ed should be mounted first.

MC,+/-lu

Scratch LU

A scratch disk LU may be specified for VMA backing store scratch files.

SC,+/-lu

SC,0 removes scratch cartridge definition.

Bad Pages

You may specify bad pages with the BP command. All bad pages must be specified prior to defining partitions. Bad pages are identified in increasing order. NOTE: Bad pages cannot be specified in the system or system common area. If a bad page exists in either of these areas, the physical memory must be repaired, replaced, or reordered.

BP,page number – identify a bad page of memory by its page number.

or

BP,pnum1,pnum2 – identify a block of bad pages in the range from pnum1 to pnum2.

Memory Commands

The system memory size and System Available Memory (SAM) can be specified with the following commands:

MS,num
sets the memory size used by RTE to “num” pages.
“Num” must be less than or equal to the actual number of pages of physical memory installed.

SA,num
sets the number of words of System Available Memory (SAM).

Restore Program Commands: RP, ST, SZ, and PR

Program files can be relinked and optionally have ID segments set up (RP'ed) during this phase. Program size and priority can also be changed as well as specifying a start-up program where RMPAR parameters can be passed.

RP,namr[,newname]
Relink the file if necessary and construct an ID segment. The program can be given a new name if desired.

ST,[p1,...,p5]
Indicate that the program given in the previous RP is to be the start-up program. If more than one ST is issued, the last program will be the actual start-up program.

SZ,nn
Size in pages of the program given in the previous RP or LK command. VMA/EMA programs cannot be sized at boot time.

PR,nn
Change the priority of the program given in the previous RP or LK command. The range is from 0 to 32767.

EN Ends this phase.

Reserved Partition Assignment

Optional reserved partitions can be defined in either two ways: by assigning programs or by simply giving the partition size. A program is assigned a reserved partition in the following manner:

AS,prog1[,prog2[...]] Up to 20 programs can be assigned the same partition with all commands for that partition being grouped together.

Commands are accepted until the area for Memory Descriptors is filled or memory is filled.

Reserved Partition Definition

Reserved partitions without assigning programs are defined as follows:

RV,k where 'k' is the number of pages to allocate for the partition.

Swap File Definition

The swap file command allows you to specify a file to which programs will be swapped. If BOOTEX finds the file in the command, the existing file will be used, ignoring the file size parameter. If the file does not exist, the file will be created. The file size will be set to 32k times the number of ID segments.

SW,namr Initialize the given file as the system swap file.

Timeslicing, Swapping, Security Code, Session Accounting

Commands to set up the timeslicing quantum, the priority swap boundary and the system security code can be entered at this point in the boot process.

QU,timeslice,pri Set the timeslice quantum to the given value. Set the priority boundary where timeslicing is to begin.

BG,boundary Set the background priority limit.

SS,newcode Change the system security code from the value in the system file to the newcode.

For systems with VC+ only:

AC[,ON/OFF] Turns session accounting on or off. Default = ON. (Note that the session accounting must be enabled for METER to function properly.)

END Command

The command input to BOOTEX is terminated with the END command.

Sample BOOTEX Command File

```
* SOURCE: 92077-17293 REV.5020 <901205.1442>
* JCR
* FHP,MCN – size up the swap file (2048 blocks)
* Primary system boot up command file (boot.cmd) for primary system
ec
* Define system and snap files
sy,primary.sys
sn.primary.snp
*
* Note: No FMGR cartridges are mounted. If needed, mount cartridge
      16 for CS-80 systems (MC,16) or mount cartridge 60 for micro-
      1000 systems (MC,60) to mount the appropriate FMGR cartridge.
*
* Define initially RP'ed programs
rp,drtr,d.rtr
rp,derr,d.err
*
rp,ci,cm
rp,cix
*
* RP the powerfail routine and DDC00/DDC01 modem handler
rp,autor
*
* Configure the system console
rp,ci,ci.s
*
* Note: the following line is used for the primary system only.
*   Remove it when you generate your system with a system
      console gen'd in.
*
* Map VCP terminal to LU1
rp,lucfg,prihp
*
* Use Welcome1.cmd
st,,1
end
*
* End RP phase
* Define swap file
* sw,swap.swp::system::2048
*
end
```

Table of Contents

Chapter 5 Diagnostics

| | |
|--|------|
| Diagnostic Control System | 5-1 |
| Diagnostic Welcome Message | 5-1 |
| Interface Card Octal Identification Codes | 5-2 |
| VCP AUTO Execution – Complete Test Series | 5-3 |
| VCP AUTO Execution – Single Test Execution | 5-5 |
| A-Series Diagnostic BOOT/LOAD Sequence | 5-8 |
| Operator Command Options | 5-9 |
| AUTO | 5-9 |
| SHOW | 5-10 |
| ASSIGN | 5-10 |
| LOG | 5-11 |
| FREEZE | 5-12 |
| RESET | 5-12 |
| COPY | 5-12 |
| CLEAR | 5-12 |
| EXIT | 5-12 |
| Diagnostic Design Language (DDL) | 5-13 |
| HP 24612A Diagnostic Media Allocation | 5-18 |
| BCM AUTO File Allocation, rev. 5000, 5010, and 5020 | 5-19 |
| BCM AUTO File Allocation, rev. 5270 | 5-20 |
| HP 24612A Diagnostic Media Options | 5-22 |
| Option 044, 3.5-Inch Floppies | 5-22 |
| Option 022, CS/80 Cartridge Tape | 5-22 |
| Option 051, 1600 bpi Magnetic Tape | 5-22 |
| Option AAH, SCSI DAT Tape | 5-22 |
| HP 24612A KERNEL Diagnostics | 5-24 |
| KERNEL Diagnostic Summary1 | 5-24 |
| Basic Instruction Diagnostic (CPU) | 5-24 |
| Memory Array Diagnostic (MAD) A400/A600/A700*; (MADMG) A900/A990 | 5-25 |
| Memory Controller Diagnostic (MCDXL*) | 5-26 |
| Memory Controller Diagnostic (MCD) | 5-27 |
| System Function Diagnostic (SFD) | 5-28 |
| I/O Master Diagnostic (IOM) | 5-29 |
| Expanded Instruction Diagnostic (EIG) | 5-30 |
| Floating Point Diagnostic (FPD) | 5-31 |
| Language Instruction Diagnostic (LIS) | 5-32 |
| Scientific Instruction Set (SIS) | 5-34 |
| CDS Basic Instruction Diagnostic (CDSBI) | 5-35 |
| CDS Procedural Call Diagnostic (CDSPC) | 5-36 |
| HP 24612A Interface Diagnostics | 5-37 |
| General Information | 5-37 |
| Diagnostic Test Hoods | 5-38 |
| General Diagnostic Operation | 5-38 |
| HP 12005A*/B Async Serial Interface (ASIC) | 5-39 |
| HP 12006A Parallel Interface (PIC) | 5-41 |
| Programmable Serial Interface (PSI) Diagnostics | 5-42 |
| HP 12008A PROM Storage Module (PROM) | 5-42 |
| HP 12009A HP-IB Interface (HPIB) | 5-43 |
| HP 12016A SCSI Interface (SCSI) | 5-45 |
| Single SCSI Card Automatic Mode Execution | 5-45 |
| Multiple SCSI Card Automatic Mode Execution | 5-46 |
| Interactive Mode Diagnostic Operation | 5-47 |

| | |
|--|-------|
| SCSI Card Self-Test | 5-48 |
| TERMPWR Check | 5-48 |
| Firmware Timestamp Display | 5-49 |
| RAM Test | 5-50 |
| Loopback Test | 5-51 |
| HP 12022A* Disk Interface/Controller Diagnostic (DID) | 5-52 |
| Interactive Diagnostic Operation | 5-53 |
| Register Definitions | 5-54 |
| HP 12040A/B/C/D 8-Channel Asynchronous Multiplexer Diagnostic (MUX) .. | 5-57 |
| Common Errors, Rev. B and C | 5-57 |
| Common Errors, Rev. D | 5-58 |
| HP 12060A/B High Level Analog Input | |
| HP 12061A 31-Channel Expansion Multiplexer | 5-58 |
| HP 12062A 4-Channel Analog Output Card Diagnostic (AOUTD) | 5-59 |
| Interactive Diagnostics | 5-60 |
| Analog Output Calibration | 5-60 |
| Analog and Digital Output Program | 5-60 |
| HP 12063A Isolated Digital I/O Card Diagnostic (DIGIO) | 5-61 |
| Optional Diagnostics | 5-62 |
| HP 12072A Data Link Diagnostic (FDL) | 5-62 |
| HP 12072A Diagnostic Error Messages | 5-64 |
| HP 12100A A400 On-Board I/O (OBIO) | 5-68 |
| HP 12153A Writable Control Store (WCS) | 5-70 |
| HP 12205A Control Store Card (CSIC) | 5-71 |
| HP 24398B Diagnostic Media Options | 5-72 |
| Option 044, 3.5-Inch Floppies | 5-72 |
| Option 022, CS/80 Cartridge Tape | 5-73 |
| Option 051, 1600 bpi Magnetic Tape | 5-75 |
| Option AAH, SCSI DAT Tape | 5-77 |
| Loading Diagnostics from 3.5-Inch Floppies | 5-77 |
| Loading Diagnostics from CS/80 Cartridge Tapes | 5-78 |
| Loading Diagnostics from 1600 bpi Magnetic Tape | 5-79 |
| Loading Diagnostics from SCSI DAT | 5-80 |
| HP 24398B Peripheral Diagnostics | 5-81 |
| CS/80 Disk Diagnostics | 5-81 |
| CS/80 Error Information | 5-85 |
| RTE-A DD*33 Error Decoding | 5-86 |
| Class of Errors | 5-87 |
| HP 7970E* HP-IB Verifier | 5-91 |
| ICD/MAC Disk* Diagnostics | 5-96 |
| HP 7974*, 7978*, 7980 Magnetic Tape Drive Exerciser | 5-99 |
| Systems Modem Diagnostic | 5-101 |
| Vector Instruction Set (VIS) Diagnostic | 5-104 |

Diagnostics

Diagnostic Control System

Diagnostic Welcome Message

The following is an example of the configuration and status message returned to the terminal. This message should be checked against the I/O cards and amount of memory physically installed in the computer.

```

HP 1000 A990           8192K BYTES MEMORY
IO-ID 000020
IO-ID 003025
IO-ID 004027

BASIC CONTROL MODULE (5270)
SYSTEM MODULES LOADED
  
```

Interface card octal identification codes are defined as shown below, and are determined through Diagnose Mode 1 of the I/O Master circuits on each installed I/O interface card (refer to any HP 1000 A-Series Computer Reference Manual).

```

IO-ID 003025
  ↓ ↓ ↓ ↓
  ↓ ↓ ↓ ↓ 25 = select code of the card
  ↓ ↓ ↓ ↓ 0 = revision level of the card
  ↓ 03 = card identification code (in octal)
  0 = 1 for intelligent I/O card
  
```

These identification codes are automatically obtained in the diagnostic welcome message when loading the HP 24612A diagnostics.

The identification code for a particular interface card can be obtained in VCP diagnose mode 1 using the following commands (user input is underlined>):

VCP> G --xx xx xxxsc

or

VCP> RDyyyysc xxxxxx

where sc is the select code (in octal) and yyyy is the ID code. In diagnose mode 2, xxxxxx represents the following data (in A/B register):

- Bits 0 - 5: Current global register value
- 6: Global register enabled/disabled
- 7: 1 = global register: select code of interface
- 8: Flag bit
- 9: Control bit
- 10: Always zero
- 11: 1 = receiving interrupt priority
- 12: 1 = break feature enabled
- 13 - 15: Always zero

Interface Card Octal Identification Codes

| Interface Card | | ID Code (octal) |
|----------------|-------------------------------------|--------------------|
| HP 12005A* | ASIC Card, standard | 0000sc |
| HP 12005B | ASIC Card, fiber optics | 0001sc |
| HP 12006A | Parallel Interface Card | 0010sc |
| HP 12007A*/B | HDLC (Modem) Card | 1020sc ‡ |
| HP 12008A | PROM I/O Card | 0030sc |
| HP 12009A | HP-IB Interface Card | 0040sc |
| HP 12010A | Breadboard Card | 0050sc |
| HP 12011A | Extender Card | † |
| HP 12012A | Priority Jumper Card | † |
| HP 12013A* | Battery Backup Card for model 6 | † |
| HP 12016A | SCSI Host Bus Adapter Card | 1150sc |
| HP 12021A* | Model 5/6 Floppy Controller | † |
| HP 12022A* | Micro/1000 Disc Interface Card | 0230sc |
| HP 12040A* | Multiplexer Card | 1060sc |
| HP 12040B* | Multiplexer Card | 1060sc |
| HP 12040C | Multiplexer Card | 1060sc |
| HP 12040D | Multiplexer Card | 1060sc |
| HP 12041A*/B | Multi-Use 8-Channel MUX Card | 0060sc |
| HP 12043A | MRJE Modem | 0020sc |
| HP 12060A* | High Level Analog Input Card | 0400sc |
| HP 12060B | High Level Analog Input Card | 0400sc |
| HP 12061A | Multiplexer Expansion Card | † |
| HP 12062A | Digital-to-Analog Card | 0440sc |
| HP 12063A | 16 IN/16 OUT Isolated Digital Card | 1410sc |
| HP 12065A | Color Video Interface Card | 0250sc |
| HP 12072A | Factory Data Link Card | 1430sc |
| HP 12076A | LAN Interface Card | 1260sc |
| HP 12092A | Data Link Master | 0020sc |
| HP 12100A | A400 On-Board 4-Channel MUX | 1777sc |
| HP 12153A | Writable Control Store (A700) | 0600sc |
| HP 12155A | PROM Control Store (A700) | 0030sc |
| HP 12205A | Control Store Interface Card (A900) | 0610sc |
| HP 37203L* | HP-IB Extender | † |
| HP 37222A | Modem Card | 0220sc |

where: sc select code.

* Discontinued product; shown for reference only

† Has no I/O master or ID number

‡ Additional PSI interfaces with ID code = 1020sc:

| | |
|-----------|-----------------------------------|
| HP 12042A | PSI Card (Modem) OEM use |
| HP 12042B | PSI Card (Direct Connect) OEM use |
| HP 12044A | 1k DS Direct Connect |
| HP 12073A | 3k DS Modem |
| HP 12075A | X.25 Modem |
| HP 12082A | 3k DS Direct Connect |

VCP AUTO Execution – Complete Test Series

1. Initiate the VCP mode of computer operation. Press the BREAK key to enter VCP mode.
2. Insert disk/tape media in drive, or ensure that the hard disk diagnostic file is accessible.
3. Enter one of the following commands at the terminal, depending on the media or interface indicated:
 - `%BDCfbuscAUTO<cr>` (HP-IB tape, disk, or Micro/1000 internal subsystem; or SCSI disk)
 - `%BDIfbuscAUTO<cr>` (Micro/1000 internal subsystem with HP 12022A* Interface)
 - `%BMTfbuscAUTO<cr>` (HP-IB magnetic tape or SCSI Digital Audio Tape (DAT))
 - `%BDS000024AUTO<cr>` (DS/1000)

where:

f = file number. Use 0 for: (1) HP-IB or SCSI disk, (2) CS/80 cartridge tape (when using bootable tape 24998-13328 boot file 0 to read index on tape, then boot again specifying file in index), (3) SCSI DAT, or (4) disk dedicated as diagnostic media.

Use 1 for magnetic tape 24998-13540 to boot file 1 for index, then boot again specifying file in index.

Use 2 for: (1) magnetic tape, or (2) CS/80 primary diagnostic cartridge tape.

Use 6 for disk restored from primary tape.

NOTE: The above applies to rev. 4010, or later, of the diagnostics. For revision 2440 and 2540, BOOTEX requires two files; therefore, use f=2 for CS/80 primary diagnostic tape or disk restored from primary tape.

b = HP-IB and SCSI bus address or Micro/1000 internal subsystem drive address (use 3 for microdiskette or 0 for hard disk).

u = unit number. Use 0 for CS/80 disk drive that includes cartridge tape drive. Use 1 for cartridge tape drive. For the HP 7906, unit number is the head number. Use 0 for the HP 7907 fixed disk and 1 for the removable disk. For Micro/1000 internal subsystem, unit number always equals 0.

sc = Select code of the interface.

* Discontinued product; shown for reference only.

4. The Diagnostic Control System (DCS) will load and execute, and the terminal will return the configuration and status information.
5. All kernel and interface diagnostic programs in the AUTO file are then loaded and executed under the control of the DCS, with the following type of information returned to the terminal as each diagnostic executes:

```
BASIC INSTRUCTION DIAGNOSTIC  
PASS COMPLETE  
DIAGNOSTIC COMPLETE
```

Refer to Kernel and Interface Diagnostic Reference Manuals (part nos. 24612-90017 and 24612-90011, respectively) for additional operating and error information.

NOTE

A test failure will cause the series to stop and return an error message to the terminal. To proceed to the next diagnostic in the series, enter BYE<cr> following the DDL> prompt.

6. The AUTO program will select the appropriate diagnostics from the AUTO file. As each selected diagnostic program executes successfully, a pass message similar to that shown above, or an error message if a failure occurs, will return to the terminal display.

To obtain detailed error information, enter RUN E<cr>.

NOTE

Diagnostics for I/O cards not installed in the system will not be loaded when using AUTO file.

7. When all diagnostic programs complete successfully, control will return to the Basic Control Module (BCM) mode, with the BCM> prompt displayed.

```
END OF AUTO  
BCM>
```

Individual kernel and interface diagnostics can be run singly or looped any number of times.

VCP AUTO Execution – Single Test Execution

VCP AUTO Execution, Single Test Mode for HP-IB Cartridge Tape (CS/80) and disk, magnetic tape, Micro/1000 Disk Interface, and SCSI disk and Digital Audio Tape (DAT).

1. Initiate the VCP mode of computer operation. Press the BREAK key to enter VCP mode.
2. Insert disk/tape media in drive, or ensure that hard disk diagnostic file is accessible.
3. Enter the following command at the terminal:
%BxxfbusCAUTO,name,RU<cr>

where:

xx = DC for HP-IB tape, disk or Micro/1000 internal subsystem; or SCSI disk. DI for Micro/1000 internal subsystem with HP12022A* Interface. MT for HP-IB magnetic tape or SCSI DAT.

f = file number. Use 0 for: (1) HP-IB or SCSI disk, (2) CS/80 cartridge tape (when using bootable tape 24998-13328 boot file 0 to read index on tape, then boot again specifying file in index), (3) SCSI DAT, or (4) disk dedicated as diagnostic media.
Use 1 for magnetic tape 24998-13540 to boot file 1 for index, then boot again specifying file in index.
Use 2 for: (1) magnetic tape, or (2) CS/80 primary diagnostic cartridge tape.
Use 6 for disk restored from primary tape.

NOTE: The above applies to rev. 4010, or later, of the diagnostics. For revision 2440 and 2540, BOOTEX requires two files; therefore, use f=2 for CS/80 primary diagnostic tape or disk restored from primary tape.

b = HP-IB and SCSI bus address or Micro/1000 internal subsystem drive address (use 3 for microdiskette or 0 for hard disk).

u = unit number. Use 0 for CS/80 disk drive that includes cartridge tape drive. Use 1 for cartridge tape drive. For the HP 7906, unit number is the head number. Use 0 for the HP 7907 fixed disk and 1 for the removable disk. For Micro/1000 internal subsystem, unit number always equals 0.

sc = Select code of the interface.

name =
Mnemonic of diagnostic to be run. See AUTO file listing.

* Discontinued product; shown for reference only.

4. The following runstrings are also available:

a. `%BxxfbuscAUTO,DDL<cr>`

Load and configure the DCS only; stop in the DDL mode.

b. `%BxxfbuscAUTO,name<cr>`

Load DCS and diagnostic; stop in the DDL mode.

c. `%BxxfbuscAUTO,name,RU<cr>`

Load DCS and diagnostic; run the diagnostic one time.

d. `%BxxfbuscAUTO,name,RU L nn<cr>`

(for Kernel diagnostics only)

Load DCS and diagnostic; run and loop diagnostic nn times.
Default is 10 passes.

e. `%BxxfbuscAUTO,name,RU T<cr>`

(for Kernel diagnostics only)

Load DCS and diagnostic; display list of tests within diagnostic
“name”.

f. `%BxxfbuscAUTO,name,RU T a b [x][@sc]<cr>`

(for Kernel diagnostics only)

Load DCS and diagnostic; run test “a” within diagnostic “b”
times; continue on error if “x” is -1; stop on error if “x” is 0 at
select code “sc”.

x is optional; default is 0; @sc is for the I/O Master (IOM)
diagnostic only.

g. `%BxxfbuscAUTO,name,RU T a b @m @n<cr>`

(for Memory Array diagnostic only)

Load Diagnostic Control System (DCS) and diagnostic; run
test “a” within diagnostic “b” times; test “m” pages (octal) of
memory starting at page number “n”.

5. The Basic Control Module (BCM) will load and execute the DCS and diagnostic, and return the configuration and status information.
6. If the mini/micro-diskette is used, the following message will be returned to the terminal:

```
LOAD MINI DISC NO. XXX PRESS RETURN
```

Insert requested disk and press <cr>.

7. During execution, the diagnostic will return the following type of information:

```
XX XXXXXX XXXXXX    < diagnostic name.
SSSS PASSED          < diagnostic test pass/fail status.
PASS COMPLETE
DDL>
```

NOTE

A test failure will cause the diagnostic to stop and return an error message, followed by the DDL> prompt. To return to the BCM mode, enter BYE<cr> following the DDL> prompt.


8. To run an additional single test within the same diagnostic, refer to the runstring options above and begin runstring at RU. For example:

```
DDL> RU T a b [x] [@sc]<cr>
```

9. To return to the BCM mode and run a different diagnostic, first enter DDL> BYE<cr> followed by a BCM> CLEAR<cr>. The terminal will return the BCM> prompt. Refer to the runstring options above and begin the runstring at AUTO. For example:

```
BCM> AUTO,name<cr>
```

A-Series Diagnostic BOOT/LOAD Sequence



Operator Command Options

AUTO

Causes the Basic Control Module (BCM) to load and execute a selected configuration of the DCS and/or diagnostic programs.

- | | |
|-----------------------------------|---|
| BCM> <i>AUTO,LOOP</i> <cr> | Starts AUTO program, loads system diagnostics, loads and executes each of the diagnostics in the AUTO file. After a complete pass, the AUTO program restarts a pass of the diagnostics. |
| BCM> <i>AUTO</i> <cr> | Starts AUTO program, returns to BCM upon one complete diagnostic pass. |
| BCM> <i>AUTO,BCM</i> <cr> | Primarily used at bootup; returns directly to BCM. |
| BCM> <i>AUTO,DDL</i> <cr> | Will load and execute the Diagnostic Design Language (DDL) program. |
| BCM> <i>AUTO,name</i> <cr> | Loads the named diagnostic. If a DDL diagnostic, executes the DDL module. |
| BCM> <i>AUTO,name,string</i> <cr> | Loads the named diagnostic and processes the runstring. |
| BCM> <i>AUTO,-diag</i> <cr> | Sets skip flag on the diagnostic; not executed during complete pass/loop. (Only skips one diagnostic.) |
| BCM> <i>AUTO,+diag</i> <cr> | Resets skip flag on the diagnostic. |

SHOW

Used to display information about the DCS. Information is sent to the terminal or a device file. Format is:

```
BCM> SHOW,xxx,dv:fn
```

where xxx is:

```
BCM> SHOW,AUTO<cr>      Displays the auto file contents.
```

```
BCM> SHOW,ASSIGN<cr>    Displays a list of reference numbers, DVRs, SCs currently assigned.
```

```
BCM> SHOW,NAME<cr>     Displays the names of programs in memory.
```

```
BCM> SHOW,LOG<cr>      Displays the current log DVRF.
```

```
BCM> SHOW<cr>          Displays common area, base page area, program names, and memory available.
```

dv:fn Device reference number and file number to which data will be output (default is console).

ASSIGN

Used to assign reference numbers to drivers as they are loaded and made part of the Diagnostic Control System (DCS). All drivers, except the primary load device, must be loaded and linked before they are assigned. This is done for setting up a log device. For example:

1. The AUTO program loads the driver by name. i.e.,

```
BCM> AUTO,CTDVR<cr>
```

2. The SHOW,ASSIGN will display current driver assignments.
3. The ASSIGN command is used to configure the driver.

```
BCM> ASSIGN,dm, dvr name, SC, unit #[,HP-IB addr]
```

```
BCM> ASSIGN,2,CTDVR,22,1      (defines dvr ref #2 to the CTDVR, SC 22B, left CTU)
```

LOG

Assigns the Diagnostic Control System (DCS) log device to an existing DVRF assignment. All returned terminal information is echoed to the log device. Note that the log device cannot be placed under test.

```
BCM> LOG,dv:fn<cr>
```

The following example illustrates how to set up a log device. In this example, the HP 2631B is connected to an HP-IB Interface at select code 25B.

NOTE: The line printer driver, LPDVR, only supports the HP 2631B printer. Newer printers are not supported by LPDVR.

```
BCM> SHOW,ASSIGN      (shows the device drivers that are  
                      currently assigned)
```

```
DVRF 1 = DCDVR 27 0 02  
PRAMS xxxxxx xxxxxx xxxxxx xxxxxx xxxxxx xxxxxx
```

(where: DVRF 1 is the device reference number.
DCDVR is the device reference name.
27 is the select code.
0 is the unit number.
02 is the HP-IB address.)

```
BCM> AUTO,LPDVR      (loads the line printer driver, LPDVR)
```

```
BCM> ASSIGN,2,LPDVR,25,0,6
```

(assigns the line printer driver to:
device reference number = 2,
select code = 25,
unit number = 0,
HP-IB address = 6 (2631B in primary))

```
BCM> SHOW,ASSIGN  
DVRF 1 = DCDVR 27 0 02  
PRAMS xxxxxx xxxxxx xxxxxx xxxxxx xxxxxx xxxxxx  
DVRF 2 = LPDVR 25 0 06  
PRAMS xxxxxx xxxxxx xxxxxx xxxxxx xxxxxx xxxxxx
```

```
BCM> LOG,2           (sets up log device to driver reference  
                    number 2; the line printer has HP-IB  
                    address 6)
```

```
BCM> FREEZE         (saves all device driver assignments and log  
                    assignments in memory)
```

FREEZE

Freezes the current memory state of the Diagnostic Control System (DCS) to include all new Device Reference Number (DVRF) log assignments, and program additions.

BCM> *FREEZE*

RESET

Used to clear all device drivers and to reset the computer; current memory and program information is displayed.

BCM> *RESET*

COPY

Duplicates files from one media to another. Copies the entire file to the end of the file mark, and writes a file mark to the new device.

BCM> *COPY, dv:fn, dv:fn<cr>*

CLEAR

Clears all unfrozen programs and DVRF assignments from memory. It should usually be executed upon completion of a diagnostic execution.

EXIT

Terminates BCM.

Diagnostic Design Language (DDL)

The HP Diagnostic Design Language consists of statements for writing diagnostic programs and commands for controlling program execution. The language is intended to provide the operator with the ability to communicate with all A/L-Series interface cards and peripherals in a high-level interpretive language while providing the flexibility of maintaining control of the flip-flops, registers, and hardware features.

All HP 24612A diagnostics are written using DDL. Valid DDL commands are listed in Table DDL-1. Table DDL-2, on the following page, lists valid DDL statements and Table DDL-3 shows DDL statements with specific select code parameters that have special defined functions.

CPU interrupts are handled in order of priority as shown below with the highest priority at the top of the list:

| Interrupt | Type | Select Code (octal) |
|---------------------------|-------------|----------------------------|
| Parity Error | 1 | 5 |
| Unimplemented Instruction | 1 | 10 |
| Memory Protect | 2 | 7 |
| Slave Request (VCP) | 2 | 17 |
| Power Fail | 2 | 4 |
| Time Base Generator | 3 | 6 |
| Interface (I/O) | 3 | 20-77 |

For Additional information on DDL refer to the *Diagnostic Design Language Operating and Programming Manual* (part no. 24612-90015). To load and execute DDL from BCM, refer to the Operator Command Options section. Note that only uppercase letters are used following the DDL> prompt.

Table DDL-1. Valid DDL Operator Commands

| Command | Command Meaning |
|-----------|-----------------------------------|
| BREAK | Suspend Current Program Execution |
| BYE | Exit DDL (returns to BCM or AUTO) |
| COMMENTS | Show Comments in Statement File |
| DELETE | Delete Statement File |
| DUMP | Save Statement File in Binary |
| EDIT | Edit Statement Line |
| LIST | List Statement File |
| LOAD | Load Statement File |
| MAP | Map Function |
| PROGRAM | Print Program Statements |
| RENUMBER | Renumber Current Statement File |
| RUN | Execute Current DDL Program |
| SAVE | Save Statement File |
| SIZE | Show Statement File Size |
| UNDEFINED | Show Undefined Statement List |

Table DDL-2. Valid DDL Operator Statements

| Statement | Statement Meaning |
|------------|---|
| ASC | ASCII Character String |
| BUF | Buffer Definition |
| CFS | Check for Stop |
| CLC | Clear Control |
| CLCC | Clear Control and Clear Flag |
| CLF | Clear Flag |
| CPBF | Compare Buffers |
| DVRQ | Device Request |
| DVIO | Device Input/Output |
| DLY | Delay |
| FMT | Format |
| GOSB/RTN | Go To Subroutine/Return |
| GOTO | Go To |
| GTSC | Get I/O Card Select Code |
| HOOD | Check if Hood is Installed |
| IPB | Initialize Buffer Pattern |
| INTP/READ | Input/Read |
| INT | Interrupt Pointer |
| IOA,B,C,D | Create I/O Subroutine |
| IOCA,B,C,D | Clear I/O Subroutine |
| IORA,B,C,D | Execute I/O Subroutine |
| LET | Let Assignment |
| LETC | Let and Check for Overflow |
| LIA | Load Input Into A-Register |
| LIAC | Load Input Into A-Register and Clear Flag |
| MAP | Mapping |
| OTA | Output A-Register |
| OTAC | Output A-Register and Clear Flag |
| PRGM | Program Identification Statement |
| PRNT/WRIT | Print/Write |
| REM | Program Remark/Comment |
| SFC | Skip if Flag is Clear |
| SFS | Skip if Flag is Set |
| SKIF | Skip If |
| STC | Set I/O Control |
| STCC | Set Control and Clear Flag |
| STF | Set Flag |
| STOP | Stop Program Execution |
| WAIT | Wait |
| WFI | Wait for Interrupt |
| YES? | Input a Yes or No Response |

Table DDL-3. DDL Special Statement Function Summary

| Statement | S. Code | Statement Meaning |
|-----------|---------|---------------------------------------|
| CLC | 0 | Asserts the CPU Control Reset Signal |
| CLF | 0 | Disables Type 3 Interrupts |
| LIA | 0 | Read Interrupt Mask |
| OTA | 0 | Write Interrupt Mask |
| SFC | 0 | Skip if Type 3 Interrupts Disabled |
| SFS | 0 | Skip if Type 3 Interrupts Enabled |
| STF | 0 | Enable Type 3 Interrupts |
| LIA | 1 | Read Processor Status Register |
| OTA | 1 | Write To Processor LEDs |
| CLC | 2 | Enable Boot ROM (L/XL) |
| CLF | 2 | Enable Global Register |
| LIA | 2 | Read Global Register |
| OTA | 2 | Write Global Register/Diagnose Mode |
| SFC | 2 | Skip if Global Register Enabled |
| SFS | 2 | Skip if Global Register Disabled |
| STC | 2 | Disable Boot ROM/Enable Slave Logic |
| STF | 2 | Disable Global Register |
| CLC | 3 | VCP: Execute 3 instructions and Break |
| LIA | 3 | VCP: Read P Save Register |
| LIAC | 3 | VCP: Read VCP Starting Address |
| OTA | 3 | VCP: Write P Save Register in I/O |
| OTAC | 3 | VCP: Write VCP Starting Address |
| CLC | 4 | Disable Type 2 and Type 3 Interrupts |
| LIA | 4 | Read Central Interrupt Register (CIR) |
| OTA | 4 | Write Central Interrupt Register |
| SFC | 4 | Skip if Power is Going Down (PFW) |
| SFS | 4 | Skip if Power is Going Up |
| STC | 4 | Enable Type 2 and Type 3 Interrupts |
| CLC | 5 | Disable Parity Interrupt |
| CLF | 5 | Clear Parity Sense to Odd (L/XL) |
| LIA | 5 | Read Parity Register (lower bits) |
| LIAC | 5 | Read Parity Register (upper bits) |
| SFC | 5 | Skip if Odd Parity Sense |
| SFS | 5 | Skip if Even Parity Sense |
| STC | 5 | Enable Parity Interrupt |
| STF | 5 | Set Parity Sense to Even (L/XL) |
| CLC | 6 | Turn Off Time Base Generator (TBG) |
| CLF | 6 | Clear TBG Flag |
| SFC | 6 | Skip if TBG Flag is Clear |
| SFS | 6 | Skip if TBG Flag is Set |
| STC | 6 | Turn On TBG |
| STF | 6 | Set the TBG Flag |

Table DDL-3. DDL Special Statement Function Summary (cont.)

| Statement | S. Code | Statement Meaning |
|-----------|---------|-----------------------------------|
| LIAC | 7 | Read the Violation Register |
| OTA | 7 | Write Memory Protect Fence (L/XL) |
| OTAC | 7 | Write Violation Register |
| STC | 7 | Turn On Memory Protect |
| CLC | 20# | Disable DMA selfconfiguration |
| CLF | 20# | Clear Flags 20 and 21 |
| LIA | 20# | Read DMA configuration address |
| OTA | 20# | Write DMA configuration address |
| SFC | 20# | Skip if Flag 20 is Clear |
| SFS | 20# | Skip if Flag 20 is Set |
| STC | 20# | Enable DMA selfconfiguration |
| STF | 20# | Set Flag 20 |
| CLC | 21# | Disable DMA transfers |
| CLF | 21# | Clear Flag 21 |
| LIA | 21# | Read DMA control word |
| OTA | 21# | Write DMA control word |
| SFC | 21# | Skip if Flag 21 is Clear |
| SFS | 21# | Skip if Flag 21 is Set |
| STC | 21# | Enable DMA Transfers |
| STF | 21# | Set Flag 21 |
| CLC | 22# | Force DMA reconfiguration |
| CLF | 22# | Clear Flag 22 |
| LIA | 22# | Read DMA Address |
| OTA | 22# | Write DMA Address |
| SFS | 22# | Skip if Flag 22 is Set |
| STF | 22# | Set Flag 22 |
| CLC | 23# | Terminate DMA operation |
| CLF | 23# | Clear Flags 20-22 |
| LIA | 23# | Read DMA Count Register |
| OTA | 23# | Write DMA Count Register |
| SFC | 23# | Skip if All Flags 20-22 are Clear |
| SFS | 23# | Skip if Any Flags 20-22 are Set |
| LIA | 24# | Read Scratch Register 1 |
| OTA | 24# | Write Scratch Register 1 |
| SFS | 24# | Skip if DMA Enabled |
| SFC | 24# | Skip if DMA Disabled |
| LIA | 25# | Read Scratch Register 2 |
| OTA | 25# | Write Scratch Register 2 |
| LIA | 26# | Read Scratch Register 3 |
| OTA | 26# | Write Scratch Register 3 |

Requires Global Register Enabled

Table DDL-3. DDL Special Statement Function Summary (cont.)

| Statement | S. Code | Statement Meaning |
|-----------|---------|--------------------------------|
| CLC | 30# | Clear Control 30 |
| CLF | 30# | Clear Flag 30 |
| LIA | 30# | Read Data Register |
| OTA | 30# | Write Data Register |
| SFC | 30# | Skip if Flag 30 is Clear |
| SFS | 30# | Skip if Flag 30 is Set |
| STC | 30# | Set Control 30 and issue DVCMD |
| STF | 30# | Set Flag 30 |
| LIA | 31# | Read Control Word |
| OTA | 31# | Write Control Word |
| LIA | 32-77# | Read Card Status Register |
| OTA | 32-77# | Card Reset |
| CLC | s.c. | Clear Control 30 flip-flop |
| CLF | s.c. | Clear Flag 30 flip-flop |
| LIA | s.c. | Read Device Data Register |
| OTA | s.c. | Write Device Data Register |
| SFC | s.c. | Skip if Flag 30 is Clear |
| SFS | s.c. | Skip if Flag 30 is Set |
| STC | s.c. | Set Control 30 and issue DVCMD |
| STF | s.c. | Set Flag 30 flip-flop |

Requires Global Register Enabled

HP 24612A Diagnostic Media Allocation

The following table is available with all HP 24612A media options. This is an example of the AUTO file structure. Both relocatable (%), and memory image (!) or (\$) files are provided so that custom diagnostic media can be created. The file type column indicates:

- 0 = System module loaded on the first execution of AUTO
- 1 = Utility program loaded only when necessary
- 2 = Driver routine
- 3 = Kernel diagnostic
- 4 = Interface diagnostic

Diagnostic programs are accessed by file name only through the AUTO program of the Basic Control Module (BCM) in the Diagnostic Control System (DCS). The AUTO program accesses diagnostics by BCM file number. If a custom diagnostic media is to be generated using a new user-written Diagnostic Design Language (DDL) diagnostic, the BCM file system numbering becomes important. You can create an AUTO file that can act as a media directory to associate diagnostics with actual file location. But this special operating system that uses the AUTO program to access files (much like FMGR or CI in RTE) uses file sizes of 32 blocks each. Thus, if you are using RTE to create new diagnostic media and create new files on the media, you must ensure that all files are in 32 block increments so that the AUTO file can access the programs when BCM is in control. Because of this need to coordinate RTE and BCM files, additional information is included in this listing of the AUTO file.

The CARTRIDGE TAPE.FILE column indicates which CTU tape (HP 264X or HP-85) contains which files. The “.file” number indicates the file number on a particular tape, but BCM actually uses the file number that is in parentheses.

The next column indicates how big each file is in terms of RTE blocks (1 RTE block = 256 bytes), and how big each file must be made when the diagnostic media is being created when using an RTE Operating System. Diagnostic files must be on the media in even multiples of the 32 block per file requirement of BCM. The BCM file number is indicated in parentheses.

The PROM column is useful only for users who develop their own diagnostic PROMs.

The DS column lists the P-file number as well as the BCM number. This sequential file numbering list also applies to magnetic tape.

The #AUTO file can be listed to indicate revision level, file number, size, and media allocation for CTUs. After the BCM prompt, enter SHOW,AUTO to list the #AUTO file.

BCM AUTO File Allocation, rev. 5000, 5010, and 5020

| | Name | Type | Cartridge tape.file | Disk RTE blk | .BCM blk | PROM BD.RMS | DS P-file |
|--------|--------|----------|------------------------|-----------------|--------------|----------------|--------------|
| | BCMDR | # | 0.2 (2) | 64 | 1.64 (0-1) | 1.4 (0-3) | 0 (0) |
| | #AUTO | # | 0.3 (3) | 25 | 1.32 (2) | 1.2 (4-5) | 1 (1) |
| | %MAPS | 0 | 0.4 (4) | 4 | 1.32 (3) | 1.1 (6) | 2 (2) |
| | %MSGs | 0 | 0.5 (5) | 16 | 1.32 (4) | 1.1 (7) | 3 (3) |
| | %DDL | 0 | 0.6 (6) | 96 | 1.96 (5-7) | 1.6 (8-13) | 4 (4) |
| DCS | %DEBUG | 1 | 0.7 (7) | 29 | 1.32 (8) | | 5 (5) |
| | %LPDVR | 2 | 0.8 (8) | 4 | 1.32 (9) | | 6 (6) |
| | %CTDVR | 2 | 0.9 (9) | 10 | 1.32 (10) | 1.1 (14) | 7 (7) |
| | %DCDVR | 2 | 0.10 (10) | 17 | 1.32 (11) | 1.1 (15) | 10 (8) |
| | %DSDVR | 2 | 0.11 (11) | 6 | 1.32 (12) | | 11 (9) |
| | %RMDVR | 2 | 0.12 (12) | 3 | 1.32 (13) | | 12 (10) |
| | %MTDVR | 2 | 0.13 (13) | 13 | 1.32 (14) | | 13 (11) |
| | %DIDVR | 2 | 0.14 (14) | 11 | 1.32 (15) | | 14 (12) |
| | %CPU | 3 | 1.2 (18) | 47 | 1.64 (16-17) | | 15 (13) |
| | !CPU | 3 | 1.3 (19) | 16 | 1.32 (18) | | 16 (14) |
| %MAD | 3 | 1.4 (20) | 17 | 1.32 (19) | | 17 (15) | |
| %MADMG | 3 | 1.5 (21) | 16 | 1.32 (20) | | 20 (16) | |
| !MAD | 3 | 1.6 (22) | 50 | 1.64 (21-22) | | 21 (17) | |
| Kernel | !MCDXL | 3 | 1.7 (23) | 45 | 1.64 (23-24) | | 22 (18) |
| | %MCD | 3 | 1.8 (24) | 34 | 1.64 (25-26) | | 23 (19) |
| | !MCD | 3 | 1.9 (25) | 28 | 1.32 (27) | | 24 (20) |
| | %SFD | 3 | 1.10 (26) | 26 | 1.32 (28) | | 25 (21) |
| | !SFD | 3 | 1.11 (27) | 32 | 1.32 (29) | | 26 (22) |
| | %IOM | 3 | 1.12 (28) | 30 | 1.32 (30) | | 27 (23) |
| | !IOM | 3 | 1.13 (29) | 25 | 1.32 (31) | | 30 (24) |
| | %EIG | 3 | 2.2 (34) | 56 | 2.64 (32-33) | | 31 (25) |
| | !EIG | 3 | 2.3 (35) | 31 | 2.32 (34) | | 32 (26) |
| | %FPD | 3 | 2.4 (36) | 58 | 2.64 (35-36) | | 33 (27) |
| Kernel | !FPD | 3 | 2.5 (37) | 28 | 2.32 (37) | | 34 (28) |
| | %LIS | 3 | 2.6 (38) | 49 | 2.64 (38-39) | | 35 (29) |
| | !LIS | 3 | 2.7 (39) | 32 | 2.32 (40) | | 36 (30) |
| | %SIS | 3 | 2.8 (40) | 29 | 2.32 (41) | | 37 (31) |
| | !SIS | 3 | 2.9 (41) | 24 | 2.32 (42) | | 40 (32) |
| | %CDSBI | 3 | 3.1 (50) | 51 | 2.64 (43-44) | | 41 (33) |
| Kernel | !CDSBI | 3 | 3.2 (51) | 26 | 2.32 (45) | | 42 (34) |
| | %CDSPC | 3 | 3.3 (52) | 27 | 2.32 (46) | | 43 (35) |
| | !CDSPC | 3 | 3.4 (53) | 26 | 2.32 (47) | | 44 (36) |
| | !ASIC | 4 | 4.2 (66) | 36 | 2.64 (48-49) | | 45 (37) |
| Intf. | !HPIB | 4 | 4.3 (67) | 47 | 2.64 (50-51) | | 46 (38) |
| | !PIC | 4 | 4.4 (68) | 27 | 2.32 (52) | | 47 (39) |
| | !PROM | 4 | 4.5 (69) | 16 | 2.32 (53) | | 50 (40) |
| | !WCS | 4 | 4.6 (70) | 14 | 2.32 (54) | | 51 (41) |
| | !CSIC | 4 | 4.7 (71) | 24 | 2.32 (55) | | 52 (42) |
| | !PSI | 4 | 4.7 (72) | 75 | 2.96 (56-58) | | 53 (43) |
| | !MUX | 4 | 4.8 (73) | 22 | 2.32 (59) | | 54 (44) |
| | !FDL | 4 | 4.9 (74) | 40 | 2.64 (60-61) | | 55 (45) |
| | !DID | 4 | 4.2 (75) | 59 | 2.64 (62-63) | | 56 (46) |
| | !AOUTD | 4 | 5.2 (82) | 32 | 3.64 (64-65) | | 57 (47) |
| Intf. | !AIMXD | 4 | 5.3 (83) | 56 | 3.64 (66-67) | | 60 (48) |
| | !DIGIO | 4 | 5.4 (84) | 38 | 3.64 (68-69) | | 61 (49) |
| | %OBIO | 4 | 5.5 (85) | 14 | 3.32 (70) | | 62 (50) |
| | !OBIO | 4 | 5.6 (86) | 75 | 3.96 (71-73) | | 63 (51) |
| | !BCM | # | 5.7 | 54 | 3.64 (74-75) | | |
| | !CTDVR | # | 5.8 | 5 | 3.32 (76) | | |
| Syst. | !DCDVR | # | 5.9 | 9 | 3.32 (77) | | |
| | !DSDVR | # | 5.10 | 3 | 3.32 (78) | | |
| | !RMDVR | # | 5.11 | 2 | 3.32 (79) | | |
| | !MTDVR | # | 5.12 | 6 | 3.32 (80) | | |
| | !DIDVR | # | 5.13 | 6 | 3.32 (81) | | |
| | %PFCON | # | 5.14 | 11 | 3.32 (82) | | |
| | A24612 | # | 5.15 | 27 | 3.32 (83) | | |

not in AUTO file

BCM AUTO File Allocation, rev. 5270

At RTE-A revision 5270, the columns for the mini-cartridge tape file numbers and the PROM file numbers were removed from the #AUTO file. Also, file number allocations were added for DAT and Magnetic Tape.

| | Name | Type | Disk Block (BCM File) | DS P-file (BCM file) | DAT/Mag Tape File | |
|--------|--------|---------|--------------------------|-------------------------|----------------------|------|
| DCS | Driver | * | 64 (0-1) | 0 (0) | (0) | |
| | #AUTO | * | 32 (2) | 1 (1) | (1) | |
| | %MAPS | 0 | 32 (3) | 2 (2) | (2) | |
| | %MSGGS | 0 | 32 (4) | 3 (3) | (3) | |
| | %DDL | 0 | 96 (5-7) | 4 (4) | (4) | |
| | %DEBUG | 1 | 32 (8) | 5 (5) | (5) | |
| | %LPDVR | 2 | 32 (9) | 6 (6) | (6) | |
| | %DCDVR | 2 | 32 (10) | 7 (7) | (7) | |
| | %DSDVR | 2 | 32 (11) | 10 (8) | (8) | |
| | %MTDVR | 2 | 32 (12) | 11 (9) | (9) | |
| | %SCDVR | 2 | 32 (13) | 12 (10) | (10) | |
| | %STDVR | 2 | 32 (14) | 13 (11) | (11) | |
| | Kernel | %CPU | 3 | 64 (15-16) | 14 (12) | (12) |
| | | !CPU | 3 | 32 (17) | 15 (13) | (13) |
| %MAD | | 3 | 32 (18) | 16 (14) | (14) | |
| %MADMG | | 3 | 32 (19) | 17 (15) | (15) | |
| !MAD | | 3 | 64 (20-21) | 20 (16) | (16) | |
| !MCDXL | | 3 | 64 (22-23) | 21 (17) | (17) | |
| %MCD | | 3 | 64 (24-25) | 22 (18) | (18) | |
| !MCD | | 3 | 32 (26) | 23 (19) | (19) | |
| %SFD | | 3 | 32 (27) | 24 (20) | (20) | |
| !SFD | | 3 | 32 (28) | 25 (21) | (21) | |
| %EIG | | 3 | 64 (29-30) | 26 (22) | (22) | |
| !EIG | | 3 | 32 (31) | 27 (23) | (23) | |
| %IOM | | 3 | 32 (32) | 30 (24) | (24) | |
| !IOM | | 3 | 32 (33) | 31 (25) | (25) | |
| %FPD | | 3 | 64 (34-35) | 32 (26) | (26) | |
| !FPD | | 3 | 32 (36) | 33 (27) | (27) | |
| %LIS | | 3 | 64 (37-38) | 34 (28) | (28) | |
| !LIS | | 3 | 32 (39) | 35 (29) | (29) | |
| %SIS | | 3 | 32 (40) | 36 (30) | (30) | |
| !SIS | | 3 | 32 (41) | 37 (31) | (31) | |
| %CDSBI | | 3 | 64 (42-43) | 40 (32) | (32) | |
| !CDSBI | | 3 | 32 (44) | 41 (33) | (33) | |
| %CDSPC | | 3 | 32 (45) | 42 (34) | (34) | |
| !CDSPC | | 3 | 32 (46) | 43 (35) | (35) | |
| %A990D | 3 | 32 (47) | 44 (36) | (36) | | |
| !A990D | 3 | 32 (48) | 45 (37) | (37) | | |

Notes: 1. All numbers in parenthesis are BCM files. 2. * = not in AUTO file

BCM AUTO File Allocation, rev. 5270 (cont.)

| | Name | Type | Disk Block (BCM File) | DS P-file (BCM file) | DAT/Mag Tape File |
|-----------|--------|-------|--------------------------|-------------------------|----------------------|
| Interface | !SCSI | 4 | 96 (49) | 46 (38) | (38) |
| | !ASIC | 4 | 64 (52-53) | 47 (39) | (39) |
| | !HPIB | 4 | 64 (54-55) | 50 (40) | (40) |
| | !PIC | 4 | 32 (56) | 51 (41) | (41) |
| | !PROM | 4 | 32 (57) | 52 (42) | (42) |
| | !WCS | 4 | 32 (58) | 53 (43) | (43) |
| | !MUX | 4 | 32 (59) | 54 (44) | (44) |
| | !PSI | 4 | 96 (60-62) | 55 (45) | (45) |
| | !CSIC | 4 | 32 (63) | 56 (46) | (46) |
| | !FDL | 4 | 64 (64-65) | 57 (47) | (47) |
| | !DID | 4 | 64 (66-67) | 60 (48) | (48) |
| | !AOUTD | 4 | 64 (68-69) | 61 (49) | (49) |
| | !AIMXD | 4 | 64 (70-71) | 62 (50) | (50) |
| | !DIGIO | 4 | 64 (72-73) | 63 (51) | (51) |
| | %OBIO | 4 | 32 (74) | 64 (52) | (52) |
| | System | !OBIO | 4 | 96 (75-77) | 65 (53) |
| !BCM | | * | 64 | | |
| !DCDVR | | * | 32 | | |
| !DSDVR | | * | 32 | | |
| !MTDVR | | * | 32 | | |
| !SCDVR | | * | 32 | | |
| !STDVR | | * | 32 | | |
| %PFCON | | * | 32 | | |

Notes: 1. All numbers in parenthesis are BCM files. 2. * = not in AUTO file

HP 24612A Diagnostic Media Options

Option 044, 3.5-Inch Floppies

| Part Number | Label | Revision |
|--|---|----------------------|
| 24612 -13409 -13410 -13411 -13412 | A-SERIES DIAGNOSTICS#0 #1 #2 A/1000 MICRO-FLOPPY#0 | 2440 thru 5020 |
| 24612 -13409 -13410 -13411 | A-SERIES DIAGNOSTICS#0 #1 #2 | 5270 |

Note that the 24612-13409 is the first diskette inserted into an HP 9121D/S or 9133X microflexible disk drive. The 24612-13412 is the first diskette used if the drive is in a Micro/1000 product using the HP 12022A interface/controller. The 24612-13410 and 24612-13411 are used in either drive.

Option 022, CS/80 Cartridge Tape

| | | |
|--------------|----------------------|----------------------|
| 24612 -13311 | A-SERIES DIAGNOSTICS | 2440 thru 5270 |
|--------------|----------------------|----------------------|

Option 051, 1600 bpi Magnetic Tape

| | | |
|--------------|----------------------|----------------------|
| 24612 -13501 | A-SERIES DIAGNOSTICS | 2440 thru 5270 |
|--------------|----------------------|----------------------|

Option AAH, SCSI DAT Tape

| | | |
|-------------|----------------------|------|
| 24612-13326 | A-SERIES DIAGNOSTICS | 5270 |
|-------------|----------------------|------|

CS/80 Super Tape, RTE-A + HP 24612A + HP 24398B

To boot diagnostics, first boot file 1 (CINFO file) to list the name and file number of the bootable files on the tape. Then, boot from the tape again using the file number given in CINFO for the file that you want to boot. To boot file 1 use one of the following bootstrings:

VCP> %BDC127 for CS/80 tape

VCP> %BDC1027 for HP 9144 tape

| | | |
|--------------|--|----------------------|
| 24998 -13328 | 24612A/24398B Diagnostics, IARSTR, IVSCSI, FORMF | 5000 thru 5270 |
|--------------|--|----------------------|

1600 bpi Super Tape, RTE-A + HP 24612A + HP 24398B

To boot diagnostics, first boot file 1 (TINFO file) to list the name and file number of the bootable files on the tape. Then, boot from the tape again using the file number given in TINFO for the file that you want to boot. To boot file 1 use one of the following bootstrings:

VCP> %BMT14027 for HP 7970 Mag tape drive

VCP> %BMT13027 for HP 7974/7978 Mag tape drive

| | | |
|--------------|--|----------------------|
| 24998 -13540 | 24612A/24398B Diagnostics, IARSTR, IVSCSI, FORMF | 5000 thru 5270 |
|--------------|--|----------------------|

SCSI DAT Tape, RTE-A + HP 24612A + HP 24398B

To boot diagnostics, first boot file 1 (TINFO file) to list the name and file number of the bootable files on the tape. Then, boot from the tape again using the file number given in TINFO for the file that you want to boot. To boot file 1 use the following bootstring:

VCP> %BMT15027

| | | |
|--------------|--|------|
| 24998 -13614 | 24612A/24398B Diagnostics, IARSTR, IVSCSI, FORMF | 5270 |
|--------------|--|------|

HP 24612A KERNEL Diagnostics

KERNEL Diagnostic Summary¹

- Basic Instruction Diagnostic (CPU)
- Memory Array Diagnostic (MAD/MADMG)
- Memory Controller Diagnostic XL (MCDXL)
- Memory Controller Diagnostic (MCD)
- System Function Diagnostic (SFD)
- I/O Master Diagnostic (IOM)
- Expanded Instruction Diagnostic (EIG)
- Floating Point Diagnostic (FPD)
- Language Instruction Set (LIS)
- Scientific Instruction Set (SIS)
- Code and Data Separation Basic Instruction Diagnostic (CDSBI)
- Code and Data Separation Procedural Call Diagnostic (CDSPC)
- A990 Instructions Diagnostic (A990D)

Note:

For all KERNEL diagnostics, two additional run options are available:

- RU,T allows independent selection of diagnostic subsections.
- RU,E will give error reporting details. If no errors were found while running the diagnostic, typing “RU,E” will, in some cases, produce an error itself.
- RU,L allows looping nn number of times.

Basic Instruction Diagnostic (CPU)

| Number | Description |
|--------|-------------------------|
| 1 | (ASG.T) ALTER SKIP GRO. |
| 2 | (MRG.O) MEM. REF. & OV |
| 3 | (IN*.T) INA/INB TEST |
| 4 | (MRG.T) MEM. REF. GRO. |
| 5 | (MRG.I) MRG IND. TST |
| 6 | (SRG.T) SHIFT ROTATE |
| 7 | (EAU.T) EXTENDED ARITH. |
| 8 | (JL*.T) JLA/JLB TEST |
| 9 | (ASG.E) EXTENDED ASG |
| -1 | (EXIT) EXIT RUN T MODE |

¹ In addition to the HP 24612A Kernel Diagnostics, the Vector Instruction Set (VIS) Diagnostic is available to test the A700 and A900 VIS instruction sets. It

is an online diagnostic available with RTE-A. Refer to the Vector Instruction Set (VIS) Diagnostic section at the end of this chapter.

Card Replacement Order

If any instruction failed during the CPU diagnostic tests, replace the computer cards in the following sequence, repeating the diagnostic between the replacement of each card, until the fault is eliminated. If you are testing an A400 or A990 board, the board must be swapped if an error occurs.

| A600/A600+ | A700* | A900 |
|----------------------|----------------------|----------------------|
| 1. Processor | 1. Lower Processor | 1. Data Path |
| 2. Memory Controller | 2. Upper Processor | 2. Sequencer |
| 3. Memory Array | 3. Memory Controller | 3. Cache Control |
| 4. Frontplane | 4. Memory Array | 4. Memory Controller |
| | 5. Floating Point | 5. Memory Array |
| | 6. Frontplane | |

Memory Array Diagnostic (MAD) A400/A600/A700*; (MADMG) A900/A990

| Number | Description |
|---------------|--------------------------------|
| 1 | (MADDT) Memory Address Test |
| 2 | (MPATT) Memory Pattern Test |
| 3 | (MWCPT) Worst Case Pattern |
| 4 | (MADPT) Address Parity Test |
| 5 | (MSBPT) Soccer Ball Pattern |
| 6 | (MPEIT) Parity Error Interrupt |

Tests 7-9 require ECA memory

| | |
|----|-----------------------------|
| 7 | (ECCBP) ECA CB Pattern Test |
| 8 | (ECADP) CB Address Parity |
| 9 | (ECSBP) CB Soccer Ball Test |
| -1 | (EXIT) To Exit |

Card Replacement Order

An error message following a MAD execution failure defines the memory area that failed. Using this information, proper memory card replacement is completed by determining which card carries the physical page of memory that failed.

In addition, the parity LED located on the failed memory array PCA (including A600/A600+ controller and the A400 board) will also be in the off state.

* Discontinued product; shown for reference only.

Execution Times

The following table indicates the approximate memory array diagnostic execution times for the configuration indicated.

| A400/600+/700 | A900 | A990 |
|----------------------|------------------|--------------------|
| 512 Kb ≈ 3 min. | 1.5 Mb ≈ 4 min. | 1.5 Mb ≈ 2.25 min. |
| 2 Mb ≈ 16 min. | 8 Mb ≈ 28 min. | 8 Mb ≈ 15.5 min. |
| 8 Mb ≈ 71 min. | 32 Mb ≈ 120 min. | 32 Mb ≈ 66.66 min. |
| 32 Mb ≈ 270 min. | | |

Memory Controller Diagnostic (MCDXL*)

L/XL Memory Controller

| Number | Description |
|---------------|-----------------------------------|
| 1 | Cross Load/Cross Store Functional |
| 2 | Cross Load/Cross Store RAM |
| 3 | Map Enable |
| 4 | DMA/Map Enable |

Card Replacement Order

The card replacement order for an error during execution on the XL memory controller diagnostic is as follows:

- XL Processor**
- 1. Memory Controller
- 2. I/O card w/ matching SC
- 3. Memory Array
- 4. Processor

* Discontinued product; shown for reference only.

Memory Controller Diagnostic (MCD)

A400/A600/A600+/A700*/A900/A990 Memory Controller

| Number | | Description |
|--------|---------|-------------------------------------|
| 1 | (INSTR) | Data 1 Instruction Check |
| 2 | (MVWB1) | XMOVE (0&1) w/int |
| 3 | (MRSTR) | Map RAM Storage Check |
| 4 | (MPACC) | Mapped Access Check |
| 5 | (MWPCT) | Memory Write Protect |
| 6 | (INSTR) | Data 2 Instruction Check |
| 7 | (MVWB2) | XMOVE (0,1,&2) w/int |
| 8 | (MRPCT) | MPT Read Check |
| 9 | (SBECT) | Single Bit Error (ECA) [†] |
| 10 | (DBECT) | Double Bit Error (ECA) [†] |
| -1 | (EXIT) | To Exit |

Card Replacement Order

The following provides the card replacement order for an error during execution of Tests 1 through 8 of the MCD on the A600+/A700*/A900. If you are testing an A400 or A990 board, the board must be swapped if an error occurs.

| A600/A600+ | A700* | A900 |
|----------------------|----------------------|----------------------|
| 1. Memory Controller | 1. Memory Controller | 1. Cache Control |
| 2. Memory Array | 2. Memory Array | 2. Memory Controller |
| 3. Processor | 3. Upper Processor | 3. Sequencer |
| | | 4. Data Path |
| | | 5. Memory Array |

The following provides the card replacement order for an error during execution of Test 9 and 10 of the MCD with the A700* only:

A700* Processor

1. Error Correcting Array
2. Memory Controller
3. Upper Processor

* Discontinued product; shown for reference only.

† A700 only

System Function Diagnostic (SFD)

These tests run on all A-Series computers except that Test 7 (BDPTY) is not run on the A900 or A990 processor.

| Number | | Description |
|--------|---------|-----------------------------|
| 1 | (PIOFT) | Processor I/O Function |
| 2 | (TBTST) | Check all TBG Functions |
| 3 | (MPTST) | Memory Protect Test |
| 4 | (UITST) | Unimplemented Instruction |
| 5 | (MLIIT) | Multi-Level Indirect |
| 6 | (OSULT) | Operating System Utilities |
| 7 | (BDPTY) | Instruction with Bad Parity |
| 8 | (PWRFL) | Power Fail Interrupt |
| -1 | (EXIT) | To Exit |

Card Replacement Order

Card replacement order for errors in Tests 1 through 7 are as follows (if you are testing an A400 or A990 board, the board must be swapped if an error occurs):

| A600/A600+ | A700* | A900 |
|----------------------|----------------------|----------------------|
| 1. Processor | 1. Lower Processor | 1. Memory Controller |
| 2. Memory Controller | 2. Upper Processor | 2. Cache Control |
| | 3. Memory Controller | 3. Sequencer |

Card replacement order for Test 8 is as follows (if you are testing an A400 or A990 board, the board must be swapped if an error occurs):

| A600/A600+ | A700* | A900 |
|----------------------|----------------------|----------------------|
| 1. Battery Backup | 1. Battery Backup | 1. Batt/Pwr Supply |
| 2. Memory Controller | 2. Memory Controller | 2. Sequencer |
| 3. Processor | 3. Lower Processor | 3. Data Path |
| | 4. Upper Processor | 4. Cache Control |
| | | 5. Memory Controller |
| | | 6. Memory Arrays |

The Power Fail test requires cycling power twice since the first power cycle will fail.

* Discontinued product; shown for reference only.

I/O Master Diagnostic (IOM)

| Number | | Description |
|--------|---------|------------------------------|
| 1 | (PCTST) | Priority Chain Test |
| 2 | (GRTST) | Global Register Test |
| 3 | (REGFL) | Register and Flag Test |
| 4 | (INTST) | Interrupt System Test |
| 5 | (DFTST) | I/O Flag 20, 21, 22, & 23 |
| 6 | (DCITS) | DMA Control and Interrupt |
| 7 | (D4WCT) | 4-Word Self Configuration |
| 8 | (DXFRT) | DMA XFER with Self Config |
| 9 | (DMPTS) | DMA Into MPT Area |
| 10 | (DTHMT) | DMA XFER Into HI Memory |
| 11 | (DPRTY) | DMA Parity Test |
| 12 | (IIMPT) | Bad I/O Instruction w/MPT On |
| 13 | (ALLIN) | All I/O Chips Interrupt |
| 14 | (MULTI) | Multi DMA Transfer |
| -1 | (EXIT) | To Exit |

Card Replacement Order

When error messages are received, the card replacement order should be as follows (if an error occurs at select code 77 when testing the A400 I/O, the A400 board must be replaced):

| A600/A600+ | A700* | A900 |
|-------------------------------|-------------------------------|-------------------------------|
| 1. I/O Card (SC) [†] | 1. I/O Card (SC) [†] | 1. I/O Card (SC) [†] |
| 2. Processor | 2. Upper Processor | 2. Cache Control |
| 3. Memory Controller | 3. Lower Processor | 3. Memory Controller |
| | 4. Memory Controller | 4. Sequencer |
| | | 5. Data Path |
| | A990 | |
| | 1. I/O Card (SC) [†] | |
| | 2. Processor | |

* Discontinued product; shown for reference only

[†] SC is the select code of the card under test indicated by the error message.

Expanded Instruction Diagnostic (EIG)

| Number | Description |
|--------|-------------------------|
| 1 | (LBT) Load Byte |
| 2 | (SBT) Store Byte |
| 3 | (CBT) Compare Bytes |
| 4 | (SFB) Scan for Byte |
| 5 | (MBT) Move Bytes |
| 6 | (CMW) Compare Words |
| 7 | (MVW) Move Words |
| 8 | (TBS) Test Bits |
| 9 | (SBS) Set Bits |
| 10 | (CBS) Clear Bits |
| 11 | (C†‡) Copy † to ‡ |
| 12 | (C‡†) Copy ‡ to † |
| 13 | (X†‡) Exchange † and ‡ |
| 14 | (IS‡) Increment Skip‡ |
| 15 | (AD‡) Add to ‡ |
| 16 | (L†‡) LD † indexed by ‡ |
| 17 | (S†‡) ST † indexed by ‡ |
| 18 | (JPY) JMP LD/Indexd Y |
| 19 | (LDX) Load/Store X |
| 20 | (LDI) LA ‡/LD‡ Indirect |
| -1 | (EXI) Exit Run T Mode |

where: † = A or B register

‡ = X or Y register

Card Replacement Order

For a failure in tests 1 through 5 on the A600+/A700*, or for the error message “TBG INTERP. DIDN’T OCCUR” on the A600+/A700*/A900, the card replacement order is as follows (if you are testing an A400 or A990 board, the board must be swapped):

| A600/A600+ | A700* | A900 |
|----------------------|----------------------|----------------------|
| 1. Processor | 1. Upper Processor | 1. Memory Controller |
| 2. Memory Controller | 2. Lower Processor | 2. Sequencer |
| 3. Memory Array | 3. Memory Controller | 3. Data Path |
| | 4. Memory Array | 4. Cache Control |
| | 5. Floating Point | 5. Memory Array |

For a failure in tests 6 through 20 on the A600+/A700*, or for any test failed on the A900, the card replacement order is as follows. (If you are testing an A400 or A990 board, the board must be swapped.)

* Discontinued product; shown for reference only.

A600/A600+

1. Processor
2. Memory Controller
3. Memory Array

A700*

1. Lower Processor
2. Upper Processor
3. Memory Controller
4. Memory Array
5. Floating Point

A900

1. Data Path
2. Sequencer
3. Cache Control
4. Memory Controller
5. Memory Array

Floating Point Diagnostic (FPD)

| Number | Description |
|--------|-------------------------|
| 1 | (.FIXS) S. FLT->S. INT |
| 2 | (.FLTS) S. INT->S. FLT |
| 3 | (.FADD) S. FP ADD |
| 4 | (.FSUB) S. FP SUB |
| 5 | (.FMPY) S. FP MPY |
| 6 | (.FDIV) S. FP DIV |
| 7 | (.FIXD) S. FLT->D. INT |
| 8 | (.FLTD) D. INT->S. FLT |
| 9 | (.TADD) D. FP ADD |
| 10 | (.TSUB) D. FP SUB |
| 11 | (.TMPY) D. FP MPY |
| 12 | (.TDIV) D. FP DIV |
| 13 | (.TFXS) D. FLT->S. INT |
| 14 | (.TFTS) S. INT->D. FLT |
| 15 | (.TFXD) D. FLT->D. INT |
| 16 | (.TFTD) D. INT->D. FLT |
| -1 | (.EXIT) Exit Run T Mode |

Card Replacement Order

Card replacement order for an FPD error on the A600+/A900, or A700* without HFP installed is as follows (if an error occurs on an A400 or A990 board, the board must be swapped):

A600/A600+

1. Processor
2. Memory Controller
3. Memory Array
4. Frontplane

A700*

1. Lower Processor
2. Upper Processor
3. Memory Controller
4. Memory Array
5. Frontplane

A900

1. Data Path
2. Sequencer
3. Cache Control
4. Memory Controller
5. Memory Array

* Discontinued product; shown for reference only.

Card replacement order for an FPD error on the A700* with HFP installed is as follows:

A700*

1. Floating Point
2. Frontplane
3. Lower Processor
4. Upper Processor
5. Memory Controller
6. Memory Array

Language Instruction Diagnostic (LIS)

| Number | Description |
|--------|--|
| 1 | (.DAD) Double Int. Add |
| 2 | (.DSB) Double Int. Subtract |
| 3 | (DSBR) D.I. Subtract Reverse |
| 4 | (.DIN) D.I. Increment |
| 5 | (.DDE) D.I. Decrement |
| 6 | (.DIS) D.I. Increment Skip |
| 7 | (.DDS) D.I. Decrement Skip |
| 8 | (.DNG) D.I. Negative |
| 9 | (.DCO) D.I. Compare |
| 10 | (.CPM) D.I. Compare |
| 11 | (.FCM) ..FCM S.F.P. |
| 12 | (DFER) .DFER |
| 13 | (CFER) .CFER |
| 14 | (ZFER) .ZFER |
| 15 | (XFER) .XFER |
| 16 | (ENTP) .ENTP-PASS PARMS |
| 17 | (ENTR) .ENTR-PASS PARMS |
| 18 | (ENTN) .ENTN-PASS PARMS |
| 19 | (ENTC) .ENTC-PASS PARMS |
| 20 | (SETP) .SETP-SET A TBL |
| 21 | (.DMP) Double Int. Multiply |
| 22 | (.DDI) Double Int. Divide |
| 23 | (DDIR) D.I. Divide Reverse |
| 24 | (PACK) Pack Floating Point Instruction |
| 25 | (.BLE) S.->D. Floating |
| 26 | (.NGL) D.->S. Floating |
| 27 | (.TCM) ..TCM - D.F.P. |
| 28 | (PWR2) .PWR2 - $Y = X * 2 ^ N$ |
| 29 | (FLUN) Unpack Floating Point Inst. |
| -1 | (EXIT) Exit Run T Mode |

* Discontinued product; shown for reference only.

Card Replacement Order

The following provides a card replacement order when an instruction in tests 1 through 23 have failed on the A700* without HFP, for a failure of Tests 1 through 20 for A700* with HFP, or for any failure on the A600+/A900 (if an error occurs on the A400 or A990 board, then the board must be replaced):

A600/A600+

1. Processor
2. Memory Controller
3. Memory Array
4. Frontplane

A700*

1. Lower Processor
2. Upper Processor
3. Memory Controller
4. Memory Array
5. Frontplane

A900

1. Data Path
2. Sequencer
3. Cache Control
4. Memory Controller
5. Memory Array

If tests 21 through 29 fail on the A700* with HFP installed, the card replacement order is as follows:

A700*

1. Floating Point Card
2. Frontplane
3. Lower Processor
4. Upper Processor
5. Memory Controller
6. Memory Array

If the LIS diagnostic returns the message “TBG INTERP. DIDN’T OCCUR”, use the following card replacement order:

A600/A600+

1. Processor
2. Memory Controller
3. Memory Array

A700*

1. Upper Processor
2. Lower Processor
3. Memory Controller
4. Memory Array
5. Floating Point

A900

1. Memory Controller
2. Sequencer
3. Data Path
4. Cache Control
5. Memory Array

* Discontinued product; shown for reference only.

Scientific Instruction Set (SIS)

NOTE: This diagnostic is supported only on the A700* with floating point card, the A900, and A990.

| Number | Description |
|--------|---------------------------|
| 1 | (COS) Cosine |
| 2 | (SIN) Sine |
| 3 | (TAN) Tangent |
| 4 | (ALOG) Natural Log |
| 5 | (ATAN) Arc tangent |
| 6 | (ALOGT) Common Log |
| 7 | (SQRT) Square Root |
| 8 | (EXP) E to the Power of X |
| 9 | (TANH) Hyperbolic Tangent |
| 10 | (DPOLY) Polynomial Eva. |
| 11 | (/CMRT) Range Reduction |
| 12 | (/ATLG) $(1-X)/(1+X)$ |
| 13 | (.FPWR) 32-Bit Expont. |
| 14 | (.TPWR) 64-Bit Expont. |
| -1 | (EXIT) Exit Run T Mode |

Card Replacement Order

Card replacement order for errors detected by the SIS diagnostic is as follows: (If an error occurs on the A990 board, the board must be replaced):

| A700* | A900 |
|----------------------|----------------------|
| 1. Floating Point | 1. Data Path |
| 2. Frontplane | 2. Sequencer |
| 3. Lower Processor | 3. Cache Control |
| 4. Upper Processor | 4. Memory Controller |
| 5. Memory Controller | 5. Memory Array |
| 6. Memory Array | |

* Discontinued product; shown for reference only.

CDS Basic Instruction Diagnostic (CDSBI)

| Number | Description |
|--------|------------------------|
| 1 | (MRG1) CP † /LD† /ST† |
| 2 | (CACQ) CACQ & CCQB |
| 3 | (CBCQ) CBCQ & CCQA |
| 4 | (MRGD) MRG Direct |
| 5 | (MRGI) MRG Indirect |
| 6 | (.CAZ) .CAZ & .CZB |
| 7 | (.CBZ) .CBZ & .CZA |
| 8 | (CIQA) Copy IQ to A |
| 9 | (CIQB) Copy IQ to B |
| 10 | (SDSP) Store Display |
| 11 | (XJCQ) X Jump Load Q |
| 12 | (ADQA) Add CQ to A |
| 13 | (ADQB) Add CQ to B |
| -1 | (EXIT) Exit Run T Mode |

where † = A or B register

If any test has failed, the card replacement order is as follows (if you are testing the A400 or A990 board, replace it):

A600/A600+

1. Processor
2. Memory Controller

A700*

1. Upper Processor
2. Lower Processor
3. Memory Controller

A900

1. Cache Card
2. Memory Controller
3. Sequencer
4. Data Path

Note: Running this diagnostic revision levels before rev 5020 with new A900 base set chips (part no. 12201-80103 through 80120) causes CDS test to fail with the following error message displayed:

CDS NOT SUPPORTED – F/W PK = 4 RV = 19

Use revision 5020 (or later) diagnostic or ignore this error for revisions prior to 5020.

* Discontinued product; shown for reference only.

CDS Procedural Call Diagnostic (CDSPC)

| Number | Description |
|--------|--------------------------|
| 1 | (.EXIT) Exit no Skip |
| 2 | (EXIT1) Exit and Skip1 |
| 3 | (EXIT2) Exit and Skip2 |
| 4 | (PCALI) Internal PCALL |
| 5 | (PCALR) .ENTR Compatible |
| 6 | (PCALN) .ENTN Compatible |
| 7 | (PCALX) External PCALL |
| 8 | (PCALV) Variable PCALL |
| -1 | (EXIT) Exit Run T Mode |

If any test has failed, the card replacement order is as follows (if you are testing the A400 or A990 board, replace it):

| A600/A600+ | A700* | A900 |
|----------------------|----------------------|----------------------|
| 1. Processor | 1. Upper Processor | 1. Cache Card |
| 2. Memory Controller | 2. Lower Processor | 2. Memory Controller |
| | 3. Memory Controller | 3. Sequencer |
| | | 4. Data Path |

* Discontinued product; shown for reference only.

A990 Instructions Diagnostic (A990D)

A990D provides six separate tests for verifying the operation of microcoded instructions that are available only on the A990 processor. A990D does not run on any other processor.

| Number | Description |
|-----------|---------------------------------------|
| 1 | (TLXMP) Load and Store Extended Map |
| 2 | (TLXMR) Load and Store Mapping |
| Registers | |
| 3 | (TWCS) Write and Read Control Store |
| 4 | (TWTM) Write and Read Timer Registers |
| 5 | (TFWID) Firmware ID for A990 |
| 6 | (TWTC) Write and Read Time-of-Day |
| Clock | |

Card Replacement Order:

The replacement order for an error during execution of Test 6 is:

1. Time-of-day clock chip
2. A990 processor board

For any other A990 instruction failure, replace the A990 board.

HP 24612A Interface Diagnostics

General Information

The following section provides a description and special operating instructions for each of the following interface card diagnostic programs:

- HP 12005A*/B Asynchronous Serial Interface (ASIC)
- HP 12006A Parallel Interface (PIC)
- HP 12007A/B Programmable Serial Interface (PSI)
- HP 12008A PROM Storage Module (PROM)
- HP 12009A HP-IB Interface (HPIB)
- HP 12016A Small Computer System Interface (SCSI)
- HP 12022A* Disk

Interface/Controller (DID)

- HP 12040A* –
/B*/C/D 8-Channel Asynchronous Multiplexer (MUX)
- HP 12044A Programmable Serial Interface (PSI)
- HP 12060A*/B –
/12061A High Level Analog Input / 31-Ch. MUX (AIMXD)
- HP 12062A 4-Channel Analog Output Card (AOUTD)
- HP 12063A Isolated Digital I/O Card (DIGIO)
- HP 12072A Data Link (FDL)
- HP 12100A A400 On-Board I/O (OBIO)
- HP 12153A Writable Control Store (WCS)
- HP 12205A Control Store Card (CSIC)

The interface diagnostics operate under control of the Diagnostic Design Language (DDL) Interpreter module which is a part of the Diagnostic Control System (DCS).

Error codes and additional operating information specific to a particular interface card diagnostic are provided in the *HP 1000 A-Series Computer Interface Diagnostic Reference Manual* (part no. 24612-90011).

The diagnostic operating procedures assume a VCP terminal is connected and enabled. To execute diagnostics without a terminal, refer to the *Diagnostic Operating and Troubleshooting Manual* (part no. 24612-90013). Refer to Chapter 10, Reference, for specific diagnostic manual part numbers.

* Discontinued product; shown for reference only.

Diagnostic Test Hoods

| | |
|---------------------------------------|-----------------|
| Test Hood for 12005 ASIC | 24397-60005 |
| Fiber Optic Test Cable for 12005B | 5061-7933 |
| Test Hood for 12006 PIC | 24397-60004 |
| Test Hood for 12007 PSI (all modem) | 5061-4916 |
| Test Hood for 12016 SCSI | 12016-60007 |
| Test Hood for 12040 MUX expansion | 5061-4901 |
| Loaded Test Hood 12040 MUX | ET30170-6001 ** |
| Test Hood for 12044 PSI (all D.C.) | 5061-3460 |
| Test Hood for 12060* Hi level analog | 12060-60003 |
| Test Hood for 12061 MUX | 12061-60002 |
| Test Hood for 12062 D-to-A converter | 12062-60002 |
| Test Hood for 12063 16 IN / 16 OUT | 12063-60002 |
| Test Hood for 12072 Factory data link | 5061-4909 |
| Test Hood for 12100 (A400) Cable | 12100-60004 |

General Diagnostic Operation

Load and execute the Diagnostic Control System (DCS). Upon loading the desired interface diagnostic, the DDL prompt will be displayed.

Type “RUN<cr>” following DDL> to start the diagnostic program.

NOTE

Typing “RUN !<cr>” will cause the diagnostic to execute on the highest priority interface card in a noninteractive mode. If failures are detected, the diagnostic terminates and prints the error message. If the diagnostic completes normally, it will automatically execute the next highest priority interface. When all diagnostic interface types have been tested the diagnostic terminates and returns with the DDL prompt.

* Discontinued product; shown for reference only.

** Test hood ET30170-6001, part of the field diagnostic kit 12040-67805, can be used in place of the non-loaded test hood (5061-4901). It provides resistive and capacitive loading to simulate an external device on each of its eight I/O ports. ROM part number 5181-6125 is part of the diagnostic kit and is required for the MUX card when this test hood is used.

HP 12005A*/B Async Serial Interface (ASIC)

After typing "RUN<cr>", the following messages will be displayed:

12005A/B ASYNCHRONOUS SERIAL INTERFACE DIAGNOSTIC
12005A INPUT SELECT CODE: If a 12005A interface card is to be tested, enter the octal select code (ie: 22<cr> or -1 to skip the request for 12005A and continue to the 12005B).

12005B INPUT SELECT CODE: Enter the octal select code (ie: 22<cr>).

HOOD INSTALLED? Enter a "YES" or "NO". On the interface card with the test hood(s) installed (part no. 24397-60005), set the U21 switches to the following:

12005A Switch U21 #1 2 3 4 5 6 7 8
Setting 1 1 1 1 1 1 1 0

12005B Switch U21 #1 2 3 4 5 6 7 8
Setting 1 1 1 1 1 1 0 1

1 = open = up; 0 = closed = down

Attach the 12005A/B Test Hood prior to executing the diagnostic. For the 12005B also connect the fiber optic loopback cable.

HOOD INSTALLED Indicates if the test hood is installed.

BAUD RATE TEST
BAUD RATE UNDER TEST = XXXX The baud rate under test will be displayed for each baud rate tested.

EXTERNAL CLOCK SOURCE TEST

BAUD RATE TEST COMPLETE Indicates termination of the baud rate test.

OPTICAL LINK PASSED Indicates the 12005B was tested with the fiber optic loopback connector.

HOOD TESTS NOT EXECUTED Indicates the test hoods are not installed.

12005A PASS COMPLETE Marks successful completion of the 12005A/B Interface Diagnostic.

INPUT SELECT CODE: To run the diagnostic again, reenter the select code for another complete pass, or enter a <cr> to put the diagnostic in the loop mode.

To discontinue program execution, enter a zero (0).

Return the 12005A/B U21 switches to the original switch configuration.

* Discontinued product; shown for reference only.

Terminal to Interface Communication Test

DDL> RU A<cr> Schedules the terminal to interface test.

1500 PRGM A TERMINAL-12005A/B INTERFACE COMMUNICATION TEST
INPUT SELECT CODE: Type in the select code of the terminal to be tested.

On the terminal under test, the following will be displayed:

TERMINAL TO 12005A/B INTERFACE COMMUNICATION TEST
TYPE TWENTY CHARACTERS ON THE KEYBOARD NOW
Enter twenty (20) characters.

ASIC TERMINAL TEST COMPLETE
nn CHARACTERS RECEIVED This message will be displayed upon receiving the last character or after a <cr> is entered.
PASS COMPLETE
INPUT SELECT CODE:

TEST FAILURE Indicates no characters were entered within 2 minutes of running the diagnostic.

Special Character Recognition Test

DDL> RU B<cr> Schedules the special character recognition test.

1700 PRGM B SPECIAL CHR. TEST
INPUT SELECT CODE: Type in the select code of the 12005A/B Interface to be tested.
The following will be displayed on the terminal connected to the 12005A/B under test:

SPECIAL CHARACTER RECOGNITION
ASCII CHAR.(OCT) T1 T2 T3 Note that this test may fail if a non-standard special character ROM is installed on the 12005 card.

| | | | |
|-----|---|---|---|
| 004 | X | | |
| 010 | X | | |
| 015 | X | | X |
| 022 | X | | |
| 036 | | X | |
| 177 | X | | |
| 204 | X | | |
| 210 | X | | |
| 215 | X | | X |
| 222 | X | | |
| 236 | | X | |
| 377 | X | | |

PASS COMPLETE
INPUT SELECT CODE:

The previously displayed message shows what special characters are recognized by the card in its three special character type modes. With a standard card, type 1 characters are EOT (4 octal or 204 octal), BACKSPACE (10 or 210), CARRIAGE RETURN (15 or 215), DC2 (22 or 222), and RUBOUT (177 or 377). The type 2 special character is the RECORD SEPARATOR (36 or 236), and the type 3 special character is the CARRIAGE RETURN (15 or 215). Note the special characters are recognized once with the most significant bit clear and once with the most significant bit set (difference is 200 octal).

The execution time with the test hood is about 90 seconds.

The execution time without the test hood is about 30 seconds.

HP 12006A Parallel Interface (PIC)

After typing "RUN<cr>", the following messages will be displayed;

12006A PARALLEL INTERFACE DIAGNOSTIC

| | |
|---|--|
| INPUT SELECT CODE: | Enter the octal select code (ie: 24<cr>). |
| HOOD INSTALLED? | Enter a "YES" or "NO". (Hood part no. is 24397-60004.) The following message will be displayed: |
| DEVICE COMMAND SENSE SWITCH – ACTIVE HIGH | This indicates that the switch U1S2 setting must be in the active high (up) setting for the correct operation of the diagnostic. |
| PASS COMPLETE | Indicates successful completion of the 12006A Interface Diagnostic. |
| INPUT SELECT CODE: | To run the diagnostic again, reenter the select code for another complete pass, or enter a <cr> to put the diagnostic in the loop mode. To discontinue program execution, enter a zero (0). Return the 12006A switches to their original switch configuration. |

The execution time with the test hood is about 10 seconds.

The execution time without the test hood is about 5 seconds.

Programmable Serial Interface (PSI) Diagnostics

After typing “RUN<cr>”, the following messages will be displayed:

5061-4940(4941),-4938(4939) PROG. SERIAL I^FFACE DIAGNOSTIC
INPUT SELECT CODE: Enter the octal select code

SELF TEST PASSED Indicates successful completion of the
PASS COMPLETE PSI Diagnostic, when the diagnostic test
INPUT SELECT CODE hood is not installed. Hood part
numbers:
Modem card: 5061-4916, 5061-3453
Direct connect: 5061-3460

DIAGNOSTIC TEST HOOD SENSED Indicates successful completion of the
SELF-TEST PASSED PSI Diagnostic, when the diagnostic
PASS COMPLETE test hood is installed.
INPUT SELECT CODE

To run the diagnostic again, reenter the select code for another complete pass, or enter a <cr> to put the diagnostic in the loop mode.

Looping will continue until an error occurs or the “BREAK” key is pressed. Typing a “%E” will return control to the beginning of the diagnostic.

To discontinue program execution, enter a zero (0).

Note: When testing a PSI card with ROM part no. 5180-1951 (self-test ROM),
STATUS = 0830; when testing with LAP-B/X.25 ROM,
STATUS = 8000; when testing with HP 12042 Data Link,
STATUS =BADC (except with 5.1 (or later) rev code).

HP 12008A PROM Storage Module (PROM)

After typing “RUN<cr>”, the following messages will be displayed;

12008A PROM CARD DIAGNOSTIC
INPUT SELECT CODE: Enter the octal select code (ie: 24<cr>)

PASS COMPLETE Indicates successful completion of the
INPUT SELECT CODE: 12008A Diagnostic.

To run the diagnostic again, reenter the select code for another complete pass, or enter a <cr> to put the diagnostic in the loop mode.

To discontinue program execution, enter a zero (0).

Return the 12006A switches to their original switch configuration.

PROM Data Access Program (Optional)

At least two PROMs must be installed in the HP 12008A card.

DDL> RU A<cr> Schedules the diagnostic for Data Access.

650 PRGM A PROM ACCESS PROGRAM

INPUT SELECT CODE: Enter the select code of the PROM card under test.

INPUT STARTING (,ENDING) ADDRESS IN OCTAL

Enter the information requested (i.e., 300, 303<cr>). If the PROM address is not in octal, is not positive, or is not within the PROM memory boundaries, the following message will be given:

YOU HAVE PASSED THE LIMITS OF THE PROM DATA

INPUT STARTING (,ENDING) ADDRESS IN OCTAL

The PROM data will be displayed.

| ADDRESS | DATA |
|---------|--------|
| (300) | 002074 |
| (301) | 102077 |
| (302) | 030202 |
| (303) | 113406 |

WOULD YOU LIKE TO CONTINUE? Enter a "YES" or a "NO" followed by a <cr>.

The execution time is about 90 seconds.

HP 12009A HP-IB Interface (HPIB)

Install jumper W1 on the board and type "RUN<cr>". The following messages will be displayed:

12009A HP-IB INTERFACE DIAGNOSTIC

INPUT SELECT CODE: Enter the octal select code (i.e., 27<cr>).

ADDR n IDENTIFIES WITH xxxx OCTAL

Indicates that an HP-IB device responds to the HP-IB Identify Command where 'n' is the device address and xxxx is the octal identification code of the HP-IB device.

DISK CONTROLLER LOOPBACK TEST ON HP-IB ADDR n

Indicates that the diagnostic identifies a disk drive.

NO HP-IB DISKS FOUND Indicates that the program does not identify a disk drive.

CARD NOT SYSTEM CONTROLLER
ON-LINE TEST NOT EXECUTED

Indicates that the interface is not configured as the controller-in-charge (U1S1).

PASS COMPLETE

INPUT SELECT CODE:

Indicates successful completion of the 12009A Interface Diagnostic.

HP 12016A SCSI Interface (SCSI)

The SCSI loopback test panel, part number 12016-60007, is required to execute the SCSI interface diagnostic loopback tests.

The SCSI diagnostic provides five tests:

- SCSI card self-test
- TERMPWR check
- Firmware timestamp display
- RAM
- Loopback

Single SCSI Card Automatic Mode Execution

To initiate automatic execution of the SCSI interface diagnostic for one SCSI card, enter:

| | |
|-------------------|--|
| DDL> RUN | When you enter <i>RUN</i> at the DDL prompt, a message stating the program name and revision number appears, followed by a prompt for the select code of the SCSI card you want to test: |
| INPUT SELECT CODE | Enter the octal select code of the card. Do not use the at sign (@) before the code number; the test expects an octal number. The tests affect the selected card only. After you select a SCSI card, a prompt asks you if the loopback test panel has been installed: |
| HOOD INSTALLED? | Hood refers to the loopback test panel. If you have attached the loopback panel and answer yes, the loopback test is included in the test sequence. Otherwise, only the firmware timestamp, TERMPWR check, self-test and RAM tests are executed (unless you have set the Z variable to a nonzero integer, which disables the RAM test). When the tests have executed, the prompt |
| INPUT SELECT CODE | appears again. If an error occurs, the error message prints before the select code prompt appears. To run the diagnostic again, enter the select code of the desired SCSI interface card. You can run the diagnostic on the same card or on a different card, or exit the program. To exit the diagnostic program and return to the DDL prompt, enter 0 (zero) at the INPUT SELECT CODE prompt. If you press the <RETURN> key at the INPUT SELECT CODE prompt without entering a select code value, the program loops (repeats the tests) continuously on the last selected SCSI card. After every successful pass, the following message prints: |
| PASS n | where <i>n</i> is the pass number. Looping continues until an error occurs or you press the <BREAK> key. After you press the <BREAK> key, enter the %E command, which sends you to the BCM> prompt. From there, you can enter the DDL command at the prompt to return to the SCSI diagnostic program. |

The following is an example SCSI DDL session, in automatic single card test mode, where *xx* is the octal select code of a SCSI card (0 returns you to the DDL prompt).

```
DDL> RUN <RET>
12016A SCSI INTERFACE DIAGNOSTIC – REV.5270
INPUT SELECT CODE xx <RET>
HOOD INSTALLED? YES <RET>
SELF-TEST PASSED.
TERMPWR ENABLED.
FIRMWARE TIMESTAMP: 900130.0004
EXECUTING RAM TEST. PLEASE WAIT.
RAM TEST PASSED.
LOOPBACK TEST PASSED.
PASS COMPLETE
INPUT SELECT CODE xx <RET>
. .
. .
. .
INPUT SELECT CODE 0
DDL>
```

Multiple SCSI Card Automatic Mode Execution

To initiate automatic execution of the SCSI interface diagnostic for multiple SCSI cards (in the same computer card cage), enter:

DDL> RUN !

The RUN ! command tests the SCSI cards in the order of their priority. The multiple card diagnostic mode does not run the loopback test (the loopback panel connects to one card at a time). Multiple card automatic mode executes the self-test, TERMPWR check, firmware timestamp test, and the RAM test unless you have set the Z variable to a nonzero integer, which disables the RAM test.

When you enter RUN ! at the DDL prompt, a message stating the program name and revision number appears, followed by the select code of the card being tested, the test results, then the select code of the next card, until all cards have been tested. The diagnostic tests the highest priority SCSI card first. If the diagnostic detects a failure, it prints an error message, terminates the program and returns to the DDL prompt. If no errors occur, the program proceeds to the next highest priority SCSI card and reports the results.

The following is an example SCSI DDL session, in automatic multiple card test mode, where *xx* and *yy* are the octal select codes of SCSI cards.

```
DDL> RUN ! <RET>
12016A SCSI INTERFACE DIAGNOSTIC – REV.5270
SELECT CODE xx UNDER TEST
SELF-TEST PASSED.
TERMPWR ENABLED.
FIRMWARE TIMESTAMP: 900130.0004
EXECUTING RAM TEST. PLEASE WAIT.
RAM TEST PASSED.
PASS COMPLETE
```

```
SELECT CODE yy UNDER TEST
SELFTEST PASSED.
TERMPWR ENABLED.
. .
. .
. .
PASS COMPLETE
DDL>
```

Interactive Mode Diagnostic Operation

The SCSI diagnostic program's interactive mode runs one of five tests on a specified SCSI card and enables you to download Z180 code from a specified file on a specified device. You can execute a test multiple times. You initiate interactive mode by entering

DDL> RUN T with or without runstring command parameters. If you enter *RUN T* without parameters, the diagnostic displays a list of tests you can run and commands you can execute, followed by a test selection prompt:

- 1 – SELF-TEST
- 2 – TERMPWR ENABLED CHECK
- 3 – FIRMWARE TIMESTAMP DISPLAY
- 4 – RAM TEST
- 5 – LOOPBACK TEST
- 10 – DEFINE DOWNLOAD DEVICE:FILE
- 11 – DOWNLOAD Z180 CODE
- 1 – EXIT DIAGNOSTIC

ENTER TEST NUMBER: You can either enter a test number or exit to the DDL prompt (-1) from the ENTER TEST NUMBER: prompt. If you enter a test number, the prompt INPUT SELECT CODE appears, enabling you to choose the SCSI card on which to run the test. Enter the octal select code of the card (do not use the @ sign before the code number; the test expects an octal number).

Options 10 (DEFINE DOWNLOAD DEVICE:FILE) and 11 (DOWNLOAD Z180 CODE) are used in conjunction with one another. Together, they enable you to download Z180 code from a specified file on a specified load device. To do this, first select option 10. Selecting option 10 brings up the prompt

ENTER DEVICE NUMBER: Enter the number of the load device from which you want to download the Z180 code (for example, a CS/80 cartridge or a tape drive). The prompt

ENTER FILE NUMBER: appears. Enter the number of the file that contains the Z180 code you want to download. The SCSI device and the file containing the Z180 code on that device are now specified. Next, select option 11. This automatically downloads the Z180 code to the SCSI card.

Note that the DEFINE DOWNLOAD DEVICE:FILE option assumes that device numbers have been assigned to the SCSI devices. The DOWNLOAD Z180 CODE option assumes that you have defined a device and named a file using option 10.

You can also download Z180 code to a SCSI card by using the RUN T command runstring twice. To do this, enter the 10 option in the first RUN T command runstring, execute it, then enter the 11 option in the next RUN T command runstring.

SCSI Card Self-Test

Running this test causes the SCSI diagnostic to issue an OTA 32B instruction to the specified SCSI card, which forces the card to execute its power-on self-test.

| LED | LED | LED | LED | Status |
|-------|-----|-----|-----|--------------------------|
| 1 | 2 | 3 | 4 | |
| OFF | ON | ON | ON | Card PROM Checksum Error |
| OFF | ON | ON | OFF | RAM Test Failed |
| OFF | ON | OFF | ON | Reserved |
| OFF | ON | OFF | OFF | DMA Test Failed |
| OFF | OFF | ON | ON | Timer Test Failed |
| OFF | OFF | ON | OFF | SCSI Chip Test Failed |
| OFF | OFF | OFF | ON | Reserved |
| OFF | OFF | OFF | OFF | Passed Test * |
| BLINK | OFF | OFF | OFF | Normal Operation ** |

- * The all-LEDs-off condition that indicates successful self-test completion only exists briefly; after this, LED number one blinks continuously, which indicates a normally functioning SCSI Card.
- ** The rate at which LED number one blinks indicates the activity level of the card. Faster blinking indicates an idle card. Slower blinking indicates a heavier load on the card. A rate as low as several seconds between blinks is normal.

TERMPWR Check

This test reports the status of the SCSI card’s bus termination power. TERMPWR status indicates whether or not TERMPWR is present. It does not indicate the TERMPWR source, which can be the SCSI card or a SCSI device.

If the SCSI card or a SCSI device is providing TERMPWR, the message “TERMPWR ENABLED” appears.

If neither a device nor the SCSI card (Switch SW1–2 is open) is providing TERMPWR, the message “TERMPWR DISABLED” appears.

Firmware Timestamp Display

This test sends a “peek” script (a command that reads data without moving the data from its current location) to the SCSI card. The peek script requests the card to transmit the firmware timestamp (the contents of memory location 0x40 through 0x4F) to the HP 1000 computer’s CPU. If the CPU receives the firmware timestamp, a message appears in the following form:

```
FIRMWARE TIMESTAMP: yymmdd.aabb
```

where *yy* is the year, *mm* is the month, and *dd* is the day of the firmware release; *aa* is the major revision code, and *bb* is the minor revision code. A period separates the date and revision code fields.

If the peek script request fails, one of the following three error messages appears, depending on the failure:

```
DEVFLAG NOT SET
```

```
RESPONSE FIFO EMPTY
```

or

```
RESPONSE TYPE INCORRECT
```

The DEVFLAG NOT SET error indicates a hardware failure. Replace the SCSI card.

The RESPONSE FIFO EMPTY error indicates that the diagnostic program received the correct device flag after sending the command to retrieve the timestamp, but the SCSI card status word (LIA 32B) indicated that the response FIFO was empty. The diagnostic program expects the response FIFO to contain the firmware timestamp response, which means that the response FIFO should not be empty. Run the SCSI card self-test to verify that this is a hardware failure. If this condition persists, replace the SCSI card.

The RESPONSE TYPE INCORRECT error indicates that the response to the firmware timestamp request did not contain the expected response type, which is five (5). Verify that the proper drivers and firmware are installed, then run this test again. If this error persists, replace the SCSI card.

RAM Test

The RAM test detects stuck-at-0 and stuck-at-1 conditions (that is, a bit always reports a 0 or a 1) in the address range 32 KByte to 512 KByte. The address range 0KB through 32KB is not tested, because these memory locations contain the on-board firmware code and the downloaded RAM test code itself.

You cannot execute the RAM test if the SCSI card's firmware timestamp is 900711.0003 or earlier (July 11, 1990, major revision 00, minor revision 03). In order to execute the RAM test, the firmware revision must be major revision 00, minor revision 04, or greater.

If the RAM test fails, the following two messages appear:

```
RAM FAILURE AT ADDR: xxxxx; BIT y.  
SUSPECT DRAM AT POSITION zzzz.
```

where *xxxxx* is the hexadecimal address where the failure was detected, *y* is the bit position, and *zzzz* is the DRAM IC that is associated with the address/bit position that failed. The DRAM IC designation will be U124, U114, U123 or U113.

You can bypass RAM test execution when running the diagnostic program by setting the variable *Z* to any nonzero integer at the DDL prompt, before executing any tests. For example, entering

```
DDL> Z=1
```

disables the RAM test. If you disable the RAM test, then attempt to run the RAM test later, a message appears that indicates that the RAM test has been disabled. When you run the diagnostic program, the message

```
RAM TEST NOT EXECUTED
```

appears with the results of the other diagnostic tests.

To enable the RAM test, set *Z*=0 at the DDL prompt.

Loopback Test

If the loopback test detects a stuck-at-1 failure (that is, a zero was written on the line, but a one was read back), the DDL program prints a message in the following form:

```
LOOPBACK ERROR: DATAx -> yyy BITS ALWAYS HI (0V).  
LOOPBACK ERROR: yyy -> DATAx BITS ALWAYS HI (0V).
```

where *DATAx* is the name of the data signal associated with the failure, and *yyy* is the name of the control line associated with the failure.

If the loopback test returns a stuck-at-0 failure (that is, a one was written on the line, but a zero was read back), the DDL program prints a message in the following form:

```
LOOPBACK ERROR: DATAx -> yyy BITS NOT ASSERTED.  
LOOPBACK ERROR: yyy -> DATAx BITS NOT ASSERTED.
```

where *DATAx* identifies the data signal associated with the failure, and *yyy* identifies the control line associated with the failure.

If bits in addition to the bit being tested assert during the stuck-at-0 test (multiple bit error), the diagnostic program prints a message in the following form:

```
LOOPBACK ERROR: DATAx -> yyy CAUSE MULTIPLE BIT ERRORS.  
LOOPBACK ERROR: yyy -> DATAx CAUSE MULTIPLE BIT ERRORS.
```

Again, *DATAx* identifies the data signal, and *yyy* identifies the control line.

Stuck-at-1 bits do not cause multiple bit errors, because they are already reported as stuck in an “on” condition.

HP 12022A* Disk Interface/Controller Diagnostic (DID)

NOTE

Without at least one peripheral device attached, the DID program will abort with an error following testing of the card logic, and at the start of the card-to-peripheral testing.

After typing “RUN<cr>”, the following messages will be displayed:

DISK INTERFACE CARD DIAGNOSTIC

INPUT SELECT CODE: Enter the octal select code (i.e., 32<cr>)

PASS COMPLETE

INPUT SELECT CODE: Indicates successful completion of the

12022A Interface diagnostic.

The diagnostic compares all disk combinations with the disk units in the system configuration switch register. If it finds a mismatch, it outputs the mismatch to the terminal.

To run the diagnostic again, reenter the select code for another complete pass, or enter a <cr> to put the diagnostic in the loop mode.

To discontinue program execution, enter a zero (0).

NOTE

The diagnostic only tests that there are disks present where the configuration switch indicates there are; it does not ascertain that the disk type is correct. For example, if there is a 15 Mbyte disk connected as drive 0 and the system configuration switch is set to indicate a 10 Mbyte disk, the diagnostic will not flag this as a misconfiguration.

* Discontinued product; shown for reference only.

Interactive Diagnostic Operation

The interactive mode consists of 17 individual tests. The runstring for interactive mode is:

```
RU T [test] [select code] [track] [sector offset]
```

where:

test = 1 through 17.

select code = select code in octal of the card under test.

track = 0 through maximum track for the desired disk.

sector offset = the offset within the defined track.

RU T alone will list the tests and their respective test number after prompting you for the select code.

Track and sector offset are used only for tests 10, 14, and 15. If set when using other tests, they are ignored. Test 11 (Restore) requires that the SDH register be set prior to executing this test. Each test prompts you for necessary data for that test.

The following is a list of the 17 interactive tests:

- 1 Set SDH Register
- 2 Set Cylinder High Register
- 3 Set Cylinder Low Register
- 4 Set Sector Number Register
- 5 Set Sector Count Register
- 6 Set Write Precomp Register
- 7 Read All Registers
- 8 Read Status Register
- 9 Read System Configuration
- 10 Seek to Track
- 11 Restore to Track 0
- 12 Reset Card
- 13 Test New Card
- 14 Read Sector
- 15 Write Sector
- 16 Dump Input Buffer
- 17 Compare I/O Buffers
- 1 EXIT

Register Definitions

Status Register (A-Register)

The status register is a read only register that contains the status of the last command executed on the drive specified in the SDH register. Status remains valid until another command is issued to the selected drive.

| 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 |
|------|-------------|-------------|-----------|-----------|------------------|-------------|-------|
| Busy | Drive Ready | Write Fault | Seek Done | Data Req. | Data Error Corr. | Write Prot. | Error |

Busy

Indicates that the card is busy executing a command. Whenever Busy is set, no other status bits are valid.

Drive Ready

Indicates the status of the ready line of the selected drive. No command can be executed until this bit is set.

Write Fault

Indicates the state of the write fault line on the selected drive. No command can be executed while this bit is set. This is a fatal drive error.

Seek Done

Indicates the state of the seek complete line for the selected drive.

Data Request

When set, this bit indicates that the board is ready to send or accept data for a read or write.

Data Error Corrected

Indicates that a successful data error correction has occurred on the data read from the hard disk. This is not applicable to floppies.

Write Protect

Indicates the state of the selected flexible disk drive write protect.

Error

Indicates that the error register has one or more errors which should be read by the host.

Error Register (B-Register)

The error register is a read only register which contains error information when the low order byte of the status register is set.

| 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 |
|-----------|---------------|-----------------|--------------|----------|-------------|------------|---------------|
| Bad Block | ECC/CRC Error | Self-test Error | ID Not Found | Not Used | Abort Comnd | TR00 Error | DAM Not Found |

Bad Block

This bit indicates that a bad block mark has been found in the specified ID field. If the command is a write, no writing will be done. If the command is a read, no read will be done. If the flaw is in the ID field, the bad block will not be detected.

ECC/CRC Error

This bit indicates that an ECC or CRC error was encountered in a data field during a read command, and was not correctable.

Self-Test Error

This bit indicates a failure occurred during self-test. The error register will be set to a value between 41 and 45 (octal) as follows:

| Error Number | Error Description |
|--------------|-------------------------------|
| 41 | Floppy controller failure |
| 42 | Winchester controller failure |
| 43 | Sector buffer failure |
| 44 | Error detection failure |
| 45 | Control Processor failure |

ID Not Found

This bit indicates that an ID field containing a specified head, cylinder, sector number or sector size was not found after retries.

Abort Command

This bit indicates that a valid command has been received that cannot be executed based on status information from the drive, such as drive not ready, seek complete not asserted, or write fault. Status and/or Error register will show the cause.

TR00 Error

This bit indicates that the controller was unable to find track zero on a restore. The controller sends up to 1023 step pulses on the hard disk and 255 step pulses on the microdiskette before setting this bit if TR00 is not detected.

DAM Not Found

This bit will be set on a read command if, after successfully identifying the ID field, the Data Address Mark was not detected within 16 bytes of the ID field.

SDH Register

The SDH register contains the sector size, drive select, head select, and ECC/CRC select bits. This is a read/write register which is organized as follows:

| 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 |
|-------------|----------------|---|-----------------|---|----------------------|---|---|
| ECC/ CRC | Sector Size | | Drive Select | | Head/Drive Select | | |

ECC/CRC 0 – CRC on
 1 – ECC on

Sector Size 0 – 256 bytes
 1 – 512 bytes
 2 – 1024 bytes
 3 – 128 bytes

Drive Select 0 – hard disk drive 1
 1 – hard disk drive 2
 2 – reserved
 3 – flexible disk drive select

Head Select
for Hard Disk 0 – head 0
 1 – head 1
 2 – head 2
 3 – head 3
 4 – head 4
 5 – head 5
 6 – head 6
 7 – head 7

Head/Drive Select
for Flexible Disks 0 – flexible disk drive 0, head select 0
 1 – flexible disk drive 0, head select 1
 2 – flexible disk drive 1, head select 0
 3 – flexible disk drive 1, head select 1

HP 12040A*/B*/C/D 8-Channel Asynchronous Multiplexer Diagnostic (MUX)

Note: Use loopback tool kit (part no. 12040-67805) or MUX diagnostic hood (part no. 5061-4901) for a more conclusive test of the input and output drivers.

After typing “RUN<cr>”, the following messages will be displayed:

| | |
|---|--|
| 12040 EIGHT CHANNEL MUX DIAGNOSTIC | |
| INPUT SELECT CODE: | Enter the octal select code. |
| REV A-C FIRMWARE INSTALLED or REV D FIRMWARE INSTALLED FIRMWARE REV CODE IS xx | One of these messages will be displayed depending on the revision of your MUX card. |
| MUX TEST PASSED PASS COMPLETE INPUT SELECT CODE: | Indicates successful completion of the 12040 Interface diagnostic. |
| | To run the diagnostic again, reenter the select code for another complete pass, or enter a <cr> to put the diagnostic in the loop mode. |
| | Looping will continue until an error occurs or the “BREAK” key is pressed. Typing a “%E” will return control to the beginning of the diagnostic. |
| | To discontinue program execution, enter a zero (0). |

Common Errors, Rev. B and C

| | |
|--|--|
| NO RESPONSE FROM MUX | Indicates that the diagnostic program cannot communicate with the MUX board. |
| MUX TEST NUMBER #N FAILED or MUX LOOPING IN TEST NUMBER #N | Indicates failure of at least one of the components on the MUX interface. |

#N indicates the test that failed as follows:

| #N | Test Failed |
|----|-----------------------------|
| 1 | Z-80A CPU |
| 2 | EPROM |
| 3 | RAM |
| 4 | Z-80A DMA |
| 5 | Z-80A CTC |
| 6 | Z-80A SIO Port 7 |
| 7 | Z-80A SIO Port 6 |
| 8 | Z-80A SIO Port 5 |
| 9 | Z-80A SIO Port 4 |
| 10 | Z-80A SIO Port 3 |
| 11 | Z-80Z SIO Port 2 |
| 12 | Z-80A SIO Port 1 |
| 13 | Z-80A SIO Port 0 |
| 14 | MUX-to-host latch circuitry |

* Discontinued product; shown for reference only.

Common Errors, Rev. D

CARD IS NOT RESPONDING TO SELF TEST

Indicates that the diagnostic program did not receive a response from the MUX card that the self-test ran.

FLAG 30 TIMEOUT WHILE READING A STATUS WORD

or

TIMEOUT WHILE WAITING FOR STATUS WORD

or

INVALID STATUS WORD RETURNED : <returned status word>

Indicates a communication problem with the firmware. Check firmware or the MUX card.

HP 12060A*/B High Level Analog Input / HP 12061A 31-Channel Expansion Multiplexer

After typing "RUN<cr>", the following messages will be displayed:

12060A 12 BIT ADC DIAGNOSTIC

INPUT SELECT CODE:

Input the octal select code.

Control/status register test:

CHECKING CONTROL/STATUS REGISTER FUNCTIONALITY

CONTROL/STATUS REGISTER TEST PASSED

Programmed I/O tests:

CHECKING PROGRAMMED I/O INTERRUPT FLAG

PROGRAMMED I/O TEST PASSED

DMA tests:

CHECKING SELF CONF. DMA INTERRUPT AND FLAG

CHECKING REGULAR DMA INTERRUPT AND FLAG

DMA TESTS

PASSED

Indicates successful completion of the above tests.

HOOD INSTALLED?

Answer "YES<cr>" or "NO<cr>".
Test hood part no. is 12060-60003

HOOD TESTS NOT EXECUTED

Indicates the test hoods are not attached

Offset test:

Results of test for 5V reference: Continues with the following tests if the

Results of gain of 1 test: test hoods are attached.

Results of auto-scan test:

Results of gain test:

External trigger test:

THERE APPEARS TO BE NO 12061 WITH THIS 12060

The diagnostic ends here if a 12061A card is not installed. Test hood part no. is 12061-60002.

* Discontinued product; shown for reference only.

THERE APPEARS TO BE A 12061 WITH THIS 12060

CONTINUING WITH 12061 TESTS

Results of tests for 9V references: The diagnostic continues here if

Results of gain of 1 test: a HP 12061A card is installed.

PASS COMPLETE
INPUT SELECT CODE:

Indicates successful completion of the diagnostic.

To run the diagnostic again, reenter the select code for another complete pass, or enter a <cr> to put the diagnostic in the loop mode.

Looping will continue until an error occurs or the "BREAK" key is pressed. Typing "%E" will return control to the beginning of the diagnostic.

To discontinue program execution, enter a zero (0).

HP 12062A 4-Channel Analog Output Card Diagnostic (AOUTD)

After typing "RUN<cr>", the following messages will be displayed:

12062A ANALOG OUTPUT CARD DIAGNOSTICS

INPUT SELECT CODE: Enter the octal select code. Test hood part no. is 12062-60002.

CHECKING CONTROL REGISTER 31 OPERATION
CONTROL REGISTER OK-CHECKING FLAGS

PASS COMPLETE
INPUT SELECT CODE:

Indicates successful completion of the 12062A Diagnostic.

To run the diagnostic again, reenter the select code for another complete pass, or enter a <cr> to put the diagnostic in the loop mode.

Looping will continue until an error occurs or the "BREAK" key is pressed. Typing "%E" will return control to the beginning of the diagnostic.

To discontinue program execution, enter a zero (0).

Interactive Diagnostics

Type “RUN I<cr>” to display the following information:

USER INTERACTION TEST
ENTER: RU C FOR ANALOG OUTPUT CALIBRATION
ENTER: RU A FOR ANALOG AND DIGITAL OUTPUTS

Analog Output Calibration

After typing “RU C<cr>”, the following messages will be displayed:

HOOD INSTALLED? If “NO” is the answer the diagnostic will not proceed with the calibration.

ENTER CARD SELECT CODE IN OCTAL Enter the octal select code.

TWEAK GAIN POTS SO ALL CHS READ -10240 MV
HIT <cr> TO ADJUST GAINS FOR ALL CHS

TWEAK GAIN POTS SO ALL CHS READ +10235 MV
HIT <cr> TO ADJUST GAINS FOR ALL CHS

END CALIBRATION PROGRAM Indicates successful completion of the Analog Output Calibration.

Analog and Digital Output Program

After typing “RU A<cr>”, the following messages will be displayed:

HOOD INSTALLED? If “NO” is the answer, the diagnostic will not proceed.

INPUT CARD SELECT CODE IN OCTAL Enter the octal select code.

ENTER THE DESIRED CHANNEL (0, 1, 2, 3)

ENTER OUTPUT VALUE IN MV (-10240 TO 10235)

ENTER DESIRED DIGITAL OUTPUTS (1=HIGH, 0=LOW)

DO YOU WANT ANOTHER OUTPUT If the answer “YES” is entered, the program will begin again asking for the select code. Any other answer will display the following message:

END ANALOG OUTPUT PROGRAM Indicates successful completion.

HP 12063A Isolated Digital I/O Card Diagnostic (DIGIO)

After typing "RUN<cr>", the following messages will be displayed:

12063A ISOLATED DIGITAL I/O DIAGNOSTIC

INPUT SELECT CODE: Enter the octal select code.

TESTING RELAY REGISTER These messages are displayed as each
TESTING MASK REGISTER section passes its test.
TESTING PRESCALE REGISTER
TESTING SENSE REGISTER
TESTING SENSE OVERRIDE REGISTER

HOOD INSTALLED? Enter "YES<cr>" or "NO<cr> ". Test hood
part no. is 12063-60002.

HOOD TEST NOT EXECUTED Diagnostic test hood is not installed.

The test hood is installed and the following tests are executed. Each message is displayed as each section passes its test.

TESTING RELAYS AND OPTOCOUPERS
TESTING INTERRUPT MASK FUNCTION
TESTING INTERRUPT POSITIVE SENSE FUNCTION
TESTING INTERRUPT NEGATIVE SENSE FUNCTION
TESTING INTERRUPT STORAGE AND SENSE OVERRIDE

CARD PASSES ALL TESTS Indicates successful completion of the
PASS COMPLETE 12063A Interface diagnostic.

To run the diagnostic again, reenter the select code for another complete pass, or enter a <cr> to put the diagnostic in the loop mode.

Looping will continue until an error occurs or until the "BREAK" key is pressed. Typing "%E" will return control to the beginning of the diagnostic.

To discontinue program execution, enter a zero (0).

Optional Diagnostics

There are five optional diagnostic programs to help in troubleshooting the HP 12063A.

To get a list of the optional programs, enter “RU I<cr>”.

To run any of the programs, enter “RU p<cr>” where p is the program letter.

- Program W This program allows an octal word to be written to any register. (For a complete description of registers, refer to the *HP 12063A Operating and Service Manual*, part no. 12063-90001.)
- Program R This program allows you to read octal data from any register.
- Program T This program will display a timing profile for any relay transition state for a specified number of readings.
- Program X This program allows you to set the maximum allowable operate time for the relays during the hood tests.
- Program C This program allows you to reset the HP 12063A.

HP 12072A Data Link Diagnostic (FDL)

After typing “RUN<cr>”, the following messages will be displayed:

12072A DATA LINK DIAG – REV 2213. Test hood part no. is 5061-4909

FDL DIAGNOSTICS
LOOP MODE: DISABLE, MESSAGE PRINTING: ENABLE
FDL: Enter “??<cr>” or “<cr>” to obtain a list
of available commands and diagnostic tests.

FDL DIAGNOSTICS AVAILABLE COMMANDS

?? LIST THIS HELP MESSAGE
EX TERMINATE THIS FDL DIAGNOSTIC
LD DISABLE LOOPING MODE
LE ENABLE LOOPING MODE
PD DISABLE MESSAGE PRINTING
PE ENABLE MESSAGE PRINTING
RF RUN ALL FIELD DIAGNOSTICS
SC SET SELECT CODE

AVAILABLE FIELD DIAGNOSTICS

1. RESET & SELF-TEST
2. NOOP TEST
3. ENABLE CARD TEST
4. ABORT INPUT TEST
5. ABORT OUTPUT TEST
6. DUMP INPUT TEST
7. STATUS REQUEST TEST
8. HOST TO PCA DATA TRANSFER TEST (PRI CH)
9. DATA LOOP BACK TEST (PRI CH)
10. HOST TO PCA DATA TRANSFER TEST (SEC CH)

LOOP MODE: DISABLE, MESSAGE PRINTING ENABLE
FDL: Enter the command or test number.

STARTING SELECT CODE: If this is the first test you are running, it will prompt you for the select code. Otherwise it will display the select code you have already chosen. To change the select code, enter the SC command when you have the FDL prompt.

NUMBER OF FDL BOARD(S): Enter the number of data link boards you want tested.

TEST xx SC xx PASS = xx ERR CT = XX

PASS COMPLETE

LOOP MODE: DISABLE, MESSAGE PRINTING ENABLE
FDL: Indicates successful completion of the diagnostic.

To run another test, enter the appropriate commands and test number.

To discontinue program execution, enter EX.

Error Messages

The error messages will be one of the following:

TEST xx ERROR = yyyyy

TEST xx ERROR = yyyyy iijj

where xx and yyyyy are decimal values and iijj is a hexadecimal value.

A complete list of error messages and their meanings are listed on the following pages.

HP 12072A Diagnostic Error Messages

| Error Number | Meaning |
|--------------|--|
| 101 | Failed to receive a response from the card for a reset-and-self-test command. |
| 102 | Failed to receive the correct solicited status for the reset-and-self-test command. Field iijj shows the status received. |
| 201 | Failed to receive a response from the card for the no-op cmd. |
| 202 | Failed to receive the correct solicited status for the no-op cmd. Field iijj shows the status received. The status should be 8000. |
| 301 | Failed to receive a response from the card for the enable-card command. |
| 302 | Failed to receive the correct solicited status for the enable-card command. Field iijj shows the status received. |
| 401 | Failed to receive a response from the card for the abort-input command. |
| 402 | Failed to receive the correct solicited status for the abort-input command. Field iijj shows the status received. |
| 501 | Failed to receive a response from the card for the abort-output command. |
| 502 | Failed to receive the correct solicited status for the abort-output command. Field iijj shows the status received. |
| 601 | Failed to receive a response from the card for the dump-input command. |
| 602 | Failed to receive the correct solicited status for the dump-input command. Field iijj shows the status received. |
| 701 | Failed to receive a response from the card when requesting the buffer size status. |
| 702 | The buffer size returned was zero. Field iijj shows the actual status received. jj should be nonzero. |
| 703 | Failed to receive a response from the card when requesting the message sent count status. |
| 704 | Message sent count is nonzero. Field iijj shows the status received. jj should be zero. |

HP 12072A Diagnostic Error Messages (Cont.)

| Error Number | Meaning |
|--------------|---|
| 705 | Failed to receive a response from the card when requesting the message receive count. |
| 706 | Message receive count is nonzero. Field iijj shows the status received. jj should be zero. |
| 707 | Failed to receive a response from the card when requesting the send retry count. |
| 708 | The send retry count is nonzero. Field iijj shows the status received. jj should be zero. |
| 709 | Failed to receive a response from the card when requesting the receive retry count. |
| 710 | The receive retry count is nonzero. Field iijj shows the status received. jj should be zero. |
| 801 | Failed to receive a response from the card for the reset-and-self-test command. |
| 802 | Failed to receive the correct solicited status to the reset-and-self-test command. Field iijj shows the status received. |
| 803 | Failed to receive a response from the card for the write cmd. |
| 804 | Failed to receive the correct solicited status for the write cmd. Field iijj shows the status received. jj should be nonzero. |
| 805 | Data transfer from host to card failed when using the host DMA |
| 806 | Failed to receive a response from the card for the end-ofdata-transfer command. |
| 807 | Failed to receive the correct solicited status for the end-of data-transfer command. Field iijj shows the status received. |
| 808 | Failed to receive a response from the card for the write cmd. |
| 809 | Failed to receive the correct solicited status for the write cmd. Field iijj shows the status received. jj should be nonzero. |
| 810 | Failed to receive a response from the card for the start-of data-transfer command. |
| 811 | Failed to receive the correct solicited status for the start-of data-transfer command. Field iijj shows the status received. |

HP 12072A Diagnostic Error Messages (Cont.)

| Error Number | Meaning |
|--------------|--|
| 812 | Programmed I/O failed. No response from the card was received to send a data word. |
| 813 | Failed to receive a response from the card for the write cmd. |
| 814 | Failed to receive the correct solicited status to the write cmd. Field iijj shows the status received. jj should be nonzero. |
| 815 | Failed to receive a response from the card for the start-of data-transfer command. |
| 816 | Failed to receive the correct solicited status for the start-of data-transfer command. Field iijj shows the status received. |
| 817 | Programmed I/O failed. No response from the card was received to send the next data word. |
| 818 | Failed to receive a response from the card for the end-of data-transfer command. |
| 819 | Failed to receive the correct solicited status for the end-of data-transfer command. Field iijj shows the status received. |
| 820 | Failed to receive a response from the card for the write cmd. |
| 821 | Failed to receive the correct solicited status for the write cmd. Field iijj shows the status received. jj should be zero. |
| 822 | Failed to receive a response from the card for the reset-and-self-test command. |
| 823 | Failed to receive the correct solicited status for the reset-and-self-test command. Field iijj shows the status received. |
| 901 | Failed to receive a response from the card for the reset-and-self-test command. |
| 902 | Failed to receive the correct solicited status for the reset-and-self-test command. Field iijj shows the status received. |
| 903 | Failed to receive a response from the card for the enable diagnostics mode command. |
| 904 | Failed to receive the correct solicited status for the diagnostics mode command. Field iijj shows the status received. |
| 905 | Failed to receive a response from the card for the write cmd. |
| 906 | Failed to receive the correct solicited status for the write cmd. Field iijj shows the status received. |

HP 12072A Diagnostic Error Messages (Cont.)

| Error Number | Meaning |
|--------------|--|
| 907 | DMA failed when transferring data from the host to the card. |
| 908 | Failed to receive a response from the card for the end-ofdata-transfer command. |
| 909 | Failed to receive the correct solicited status for the end-of data-transfer command. Field iijj shows the status received. |
| 910 | Failed to receive the unsolicited read status from the card. |
| 911 | Failed to receive a response from the card for the unsolicited status acknowledge command. |
| 912 | Failed to receive the correct solicited status for the unsolicited status acknowledge command. Field iijj shows status received. |
| 913 | Failed to receive the correct unsolicited status. Field iijj shows the status received. |
| 914 | Failed to receive a response from the card for the read cmd. |
| 915 | Failed to receive the correct solicited status for the read command. Field iijj shows the status received. |
| 916 | DMA failed for the data transfer from the card to the host. |
| 917 | Failed to receive a response from the card for the end-ofdata-transfer command. |
| 918 | Failed to receive the correct solicited status for the end-of data-transfer command. Field iijj shows the status received. |
| 919 | The loop-back data is not the same as the sent data. |
| 920 | Failed to receive a response from the card for the reset-and self-test command. |
| 921 | Failed to receive the correct solicited status for the reset-and-self-test command. Field iijj shows the status received. |
| 1001 | Failed to receive a response from the card for the reset-and-self-test command. |
| 1002 | Failed to receive the correct solicited status to the reset-and-self-test command. Field iijj shows the status received. |
| 1003 | Failed to receive a response from the card for the write cmd. |
| 1004 | Failed to receive the correct solicited status for the write cmd. Field iijj shows the status received. jj should be nonzero. |

HP 12072A Diagnostic Error Messages (Cont.)

| Error Number | Meaning |
|--------------|--|
| 1005 | Data transfer from host to card failed when using host DMA |
| 1006 | Failed to receive a response from the card for the end-of data-transfer command. |
| 1007 | Failed to receive the correct solicited status for the end-of data transfer command. Field ijij shows the status received. |
| 1020 | Failed to receive a response from the card for the write cmd. |
| 1021 | Failed to receive the correct solicited status for the write cmd. Field ijij shows the status received. jj should be zero. |
| 1022 | Failed to receive a response from the card for the reset-and-self-test command. |
| 1023 | Failed to receive the correct solicited status for the reset-and-self-test command. Field ijij shows the status received. |

HP 12100A A400 On-Board I/O (OBIO)

After typing "RUN<cr>", the following messages will be displayed:

INPUT SELECT CODE: Enter 77 (octal) for OBIO.

HOOD INSTALLED? Enter "yes<cr>" or "no<cr>". Test hood part no. is 12100-60004.

FIRMWARE REVCODE IS : This message is displayed if you answered
xx REGISTER TEST "yes" to the previous question.

REGISTER TEST PASSED
CPU TO MCU COMMUNICATION TEST Indicates successful completion of the register test.

CPU TO MCU COMMUNICATION TEST PASSED Indicates successful completion of the CPU to MCU test.

LOOPBACK HOOD TEST

Indicates that the Loopback Hood Test has started if a "yes" was entered to the loopback hood installed question.

Note: To test ports B and C, install the RS-422 side of the loopback hood. Set the switch on the breakout panel to DCE for the port being tested, then run the test.

RS-422 can only be tested with DCE. Reinstall the loopback hood with the RS-232 side.

LOOPBACK HOOD INSTALLED ON PORT A?

Answer "yes" to have the port tested or "no" to go to the next port. You will then be prompted for Ports B, C, and D in the same manner. Note that all four ports must be configured before any tests are run.

THE RS 422 STANDARD APPEARS TO BE INSTALLED ON PORT C
(RI AND CTS ASSERTED WHEN RTS ASSERTED)

or

THE RS 232 STANDARD APPEARS TO BE INSTALLED ON PORT B
(CD AND DSR ASSERTED WHEN RTS ASSERTED)

This message is displayed if Port B and/or Port C have been selected for testing.

It is possible to test all four ports in a single pass if you have four test hoods available. If you have only one test hood, you must move the hood and repeat the test for each port to be tested.

ARE YOU IN LOOPING MODE?

This message is displayed when all of the ports with loopback hoods have been tested. If you answer "yes", there will be no further prompts concerning loopback hood tests. The test continues to loop on the ports selected. Normally you would not do this if you have previously chosen the looping mode.

If you answer "no", the following message will be displayed:

DO YOU WANT TO TEST MORE PORTS?

If you enter "yes", then you are prompted to select ports to be tested by again entering "yes" to the appropriate prompt.

LOOPBACK HOOD INSTALLED ON PORT A?
LOOPBACK HOOD INSTALLED ON PORT B?
LOOPBACK HOOD INSTALLED ON PORT C?
LOOPBACK HOOD INSTALLED ON PORT D?

Use this sequence to re-execute the test with the same ports testing the other communication standard, or to test additional ports when using a single hood..

DO YOU WANT TO TEST MORE PORTS?

Terminates the looping test sequence if you answer "no".

PASS COMPLETE
INPUT SELECT CODE

Indicates termination of the first pass if you answered "no" to previous question.

To run the diagnostic again, reenter the select code 77 for another complete pass, or enter a <cr> to put the diagnostic in the loop mode.

Looping will continue until an error occurs or the "BREAK" key is pressed. Typing a "%E" will return control to the beginning of the diagnostic.

To discontinue program execution, enter a zero (0).

The execution time with all the test hoods is about 60 seconds. The execution time without a test hood is about 30 seconds.

HP 12153A Writable Control Store (WCS)

NOTE

Always execute the IOM diagnostic before running WCS to ensure proper operation of I/O Master functions.

The Writable Control Store (WCS) diagnostic provides a test of both the I/O backplane interface and the micro-instruction frontplane interface on the WCS card. The diagnostic also checks the address counter, map RAM, and data RAMs on the card.

Testing begins with the lowest priority WCS card (adjacent to processor card) installed in the computer system, and tests each WCS card in turn from the lowest to the highest priority.

Type "RUN<cr>" to begin the diagnostic.

HP 12205A Control Store Card (CSIC)

After typing “RUN<cr>”, the following messages will be displayed:

12205A CONTROL STORE CARD DIAGNOSTIC

INPUT SELECT CODE: Enter the octal select code

PASS COMPLETE Indicates successful completion of the
INPUT SELECT CODE: 12205A Diagnostic.

To run the diagnostic again, reenter the select code for another complete pass, or enter a <cr> to put the diagnostic in the loop mode.

To discontinue program execution, enter a zero (0).

Under the single test diagnostic operation, enter the following runstring:

RU T x y z

where:

x = test number

y = loop number

z = select code of control store card

The CSIC diagnostic contains five separate tests.

| Test # | Test Description |
|--------|--------------------------------|
| 1 | Turn Control Store Card On |
| 2 | Turn Control Store Card Off |
| 3 | Read/Write Test |
| 4 | Frontplane Test |
| 5 | Download and Execute Microcode |

HP 24398B Diagnostic Media Options

Option 044, 3.5-Inch Floppies

Rev. 5000 thru 5020

| Part Number | Label | Program | File # |
|-------------|-----------------|------------------------|--------|
| 24398-13414 | MCFLPY PRPHL D1 | EXRTP (EXER & TAPE) | 0 |
| 24398-13415 | MCFLPY PRPHL D2 | OPER MTVER | 0 2 |
| 24398-13416 | MCFLPY PRPHL D3 | MACICD | 0 |
| 24398-13417 | MCFLPY PRPHL D4 | MTEXR | 0 |
| 24398-13418 | MCFLPY PRPHL D5 | TESTM | 0 |

Rev. 5270

| Part Number | Label | Program | File # |
|-------------|-----------------|------------------------|--------|
| 24398-13414 | MCFLPY PRPHL D1 | EXRTP (EXER & TAPE) | 0 |
| 24398-13415 | MCFLPY PRPHL D2 | MTVER | 0 |
| 24398-13416 | MCFLPY PRPHL D3 | OPER | 0 |
| 24398-13417 | MCFLPY PRPHL D4 | MTEXR | 0 |
| 24398-13418 | MCFLPY PRPHL D5 | TESTM | 0 |

Option 022, CS/80 Cartridge Tape

Rev. 5000

| Part Number | Description | Program | File # |
|-------------|---|---------|--------|
| 24398-13318 | 24398B Diagnostics only | CINFDS | 0 |
| | | EXRTP | 2 |
| | | OPER | 6 |
| | | MTVER | 10 |
| | | MACICD | 12 |
| | | MTEXR | 17 |
| | | TESTM | 22 |
| | | LANMEM | 24 |
| 24998-13328 | ARSTR, PBV, FORMF DIAGS Bootable Files | CINFO | 0 |
| | | 24612A | 2 |
| | | EXRTP | 15 |
| | | OPER | 21 |
| | | MTVER | 23 |
| | | MACICD | 25 |
| | | MTEXR | 31 |
| | | TESTM | 34 |
| | | LANMEM | 36 |
| | | !ARSTR | 44 |
| | | !PBV | 53 |
| | | FORMF | 56 |
| | | FRMER | 61 |

Rev. 5010, 5012, 5020

| Part Number | Description | Program | File # |
|--------------------|---|---|--|
| 24398-13318 | 24398B Diagnostics only | CINFDS EXRTP OPER MTVER MACICD MTEXR TESTM LANMEM | 0 2 6 10 12 17 22 24 |
| 24998-13328 | ARSTR, PBV, FORMF DIAGS Bootable Files | CINFO 24612A EXRTP OPER MTVER MACICD MTEXR TESTM LANMEM !ARSTR !PBV FORMF FRMER | 0 2 15 21 23 25 32 35 37 45 54 57 62 |

Rev. 5270

| Part Number | Description | Program | File # |
|--------------------|---|--|--|
| 24398-13318 | 24398B Diagnostics only | CINFDS EXRTP OPER MTVER MTEXR TESTM LANMEM | 0 2 6 10 12 15 17 |
| 24998-13328 | ARSTR, VSCSI, FORMF DIAGS Bootable Files | CINFO 24612A EXRTP OPER MTVER MTEXR TESTM LANMEM !ARSTR !VSCSI FORMF | 0 2 15 21 23 25 30 32 40 47 54 |

Option 051, 1600 bpi Magnetic Tape

Rev. 5000

| Part Number | Description | Program | File # | | |
|-------------|---|---------|--------|--------|-----|
| 24398-13501 | 24398B Diagnostics only | TINFDS | 1 | | |
| | | EXRTP | 2 | | |
| | | OPER | 3 | | |
| | | MTVER | 4 | | |
| | | MACICD | 5 | | |
| | | MTEXR | 6 | | |
| | | TESTM | 7 | | |
| | | LANMEM | 10 | | |
| 24998-13540 | ARSTR, PBV, FORMF DIAGS Bootable Files | TINFO | 1 | | |
| | | !ARSTR | 2 | | |
| | | FORMF | 3 | | |
| | | FRMER | 4 | | |
| | | !PBV | 5 | | |
| | | 24612A | 6 | | |
| | | EXRTP | 103 | | |
| | | OPER | 104 | | |
| | | MTVER | 105 | | |
| | | MACICD | 106 | | |
| | | MTEXR | 107 | | |
| | | TESTM | 110 | | |
| | | | | LANMEM | 111 |

Rev. 5010, 5012, 5020

| Part Number | Description | Program | File # |
|--------------------|---|----------------|---------------|
| 24398-13501 | 24398B Diagnostics only | TINFDS | 1 |
| | | EXRTP | 2 |
| | | OPER | 3 |
| | | MTVER | 4 |
| | | MACICD | 5 |
| | | MTEXR | 6 |
| | | TESTM | 7 |
| | | LANMEM | 10 |
| 24998-13540 | ARSTR, PBV, FORMF DIAGS Bootable Files | TINFO | 1 |
| | | !ARSTR | 2 |
| | | EXRTP | 3 |
| | | OPER | 4 |
| | | MTVER | 5 |
| | | MACICD | 6 |
| | | MTEXR | 7 |
| | | TESTM | 10 |
| | | LANMEM | 11 |
| | | A24612 | 13 |
| | | FORMF | 110 |
| | | FRMER | 111 |
| !PBV | 112 | | |

Rev. 5270

| Part Number | Description | Program | File # |
|--------------------|---|----------------|---------------|
| 24398-13501 | 24398B Diagnostics only | TINFDS | 1 |
| | | EXRTP | 2 |
| | | OPER | 3 |
| | | MTVER | 4 |
| | | MTEXR | 5 |
| | | TESTM | 6 |
| | | LANMEM | 7 |
| 24998-13540 | ARSTR, VSCSI, FORMF DIAGS Bootable Files | TINFO | 1 |
| | | !ARSTR | 2 |
| | | EXRTP | 3 |
| | | OPER | 4 |
| | | MTVER | 5 |
| | | MTEXR | 6 |
| | | TESTM | 7 |
| | | LANMEM | 10 |
| | | 24612A | 12 |
| | | !VSCSI | 107 |
| FORMF | 110 | | |

Option AAH, SCSI DAT Tape

Rev. 5270

| Part Number | Description | Program | File # |
|-------------|---|---------|--------|
| 24398-13621 | 24398B Diagnostics only | TINFDS | 1 |
| | | EXRTP | 2 |
| | | OPER | 3 |
| | | MTVER | 4 |
| | | MTEXR | 5 |
| | | TESTM | 6 |
| | | LANMEM | 7 |
| 24998-13614 | ARSTR, VSCSI, FORMF DIAGS Bootable Files | TINFO | 1 |
| | | !ARSTR | 2 |
| | | EXRTP | 3 |
| | | OPER | 4 |
| | | MTVER | 5 |
| | | MTEXR | 6 |
| | | TESTM | 7 |
| | | LANMEM | 10 |
| | | 24612A | 12 |
| | | !VSCSI | 107 |
| FORMF | 110 | | |

Loading Diagnostics from 3.5-Inch Floppies

To load the HP 24398B diagnostics from floppies, insert the floppy that has the diagnostic program you want to run and enter the following bootstring:

```
VCP> %Bxxfbusc
```

- where: *xx* = DC for CS/80 disks
DI for Micro/1000 integrated disk w/ 12022 controller:
- f* = file number of diagnostic program
- b* = HP-IB bus address; b=3 for integrated disk w/ 12022.
- u* = unit
- sc* = select code

Refer to the Primary System Configuration tables in Chapter 3 to determine the values of *b*, *u*, and *sc* to use for the device from which you are booting. Note that these only apply to the Primary System; your system configuration may differ.

Loading Diagnostics from CS/80 Cartridge Tapes

The HP 24612A/24398B diagnostics are available with the Primary System on the following CS/80 cartridge tapes:

24998-13327 (Primary/Diags/Master)
24998-13328 (ARSTR, VSCSI, FORMF, DIAGS Bootable Files)

The diagnostics listed on tape number 24998-13327 are the same as those on tape number 24998-13328. The 24998-13327 version must first be restored to disk using ARSTR, before they can be accessed.

The diagnostics on the 24998-13328 tape are bootable from the cartridge tape drive. The contents of the CS/80 tape 24998-13328 are listed in a file called CINFO. CINFO is a bootable system whose only purpose is to print a file that lists the name and sequence number of bootable files on the tape.

There is one copy of CINFO. It can be read by entering one of the following bootstrings:

VCP> %bdc1027 (for the HP 9144/45 tape drive)

VCP> %bdc127 (for other CS/80 tape drives)

Then press the break key and re-enter the bootstring using the file number of the diagnostic you want to run.

NOTE

The file sequences of these diagnostics, shipped with the Primary System, are not the same as those for the HP 24398B and HP 24612A standalone products. When using the diagnostic manuals, use the file numbers in the CINFO file on the 24998-13328 tape instead of those listed in the manuals. These numbers must be in the bootstring in order to select the diagnostic you wish to run. Also note that file numbers may change from one revision to another; thus, read your actual tape to get the file numbers.

Loading Diagnostics from 1600 bpi Magnetic Tape

The HP 24612A/24398B diagnostics are supplied with the Primary System on the following 1600 bpi magnetic tapes:

24998-13539 (Primary/Diags/Master)
24998-13540 (ARSTR, VSCSI, FORMF, DIAGS Bootable Files)

The diagnostics contained on tape number 24998-13539 are the same as those on tape number 24998-13540. The 24998-13539 version must first be restored to disk using ARSTR, before they can be accessed.

The diagnostics on the 24998-13540 tape are bootable from the magnetic tape drive. The contents of the mag tape 24998-13540 are listed in a file called TINFO. TINFO is a bootable system whose only purpose is to print a file that lists the name and sequence number of bootable files on the tape.

There is one copy of TINFO. It can be read by entering one of the following bootstrings:

VCP> %bmt13027 (for the HP 7974/78/79/80 tape drive)

VCP> %bmt14027 (for the HP 7970† mag tape drive)

Then press the break key and re-enter the bootstring using the file number of the diagnostic you want to run.

NOTE

The file sequences of these diagnostics, shipped with the Primary System, are not the same as those for the HP 24398B and HP 24612A standalone products. When using the diagnostic manuals, use the file numbers in the TINFO file on the 24998-13540 tape instead of those listed in the manuals. These numbers must be in the bootstring in order to select the diagnostic you wish to run. Also note that file numbers may change from one revision to another; thus, read your actual tape to get the file numbers.

† When booting the HP 24612A diagnostics on rev 2540 and 4010 tapes from an HP 7970E* using an A900 with a rev 13 (or later) base set, the diagnostic will fail with the message:

MTDVR #1 ERROR 6
DVR ERROR 24

This is due to BCM timing out when searching for diagnostic files after rewinding since larger (ARSTR) files are stored at the beginning of the tape. To avoid this, use a rev 5.0 (or later) tape.

Loading Diagnostics from SCSI DAT

The HP 24612A/24398B diagnostics are supplied with the Primary System on the following SCSI DAT tapes:

24998-13613 (Primary/Diags/Master)
24998-13614 (ARSTR, VSCSI, FORMF, DIAGS Bootable Files)

The diagnostics contained on tape number 24998-13613 are the same as those on tape number 24998-13614. The 24998-13613 version must first be restored to disk using ARSTR, before they can be accessed.

The diagnostics on the 24998-13614 tape are bootable from the SCSI DAT tape drive. The contents of tape 24998-13614 are listed in a file called TINFO. TINFO is a bootable system whose only purpose is to print a file that lists the name and sequence number of bootable files on the tape.

There is one copy of TINFO. It can be read by entering the following bootstring:

```
VCP> %bmt15027
```

Then press the break key and re-enter the bootstring using the file number of the diagnostic you want to run.

NOTE

The file sequences of these diagnostics, shipped with the Primary System, are not the same as those for the HP 24398B and HP 24612A standalone products. When using the diagnostic manuals, use the file numbers in the TINFO file on the 24998-13614 tape instead of those listed in the manuals. These numbers must be in the bootstring in order to select the diagnostic you wish to run. Also note that file numbers may change from one revision to another; thus, read your actual tape to get the file numbers.

HP 24398B Peripheral Diagnostics

CS/80 Disk Diagnostics

For operating instructions and error messages refer to the CS/80 Exerciser Manual (part no. 5955-3462).

To load the diagnostics, insert the media containing the diagnostic and enter the appropriate bootstring.

Hit any key to get the RTE prompt, then type the following:

```
RTE:RU,name,1,1
```

where:

```
name = EXER  
      TAPE  
      OPER
```

Notes:

- 1. EXER and TAPE are contained in the file named EXRTP.
- 2. OPER is contained in the file named OPER.
- 3. 1,1 is required by all CS/80 diagnostic programs before rev. 2540.

CS/80 EXTERNAL EXERCISER

Input drive LU?

Rev. 2540 or before

| HP-IB Address | SC 27 | SC 25 |
|---------------|-------|-------|
| 0 | LU 10 | LU 20 |
| 1 | LU 11 | LU 21 |
| 2 | LU 12 | LU 22 |
| 3 | LU 13 | LU 23 |
| 4 | LU 14 | LU 24 |
| 5 | LU 15 | LU 25 |
| 6 | LU 16 | LU 26 |
| 7 | LU 17 | LU 27 |

Rev. 4010

| HP-IB Address | SC 27 |
|---------------|-------|
| 0 | LU 10 |
| 1 | LU 11 |
| 2 | LU 12 |
| 3 | LU 13 |
| 4 | LU 14 |
| 5 | LU 15 |
| 6 | LU 16 |
| 7 | LU 17 |

Input DRIVE ADDRESS?
[HP-IB address of CS/80 drive]

Input the test name

RTE:RU,EXER

The following commands are available when running under the EXER program:

- CE MODE[†] – enables CE capabilities at rev 5.0 (and later)
- CANCEL – cancels the previous command
- CHANNEL – HP-IB channel test
- CICLEAR – channel independent clear utility
- CLEAR LOGS – clear internal logs
- DIAG – internal diagnostic test
- ERRSUM – print error summary data
- ERT LOG – print ERROR RATE TEST log
- EXIT – either stops program or re-prompts for test name
- EXIT – is allowed as an input for all input prompts
- FAULT LOG – print drive fault log
- INIT MEDIA – initializes the selected devices media
- HELP – prints this file over
- PRESET – preset drive utility
- REQSTAT – request status message
- REV – print revision data
- RF SECTOR – read full sector utility
- RO ERT – read only error rate test
- RUN LOG – print run-time data error log
- SDCLEAR – selected device clear
- SENSE – print sensor data
- SPARE – spare block utility
- TABLES – print internal table data
- UNIT – set unit utility
- WTR ERT – write then read ERT

RTE:RU,TAPE

The following commands are available when running under the TAPE program:

Note: When testing an HP 9144A Tape Subsystem, run the UNIT utility to set the unit to 0. When testing HP 791x* Integrated Cartridge Tape drive Subsystems, set the unit to 1.

| | |
|------------|--------------------------------------|
| CANCEL | – cancels the previous command |
| CERT | – certify tape |
| CICLEAR | – channel independent clear utility |
| CLEAR LOGS | – clear internal logs |
| ERT LOG | – print ERROR RATE TEST summary data |
| HELP | – prints this file over |

* Discontinued product; shown for reference only.

† Commands involving writing to a disk require CE capabilities at rev 5.0 (and later).

| | |
|------------|----------------------------------|
| INIT MEDIA | – format media utility |
| PRESET | – preset drive utility |
| RO ERT | – read only error rate test |
| REQSTAT | – request status |
| RUN LOG | – print run-time data error log |
| SDCLEAR | – selected device clear |
| SPARE – | spare block utility |
| TABLES | – print internal table data |
| UNIT | – set unit utility |
| UNLOAD | – unload tape utility |
| USE LOG | – print TAPE use log |
| WRITE FM | – write end of file mark on tape |
| WTR ERT | – write then read ERT |

RTE:RU,OPER

The following commands are available when running under the OPER program:

- HELP – prints this list over
- EXEC – executes the command steps
- EDIT – allows the editing of program steps
- LIST – allows the listing of program steps
- STOP – stops this program
- NEW – restarts the program from step 1
- EXIT – exits this program; EXIT is allowed for all input

Allowable Program Steps:

- LCRD – Locate and read
- LCWR – Locate and write
- CMPR – Write, Read and compare
- COMP – Complementary commands
- RQST – Request status
- CLR – Channel Independent Clear
- LOOP – Loop the following program steps until the end of the program or the first ENDLP command is encountered
- ENDLP – Described above
- INSK – Incremental seek
- NULL – Nulls a program step

CS/80 Error Information

For unsuccessful data transmissions, the system will return the following error messages.

I/O -RQ LUxx

An illegal I/O request was received for one of the following reasons:

1. Negative track or sector value was specified.
2. Odd valued sector number was specified.
3. Sector or track number was specified that was greater than the maximum allowed value.
4. Attempt was made to write more sectors than are available on the disk.

I/O -NR LUxx,D

LUxx not ready due to one of the following reasons:

1. No disk.
2. Drive not connected.
3. Tape not inserted.

I/O -TE LUxx

Disk transmission error.

I/O -WP LUxx

Device write protected.

I/O -FA LUxx

Drive fault.

I/O -TO LUxx

Drive or device not connected or on-line.

RTE-A DD*33 Error Decoding

If an error occurs from the CS/80 disk device driver, DD*33, the following error messages will be output to the terminal:

```
LU xx ty ST = XXXXXX  
PARM = AAAAAA BBBBBB CCCCCC  
DDDDDD EEEEEEE
```

where:

- xx is the LU number.
- ty is the two-letter type of error as shown below and explained on the following pages:
 - RE = Reject Errors = Class 1
 - FA = Fault Errors = Class 2
 - TE = Access Errors = Class 3
 - IN = Information Errors = Class 4
 - WN = Driver Retry (CS/80 timeout)

XXXXXX is an octal field format representation for the error class. This octal number can be looked up directly on the following pages for specific details concerning error.

PARM is the five word parameter field in DECIMAL representation.

Interpretation of PARM for all errors, unless noted otherwise in the class error field definition, is as follows:

1. Convert decimal values in each field to a hexadecimal value. Arrange (for convenience) the new values as shown here:

```
AAAAAA = H1H2 BBBBBB = H3H4  
CCCCCC = H5H6 DDDDDD = H7H8  
EEEEEE = H9H0
```

Conversion notes: 16E3 = 4,096; 16E2 = 256;
decimal-to-hex: 10=A 11=B 12=C 13=D 14=E 15=F

2. H1 through H0 are the hex CS/80 parameters P1-P0 respectively.

3. P1-P6 (H1-H6) together form the new target block address on the disk drive. This information can be usually disregarded except when noted differently in specified error field description.
4. P7-P10 (H7-H10) are the four most recent DERRs from the CS/80 disk drive. For 793x drives these numbers individually must be converted to decimal in order to look up in DMDs handbook.

Class of Errors

RE – Reject Errors Field

The reject errors field format is:

< x x 1 x x 2 3 4 5 6 7 x 8 x x x >

where:

- 1 – Channel Parity Errors (2000B)
A channel command was received without odd parity.
- 2 – Illegal Opcode (2000B)
Unrecognizable opcode was received.
- 3 – Module Addressing (1000B)
Illegal unit or volume was received.
- 4 – Address Bounds (400B)
The target address exceeded the bounds for this device.
- 5 – Parameter Bounds (200B)
A parameter other than unit, volume, or address is out of bounds for this device.
- 6 – Illegal Parameter (100B)
A parameter field has the wrong length for the opcode preceding it.
- 7 – Message Sequence Error (40B)
The message sequence has been violated. (This error will be suppressed if any reject or fault errors have occurred prior to sequence error.)
- 8 – Message Length Error (10B)
The total length of the execution message is different from the current default values based on the present command.

Note: Reject errors are not drive related. These errors are command line, interface, and software caused.

FA – Fault Errors Field

The fault errors field format is:

< x 1 x 2 x x 3 x 4 x 5 6 7 x 8 9 >

where:

- 1 – Cross Unit Error (40000B)
Error occurred during a copy data operation. Parameters P1-P6 contain the encoded values of each unit which experienced an error. A byte of all ones indicates no additional units.
- 2 – Controller Fault (10000B)
Hardware controller fault has occurred.
- 3 – Unit Fault (1000B)
Hardware unit fault has occurred.
- 4 – Diagnostic Result (200B)
Hardware failed a diagnostic test, indicated in the parameter field as follows:

P1-P2 contain the most and next-most suspect component, P3-P4 contain the TERROR associated with P1-P2, respectively,
P5-P6 are not used,
P7-P10 contain DERROR information as usual.
- 5 – Release for Operator Request (40B)
Release is required by the drive to service an operator request; i.e., load or unload. Programs should grant or deny this request.
- 6 – Release Required for Diagnostic (20B)
Release is required for diagnostics initiated from the front panel.
- 7 – Release Required for Internal Maintenance (10B)
Release is required so that the drive can update logs or perform head alignment. If release is not granted, error information may be lost.
- 8 – Power-Fail (2B)
Power to the drive failed, a diagnostic destroyed drive state, or a pack was loaded.

- 9 – Release Completed (1B)
The drive has returned from automatic release; the preceding transaction should be retried.

TE – Access Errors Field

The access errors field format is:

< 1 2 3 4 5 6 x x 7 8 x 9 10 x x x >

where:

- 1 – Illegal Parallel Operation (100000B)
The operation requested cannot be executed in parallel with other operations in progress.
- 2 – Uninitialized Medium (40000B)
The medium is unformatted or unusable in this device.
- 3 – No Spares Available (20000B)
The spare block command cannot be executed due to lack of spare media.
- 4 – Not Ready (10000B)
The selected unit is not ready for access at this time.
- 5 – Write Protect (4000B)
The selected volume is write protected.
- 6 – No Data Found (2000B)
A block accessed during a read has not been written.
- 7 – Unrecoverable Data Overflow (200B)
The last transaction had more than one unrecoverable data error.
- 8 – Unrecoverable Data Error (100B)
The controller was unable to read data at block address in the parameter field (P1-P6). The data cannot be totally recovered, although reading with maximum retries will get the controller's best guess.
- 9 – End of File (20B)
An end of file mark was encountered during the read.
- 10 – End of Volume (10B)
The last access attempted to access past the end of the volume. The parameter field (P1-P6) contains the block address of the last block on the volume.

IN – Information Errors Field

The information errors field format is:

< 1 2 3 4 5 x x 6 x 7 8 9 x 10 x x >

where:

- 1 – Release for Operator Request (100000B)
The controller requests release to allow operator request (i.e. load/unload, save/restore.) Parameters P1-P6 contain encoded values of each unit requesting release, where a byte of all ones indicates no additional units.
- 2 – Release for Diagnostic Request (40000B)
Release for diagnostic generated by front panel or self-test. Parameter field same as in (1) above.
- 3 – Release for Internal Maintenance (20000B)
Request release to update error logs or perform maintenance. Parameter field same as in (1) above.
- 4 – One Spare Left (10000B)
There is only one spare block left on this media volume.
- 5 – Data Overrun/Latency Induced (4000B)
During a transfer, a latency occurred when the system could not accept data as fast as the device could send due to slow transfer rate or seek retry.
- 6 – Auto Sparring Invoked (400B)
A defective block was automatically spared by the device.
- 7 – Recoverable Data Overflow (100B)
The last transaction had more than one recoverable data error.
- 8 – Marginal Data (40B)
The last request generated an error which was recovered with difficulty. Parameters P1-P6 indicate the block address of the marginal data block.
- 9 – Recoverable Data Error (20B)
The last request generated an error which was recovered by retry or error correction. No data was lost. Parameters P1-P6 indicate the block address of recoverable data.
- 10 – Maintenance Track Overflow (4B)
The error and fault logs on the device are full.

WN – Warning – driver retry (rev 5.0 or later). Status, parameters, and error fields are not valid.

Disk Drive – Block Address Conversion

When the disk drive data block address is known, and the cylinder, head, and sector of the data is desired, perform the following:

Calculate the following using drive specific information:

- a. Divisor1 = (# Sectors/Track) x (# Data Heads)
- b. Divisor2 = (# Sectors/Track)

$$\frac{\text{Data Block Address}}{\text{Divisor1}} = \text{Cylinder with Remainder1}$$
$$\frac{\text{Remainder1}}{\text{Divisor2}} = \text{Head with Remainder2}$$
$$\text{Remainder2} = \text{Sector}$$

HP 7970E* HP-IB Verifier

For operating instructions and error messages refer to the HP 7970E* Verifier Manual (part no. 07970-90980).

The HP-IB address of the magnetic tape drive must be set to 4 and select code of the HP-IB interface must be set to 27 (for diagnostic revisions 2540 through 5020).

To load the diagnostic, insert the media containing the diagnostic and enter the appropriate boot string given in the Diagnostic Media Options and Boot Commands section.

The diagnostic will automatically run one complete pass using the defaults. Therefore, you must have the tape (with write ring) loaded and on-line.

After one complete pass, the system will return the following:

PASS 1 COMPLETE

To run the diagnostic, hit any key to get the RTE: prompt, then type the following:

RTE: RU,MTVER,1110B,[msg/HLT],[tests1],[tests2],[#passes]

* Discontinued product; shown for reference only.

where:

- msgc/hlt = 1 – Suppress information messages; halt after error messages.
 - 2 – Print error and information messages; suppress error halts.
 - 3 – Print error and information messages; permit error halts (default condition).
 - 4 – Suppress error and information messages; suppress error halts.
- tests1 = Selected test desired to be run as shown on following page. Default tests are 32777B.
- tests2 = Selected test desired to be run as shown on following page. Default test is 20000B.
- #passes = Number of passes to execute, –1 to repeat indefinitely. Default is 1 pass.

Common test selections, error information, and directive messages are shown on the following pages.

Test/Bit Selection

| | Tests 1 | | | | | | | | | | | | | | | | Tests 2 | | |
|----------|---------|----|----|----|----|----|---|---|---|----|----|----|----|----|----|----|---------|----|----|
| Bit No. | 15 | 14 | 13 | 12 | 11 | 10 | 9 | 8 | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 | 15 | 14 | 13 |
| Test No. | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 16 | 17 | 18 |

Test/Octal Selection

| Test No. | Octal No. | Test Description | |
|----------------------------|-----------|------------------|-------------------------------------|
| Tests1 | 1 | – | Not Used |
| | 2 | 40000B | Power On Test |
| | 3† | 20000B | Identify Test |
| | 4† | 10000B | Loopback Test |
| | 5 | 4000B | Manual Test |
| | 6† | 2000B | Write Gap Test |
| | 7† | – | Not Used |
| | 8† | 400B | Write Test |
| | 9† | 200B | Backspace/Forward Space Record Test |
| | 10† | 100B | Backspace/Forward Space File Test |
| | 11† | 40B | Read/Write Test |
| | 12† | – | Not Used |
| | 13† | 10B | Rewind and Busy Test |
| | 14† | 4B | BOT Checks |
| | 15† | 2B | Tape Runaway Test |
| | 16† | – | Not Used |
| Tests2 | 17 | – | Not Used |
| | 18 | – | Not Used |
| | 19† | 20000B | Rewind at End of Pass |
| † Default test selections. | | | |

Common Test Selections

RU,MTVER,1110B,3,32777B,20000B

Execute all tests that do not require operator intervention, with message and error halts enabled.

RU,MTVER,1110B,3,77777B,20000B

Execute all tests (including manual tests) with message and error halts enabled.

RU,MTVER,1110B,3,31763B,0,–1

Execute all tests (except those with manual intervention and those containing rewind) with message and error halts enabled.

Error, Information and Directive Messages

The following is a list of Verifier Error, Information, and Directive Messages. Numbers followed by a “B” are octal numbers; all other numbers are decimal numbers. A number sign (#) indicates the position of a number supplied at run-time.

| Message No. | Description |
|-------------|---|
| E01 | DSJ is # should be # |
| E04 | Status is #B #B #B should be #B #B #B |
| E05 | Poll response is #B should be #B |
| E07 | Byte # is #B should be #B |
| E08 | EOF not found where expected |
| E09 | EOF found where not expected |
| E10 | Read # bytes, expected # |
| E11 | Byte counter = #, expected # |
| I12 | Turn power Off and On |
| E13 | No poll response |
| E14 | Poll response not cleared |
| E17 | Identify is #B, should be #B |
| I18 | Mount tape without write ring, press LOAD and ON-LINE |
| I22 | Mount tape with write ring, press LOAD and ON-LINE |
| E23 | Unit still on-line |
| I24 | Put unit on-line |
| I25 | EOT |
| E28 | GAP command failed to move tape |
| E29 | WRITE PROTECT status not set |
| E30 | Tape runaway fail |
| E33 | HP-IB time-out |
| I34 | # Retries |

Status Registers

| Status Register 1 |
|--|
| DIO Lines 1 = On-line 2 = Multiple Track Error (MTE) 3 = File Protected (Not Write Enabled; No Write Ring) 4 = Command Rejected 5 = Single Track Error (STE) 6 = End-of-Tape (EOT) 7 = Load Point (LP)/Beginning-of-Tape (BOT) 8 = End-of-File (EOF) |
| Status Register 2 |
| DIO Lines 1 = Interface Busy 2 = Tape Unit Busy 3 = Rewinding 4 = Tape Runaway 5 = Data Timing Error (DTE) 6 = Selected Tape Unit LSB 7 = Selected Tape Unit MSB 8 = Reserved |
| Status Register 3 |
| DIO Lines 1 = Tape Unit 0 has been placed on-line 2 = Tape Unit 1 has been placed on-line 3 = Tape Unit 2 has been placed on-line 4 = Tape Unit 3 has been placed on-line 5 = Command Parity Error 6 = Power has been restored 7 = Reserved 8 = Reserved |

ICD/MAC Disk* Diagnostics

For operating instructions and error messages refer to the *ICD/MAC Disk Diagnostic Reference Manual* (part no. 5955-4355). Use select code 25 or 27.

NOTE

ICD disks are not supported on the A-Series Computers but may be tested using MACICD. MACICD is no longer supplied with the 24398B diagnostic product rev. 5270 and later.

To load the diagnostics, insert the media containing the diagnostic and enter the appropriate bootstring.

FORM

The FORM program is an off-line, physical disk formatting utility for MAC disk drives. However, this tool requires careful use, because it is capable of erasing all LU and spare track designations.

To best use this utility, you should have a track map table and a working knowledge of track sparing and disk formatting. The track map table is found on the first page of the generation map for the system.

FORM will report any non-zero status conditions that occur due to soft errors (such as seek retries), as well as hard errors.

| | |
|-------------|-----------------------------------|
| SP | Spare a Track |
| VE | Verify Tracks |
| RE | Reformat Tracks |
| MD | Mark a Track Defective |
| EX,EN or /E | FORM will restart and prompt TASK |

* Discontinued product; shown for reference only.

DIAG

DIAG is an interactive, stand alone disk diagnostic that tests the disk through physical references to the disk and references to other control sections of the drive.

DIAG runs on A-Series systems with physical addressing. Therefore, no device specific LUs are needed.

DIAG should only be run after the completion of the system installation and after running self-test. If self-test fails, follow the troubleshooting procedure outlined in the appropriate manual. Once self-test is passed, run the verification test supplied with the system. If the system does not boot up, fails verification test, or encounters abnormal conditions, use this diagnostic. The diagnostic returns information which can be used to isolate a fault at the module level.

DIAG requires two scratch tracks for testing. Data will be destroyed on these tracks with the preamble left intact.

ERT

ERT, the Error Rate Program, is designed to run on A-Series Systems with MAC disk drives*. It should be used when the error rate of a particular disk drive and/or media is suspected to be particularly high.

As generated, no other system activity is possible. The ERT program has complete access to the system disk and data will be overwritten and lost from the physical unit/cylinder/head combinations used by the test.

Program execution is interactive and requires a certain amount of configuration.

DISCZ

DISCZ provides the capability to string up, and loop on, any combination of the discrete disc commands that are available. This provides a capability to locate suspected problems.

* Discontinued product; shown for reference only.

Operator Control Commands

?? – Help
??,xx – where xx is any command
LL,lu – change list device
CU – change unit number
LU,lu – change disk LU
LE – lock EQT of disk LU
UE – unlock EQT
SW – set display window
IB – initialize buffer
DB – display data buffer
MW – modify word
/E – exit program
CO – send comment to list device

Disk Commands

DJ – get DSJ status
ST – get status byte
SK – seek to physical address SK, cyl, head, sector
SM – set file mask
RC – recalibrate
RA – request address
AR – address record
ID – get HP-IB ID bytes
EN – end command
RD – read data
RF – read full sector
RO – read with offset
RW – read without verify
VF – verify sectors
WD – write data
WF – write full sector
IN – initialize

Program Control Commands

EP – erase program
LP – list program
SP – start program
GO – go to; allows looping within the program
N= – loop counter
nn – add line to program

HP 7974*, 7978*, 7980 Magnetic Tape Drive Exerciser

For operating instructions and error messages refer to the 7974 Exerciser Manual (part no. 24398-90007).

To run the diagnostic, insert the media containing the diagnostic and enter the appropriate boot string given in the Diagnostic Media Options and Boot Commands section.

The memory based Exerciser software expects the tape drive under test to be at select code 27, HP-IB address 3, lu 7.

The Exerciser will begin execution, asking for the LU of the tape drive to be tested. The Exerciser then verifies the drive tape and displays the following warning and main menu:

NOTE

Some of these options are destructive to tape contents and require a SCRATCH tape.

- 1 Test All
- 2 Clear
- 3 Identify
- 4 Loopback
- 5 Power-on Self-Test
- 6 Status
- 7 Internal Device Error Logs
- 20 Selectable Self-Tests
- 30 Selectable Tape Movement Commands
- 40 Selectable Tape Write Commands
- 45 Selectable Tape Read Commands
- 50 Service Utilities

- 0 Exit the Exerciser

Enter the desired option number:

Select one of the options by number, press return, the Exerciser will proceed to execute that option. Within the option, there may be another menu to select particular functions.

* Discontinued product; shown for reference only.

Note that you can always select 0 to exit. Enter 0 in any option menu to return to the main menu. Enter 0 in the main menu to exit the Exerciser.

Error messages displayed will, in some cases, list a possible offending Field Replaceable Unit (FRU). If the option finds more than one offending FRU, the candidates will be listed in order, with the most probable offender first.

Status Registers

| Status Register 1 |
|---|
| <p>DIO Lines</p> <ul style="list-style-type: none"> 8 = End-of-File (EOF) Detected 7 = At Load Point 6 = Beyond the End-of-Tape (EOT) 5 = Error Correction or Retries Have Occurred 4 = Command Rejected – See Byte 4 3 = Loaded Tape is Write Protected 2 = Unrecoverable Data or Format Error – See Byte 5 1 = On-Line |
| Status Register 2 |
| <p>DIO Lines</p> <ul style="list-style-type: none"> 8 = Reserved 7 = Unknown Density on Tape 6 = Data Parity Error 5 = Data Error (Timing) 4 = Tape Runaway 3 = Reserved 2 = Reserved 1 = Immediate Response Mode |
| Status Register 3 |
| <p>DIO Lines</p> <ul style="list-style-type: none"> 8 = In PE (1600 BPI) Mode 7 = In NRZI (800 BPI) Mode 6 = Power Has Been Restored 5 = HP-IB Command Parity Error 4 = Tape Position is Unknown (Unrecovered) 3 = Tape Drive Formatter Error – See Byte 5 2 = Tape Drive Servo Error – See Byte 5 1 = Tape Drive Controller Error – See Byte 5 |

Status Registers (Cont.)

| Status Register 4 |
|---|
| DIO Lines 1 – 5 = Retry Count 6 – 8 = Command Rejected Error Detail 0 = No Further Detail 1 = No Further Detail 2 = Device Reject – See Byte 5 3 = Protocol Reject – See Byte 5 4 = No Further Detail 5 = Prior Error Reject – See Byte 5 6 = No Further Detail 7 = Self Test Failure |
| Status Register 5 |
| This byte contains binary coded information regarding the specific error encountered. |
| Status Register 6 |
| This byte is used only with transparent status messages of soft and hard errors in immediate response mode. It contains the number of commands pending at the time of the error. |

Systems Modem Diagnostic

Use software revision 5010 or later. For operating instructions and error messages refer to the *Systems Modem On-Line Diagnostic Manual* (part no. 24398-90004).

To run the diagnostics, insert the media containing the diagnostic and enter the appropriate boot string given in the Diagnostic Media Options and Boot Commands section.

Before execution of the diagnostic, it is necessary to initialize the port. The 'CN' program is used for this purpose. Enter the following command from the RTE prompt.

```
RTE: RU,CN,P1,P2,P3
```

where:

P1 – modem LU (must be 10–17)

P2 – 30B

P3 – port configuration word (refer to IDM00 Control Request section, Function code 30B of the RTE-A Driver Reference Manual, part no. 92077-90011).

Bits 15-14 number of bits/char (binary code):

00 = 5 bits/char

10 = 6 bits/char

01 = 7 bits/char

11 = 8 bits/char

Bit 13 Set to 1 (specifies modem port).

Bit 12 Baud rate generator used for MUX:

1 for gen. #1 or

0 for gen. #0

Refer to the 12040 MUX Installation Manual for cable connections.

Bits 11-10 Number of stop bits

00 = reserved

10 = 1.5 bits

01 = 1 stop bit

11 = 2 stop bits

Bits 9-8 Select Parity

00 = none

10 = none

01 = odd

11 = even

Bit 7 ENQ/ACK handshake: 1 – enable
0 – disable

Bits 6-3 Baud rate; 300 or 1200 for 12040

06B = 300

07B = 1200B

Bits 2-0 Port number, must be 0-6 in binary

After initializing the port, execute TESTM in the following manner:

RTE: RU,TESTM, loglu, locsc, loccp, #test,iopt,remno,locno

where:

loglu – log Device (Default = Terminal)

locsc – Local Modem Select Code (MUX Card)
(end with B for octal)

loccp – Local Modem Card Cage Port (Default = 0)

#test – Number of tests (Default = 1)

- iopt – Run Option (Default = 0)
 - 0 – for test 1 high speed local analog loop, and test 2 for low speed local analog loop.
 - 1 – for test 1 high speed local analog loop, and test 2 for low speed local analog loop, and test 3 remote digital loop.

remno – Remote Telephone Number*

locno – Local Telephone Number*

* Add the prefix ‘P’ for pulsed telephones and ‘T’ for Touch-Tone.

Example:

RTE: RU,CN,10,30B,17227B

RTE: RU,TESTM,1,22B,2,1,0

test option 0 (local analog loop) with MUX select code = 22B, port 2, and test executed once.

or

RTE: RU,TESTM,1,22B,2,1,1,T9962178,T3360

test option 1 (local and remote loopback with MUX select code 22B, port 2, execute test once, local phone no. 3360, and remote phone number 996-2178.

Commands used for HP 37214 “Queensferry” modem card cage:

@: Take control

K: Release

H: High speed

L: Low speed

E: Enable auto answer

Y: Disable

T: Tone dialing

P: Pulse dialing

*: 2 second delay

U*: Analog loopback

V*: Digital loopback

W: Disable loopback

Vector Instruction Set (VIS) Diagnostic

This is an online diagnostic for VIS firmware (A900/A990 processor and A700* processor with the floating point card). It is supplied with RTE-A software in %VISOA. To load the diagnostic, LINK the relocatable, making sure to search \$VLBA1.LIB (vector library). The run string is:

VISOD, <output lu>,<number of passes>,<EMA test>

The default will output to the terminal, run one pass, but will not execute EMA/VMA tests. To execute EMA/VMA tests, any non-zero value as the third parameter will work.


Table of Contents

Chapter 6 Adjustments


| | |
|--|-----|
| Model 6 Power Supply Adjustments | 6-1 |
|--|-----|

Adjustments

Model 6 Power Supply Adjustments



TEST POINTS ARE NEXT TO CARD CAGE



| Voltage | Range |
|---------|---------------|
| +5V | 5.05 - 5.25 |
| +12V | 11.4 - 12.6 |
| -12V | -11.4 - -12.8 |

Table of Contents


Chapter 7 Peripherals

| | |
|--|-----|
| Peripheral Installation | 7-1 |
| A600 Model 6 Terminal Installation | 7-1 |
| Peripheral Configuration | 7-2 |
| 2392A Terminal Configuration | 7-2 |
| 2393/97A and 150-I/150-II Terminal Configuration | 7-2 |
| 2621A Terminal Configuration | 7-3 |
| 2622/23/25/26/28A Terminal Configuration | 7-3 |
| 2624A Terminal Configuration | 7-4 |
| 293x Printer Configuration | 7-5 |

Peripherals

Peripheral Installation

A600 Model 6 Terminal Installation



L8300-04

Peripheral Configuration

2392A Terminal Configuration

On the 2392A, set the baud rate as described in Table 7-1 (baud rate is dependent on the interface used). Display the terminal configuration screen labels and ensure that the rest of the configuration appears as follows:

| |
|------------------------|
| TERMINAL CONFIGURATION |
|------------------------|

| | | |
|-------------------------------------|-------------------------|--------------------------|
| Datacomm/Ext Dev <i>PORT1/PORT2</i> | Keyboard <i>USASCII</i> | |
| Terminal Id <i>2392A</i> | Language <i>ENGLISH</i> | |
| Local Echo <i>OFF</i> | Start Col <i>01</i> | Bell <i>OFF</i> |
| XmitFunction <i>NO</i> | SPOW(B) <i>NO</i> | InhEolWrp(C) <i>NO</i> |
| InhHndShk (G) <i>NO</i> | Inh DC2(H) <i>NO</i> | EscXfer(N) <i>NO</i> |
| FldSeparator <i>U/S</i> | BlkTermntr <i>R/S</i> | ReturnDef <i>C/R</i> |
| | | Line/Page(D) <i>LINE</i> |

| |
|------------------------|
| DATACOMM CONFIGURATION |
|------------------------|

| | | |
|-----------------------|-------------------------------|----------------------|
| Baud Rate <i>9600</i> | Parity/DataBits <i>NONE/8</i> | |
| Asterisk <i>OFF</i> | Chk Parity <i>NO</i> | SR(CH) <i>LO</i> |
| RecvPace <i>NONE</i> | | EnqAck <i>YES</i> |
| XmitPace <i>U/S</i> | | CS(CB)Xmit <i>NO</i> |

2393/97A and 150-I/150-II Terminal Configuration

On these terminals, select the system defaults for both Datacomm and Terminal Configurations. Select HP 1000 PT.PT. Set the baud rate as described in Table 7-1 (baud rate is dependent on the interface used).

Table 7-1. Baud Rate Selection for Serial Interfaces

| Serial Interface Used | Baud Rate |
|---|---|
| 12005A/B | Selected by U21 switch on 12005 card. |
| 12040B/C | 9600 |
| 12040D or 12100A A400 on-board I/O | VCP speed senses and operates at the baud rate selected by the terminal if speed sense is enabled using the CPU Boot Sel switches. Default: 9600 |

2621A Terminal Configuration

On the 2621A, set the baud rate as described in Table 7-1 (baud rate is dependent on the interface used). Display the configuration screen labels (refer to the terminal owner's manual) and make sure the rest of the configuration appears as follows:

| | | | | | | | |
|-----------|--------|--------|--------|-----------|----|-----------|--------|
| Baud Rate | Parity | Duplex | Straps | Handshake | Hz | Start Col | Return |
| 9600 | NONE | FULL | bcgHxz | Ext | 60 | 1 | cr |

NOTE

Make sure the remote function label appears with an asterisk (*); the BLOCK MODE and AUTO LF function labels appear without an asterisk. For some installations the Hz should be 50 instead of 60.

It may be desirable to have CAPS LK function label appear with an asterisk, but this is not required for most HP software.

2622/23/25/26/28A Terminal Configuration

On the 2622A, set the baud rate as described in Table 7-1 (baud rate is dependent on the interface used). Display the terminal configuration screen labels and ensure that the rest of the configuration appears as follows:

TERMINAL CONFIGURATION

| | | | | | | | |
|---------------|---------|------------|-----|--------------|----|--------------|------|
| Language | USASCII | FrameRate | 60 | | | | |
| Return Def | c/r | | | | | | |
| Local Echo | OFF | Caps Lock | OFF | Start Col | 01 | ASCII 8 Bits | NO |
| Xmit Fncn(A) | NO | SPOW(B) | NO | InhEolWrp(C) | NO | Line/Page(D) | Line |
| InhHndShk (G) | NO | Inh DC2(H) | NO | | | | |
| FldSeparator | u/s | BlkTermntr | r/s | | | | |

DATACOMM CONFIGURATION

| | | | | | |
|------------|------|------------|------|--------|-----|
| BaudRate | 9600 | Parity | NONE | EnqAck | YES |
| Chk Parity | NO | SR(CH) | LO | | |
| RecvPace | NONE | | | | |
| XmitPace | NONE | CS(CB)Xmit | YES | | |

NOTE

For typical installations, the 2622/23 terminals can all be set to default configuration for terminal and datacomm, then the baud rate is selected as described in Table 7-1.

2624A Terminal Configuration

On the 2624A, set the baud rate as described in Table 7-1 (baud rate is dependent on the interface used). Display the terminal configuration screen labels and ensure that the rest of the configuration appears as follows:

TERMINAL CONFIGURATION

| | | | | | | | |
|---------------|----------------|------------------|--------------------|--------------------|-----------|--------------|-------------|
| Bell | <i>OFF</i> | Click | <i>OFF</i> | FrameRate | <i>60</i> | Tab=Space | <i>NO</i> |
| Language | <i>USASCII</i> | Datacomm/Printer | <i>Port1/Port2</i> | | | PrinterNulls | <i>0</i> |
| Return Def | <i>c/r</i> | | | | | | |
| Local Echo | <i>OFF</i> | Caps Lock | <i>OFF</i> | Start Col | <i>01</i> | ASCII 8 Bits | <i>NO</i> |
| Xmit Fnctn(A) | <i>NO</i> | SPOW(B) | <i>NO</i> | InhEolWrp(C) | <i>NO</i> | Line/Page(D) | <i>LINE</i> |
| InhHndShk (G) | <i>NO</i> | Inh DC2(H) | <i>NO</i> | Auto Term(J) | <i>NO</i> | ClearTerm(K) | <i>NO</i> |
| InhSlfTst (L) | <i>NO</i> | | | Esc Xfer(N) | <i>NO</i> | InhDcTst(W) | <i>NO</i> |
| FldSeparator | <i>u/s</i> | BlkTermntr | <i>r/s</i> | FormsBufSize(256x) | <i>0</i> | | |
| ESC) | @ | A | B | C | | Alt Set | B |
| | USASCII | | LINE DRAWING | | | | |

FORMAT MODE

| | | | | | |
|--------------|-----------|--------------------|----------|----------|-------------------|
| Decimal Type | <i>US</i> | Implied Dec Digits | <i>2</i> | Transmit | <i>All Fields</i> |
|--------------|-----------|--------------------|----------|----------|-------------------|

DATACOMM CONFIGURATION

(use full duplex hardwired Port 1)

| | | | | | | | | | |
|----------|-------------|------------|-------------|-----------|-----------|------------|------------|-----|------------|
| BaudRate | <i>9600</i> | Parity | <i>NONE</i> | DataBits | <i>8</i> | BufSize | <i>128</i> | Clk | <i>INT</i> |
| Asterisk | <i>OFF</i> | | | StopBits | <i>1</i> | EnqAck | <i>YES</i> | | |
| TR(CD) | <i>HI</i> | Chk Parity | <i>NO</i> | SR(CH) | <i>LO</i> | StrNulDel | <i>YES</i> | | |
| RecvPace | <i>NONE</i> | | | SRRXmit | <i>NO</i> | RR(CF)Recv | <i>NO</i> | | |
| XmitPace | <i>NONE</i> | | | SrrInvert | <i>NO</i> | CS(CB)Xmit | <i>NO</i> | | |

NOTE

For typical installations, the 2622/23/24/26/27 terminals can all be set to default configuration for terminal and datacomm, then the baud rate is selected as described in Table 7-1.

293x Printer Configuration

On the 293x Printers, select the configuration below based on the interface being used:

Serial Interface:

***** DATA SETTINGS *****

| BAUD RATE | DATA BITS | PARITY | PARITY CHECK | STRIP NULL |
|-------------|-----------|-------------|--------------|------------|
| <i>2400</i> | <i>8</i> | <i>none</i> | <i>off</i> | <i>off</i> |

***** CONTROL SETTINGS *****

| XON/XOFF | ENQ/ACK | BINARY ENQ/ACK | DTR/CD | (S)RTS/SCA | CTS/CB | RS/CH |
|-----------|------------|----------------|-------------|------------|---------------|------------|
| <i>on</i> | <i>off</i> | <i>off</i> | <i>High</i> | <i>Low</i> | <i>Ignore</i> | <i>Low</i> |

HP-IB Interface:

| SECONDARY COMMANDS | LISTEN ALWAYS | SERVICE REQUEST | ADDRESS |
|--------------------|---------------|-----------------|----------|
| <i>on</i> | <i>off</i> | <i>off</i> | <i>6</i> |

Table of Contents

Chapter 8 Replacement Parts

| | |
|--|------|
| Replaceable Parts/Exchange Assemblies | 8-1 |
| Processors | 8-1 |
| A400 | 8-1 |
| A600/A600+ | 8-2 |
| A700 | 8-3 |
| A900 | 8-4 |
| A990 | 8-4 |
| Box-Specific Parts Lists | 8-5 |
| Model 6 (10-Slot Box) | 8-5 |
| Micro 14/16 (6-Slot Box) | 8-5 |
| Micro/1000 (16-Slot Box) | 8-6 |
| Model 26/27/29/99 (20-Slot Box) | 8-7 |
| I/O Extender (12025A/B) | 8-8 |
| I/O Interface Exchange Assemblies | 8-9 |
| HP-IB Cables | 8-9 |
| Power Supply History | 8-10 |
| 12040 Multiplexer Replaceable Parts (current) | 8-11 |
| 12040 MUX Assembly Revisions History | 8-11 |
| 12040 MUX Accessories History | 8-12 |
| 12076A LAN/1000 Replaceable Parts | 8-13 |
| Power Cord and Cordset Replaceable Parts | 8-13 |
| A-Series Firmware History | 8-14 |
| A400 Base Set Firmware | 8-14 |
| A400 OBIO Firmware | 8-14 |
| A400 VCP Firmware | 8-14 |
| A600 Minifloppy Controller | 8-15 |
| A600 Base Set Firmware | 8-15 |
| A600+ Base Set Firmware | 8-17 |
| A600/A600+ VCP Firmware | 8-18 |
| A700 Base Set Firmware | 8-19 |
| A700 Floating Point History | 8-20 |
| A700 VCP Firmware History | 8-20 |
| A900 Firmware History | 8-22 |
| A900 VCP Firmware History | 8-29 |
| A990 Firmware History | 8-31 |
| PSI Firmware History | 8-32 |
| 12007B 1000-1000 Modem Interface | |
| 12044A 1000-1000 Direct Connect Interface | 8-32 |
| 12042B OEM P.S.I | 8-32 |
| 12043A MRJE (download) | 8-32 |
| 12072A Data Link Slave firmware | 8-32 |
| 12073A 1000-3000 Modem Interface | |
| 12082A 1000-3000 Direct Connect Interface | 8-33 |
| 12075A X.25 (LAP-B) Modem Interface | 8-33 |
| 12092A Multipoint Master Modem Interface | 8-33 |
| 12016A SCSI Firmware History | 8-33 |
| 12040A/B/C MUX Firmware History | 8-34 |
| 12040D MUX Firmware History | 8-35 |
| 12076A LAN/1000 Interface Controller Card Firmware | 8-35 |
| 12041B 8-Channel MUX OEM Version | 8-35 |

Replacement Parts

Replaceable Parts/Exchange Assemblies

Processors

A400

| Part Number | Exchange Number | Description |
|--------------------|------------------------|--------------------------------|
| 12100-60001 | 12100-69001 | A400 CPU/512k Mem/OBIO |
| 12100-60005 | -- | OBIO cable with breakout panel |
| 12103-60016 | 12103-69016 | Memory Array 512kB |
| 12103-60004 | 12103-69004 | Memory Array 1MB |
| 12103-66001 | 12103-69101 | Memory Array 2MB |
| 12103-66002 | 12103-69102 | Memory Array 4MB |
| 12103-66003 | 12103-69103 | Memory Array 8MB |
| 12038-60005 | -- | 2-Connector Memory Frontplane |
| 12038-60002 | -- | 3-Connector Memory Frontplane |
| 12038-60003 | -- | 4-Connector Memory Frontplane |

A600/A600+

| Part Number | Exchange Number | Description |
|--------------------|------------------------|-------------------------------|
| 12101-60047 | 12101-69047* | A600 Processor |
| 12105-60024 | 12105-69024* | A600+ Processor |
| 12102-60009 | 12102-69009* | Memory Controller 128kB |
| 12102-60010 | 12102-69010* | Memory Controller 512kB |
| 12103-60015 | 12103-69015 | Memory Array 128kB |
| 12103-60016 | 12103-69016 | Memory Array 512kB |
| 12103-60004 | 12103-69004 | Memory Array 1MB |
| 12103-66001 | 12103-69101 | Memory Array |
| 12103-66002 | 12103-69102 | Memory Array 4MB |
| 12103-66003 | 12103-69103 | Memory Array 8MB |
| 12110-60003 | 12110-69003* | ECC Memory Controller 512kB |
| 12110-60004 | 12110-69004* | ECC Memory Controller 1MB |
| 12111-60001 | 12111-69001 | ECC Memory Array 512kB |
| 12111-60002 | 12111-69002 | ECC Memory Array 1MB |
| 12111-60003 | 12111-69003 | ECC Memory Array 2MB |
| 12038-60005 | -- | 2-Connector Memory Frontplane |
| 12038-60002 | -- | 3-Connector Memory Frontplane |
| 12038-60003 | -- | 4-Connector Memory Frontplane |
| 12038-60004 | -- | 5-Connector Memory Frontplane |

* All exchange assemblies include firmware.

A700

| Part Number | Exchange Number | Description |
|--------------------|------------------------|------------------------------|
| 12152-60001 | 12152-69001 | Upper Processor |
| 12152-60063 | 12152-69063* | Lower Processor |
| 12152-60052 | 12152-69052* | Memory Controller |
| 12153-60001 | 12153-69101 | Writable Control Store |
| 12155-60001 | -- | PROM Control Store Board |
| 12156-60037 | 12156-69037* | Floating Point PCA |
| 5061-3480 | -- | WCS/PCS Flex Frontpl. Conn. |
| 12155-80002-5 | -- | PCS Test PROMs |
| 12103-60015 | 12103-69015 | Memory Array 128kB |
| 12103-60017 | 12103-69002 | Memory Array 256kB |
| 12103-60016 | 12103-69016 | Memory Array 512kB |
| 12103-60004 | 12103-69004 | Memory Array 1MB |
| 12103-66001 | 12103-69101 | Memory Array 2MB |
| 12103-66002 | 12103-69102 | Memory Array 4MB |
| 12103-66003 | 12103-69103 | Memory Array 8 MB |
| 12104-60001 | 12104-69001 | ECC Memory Card 512kB |
| 12111-60001 | 12111-69001 | ECC Memory Array 512kB |
| 12111-60002 | 12111-69002 | ECC Memory Array 1MB |
| 12111-60003 | 12111-69003 | ECC Memory Array 2MB |
| 12160-60001 | -- | 2-Conn. Processor Frontplane |
| 12156-60002 | -- | 3-Conn. Processor Frontplane |
| 12038-60005 | -- | 2-Conn. Memory Frontplane |
| 12038-60002 | -- | 3-Conn. Memory Frontplane |
| 12038-60003 | -- | 4-Conn. Memory Frontplane |
| 12038-60004 | -- | 5-Conn. Memory Frontplane |

* These exchange assemblies include firmware.

A900

| Part Number | Exchange Number | Description |
|--------------------|------------------------|-------------------------------|
| 12201-60104 | 12201-69104 | Sequencer PCA** |
| 12202-60002 | 12202-69002 | Data Path PCA** |
| 12203-60018 | 12203-69018 | Cache Control PCA* |
| 12204-60005 | 12204-69005 | Memory Controller PCA |
| 12205-60001 | 12205-69001 | Control Store |
| 12220-60001 | 12220-69001 | Memory Array 768k bytes |
| 12221-60001 | 12221-69001 | ECC Memory Array 3M bytes |
| 12221-66001 | 12221-69101 | ECC Memory Array 8M bytes |
| 12222-60001 | -- | 2-Connector Memory Frontplane |
| 12222-60002 | -- | 3-Connector Memory Frontplane |
| 12222-60003 | -- | 4-Connector Memory Frontplane |
| 12222-60004 | -- | 5-Connector Memory Frontplane |
| 12222-60005 | -- | 6-Connector Memory Frontplane |
| 12222-60006 | -- | 7-Connector Memory Frontplane |
| 12222-60007 | -- | 8-Connector Memory Frontplane |
| 12205-60002 | -- | Control Store Frontplane |

* The newer cache control board (part no. 12203-60011 or 12203-60017) is needed for I/O Extender support.

** These exchange assemblies include firmware.

A990

| Part Number | Exchange Number | Description |
|--------------------|------------------------|--------------------------------|
| 12990-60102 | 12990-69102 | A990 CPU Card (pin and socket) |
| 12990-60202 | 12990-69202 | A990 CPU Card (edge connector) |
| 1826-2068 | -- | Time-of-Day Clock Chip |
| 12990-80106 | -- | Firmware EPROM Chip |
| 12990-60020 | -- | Jumper board for A900 upgrades |
| 12220-60001 | -- | 768 KByte ECC Memory Card |
| 12221-60001 | -- | 3 MByte ECC Memory Card |
| 12221-66001 | -- | 8 MByte ECC Memory Card |
| 12230-60001 | -- | Connector to 1 Memory Card |
| 12230-60002 | -- | Connector to 2 Memory Cards |
| 12230-60003 | -- | Connector to 3 Memory Cards |
| 12230-60004 | -- | Connector to 4 Memory Cards |

Box-Specific Parts Lists

Model 6 (10-Slot Box)

| Part Number | Exchange Number | Description |
|-------------|-----------------|------------------------------------|
| 12013-60001 | 12013-69001 | Battery Backup Card |
| 12021-60001 | 12021-69001* | Minifloppy Controller |
| 09130-60600 | 09130-69600 | Flexible Disc Drive |
| 09130-66501 | -- | Drive Electronics Board |
| -- | -- | 200W Power Supply** |
| 02142-60001 | -- | 8-slot system backplane |
| 02142-60002 | -- | Power Distribution board |
| 02142-60005 | -- | Power Control Assembly |
| 02142-60012 | -- | Disc Drive Power Cable |
| 02142-60014 | -- | ASIC to 262X terminal cable |
| 3160-0294 | -- | Pedestal Box Fan |
| 8120-3354 | -- | Cntrlr. to HP-IB IF Cable (short) |
| 8120-3377 | -- | Cntrlr. to disc drive ribbon cable |
| 8120-3396 | -- | Cntrlr. to HP-IB IF Cable (long) |

* These exchange assemblies do not include firmware.

** Refer to Power Supply History.

Micro 14/16 (6-Slot Box)

| Part Number | Exchange Number | Description |
|-------------|-----------------|------------------------------------|
| -- | -- | 160W Power Supply* |
| 02420-60001 | -- | Backplane, 6-slot |
| 02420-40001 | -- | Front Cover (incl. captive screws) |
| 3150-0511 | -- | Air Filter |
| 02420-00008 | -- | Rear door (incl. captive screw) |
| 3160-0493 | -- | Fan assembly (includes cable) |
| 2110-0010 | -- | fuse, 5A 250V normal blow |
| 2110-0565 | -- | fuse holder cap |

* Refer to Power Supply History.

Micro/1000 (16-Slot Box)

| Part Number | Exchange Number | Description |
|-------------|-----------------|--|
| 02430-60022 | -- | A4/6/700 Chassis with Power Supply |
| 02430-60023 | -- | A900 Chassis with Power Supply |
| -- | -- | 300W Power Supply* |
| 02430-60015 | -- | A400/ A600/A700 Backplane |
| 02430-60004 | -- | A900 Backplane |
| 1902-0939 | -- | Backplane diode – 5 volt |
| 1902-0941 | -- | Backplane diode – 12 volt |
| 02430-60009 | -- | Voltage Jumper Card |
| 02430-40001 | -- | Front Cover (blank) |
| 02430-40002 | -- | Front Cover (single flexible disc drive) |
| 3150-0459 | -- | Air Filter |
| 02430-60026 | -- | PDU and Fan Assembly |
| 3160-0420 | -- | Fan |
| 02430-00015 | -- | Shroud |
| 02430-00030 | -- | Rear Left Panel |
| 02430-00029 | -- | Rear Right Panel |
| 12154-60005 | 12154-69005 | Battery Backup Card |
| 12154-60002 | -- | Battery Backup Cable |
| 1420-0321 | -- | Battery Pack |
| 12159-60001 | -- | 25 kHz Power Module |
| 2110-0001 | -- | Fuse |

12022A INTEGRATED DISC SUBSYSTEM-SPECIFIC PARTS

| | | |
|-------------|-------------|--|
| 0950-1639 | 09121-69521 | 3.5" Single-Sided Floppy Drive |
| 09114-67511 | 09114-69511 | 3.5" Double-Sided Floppy Drive |
| 09133-67102 | 09133-69102 | 10 MB Hard Disc Drive Assy, ST 412 |
| 09133-67101 | 09133-69101 | 10 MB Hard Disc Logic PCA, ST 412 |
| 09133-67104 | 09133-69104 | 15 MB Hard Disc Drive Assy, ST 419 |
| 09133-67105 | 09133-69105 | 15 MB Hard Disc Logic PCA, ST 419 |
| 09133-67206 | 09133-69206 | 20 MB Hard Disc Module, ST 225 (includes logic PCA) |
| 12022-60008 | 12022-69008 | Disc Drive Interface PCA |
| 12022-60002 | -- | Cable, All Hard Discs, Control |
| 12022-60003 | -- | Cable, All Hard Discs, Data |
| 12022-60004 | -- | Cable, All Hard Discs, Power |
| 12022-60005 | -- | Cable, All Flexible Discs, Control/Data |
| 12022-60006 | -- | Cable, Single-Sided Floppy, Power |
| 12022-60010 | -- | Cable, Double-Sided Floppy, Power |

12122A INTEGRATED DISC SUBSYSTEM-SPECIFIC PARTS

| | | |
|-------------|-------------|-------------------------------------|
| 45816-67111 | 45816-69111 | 3.5 Winchester Disk 20 MB |
| 09123-67101 | 09123-69101 | 3.5 Flexible Disk Drive |
| 09153-67530 | 09153-69530 | Controller PCA |
| 97596-61602 | -- | Ribbon Cable – HPiB to 9153 Cntrlr. |
| 97596-61603 | -- | Cable – Controller to Flexible Disk |
| 97596-66501 | -- | Power Cable to 9153 Controller |
| 97596-04701 | -- | Mounting Tray |
| 09153-61604 | -- | Cable – Controller to Hard Disk |

*Refer to Power Supply History.

Model 26/27/29/99 (20-Slot Box)

| Part Number | Part Number | Description |
|--------------|-------------|------------------------------------|
| -- | -- | 440W Power Supply* |
| 12151-60024 | -- | A4/6/700 Chassis with Power Supply |
| 12210-60009 | -- | A900 Chassis with Power Supply |
| 12151-60002 | -- | A400/600/700 Backplane |
| 12210-60002 | -- | A900 Backplane |
| 1902-0939 | -- | Backplane diode – 5 volt |
| 1902-0941 | -- | Backplane diode – 12 volt |
| 29429-60006 | -- | Power Distribution Unit |
| 0950-1687 ** | -- | Battery Backup Module |
| 0950-0877 ** | -- | 25 kHz Module |
| 4208-0405 | -- | Filter |
| 12151-60026 | -- | Chassis |
| 12210-00020 | -- | Battery Support |
| 12210-00009 | -- | Front Deflector |
| 5061-6642 | -- | Fan Panel |
| 12210-00022 | -- | Rear Shield |
| 12151-60009 | -- | Fan Cable |
| 12151-60006 | -- | AC Filter Cable |
| 12151-60007 | -- | AC Power Cable |
| 9135-0312 | -- | Line Filter |
| 3160-0315 | -- | Fan |
| 3160-0092 | -- | Fan Guard |
| 12151-60008 | -- | Test Point Cable |
| 5061-6652 | -- | Rear Panel |
| 3101-0402 | -- | AC Power Switch |
| 1251-4470 | -- | Power Receptacle |
| 12151-60010 | -- | Battery Backup Cable |
| 1420-0304 | -- | Battery Pack |
| 12151-60015 | -- | Cable Retainer Hardware Kit |

* Refer to Power Supply History.

** For Boschert power supply only, the new YEW power supply (0950-1849) has battery backup built in.

I/O Extender (12025A/B)

| Part Number | Exchange Number | Description |
|--------------------|------------------------|---------------------------------------|
| 02430-60022 | -- | 14-slot box without power supply |
| 12151-60024 | -- | 20-slot box with power supply |
| 12025-66001 | 12025-69101 | I/O Control Card |
| 12025-60002 | 12025-69002 | Extender Control Card |
| 12025-80003 | -- | Interrupt Jumper Card for 14-slot box |
| 12025-80004 | -- | Interrupt Jumper Card for 20-slot box |
| 12025-60007 | -- | CPU-to-extender connecting cable |

Note: The 12025A uses the A4/6/700 version of the 14-slot box and the 12025B uses the A4/6/700 version of the 20-slot box. Use the 14- and 20-slot box parts lists given previously in this chapter for box-related part numbers.

I/O Interface Exchange Assemblies

| Product Number | Exchange Number | Description |
|-----------------------|------------------------|--|
| 12005A | 12005-69010 | Async Serial IF |
| 12005B | 12005-69012 | Async Serial IF (fiber optics) |
| 12006A | 12006-69003 | Parallel IF |
| 12007B | 5061-4941 | HDLC Modem IF (CCITT Compatible) (PSI-Modem) |
| 12008A | 12008-69002 | PROM Storage Module |
| 12009A | 12009-69020 | HP-IB IF |
| 12011A | 12011-60001 | Extender Board for I/O Cards |
| 12012A | 12012-60001 | Priority Jumper Card |
| 12022A | 12022-69008 | Integral Disc Interface |
| 12040A/D | 12040-69014 | 8-Channel Async MUX |
| 12041A/B | 12040-69014 | 8-Channel Async MUX |
| 12042B | 5061-4941 | Programmable Serial Interface (PSI-Modem) |
| 12043A | 5061-4941 | MRJE (PSI-Modem) |
| 12044A | 5061-3463 | HDLC Direct Connect IF (PSI DIRCON) |
| 12060A | 12060-69001 | Hi-Level Analog Input IF |
| 12061A | 12061-69001 | 32-Channel Expansion Mux |
| 12062A | 12062-69001 | 4-Channel Analog Output IF |
| 12063A | 12063-69001 | 16-IN/16-OUT Isolated Dig IF |
| 12065A | 12065-69001 | Video Out |
| 12072A | 5061-4911 | Data Link Slave Interface |
| 12073A | 5061-4941 | Bisync Modem Interface (PSI-Modem) |
| 12075A | 5061-4941 | X.25 (PSI-Modem) |
| 12076A | 12076-69001 | LAN/1000 Interface |
| 12082A | 5061-3463 | Bisync Direct Connect Interface (PSI-DIRCON) |
| 12092A | 5061-4941 | Data Link Master (PSI-Modem) |
| 18651B | 18651-69032 | Loop Control Card |
| 37222A | 37222-69101 | Integral Modem |

HP-IB Cables

| Product/Part Number | Description |
|----------------------------|----------------------|
| 12009-60014 | 2-meter HP-IB Cable |
| 10833A | 1-meter HP-IB Cable |
| 10833B | 2-meter HP-IB Cable |
| 10833C | 4-meter HP-IB Cable |
| 10833D | .5-meter HP-IB Cable |

Power Supply History

| Watts | Products | New Part No. | Exchange Part No. | Reason for change |
|-------|--------------------------|--------------|-------------------|--------------------------------------|
| 160W | Micro14/16 6-slot box | 0950-1792 | 0957-0023 | Original |
| | | 0950-1822 | 0957-0024 | Add remote AC select switch conn. |
| 200W | Model 5,6 10-slot box | 0950-0848 | 0950-0849 | Original |
| | | 0950-0848 | 0950-0874 | C19 could explode |
| | | 0950-0885 | 0957-0001 | PON intermittent |
| 300W | Micro/1000 | 0950-1646 | 0957-0004 | Original |
| | | 0950-1788 | 0950-1806 | Change to YEW. |
| 420W | 20-slot box | 0950-0873 | 0950-0875 | Original |
| 440W* | 20-slot box | 0950-0893 | 0957-0002 | 25 kHz accessory |
| | | 0950-1648 | 0957-0002 | Mechanical modif. |
| | | 0950-1671 | 0957-0012 | need better mount |
| | | 0950-1849 | 0957-0028 | Change to YEW. |
| | | 0950-1962 | 0957-0041 | Screw-on bracket. |
| | | 0950-2039 | 0957-0047 | Battery discharge. |
| | | 0950-2100 | 0957-0051 | Fused on/off switch. |

* For 440W power supply, battery jumper card is 12151-80004 and the battery backup card is 0950-1687 for the 0950-1671 power supply or before. The YEW power supply has battery backup and 25kHz built in to the supply.

12040 Multiplexer Replaceable Parts (current)

| HP Part No. | Description |
|-------------|--|
| 28658-60005 | Plastic J-box |
| 28658-63005 | Cable from MUX to J-box, BRG-0 = port 0 |
| 1252-0508 | Connector kit for do-it-yourself cables to new J-box |
| 5001-5278 | Mounting bracket for the plastic J-box |
| 2110-0679 | 5v Fusible Link |
| 2110-0665 | ±12v Fusible Link |

12040 MUX Assembly Revisions History

| Old Assembly | New Assembly | Old Exchange | New Exchange | Service Note |
|----------------|--------------|--------------|--------------|--------------|
| 12040A: | | | | |
| 5061-3427 | -- | 5061-4906 | 12040-69014 | N/A |
| 12040B: | | | | |
| 5061-3427 | 12040-60003 | 5061-4906 | 12040-69003 | 12040B-06 |
| 12040-60003 | (no change) | 12040-69003 | 12040-69013 | 12040B-09 |
| 12040-60003 | (no change) | 12040-69013 | 12040-69023 | 12040B-11 |
| 12040-60003 | 12040-60014 | 12040-69023 | 12040-69014 | N/A |
| 12040C: | | | | |
| 12040-60003 | 12040-60004 | 12040-69023 | 12040-69004 | 12040C-01 |
| 12040-60004 | 12040-60014 | 12040-69004 | 12040-69014 | 12040C-02 |
| 12040D: | | | | |
| 12040-60014 | 12040-60114 | 12040-69014 | (no change) | 12040D-01 |

12040 MUX Accessories History

12040A:

Connection panel was a separate product, 12828A, consisting of:

| | |
|-------------|---------------------|
| 12828-60001 | MUX panel |
| 12828-60002 | Card-to-panel cable |
| 12828-60004 | Connector kit |
| 12828-00004 | Rack mount bracket |

The 12828-60002 cable hood was wired for:

BRG0 = Port 0
BRG1 = Ports 1 -7

12040B:

Same as the 12040A except the cable changed from 12828-60002 to 12040-60002. The 12040-60002 cable hood was wired for:

BRG0 = Port 7
BRG1 = Ports 0 -6

12040C/D:

The 12828A connection panel was replaced by the 28658-60005 connection panel which is not a separate product, but a component of the 12040C. The 28658-60005 consists of:

| | |
|-------------|---------------------------------|
| 28658-60005 | Mux panel |
| 28658-63005 | Interface-to-panel cable |
| 8120-4510 | 17 twisted pair 24AWG cable, 3m |
| 1251-6077 | 80-pin card edge connector |
| 1252-0369 | 50-pin shielded connector |

The 28658-63005 cable differs from the 12040-60002 cable in two ways: the 28658-63005 panel-end connector is 50 pins versus 36 pins in the 12040-60002; and the 12-volt supplies are not brought out to the connector panel, which results in a change to the RS-232 port connector wiring. Also, the baud rate generators are rewired to the original version:

BRG0 = Port 0
BRG1 = Ports 1 -7

Note: +/- 12V is no longer available on the new 28658 box. Customers needing this voltage as a reference or control voltage only, may fabricate their own cable and bring out the voltages as needed. These voltages are not designed to provide external power for devices connected to the MUX. (Power consumption for the MUX would not be predictable.)

12076A LAN/1000 Replaceable Parts

| HP Part No. | Description |
|-------------|--|
| 12076-63001 | IEEE 802.3 based LANIC Card Edge Connector Cable (Stub Cable), 1 meter |
| 92254A | IEEE 802.3 based AUI Cable, 6 meters, with D-connector on each end |
| 30241-60101 | IEEE 802.3 based Medium Attachment Unit (MAU) assembly |
| 0362-0819 | Coaxial Cable Tap Kit |
| 2110-0520 | 125 volt, 5A fuse |

Power Cord and Cordset Replaceable Parts

A power cord only has a plug on one end; the other end is stripped. A cord set has a plug on both ends.

| Part No. | System | Cabinet | Phase | Plug Type |
|-------------|----------------|-------------------|--------------|-------------------------------|
| 8120-4280* | 2196C | 29431G (tall) | split phase | NEMA L14-20P |
| 8120-4308** | 2197C 2199C | | — | CEE 22 (male and female ends) |
| 8120-2517* | 2196D | 29429A (short) | single phase | NEMA 5-20P |
| 8120-4308** | 2197D 2199D | | — | CEE 22 (male and female ends) |

*Power Cord

**Cordset

A-Series Firmware History

A400 Base Set Firmware

| | |
|-------------|----------|
| 12100-80010 | (U1212)* |
| 12100-80011 | (U1312)* |
| 12100-80012 | (U1412)* |
| 12100-80013 | (U1512)* |

Revision 4000
Original Release

* These parts are bundled in with the 12100-60001 A400 board.

| | |
|-------------|----------|
| 12100-80015 | (U1212)* |
| 12100-80016 | (U1312)* |
| 12100-80017 | (U1412)* |
| 12100-80018 | (U1512)* |

Revision 4000

| | |
|-------------|---------|
| 12100-80019 | (U1212) |
| 12100-80020 | (U1312) |
| 12100-80021 | (U1412) |
| 12100-80022 | (U1512) |

Revision 4000

See S/N 12100A-04

| | |
|-------------|----------|
| 12100-80023 | (U1212)* |
| 12100-80024 | (U1312)* |
| 12100-80025 | (U1412)* |
| 12100-80026 | (U1512)* |

Revision 4000

* The supplier changed from Signetics to Cypress (see S/N 12100A-09)

A400 OBIO Firmware

| | |
|-------------|---------|
| 12100-80002 | (U304)* |
| 12100-80002 | (U504)* |
| 12100-80002 | (U704)* |
| 12100-80002 | (U804)* |

Revision 4000

Original Release (Note: SPORT reports 4.06)

* These parts are bundled in with the 12100-60001 A400 board.

A400 VCP Firmware

| | |
|-----------|---------|
| 5180-4271 | (U908) |
| 5180-4272 | (U1108) |

Revision 4020

Original Release
Required for D-MUX console

| | |
|-----------|---------|
| 5180-4286 | (U908) |
| 5180-4287 | (U1108) |

Revision 4020

Same as 5180-4271/72, but plastic ROMs

| | |
|-----------|---------|
| 5181-8604 | (U908) |
| 5181-8605 | (U1108) |

Revision 4021

SCSI boot capability.
Included in upgrade kit 5181-8607

| | |
|-----------|---------|
| 5181-8657 | (U908) |
| 5181-8658 | (U1108) |

Revision 4021

Vendor change.
Included in upgrade kit 5181-8607

A600 Minifloppy Controller

| | | |
|--------|------|-----------|
| PROM 1 | U73 | 5180-0136 |
| PROM 2 | U63 | 5180-0137 |
| PROM 3 | U43 | 5180-0144 |
| CPU | U22 | 1820-2298 |
| Cntrlr | U105 | 1820-2456 |
| GPIB | U12 | 1820-2549 |

A600 Base Set Firmware

| |
|----------------------|
| 12101-60001 |
| 12101-80002 (U0706) |
| 12101-80003 (U0806) |
| 12101-80004 (U1006) |
| 12101-80005 (U0506) |
| 12101-80006 (U0606) |
| 12101-80007 (U1106) |
| 12101-80008 (U0906) |
| 12101-80009 (U0305) |
| 12101-80010 (U0505) |
| 12101-80011 (U0605)* |
| 12101-80012 (U0705)* |
| 12101-80013 (U0805)* |
| 12101-80014 (U1005)* |

Revision 4000

Original Release

* These parts are bundled in with the 12101-60001 processor board. The 12101-60002 assembly no longer includes these PROMs.

| |
|----------------------|
| 12101-60001 |
| 12101-80002 (U0706) |
| 12101-80003 (U0806) |
| 12101-80021 (U1006)* |
| 12101-80005 (U0506) |
| 12101-80006 (U0606) |
| 12101-80007 (U1106) |
| 12101-80008 (U0906) |
| 12101-80009 (U0305) |
| 12101-80010 (U0505) |
| 12101-80011 (U0605)# |
| 12101-80012 (U0705)# |
| 12101-80013 (U0805)# |
| 12101-80014 (U1005)# |

Revision 4000

* Changed to fix bug. .FDIV with E-Register set returns incorrect results. (See S/N 12101A-01)

These parts are bundled in with the 12101-60001 processor board. The 12101-60002 assembly no longer includes these PROMs.

| | |
|-------------|----------|
| 12101-60002 | |
| 12101-80024 | (U0706)* |
| 12101-80025 | (U0806)* |
| 12101-80027 | (U1006)* |
| 12101-80022 | (U0506)* |
| 12101-80023 | (U0606)* |
| 12101-80028 | (U1106)* |
| 12101-80026 | (U0906)* |
| 12101-80029 | (U0305)* |
| 12101-80030 | (U0505)* |
| 12101-80031 | (U0605)* |
| 12101-80032 | (U0705)* |
| 12101-80033 | (U0805)* |
| 12101-80013 | (U1005)* |

Revision 401

- * Update 12101-60002 to 12101-60002 by removing four socketed mapping PROMs (12101-80001, 80012, 80013, and 80014). Firmware adds Data2 map instruction. (See S/N 2106AD-02)

REQUIRED TO RUN RTE-A

| | |
|-------------|----------|
| 12101-60002 | |
| 12101-80024 | (U0706) |
| 12101-80025 | (U0806) |
| 12101-80027 | (U1006) |
| 12101-80022 | (U0506) |
| 12101-80023 | (U0606) |
| 12101-80028 | (U1106) |
| 12101-80026 | (U0906) |
| 12101-80034 | (U0305)* |
| 12101-80035 | (U0505)* |
| 12101-80031 | (U0605) |
| 12101-80032 | (U0705) |
| 12101-80033 | (U0805) |
| 12101-80013 | (U1005) |

Revision 401

- * Changed to fix bug. .PWR2 causes Unimplemented Instruction Trap Interrupt (See S/N 2106AK-01)

| | |
|-------------|----------|
| 12101-60002 | |
| 12101-80037 | (U0706)* |
| 12101-80025 | (U0806) |
| 12101-80027 | (U1006) |
| 12101-80022 | (U0506) |
| 12101-80036 | (U0606)* |
| 12101-80028 | (U1106) |
| 12101-80026 | (U0906) |
| 12101-80034 | (U0305) |
| 12101-80035 | (U0505) |
| 12101-80031 | (U0605) |
| 12101-80032 | (U0705) |
| 12101-80033 | (U0805) |
| 12101-80013 | (U1005) |

Revision 401

- * Changed to fix bug. Power-Fail routine is not executed at power-fail. (See S/N 2106AK-01)

| | |
|-------------|----------|
| 12101-60002 | |
| 12101-80040 | (U0706)* |
| 12101-80041 | (U0806)* |
| 12101-80043 | (U1006)* |
| 12101-80038 | (U0506)* |
| 12101-80039 | (U0606)* |
| 12101-80044 | (U1106)* |
| 12101-80042 | (U0906)* |
| 12101-80034 | (U0305) |
| 12101-80035 | (U0505) |
| 12101-80031 | (U0605) |
| 12101-80032 | (U0705) |
| 12101-80033 | (U0805) |
| 12101-80013 | (U1005) |

Revision 1001

* .FDV produces incorrect results for certain operands. (See S/N 2106AK-04)

This firmware is included in Upgrade Kits 12101-60045 and 12101-60046.

A600+ Base Set Firmware

| | |
|-------------|---------|
| 12105-80002 | (U0405) |
| 12105-80003 | (U0505) |
| 12105-80004 | (U0605) |
| 12105-80005 | (U0705) |
| 12105-80006 | (U0805) |
| 12105-80007 | (U0905) |
| 12105-80008 | (U1005) |
| 12105-80009 | (U0308) |
| 12105-80010 | (U0808) |

Revision 3

Original Release

| | |
|-------------|----------|
| 12105-80024 | (U0405)* |
| 12105-80025 | (U0505)* |
| 12105-80026 | (U0605)* |
| 12105-80027 | (U0705)* |
| 12105-80028 | (U0805)* |
| 12105-80029 | (U0905)* |
| 12105-80030 | (U1005)* |
| 12105-80009 | (U0308) |
| 12105-80010 | (U0808) |

Revision 4

* Changed to fix bugs. .EXIT0, .EXIT1, and EXIT2 changed to always read the CST from the code map. The JLA, JLB, and JLY instructions were altered to execute one machine cycle faster (227 ns).

A600/A600+ VCP Firmware

| | |
|-----------|--------|
| 5180-0173 | (U606) |
| 5180-0174 | (U706) |

Revision 4
Original Release

| | |
|-----------|---------|
| 5180-0189 | (U606)* |
| 5180-0190 | (U706)* |

Revision 6
* Changed to fix bugs. Two power-fails in quick succession may result in an incorrect auto-restart. Booting remotely over FDL causes system to hang. Erroneous parity error message if memory is lost. Also several inconveniences are fixed and enhancements added. (See S/N 12102A-01)

| | |
|-------------|---------|
| 12102-80003 | (U606)* |
| 12102-80004 | (U706)* |

Revision 4001
* Changed to run with VC+. Also adds boot loaders for 1600 bpi Map Tape, 3.5" Microfloppy, and 10 MB Mini-Winchester disc. VCP size is 8K and resides in EPROM. Included in 12107A A600+ Upgrade Kit. (See S/N 2106AK-3)

| | |
|-----------|---------|
| 5180-4253 | (U606)* |
| 5180-4254 | (U706)* |

Revision 4004
* Changed to fix bug. If system disc and CPU are powered up simultaneously the CPU will not auto boot. (See S/N 2106AK-6A)

| | |
|-----------|---------|
| 5180-4263 | (U606)* |
| 5180-4264 | (U706)* |

Revision 4011
* Fixed Break Disable processing on the 12040B/C MUX.

| | |
|-----------|---------|
| 5180-4271 | (U606)* |
| 5180-4272 | (U706)* |

Revision 4020
* A400 release, new I/O table in VCP power-up message. Supports new serial I/O drivers introduced with RTE-A rev. 4.1.
Required for D-MUX console.

| |
|-----------|
| Kit P/N |
| 5180-4274 |

| | |
|-----------|--------|
| 5180-4286 | (U606) |
| 5180-4287 | (U706) |

Revision 4020
Same as 5180-4271/72, but plastic ROMs

| | |
|-----------|--------|
| 5181-8604 | (U606) |
| 5181-8605 | (U706) |

Revision 4021

SCSI boot capability.

Included in upgrade kit 5181-8607

| | |
|-----------|---------|
| 5181-8657 | (U606)* |
| 5181-8658 | (U706)* |

Revision 4021

* Due to a vendor

~~change~~ included in upgrade kit
5181-8607. (See S/N 2139B-15)

A700 Base Set Firmware

| | |
|-------------|--------|
| 12152-80011 | (U91) |
| 12152-80012 | (U101) |
| 12152-80013 | (U111) |
| 12152-80014 | (U121) |

Original Release

| | |
|-------------|---------|
| 12152-80031 | (U91)* |
| 12152-80032 | (U101)* |
| 12152-80033 | (U111)* |
| 12152-80034 | (U121)* |

* Changed to fix bug. DDS will skip incorrectly.

| | |
|-------------|---------|
| 12152-80035 | (U91)* |
| 12152-80036 | (U101)* |
| 12152-80037 | (U111)* |
| 12152-80038 | (U121)* |

* Add Code and Data Separation Instructions. Also several bugs were fixed. .LWD1 and .LWD2 are not privileged instructions. Any instruction in the A/B-Registers which causes an MP violation freezes the computer. (See S/N 2107AK-01)

This firmware is included in Upgrade Kit 12152-60043.

REQUIRED TO RUN VC+

| | |
|-------------|---------|
| 12152-80053 | (U91)* |
| 12152-80054 | (U101)* |
| 12152-80055 | (U111)* |
| 12152-80056 | (U121)* |

Revision 2500 (currently supported Base Set)

* Changed to be compatible with the I/O Extender.

A700 Floating Point History

| | |
|-------------|--------|
| 12156-80005 | (U106) |
| 12156-80006 | (U105) |
| 12156-80007 | (U103) |
| 12156-80008 | (U102) |

| | |
|-------------|--------|
| 12156-80013 | (U106) |
| 12156-80014 | (U105) |
| 12156-80015 | (U103) |
| 12156-80016 | (U102) |

| | |
|-------------|--------|
| 12156-80017 | (U106) |
| 12156-80018 | (U105) |
| 12156-80019 | (U103) |
| 12156-80020 | (U102) |

| | |
|-------------|--------|
| 12156-80025 | (U106) |
| 12156-80026 | (U105) |
| 12156-80027 | (U103) |
| 12156-80028 | (U102) |

| | |
|-------------|--------|
| 12156-80029 | (U106) |
| 12156-80030 | (U105) |
| 12156-80031 | (U103) |
| 12156-80032 | (U102) |

| | |
|-------------|--------|
| 12156-80033 | (U106) |
| 12156-80034 | (U105) |
| 12156-80035 | (U103) |
| 12156-80036 | (U102) |

Currently supported FP firmware

(See S/N 2107AK-01)

A700 VCP Firmware History

| | |
|-----------|-------|
| 5180-0173 | (U15) |
| 5180-0174 | (U35) |

Revision 4

Original Release

| | |
|-----------|--------|
| 5180-0189 | (U15)* |
| 5180-0190 | (U35)* |

Revision 6

* Changed to fix bugs. Two power-fails in quick succession may result in an incorrect auto-restart. Booting remotely over FDL causes system to hang. Erroneous parity error message if memory is lost. Also several inconveniences are fixed and enhancements added.

(See S/N 12102A-01)

| | |
|-------------|--------|
| 12152-80039 | (U15)* |
| 12152-80040 | (U35)* |
| 12152-80041 | (U55)* |
| 12152-80042 | (U65)* |

Revision 4001

- * Changed to run with VC+. Also adds boot loaders for 1600 bpi Map Tape, 3.5" Microfloppy, and 10 MB Mini-Winchester disc. (See S/N 2107AK-01)

| | |
|-------------|--------|
| 12152-80043 | (U15)* |
| 12152-80044 | (U35)* |
| 12152-80045 | (U55)* |
| 12152-80046 | (U65)* |

Revision 4004

- * Changed to fix bug. If system disc and CPU are powered up simultaneously, the CPU will not auto boot. (See S/N 2107AK-2A)

Included in Upgrade Kit 12152-60043.

| | |
|-------------|--------|
| 12152-80058 | (U15)* |
| 12152-80059 | (U35)* |
| 12152-80060 | (U55)* |
| 12152-80061 | (U65)* |

Revision 4011

- * Fixed Break Disable processing on the 12040B/C MUX.

| | |
|-------------|--------|
| 12152-80065 | (U15)* |
| 12152-80066 | (U35)* |
| 12152-80067 | (U55)* |
| 12152-80068 | (U65)* |

Revision 4020

- * A400 release, new I/O table in VCP power-up message. Supports new serial I/O drivers introduced with RTE-A Rev. 4.1.

Included in Upgrade Kit 12152-64004.

Required for D-MUX console.

| | |
|-------------|--------|
| 12152-80069 | (U15)* |
| 12152-80070 | (U35)* |
| 12152-80071 | (U55)* |
| 12152-80072 | (U65)* |

Revision 4021

- * SCSI boot support. (See S/N 2139B-13)

Included in Upgrade Kit 12152-64005.

A900 Firmware History

| | |
|-------------|---------|
| 12201-80003 | (U0803) |
| 12201-80004 | (U0802) |
| 12201-80005 | (U0801) |
| 12201-80006 | (U1103) |
| 12201-80007 | (U1102) |
| 12201-80008 | (U1101) |
| 12201-80009 | (U0703) |
| 12201-80010 | (U0702) |
| 12201-80011 | (U0701) |
| 12201-80012 | (U1003) |
| 12201-80013 | (U1002) |
| 12201-80014 | (U1001) |
| 12201-80015 | (U0603) |
| 12201-80016 | (U0602) |
| 12201-80017 | (U0601) |
| 12201-80018 | (U0903) |
| 12201-80019 | (U0902) |
| 12201-80020 | (U0901) |
| 12201-80021 | (U1407) |
| 12201-80022 | (U1607) |

Original Release

| | |
|-------------|----------|
| 12201-80024 | (U0803)* |
| 12201-80025 | (U0802)* |
| 12201-80026 | (U0801)* |
| 12201-80027 | (U1103)* |
| 12201-80028 | (U1102)* |
| 12201-80029 | (U1101)* |
| 12201-80030 | (U0703)* |
| 12201-80031 | (U0702)* |
| 12201-80032 | (U0701)* |
| 12201-80033 | (U1003)* |
| 12201-80034 | (U1002)* |
| 12201-80035 | (U1001)* |
| 12201-80036 | (U0603)* |
| 12201-80037 | (U0602)* |
| 12201-80038 | (U0601)* |
| 12201-80039 | (U0903)* |
| 12201-80040 | (U0902)* |
| 12201-80041 | (U0901)* |
| 12201-80042 | (U1407)* |
| 12201-80043 | (U1607)* |

* Rewrite firmware to execute Code and Data Separation Instructions. Firmware change must be accompanied by a new Cache Control Board: 12203-60004.

This firmware is included in the 12203A Opt 001 Retrofit Kit.

REQUIRED TO RUN RTE-A AND VC+

| | |
|-------------|----------|
| 12201-80024 | (U0803) |
| 12201-80044 | (U0802)* |
| 12201-80026 | (U0801) |
| 12201-80027 | (U1103) |
| 12201-80028 | (U1102) |
| 12201-80029 | (U1101) |
| 12201-80030 | (U0703) |
| 12201-80031 | (U0702) |
| 12201-80032 | (U0701) |
| 12201-80033 | (U1003) |
| 12201-80034 | (U1002) |
| 12201-80035 | (U1001) |
| 12201-80036 | (U0603) |
| 12201-80037 | (U0602) |
| 12201-80038 | (U0601) |
| 12201-80039 | (U0903) |
| 12201-80040 | (U0902) |
| 12201-80041 | (U0901) |
| 12201-80042 | (U1407) |
| 12201-80043 | (U1607) |

* Computer does not Power-Fail Auto-restart. When power is restored, the computer comes up in VCP mode. (See S/N 2139A-01)

| | |
|-------------|----------|
| 12201-80045 | (U0803)* |
| 12201-80046 | (U0802)* |
| 12201-80047 | (U0801)* |
| 12201-80048 | (U1103)* |
| 12201-80049 | (U1102)* |
| 12201-80050 | (U1101)* |
| 12201-80030 | (U0703) |
| 12201-80031 | (U0702) |
| 12201-80032 | (U0701) |
| 12201-80033 | (U1003) |
| 12201-80034 | (U1002) |
| 12201-80035 | (U1001) |
| 12201-80036 | (U0603) |
| 12201-80037 | (U0602) |
| 12201-80038 | (U0601) |
| 12201-80039 | (U0903) |
| 12201-80040 | (U0902) |
| 12201-80041 | (U0901) |
| 12201-80042 | (U1407) |
| 12201-80043 | (U1607) |

* If negative indicies for EMA arrays are used, incorrect addresses are generated. This may appear as a Memory Protect error. (See S/N 2139A-2)

| | |
|-------------|----------|
| 12201-80052 | (U0803)* |
| 12201-80053 | (U0802)* |
| 12201-80054 | (U0801)* |
| 12201-80055 | (U1103)* |
| 12201-80056 | (U1102)* |
| 12201-80057 | (U1101)* |
| 12201-80030 | (U0703) |
| 12201-80031 | (U0702) |
| 12201-80032 | (U0701) |
| 12201-80033 | (U1003) |
| 12201-80034 | (U1002) |
| 12201-80035 | (U1001) |
| 12201-80036 | (U0603) |
| 12201-80037 | (U0602) |
| 12201-80038 | (U0601) |
| 12201-80039 | (U0903) |
| 12201-80040 | (U0902) |
| 12201-80041 | (U0901) |
| 12201-80042 | (U1407) |
| 12201-80043 | (U1607) |

* Changed to fix bug. Computers with battery backup will not auto-restart. Also, a compare byte instruction (CBT) incorrectly clears the X-Register.
(See S/N 2139A-2)

| | |
|-------------|----------|
| 12201-80060 | (U0803)* |
| 12201-80053 | (U0802) |
| 12201-80054 | (U0801) |
| 12201-80055 | (U1103) |
| 12201-80061 | (U1102)* |
| 12201-80062 | (U1101)* |
| 12201-80030 | (U0703) |
| 12201-80031 | (U0702) |
| 12201-80032 | (U0701) |
| 12201-80033 | (U1003) |
| 12201-80034 | (U1002) |
| 12201-80035 | (U1001) |
| 12201-80036 | (U0603) |
| 12201-80037 | (U0602) |
| 12201-80038 | (U0601) |
| 12201-80039 | (U0903) |
| 12201-80040 | (U0902) |
| 12201-80041 | (U0901) |
| 12201-80042 | (U1407) |
| 12201-80043 | (U1607) |

Revision 11

* A900 TBG runs too slow. The TBG loses approximately 24 seconds per day due to a firmware bug.
(See S/N 2139A-4)

This firmware included in Upgrade Kit 12201-60051.

| | |
|-------------|----------|
| 12201-80060 | (U0803) |
| 12201-80053 | (U0802) |
| 12201-80054 | (U0801) |
| 12201-80055 | (U1103) |
| 12201-80061 | (U1102) |
| 12201-80062 | (U1101) |
| 12201-80063 | (U0703)* |
| 12201-80064 | (U0702)* |
| 12201-80065 | (U0701)* |
| 12201-80066 | (U1003)* |
| 12201-80067 | (U1002)* |
| 12201-80068 | (U1001)* |
| 12201-80036 | (U0603) |
| 12201-80037 | (U0602) |
| 12201-80038 | (U0601) |
| 12201-80039 | (U0903) |
| 12201-80040 | (U0902) |
| 12201-80041 | (U0901) |
| 12201-80042 | (U1407) |
| 12201-80043 | (U1607) |

* Changed to fix bug. Erroneous results returned when .FPWR is followed by .FAD in MACRO code. This code is generated by the FORTRAN compiler in the expression: $B=2*A**3$
(See S/N 2139A-6)

This firmware included in Upgrade Kit 12201-60069.

| | |
|-------------|----------|
| 12201-80060 | (U0803) |
| 12201-80053 | (U0802) |
| 12201-80054 | (U0801) |
| 12201-80055 | (U1103) |
| 12201-80061 | (U1102) |
| 12201-80062 | (U1101) |
| 12201-80063 | (U0703) |
| 12201-80064 | (U0702) |
| 12201-80065 | (U0701) |
| 12201-80066 | (U1003) |
| 12201-80067 | (U1002) |
| 12201-80068 | (U1001) |
| 12201-80070 | (U0603)* |
| 12201-80071 | (U0602)* |
| 12201-80072 | (U0601)* |
| 12201-80073 | (U0903)* |
| 12201-80074 | (U0902)* |
| 12201-80075 | (U0901)* |
| 12201-80042 | (U1407) |
| 12201-80043 | (U1607) |

* Changed to fix bug. When using the .NGL instruction in MACRO to convert double precision floating point to single precision floating point, incorrect results were obtained if the instruction immediately following .NGL used address 000000 or 000001 to reference the A- or B-Registers.
(See S/N 2139A-B)

| | |
|-------------|----------|
| 12201-80076 | (U0803)* |
| 12201-80077 | (U0802)* |
| 12201-80078 | (U0801)* |
| 12201-80079 | (U1103)* |
| 12201-80080 | (U1102)* |
| 12201-80081 | (U1101)* |
| 12201-80063 | (U0703) |
| 12201-80064 | (U0702) |
| 12201-80065 | (U0701) |
| 12201-80066 | (U1003) |
| 12201-80067 | (U1002) |
| 12201-80068 | (U1001) |
| 12201-80070 | (U0603) |
| 12201-80071 | (U0602) |
| 12201-80072 | (U0601) |
| 12201-80073 | (U0903) |
| 12201-80074 | (U0902) |
| 12201-80075 | (U0901) |
| 12201-80042 | (U1407) |
| 12201-80043 | (U1607) |

* Changed to fix bug. Interim bank that contains SQRT fix but not I/O Extender changes. When taking the square root of floating point numbers that had all 1's in the mantissa and exponent combinations $4 \cdot 16^{*n}$, an incorrect result was obtained.

| | |
|-------------|----------|
| 12201-80084 | (U0803)* |
| 12201-80085 | (U0802)* |
| 12201-80086 | (U0801)* |
| 12201-80087 | (U1103)* |
| 12201-80088 | (U1102)* |
| 12201-80089 | (U1101)* |
| 12201-80063 | (U0703) |
| 12201-80064 | (U0702) |
| 12201-80065 | (U0701) |
| 12201-80066 | (U1003) |
| 12201-80067 | (U1002) |
| 12201-80068 | (U1001) |
| 12201-80070 | (U0603) |
| 12201-80071 | (U0602) |
| 12201-80072 | (U0601) |
| 12201-80073 | (U0903) |
| 12201-80074 | (U0902) |
| 12201-80075 | (U0901) |
| 12201-80042 | (U1407) |
| 12201-80043 | (U1607) |

* Changed to fix bug. This revision contains both the SQRT fix and changes for the I/O Extender. (See S/N 2139A-9)
This firmware included in Upgrade Kit 12201-60083.

| | |
|-------------|----------|
| 12201-80090 | (U0803)* |
| 12201-80091 | (U0802)* |
| 12201-80092 | (U0801)* |
| 12201-80093 | (U1103)* |
| 12201-80094 | (U1102)* |
| 12201-80095 | (U1101)* |
| 12201-80063 | (U0703) |
| 12201-80064 | (U0702) |
| 12201-80065 | (U0701) |
| 12201-80066 | (U1003) |
| 12201-80067 | (U1002) |
| 12201-80068 | (U1001) |
| 12201-80070 | (U0603) |
| 12201-80071 | (U0602) |
| 12201-80072 | (U0601) |
| 12201-80073 | (U0903) |
| 12201-80074 | (U0902) |
| 12201-80075 | (U0901) |
| 12201-80042 | (U1407) |
| 12201-80043 | (U1607) |

- * Changed to fix bug.
Fixed break disable problem
(needed in conjunction with
rev. 4011 of VCP).

See S/N 2139A-19.

This firmware is included in
Upgrade Kit 12201-60090.

| | |
|-------------|----------|
| 12201-80096 | (U0803)* |
| 12201-80097 | (U0802)* |
| 12201-80098 | (U0801)* |
| 12201-80099 | (U1103)* |
| 12201-80100 | (U1102)* |
| 12201-80101 | (U1101)* |
| 12201-80063 | (U0703) |
| 12201-80064 | (U0702) |
| 12201-80065 | (U0701) |
| 12201-80066 | (U1003) |
| 12201-80067 | (U1002) |
| 12201-80068 | (U1001) |
| 12201-80070 | (U0603) |
| 12201-80071 | (U0602) |
| 12201-80072 | (U0601) |
| 12201-80073 | (U0903) |
| 12201-80074 | (U0902) |
| 12201-80075 | (U0901) |
| 12201-80042 | (U1407) |
| 12201-80043 | (U1607) |

- * Changed to fix Machine
Check bug.

See S/N 2139A-23.

This firmware is included in
Upgrade Kit 12201-60097.

| | |
|-------------|----------|
| 12201-80103 | (U0803)* |
| 12201-80104 | (U0802)* |
| 12201-80105 | (U0801)* |
| 12201-80106 | (U1103)* |
| 12201-80107 | (U1102)* |
| 12201-80108 | (U1101)* |
| 12201-80109 | (U0703)* |
| 12201-80110 | (U0702)* |
| 12201-80111 | (U0701)* |
| 12201-80112 | (U1003)* |
| 12201-80113 | (U1002)* |
| 12201-80114 | (U1001)* |
| 12201-80115 | (U0603)* |
| 12201-80116 | (U0602)* |
| 12201-80117 | (U0601)* |
| 12201-80118 | (U0903)* |
| 12201-80119 | (U0902)* |
| 12201-80120 | (U0901)* |
| 12201-80042 | (U1407) |
| 12201-80043 | (U1607) |

* Changed to fix:

- self-test error after 50 or more power cycles (duplicated only with 50 Hz power).
- base relativity problem with VIS instructions.
- cross map move bytes (MBxx) instructions now work for all cases.
- self-test diagnoses incorrectly with first 1Mb bank in the 8Mb memory board; reports a single-bit error.

See S/N 2139A-30.

This firmware is included in Upgrade Kit 12201-60103.

A900 VCP Firmware History

NOTE

The old cache board, part no. 12203-60004, must have the old ROMs (prefix 12203-) and the new cache board must have the new ROMs (prefix 5180- or 5181-).

| |
|---------------------|
| 12203-80002 (U0908) |
| 12203-80003 (U1208) |

Original Release

| |
|----------------------|
| 12203-80005 (U0908)* |
| 12203-80006 (U1208)* |

Revision 4001

* REQUIRED TO RUN RTE-A AND VC+

Included in the 12203A Opt. 001 Retrofit Kit.

| |
|----------------------|
| 12203-80007 (U0908)* |
| 12203-80008 (U1208)* |

Revision 4001

* Add boot loaders for 1600 bpi Map Tape, 3.5" Microfloppy, and 10 MB Mini-Winchester disc. VCP is now in 8k EPROMs. (See S/N 2139A-3)

| |
|----------------------|
| 12203-80009 (U0908)* |
| 12203-80010 (U1208)* |
| or |
| 5180-4253** (U0908)* |
| 5180-4254** (U1208)* |

Revision 4004

* Change to fix bug. If system disc and CPU are powered up simultaneously, the CPU will not auto boot. (See S/N 2139A-2)

** These are new VCP ROMs used in the new A900 Cache board, part no. 12203-60011. The new board was needed for I/O Extender compatibility, and also includes field improvements. This set of ROMs is identical to those in the A600+. (See S/N 2139A-10)

12203-80012 (U0908)*
12203-80013 (U1208)*
or
5180-4263** (U0908)*
5180-4264** (U1208)*

Revision 4011

- * Fixed Break Disable processing on the 12040B/C MUX.
- ** These ROMs are used in newer A900 Cache board, part no. 12203-60011/17/18.

12203-80015 (U0908)*
12203-80016 (U1208)*
(Kit P/N 12203-64001)
or
5180-4271** (U0908)*
5180-4272** (U1208)*
(Kit P/N 5180-4274)

Revision 4020

- * A400 release, new I/O table in VCP power-up message. Supports new serial I/O drivers introduced with RTE-A rev. 4.1.
- ** These ROMs are used in newer A900 Cache board, part no. 12203-60011/17/18. Required for D-MUX console.

5180-4286 (U0908)*
5180-4287 (U1208)*

Revision 4020

- * Same as 5180-4271/72, but plastic ROMs

5181-8604 (U0908)*
5181-8605 (U1208)*

Revision 4021

- * SCSI boot capability. These ROMs are used in newer A900 Cache board, part no. 12203-60011/17/18.
- Included in upgrade kit
5181-8607.

5181-8657 (U0908)*
5181-8658 (U1208)*

Revision 4021

- * Due to a vendor change, these ROMs are used in newer A900 Cache board, part no. 12203-60011/17/18.
- Included in upgrade kit
5181-8607. (See S/N 2139B-15)

A990 Firmware History

The A990 firmware has a different structure than previous A-Series CPUs. It is composed of one EPROM that contains several pieces of code: VCP, baseset, self-test, and the configuration file for the memory/IO controller chip.

Each firmware program in the EPROM is called a product, and has a unique product ID number. The EPROM contains a directory with an entry for each product. The entry contains (among other things) the product ID and the revision number of the product. The directory also contains an entry for the entire EPROM. The entire EPROM is designated as product 0. The revision of product 0 is the revision of the entire EPROM.

This structure allows each product in the EPROM to have its own revision number. When a change is made to VCP, for example, the revision number of the VCP product must be incremented. Also, the revision number of the entire EPROM must be incremented. By looking at the revision numbers of the products in the EPROM, you can determine which products have changed in a new EPROM. You can use the HP 24612A Diagnostic “A990D” Test 5 to list the firmware revision of the A990 EPROM.

| Product # (in octal) | Rev 8 | Rev 9 | Description |
|-------------------------|--|--|----------------------------|
| | <u>12990-80106</u> Revision # (in octal) | <u>12990-80111</u> Revision # (in octal) | |
| 000 | 010 | 011 | Entire EPROM |
| 001 | 023 | 024 | VCP |
| 002 | 002 | 002 | STST0 (Self-test module 0) |
| 005 | 001 | 001 | XILINX (memory/IO) |
| 003 | 003 | 003 | STSTC (Self-test module C) |
| 011 | 002 | 002 | STSTD (Self-test module D) |
| 012 | 003 | 003 | STSTE (Self-test module E) |
| 013 | 004 | 004 | STSTF (Self-test module F) |
| 014 | 002 | 002 | STSTG (Self-test module G) |
| 015 | 004 | 005 | STSTH (Self-test module H) |
| 210 | 001 | 002 | Baseset microcode |

PSI Firmware History

12007B 1000-1000 Modem Interface **12044A 1000-1000 Direct Connect Interface**

| | |
|---------------------|--|
| 91750-80008/80009 | Original HDLC firmware. |
| 91750-80008/80021 | Refer to SN 12007B-04, 12044A-07. Fixes for: <ol style="list-style-type: none">1) Intermittent timeouts2) A-Series remote boot fails at less than 9600 baud3) Re-transmission if CRC error occurs in last frame |
| 5180-7233 | The two 4k byte EPROMs were replaced with one 8k EPROM. Refer to SN 12007B-05, 12044A-08. Fixes for: <ol style="list-style-type: none">1) Duplicate frames2) Deadlock and loss of communication |
| 5181-6113 (current) | Refer to SN 12007B-09 and 12044A-10. ROM from vendor changed. |

12042B OEM P.S.I

| | |
|-----------|----------------------|
| 5180-1951 | Self-test code only. |
|-----------|----------------------|

12043A MRJE (download)

| | |
|-----------|------------------------|
| 5180-1966 | Original |
| 5180-7290 | Refer to SN 12043A-05. |

12072A Data Link Slave firmware

| | |
|-----------|------------------------------------|
| 5180-1957 | Original Data Link Slave firmware. |
| 5180-1965 | Refer to SN 12072A-01 |

5180-1974 (current) No service note written.

12073A 1000-3000 Modem Interface
12082A 1000-3000 Direct Connect Interface

91750-80010/80011 Original BISYNC firmware.
91750-80012/80013 Refer to SN 12073A-1, 12082A-1.
Fix for intermittent link failures.
91750-80016/80017 Refer to SN 12073A-2, 12082A-2.
Auto re-enable capability added.
5180-7263/7264 (current) Minor enhancement.

12075A X.25 (LAP-B) Modem Interface

5180-1975/1976 Original LAP-B firmware.
5180-7220/7221 Refer to SN 12075A-03. Data
loss fix.
5180-7232 Lost frames fix and the two 4k byte
EPROMs were replaced with one
8k EPROM.
Refer to SN 12075A-05.
5180-7260 (current) Refer to SN 12075A-07. Enhanced
loss of communication handling.

12092A Multipoint Master Modem Interface

12092-80001/80002 Original Data Link/Multipoint Master
firmware.
12092-80003/80004 Refer to SN 12092A-02.
12092-80005/80006 (current)

12016A SCSI Firmware History

12016-80003 Original firmware (PC board part number
12016-60001).

| | |
|-------------|--|
| 12016-80005 | PC board upgraded for reliability (new PC board P/N: 12016-60101). |
| 12016-80009 | Refer to SN 12016A-03. Added SCSI boot. |

12040A/B/C MUX Firmware History

| ROM Part no. | Changes |
|--------------|---|
| 12040-80001 | Original “A” version. |
| 12040-80002 | “A” version. Fixed port lockup due to powering down terminal. |
| 5180-1970 | “B” version of the product (12040B). Changes are: <ul style="list-style-type: none">– round-robin buffer handling– no echo for control characters handled correctly– split baud rate groups added– character count reset fixed– cancel-all logic for parity fixed– ENQ/ACK handshake counter fixed– QTD modem box capability added– XON/XOFF added. |
| 5180-7227 | “almost-a-C” version.(Not a warranty upgrade) Changes are: <ul style="list-style-type: none">– ENQ/ACK timer changed to 10 seconds– control request can force XON– ports using parity now handle terminal power-downs– BREAK on odd parity ports no longer hangs port– KATAKANA (or character with hi-bit on) no longer hangs port if = is terminator. |
| 5180-7228 | “C” version (12040C, not a warranty upgrade) The only change was to set both BRG-0 and BRG-1 to 9600 baud to simplify use of the MUX as a console. |

12040D MUX Firmware History

- 5180-7245 Original “D” version.
Changes are:
– Improved performance.
– Auto speed sense.
– Expanded baud rate grouping.
– Increased type-ahead buffer.
– Mirrors HP 3000 terminal IF protocol.
- 5180-7262 “D” mux, revision 4.11.
Changes are:
Fix for port lockup caused by transparent read and zero length buffer received, that is, two carriage returns in a row.
- 5180-7268 “D” mux, revision 5.02.
Changes are:
– Data loss using TELNET fixed.
– Unsolicited interrupt after aborted write request fixed.
– Data loss on timeout with RD bit set in CN34B request fixed.
– Fix for driver–defined error 29.
– Support of QTD modem card cage.
- 5180-7289 “D” mux, revision 5.19. Fixes for the following symptoms: port hangs, illegal interrupts, and driver-defined errors 25, 28, and 29.
- 5180-7300 “D” mux, revision 5.20. Current as of September ’90. Fixes for driver-defined error 29 when configured to “Return Data on timeout”. This feature enabled by setting bit 9 in CN34B. Refer to SN 12040D-08A.

12076A LAN/1000 Interface Controller Card Firmware

| | | |
|------|-------------|--------|
| U56 | 12076-81004 | EPROM |
| U58 | 12076-81005 | EPROM |
| U291 | 12076-81006 | NOVRAM |

12041B 8-Channel MUX OEM Version

- 5180-1968 Self-test/Download/Debug Monitor ROM.

Table of Contents


Chapter 9 Diagrams

| | |
|---|------|
| A400 Board (12100-60001) | 9-1 |
| A600 Processor (12101-60001) | 9-2 |
| A600+ Processor (12105-60001) | 9-3 |
| A600/A600+ Parity Memory Controller (12102-60001/60002) | 9-4 |
| A600+ ECC Memory Controller (12110-60001/60002) | 9-5 |
| A700 Lower Processor (12152-60002) | 9-6 |
| A700 Memory Controller (12152-60003) | 9-7 |
| A700 Floating Point Processor (12156-60001) | 9-8 |
| A900 Cache Control (12203-60004) | 9-9 |
| A900 Data Path (12202-60001) | 9-10 |
| A900 Sequencer (12201-60001) | 9-11 |
| A900 Control Store (12205-60001) | 9-12 |
| A990 Board (12990-60102 or -60202*) | 9-13 |
| SCSI Interface Card (12016-60101) | 9-14 |
| LAN/1000 Interface Controller (12076-60001) | 9-15 |


Diagrams

Refer to Firmware History for ROM part numbers.


A400 Board (12100-60001)




A600 Processor (12101-60001)




A600+ Processor (12105-60001)



A600/A600+ Parity Memory Controller (12102-60001/60002)




A600+ ECC Memory Controller (12110-60001/60002)




A700 Lower Processor (12152-60002)

Frontplane Edge




A700 Memory Controller (12152-60003)

Frontplane Edge




A700 Floating Point Processor (12156-60001)



Floating Point Chips


- | | |
|-----------|--------------------|
| 1AE7-6200 | U65 (Add/Subtract) |
| 1AH4-6200 | U66 (Multiply) |
| 1AH7-6201 | U68 (Divide) |

A900 Cache Control (12203-60004)



A900 Data Path (12202-60001)


Frontplane Edge




Floating Point Chips

| | |
|-----------|--------------------------|
| 1TT4-0501 | U0807 (Multiply) |
| 1TT5-0501 | U0905 (Add/ Subtract) |
| 1TT6-0501 | U1106 (Divide) |


A900 Sequencer (12201-60001)



A900 Control Store (12205-60001)




A990 Board (12990-60102 or -60202*)



| | |
|-------|-------------|
| U1910 | 1826-2068 |
| U1913 | 12990-80106 |

* Note that this is a diagram of the edge-connector version of the A990 CPU card (12990-60202); the pin-and-socket version (12990-60102) has a different backplane connector but an identical parts layout.

SCSI Interface Card (12016-60101)



LAN/1000 Interface Controller (12076-60001)

Backplane Edge




Table of Contents

Chapter 10 Reference

| | |
|----------------------------------|------|
| A-Series Reference Manuals | 10-1 |
| Hardware Manuals | 10-1 |
| Software Manuals | 10-2 |
| Interface Manuals | 10-2 |
| Diagnostic Manuals | 10-3 |

Reference

A-Series Reference Manuals

Hardware Manuals

| | |
|---|-------------|
| HP 1000 A400 Computer Reference | 02424-90001 |
| HP 1000 A400 Computer Installation and Service | 02134-90001 |
| HP 1000 A400 Engineering Reference Document | 02424-90003 |
| HP 1000 A600/A600+ Computer Reference | 02156-90001 |
| HP 1000 A600 Computer Installation and Service | 02156-90002 |
| HP 1000 A600/A600+ Engineering Ref. Document | 02156-90003 |
| HP 1000 A600 Model 6 Installation and Service | 02136-90001 |
| HP 1000 A700 Computer Reference | 02137-90001 |
| HP 1000 A700 Computer Installation and Service | 02137-90002 |
| HP 1000 A700 User Control Store Inst. and Service | 02137-90003 |
| HP 1000 A700 Engineering Reference Document | 02137-90005 |
| HP 12156A FPP Installation and Service | 12156-90001 |
| HP 92045A Microprogramming Reference | 92045-90001 |
| HP 1000 A900 Computer Reference | 02139-90001 |
| HP 1000 A900 Computer Installation and Service | 02139-90002 |
| HP 1000 A900 Engineering Reference Document | 02139-90003 |
| HP 1000 A990 Computer Reference | 02959-90001 |
| HP 1000 A990 Upgrade Installation and Service | 12990-90011 |
| HP 1000 A990 20-Slot Installation and Service | 02959-90002 |
| HP 1000 A990 16-Slot Installation and Service | 02939-90001 |
| HP 92049A Microprogramming Reference | 92049-90001 |
| HP 1000 Model 26/27/29 Installation and Service | 02196-90002 |
| HP Micro 14/16 Computer Installation and Service | 02420-90001 |
| HP Micro/1000 System/Computer Inst. and Service | 02430-90001 |
| HP 12025A/B Input/Output Extender Support | 12025-90001 |
| HP 1000 A-Series I/O Interfacing Guide | 02103-90055 |

Software Manuals

| | |
|--|-------------|
| Getting Started with RTE-A | 92077-90039 |
| RTE-A User's Manual | 92077-90002 |
| RTE-A Utilities | 92077-90004 |
| RTE-A Programmer's Reference | 92077-90007 |
| RTE-A LINK | 92077-90035 |
| RTE-A Driver Reference | 92077-90011 |
| RTE-A System Design | 92077-90013 |
| RTE-A Driver Designer's | 92077-90019 |
| RTE-A System Generation and Installation Guide | 92077-90034 |
| RTE-A Quick Reference Guide | 92077-90020 |
| RTE-A Index and Glossary | 92077-90036 |
| RTE-A and RTE-6/VM Relocatable Libraries | 92077-90037 |
| RTE-A Primary System Reinstallation | 92077-90038 |
| Binder for Quick Reference Guide | 5958-5156 |
| EDIT/1000 User's | 92074-90001 |
| HP-IB User's Manual | 59310-90064 |
| Macro/1000 Assembler Reference | 92059-90001 |
| Small Disc User's Guide | 5958-9152 |

Interface Manuals

| | |
|---|-------------|
| HP 12005A Asynchronous Serial IF Reference | 12005-90001 |
| HP 12005B Asynchronous Serial IF Reference | 12005-90002 |
| HP 12006A Parallel Interface Reference | 12006-90001 |
| HP 12007A HDLC MODEM Interface Reference | 12007-90001 |
| HP 12008A PROM Storage Module Reference | 12008-90001 |
| HP 12009A HP-IB Interface Reference | 12009-90001 |
| HP 12016A SCSI Host Bus Adapter Inst. and Reference | 12016-90001 |
| HP 12040A 8-Channel Multiplexer Reference | 12040-90001 |
| HP 12040C 8-Channel Multiplexer Reference | 12040-90022 |
| HP 12041B Downloadable MUX Reference | 12041-90001 |
| HP 12042A Programmable Serial IF Reference | 12042-90001 |
| HP 12044A HDLC Direct Connect IF Reference | 12044-90001 |
| HP 12060A Analog to Digital IF Reference | 12060-90001 |
| HP 12062A Digital to Analog IF Reference | 12062-90001 |
| HP 12063A Isolated Digital IF Reference | 12063-90001 |
| HP 12065A Color Video Output IF Reference | 12065-90001 |
| HP 12072A Data Link Slave IF Reference | 12072-90001 |
| HP 12076A LAN/1000 Link Installation Manual | 12076-90001 |
| LAN/1000 Node Manager's Manual | 12076-90002 |

Diagnostic Manuals

| | |
|--|---------------|
| Diagnostic Operating and Troubleshooting | 24612-90013 |
| Diagnostic Design Language Prog Reference | 24612-90015 |
| Kernel Diagnostics Reference | 24612-90017 |
| Introduction to HP 1000 A-Series Diagnostics | 24612-90010 |
| Interface Diagnostic Reference | 24612-90011* |
| HP 7970E HP-IB 1000 A/L-Series Verifier | 07970-90908 |
| 7970E and Systems Modem Diag Reference | 24398-90008** |
| CS/80 External Exerciser | 5955-3462 |
| ICD/MAC Disc Diagnostic Reference | 5955-4355 |
| 7974/7978 Tape Drive A-Series Exerciser | 5958-9137† |

* This manual contains the contents of the following manuals that have been discontinued:

| | |
|--|-------------|
| HDLC Interface Diagnostic Reference | 24600-90001 |
| Data Link Slave Interface Diagnostic Reference | 24600-90002 |
| Analog to Digital Interface Diagnostic Reference | 24601-90001 |
| Digital to Analog Interface Diagnostic Reference | 24601-90002 |
| Isolated Digital Interface Diagnostic Reference | 24601-90003 |
| MUX Interface Diagnostic Reference | 12040-90003 |
| Interface Diagnostics Reference | 24612-90004 |

** This manual contains the contents of the following manuals that have been discontinued:

| | |
|--|-------------|
| System Modem Diagnostic Reference | 24398-90004 |
| Micro-Flexible Disc Diagnostic | 24398-90005 |
| Loading Your 24398B Diagnostic from Mag Tape | 24398-90006 |

† This manual was previously Part No. 24398-90007.