

# Intel® Server Board SHG2 Quick Start User Guide

## Start Here

Thank you for buying an Intel® Server Board. The following information will help you prepare your server board for integration with your selected server chassis. This Guide is for technically qualified persons. Expanded installation instructions and complete product information are available in the *Intel® Server Board SHG2 Product Guide* located on the Resource CD. Translations of the *Intel Server Board Product Guide* are available at:  
 您可在下列网址上查阅到 Intel 服务器主板产品指南的译文:  
 La traducción de la Guía del Producto Intel Server Board se encuentra disponible en:  
<http://support.intel.com/support/motherboards/server/SHG2>


### Minimum Hardware Requirements

- To avoid integration difficulties and possible board damage, your system must meet the following minimum requirements:
- Processor:** Minimum of one 1.8 GHz Intel® Xeon™ processor with 512K cache support in a 603-pin micro Pin-Grid Array (PGA).
  - Memory:** Minimum of two identical 128 MB ECC, DDR 200 or 266-compliant registered SDRAM 168-pin gold DIMMs.
  - Power:** Minimum of 450W with 1.2A standby current which meets the SSI EPS 12V specification.

Additional resources and support for your server board, including tested chassis, qualified memory and chassis components, specifications, and software updates, can be found at:  
<http://support.intel.com/support/motherboards/server/SHG2>

### Before you begin

You will need the following tools and equipment:



## Build Value With Intel

### Server Products, Programs and Support

Get the high-value server solutions you need by taking advantage of the outstanding value Intel provides to system integrators:

- High-quality server building blocks
- Extensive breadth of server building blocks
- Solutions and tools to enable e-Business
- Comprehensive training services †
- Worldwide 24x7 technical support [AT&T Country Code + 866-655-6565] †
- World-class service, including a three-year warranty and Advanced Warranty Replacement †

For more information on Intel's added-value server offerings, visit the Intel® ServerBuilder website at: [www.intel.com/go/serverbuilder](http://www.intel.com/go/serverbuilder)


Intel ServerBuilder is your one-stop shop for information about all of Intel's Server Building Blocks such as:

- Product information including product briefs and technical product specifications
- Sales tools such as videos and presentations
- Configuration tools to help you build complete solutions
- Training information such as the Intel® Online Learning Center
- Support information and much more


† Available only to Intel® Channel Program Members, part of Intel® e-Business Network.

## 1 Installing the I/O Shield and Gasket


### A Attaching the Gasket to the I/O Shield




### B Attaching the Label to the I/O Shield



### C Installing the I/O Shield



See the *Intel Server Board SHG2 Product Guide* for product safety and EMC regulatory compliance information.  
 If you are not familiar with ESD (Electro-Static Discharge) procedures to be used during system assembly, complete ESD Procedures are described in your *Intel Server Board SHG2 Product Guide*.




## 2 Installing Memory


### DIMM Memory Modules

Memory banks must be populated in pairs. Support for 2-way memory interleaving requires the use of identical memory modules.

1. Open both DIMM Socket Levers.
2. Insert DIMM making sure the connector edge of the DIMM aligns correctly with the slot.
3. Check that socket levers are securely latched.




## 3 Installing the Chassis Standoffs



**For the Intel® SC5200 chassis:** Install standoffs in positions, 5, 18, S, 19 and in the eight positions marked P.


## 4 Installing the Server Board




## 6 Installing the Wind Tunnel

**Note:** If installing the server board in the Intel® SC5200 Hot-Swap, Redundant Power Chassis, do not install the Processor Wind Tunnel.


### A Attaching the Wind Tunnel Assembly




### B Attaching the Heat Sink Fan



### D Attaching Exhaust Section




### C Attaching the Air Intake Section




## 5 Installing the Processor(s)

**Note:** If installing only one processor, it must be installed in the Processor Socket labeled CPU1, which is closest to the corner of the server board. If installing a second processor, verify that the processors are identical, same voltage and speed.


### A Installing the Retention Brackets




### B Attaching the Processor



### C Applying Thermal Grease



### D Attaching the Heat Sink






**7 Making Connections to the Server Board**

**Server Board Connection Quick Reference:**

- |                      |                                |                          |
|----------------------|--------------------------------|--------------------------|
| A. Main Power        | J. Floppy Disk Drive connector | R. HSBP-A                |
| B. Aux Sig.          | K. Secondary IDE               | S. HDD LED               |
| C. +12 V CPU Power   | L. System Fan 6                | T. LVD SCSI B            |
| D. CPU1 Fan          | M. Primary IDE                 | U. Front Panel connector |
| E. CPU2 Fan          | N. IPMB                        | V. LVD SCSI A            |
| F. Front Panel USB   | O. System Fan 3                | W. Chassis Intrusion     |
| G. Serial B          | P. System Fan 4                | X. System Fan 1          |
| H. Jumper Block CN27 | Q. HSBP-B                      | Y. System Fan 2          |
| I. System Fan 5      | Z. ICMB                        |                          |




**Intel SC5200 Base Server Chassis Note**  
Connect front system fans to connectors 3 and 4 on the server board.

**Intel SC5200 Hot-Swap, Redundant Power Server Chassis Note**  
Be sure to attach system fans to their correspondingly numbered connector on the server board. System fan numbers have been printed on the front and rear system fan holders.

**8 Cable Routing**


**IDE and SCSI Cables - SC5200 Base Chassis**



IDE and SCSI cables that connect to devices in the lower device bays should be routed around the epac as shown.


1. Remove the top half of the epac.
2. Route cable(s) as shown.
3. Replace the top half of the epac.

**Floppy Drive and Front Panel USB Cables - SC5200 Base Chassis**




Route the floppy drive cable and the front panel USB cable as shown.

**Cable Routing - SC5200 Hot-Swap Chassis**



**9 Installing the Serial B Cable**

For the Intel SC5200 chassis, you can connect the Serial Port B cable to either the back of the chassis or, on a rack mount system, to the front of the chassis.



1. Use a screw driver to remove the connector knock out.
2. Install the Serial B cable by inserting it into the chassis back panel cutout and attaching the two hex screws as shown.
3. Attach the other end to the Serial B connector on the server board. See step 7 for connector location on the server board.

**11 Getting Started with Intel® Server Management and Intel® SMaRT Tool (Optional)**

Intel® Server Management Software and the hard drive Service Partition provide real-time monitoring and alerting for your SHG2 server hardware, emergency remote management, and remote server setup. Intel Server Control is implemented by installing it within client-server architecture. The Service Partition provides you with the ability to remotely access a local partition on the server and to identify and diagnose server health issues. Remote access is provided through either a modem or network connection.

The Intel® Server Maintenance and Reference Training (SMaRT) Tool is an interactive software tool providing support information to assist with the maintenance and repair of Intel-based server systems and accessories. SMaRT Tool features visual, step-by-step instructions for replacing parts; a complete Field Replacement Unit (FRU) database containing part numbers and images; product spares lists, and worldwide Intel support information.

Intel Server Management provides an interface to the Intel® SMaRT Tool, combining remote error detection and alerting with interactive maintenance and repair assistance. When Intel Server Management detects a hardware error and a part needs replacing, SMaRT Tool can be launched directly from Intel Server Management to locate the correct part information and corresponding "How to Replace" steps required to quickly get the server back up and running.

To activate Intel Server Management's interface with the Intel SMaRT Tool, both software programs need to be installed. You can install the software on a server or on a workstation used to manage the server. The information here describes installation on a system running a Microsoft Windows® operating system. For other operating systems, see the Installation Guide & User Guide located in the "ISM/Docs" folder on the Intel Server Management CD-ROM. SMaRT Tool may only be installed on a system running a Microsoft Windows® operating system.

**Note:** Prior to installation, uninstall any previous version of Intel Server Control.

**Installing Service Partition on the Server (Optional)**

The Service Partition provides advanced remote management and configuration functionality. Installation is optional.

1. Power-on the server, insert the *Intel® Server Management CD* into the CD-ROM drive and boot to the CD.
2. Select **Utilities > Run Service Partition Administrator > Create Service Partition-first time**.
3. Select an available hard drive. The server will reboot the CD.
4. After the server reboots, select **Format Service Partition and Install Software**.
5. Exit the menu, Remove the CD and reboot to install the server operating system.

**Installing your Operating System**

Install your operating system now.

**Installing Intel Server Management**

You can install Intel Server Management on a local server or on a remote workstation that is used to manage a LAN/WAN.

1. Insert the *Intel Server Management CD* into the system's CD-ROM drive.
2. Click **Install Server Management**.
3. Complete the Registration form and click **Submit**.
4. Select the applicable system option.
5. Review the Intel Software License Agreement and click **Submit**.
6. If installing to a local server, click **Install Now**. If this is a multiple system installation, click **Add** to compile a list of systems and then click **Install Now**.

7. Select **Reboot Now or Reboot Later**.
8. Remove the Intel Server Management CD.

**Installing Intel SMaRT Tool**


SMaRT Tool may only be installed on a system running a Microsoft Windows® operating system. To download the SHG2 SC5200 server system module for SMaRT Tool, you must have internet access.

1. Insert the *Intel Server Board SHG2 Resource CD* into the system's CD-ROM drive.
2. Click on **Intel® SMaRT Tool** in the menu on the left side of the screen.
3. In the green **Make a Selection** drop-down menu, select **SMaRT Tool Install Guide**. Print the Guide, and keep it on hand for reference. Review the SMaRT Tool Install Guide prior to proceeding.
4. In the **Make a Selection** drop-down menu, select **Install SMaRT Tool**.
5. Click on the **Run Installer** icon to launch the SMaRT Tool Setup program.
6. Follow the on-screen installation instructions. Review the Intel Software License Agreement and click **Accept**. When installation is complete, launch SMaRT Tool.
7. In SMaRT Tool's Welcome page, click on **Systems**.
8. Select **Select System > Servers > Xeon™ > SHG2 SC5200** and then follow the on-screen instructions to download the SHG2 SC5200 server system module. When download is complete, SMaRT Tool will restart.
9. Select **Systems > Select System > Servers > Xeon™ > SHG2 SC5200** to access information on your new server system.
10. You can invoke SMaRT Tool directly from Intel Server Management's Platform Instrumentation Control application by clicking on the SMaRT Tool icon, or by selecting **Launch SMaRT Tool** from the **SMaRT Tool** menu. The interface between the two programs is context-sensitive. To find out more about the integration between Intel SMaRT Tool and Intel Server Management, please select **SMaRT Tool and Server Management** in the green **Make a Selection** drop-down menu.

**10 Finishing Up**


Before installing your operating system, you must finish your chassis installation and connect I/O connectors and AC power.

1. Replace the chassis cover.
2. See your chassis documentation to complete rack or pedestal installation.
3. Connect your keyboard, mouse, video and other I/O cables as shown.
4. Connect the AC Power cable.



**Reference**

**Server Board Component Layout**



**Component Descriptions:**

- |                                      |                      |                           |
|--------------------------------------|----------------------|---------------------------|
| A. Primary Processor Socket (CPU1)   | O. System Fan 3      | FF. NIC2 (Gbit)           |
| B. CPU2 Fan                          | P. System Fan 4      | GG. System I/O connectors |
| C. Secondary Processor Socket (CPU2) | Q. HSBP-B            | HH. DIMMs                 |
| D. Front Panel USB                   | R. HSBP-A            | II. Main Power            |
| E. Serial B                          | S. HDD Led           | JJ. Aux. Sig.             |
| F. Jumper Block CN27                 | T. LVD SCSI B        | KK. +12 V CPU Power       |
| G. System Fan 5                      | U. Battery           | LL. CPU1 Fan              |
| H. Floppy Disk Drive connector       | V. LVD SCSI A        |                           |
| I. Secondary IDE                     | W. Jumper Block CN53 |                           |
| J. System Fan 6                      | X. Chassis Intrusion |                           |
| K. Primary IDE                       | Y. PCI-X 64/133      |                           |
| L. Front Panel connector             | Z. PCI 32/33         |                           |
| M. IPMB                              | AA. PCI 64/100       |                           |
| N. Jumper Block CN43                 | BB. System Fan 1     |                           |
|                                      | CC. System Fan 2     |                           |
|                                      | DD. ICMB             |                           |
|                                      | EE. NIC1 (10/100)    |                           |

**Common Problems and Solutions**

- The system does not boot or show video at power on.**
- If configuring with only one processor verify that the processor is in the Primary Processor socket (CPU 1).
  - Beep code 1-3-3-1 means you have unrecognized or bad memory. Remove and replace DIMMs one at a time to isolate which one is causing problems.
  - Verify that +12V CPU Power is connected.
  - Remember, all DIMMs must be:
    - Registered DDR 200 or 266-compliant 2.5V SDRAM
    - Paired with an identical DIMM in a bank
- The system sometimes works, but is exhibiting erratic behavior.**
- This is typically the result of using an under-rated power supply. Make sure you are using at least a 450 W power supply which meets the SSI EPS 12V specification. For more information, see <http://www.ssforum.org>

**Accessories and Order Codes**

Item	Product Code
Intel® SC5200 Server Chassis Base Chassis	KHD3BASE450
Intel® SC5200 Server Chassis Redundant Power Chassis	KHD3HSRP650
Intel® SC5200 Server Chassis Rack Optimized Redundant Power Chassis	KHD3HSRP650R
Intel® SC5200 Server Chassis spares kit	FHD3SPRS
Intel® RAID Controllers	SRCU42L SRCU32U SRCMRR