Shugart Drive options required for Xebec 1200.

A. Pluggable options dependent on unit number selection.

Pluggable Jumper	As Shipped from Shugart		Required for Drive 0		Required for Drive 1		Required for Drive 2	
	Open	Plugged	Open	Plugged	Open	Plugged	Open	Plugge
T1,T3,T4,T5,T6		х		х	х		х	Trade of the Control
DS1		Х		х	х		x	
DS2	х		х			х	X	
DS3	Х		х		Х			** <b>X</b> * **

B. Pluggable option, all drive regardless of unit number.

Pluggable Jumper	As shipped from Shugart		Required for all Drives		
	Open	Plugged	Open	Plugged	
T2,DS,C,Y	х			Х	Change required
HL,X,Z		х	х		Change required
DS4,D,DC	X	,	x		No change
A,B		Х		Х	No change

C. Cut and jumper options. no change

Cut & Jump Options	As shipped from Shugart		
	<b>O</b> pen	Short	
NP,8,16,D1,D2, D4,DDS	х		
RR,RI,R,I,S, WP,32,I/O Pins 2,4,6,8,10,12, 14,16,18		x	

For use in the Xebec 1200, the following Shugart drive part number is required. For other configurations, consult Xebec.

