

9306 Model 200 Netfinity NetBAY22 Unpacking Instructions

Before you begin, read through these instructions to familiarize yourself with the unpacking procedure.

Follow these instructions to unpack the rack.

1



DANGER

The empty rack weighs 82 kg (181 lbs). Two or more people are required to complete this procedure.

You need the following items to unpack the rack:

Utility knife

5 mm hex key (provided in the miscellaneous parts kit that comes with the rack)

12 mm open-end wrench

IBM Netfinity NetBAY22 Unpacking Instructions (this booklet)

Selecting a Location

To avoid damaging the rack, move the rack to the location where it will be installed before unpacking it or installing options. When selecting a location for the rack, consider the following:

The dimensions (width x depth x height) of the rack are:

Before Unpacking 66 cm x 98 cm x 137 cm (26 in. x 38.5 in. x 54 in.)

After Unpacking 60 cm x 88 cm x 118 cm (23.5 in. x 34.5 in. x 46.5 in.)

The maximum weight of the rack is 82 kg (181 lbs) empty and 424 kg (935 lbs) full.

The rack requires the following clearances:

