

.REM *

IDENTIFICATION

PRODUCT CODE: AC-9357D-MC
PRODUCT NAME: CZTADD0 TA11 MOTION TST
DATE REVISED: FEB 1978
MAINTAINER: DIAGNOSTIC ENGINEERING
AUTHOR: JIM LACEY

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS DOCUMENT.

NO RESPONSIBILITY IS ASSUMED FOR THE USE OR RELIABILITY OF SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL OR ITS AFFILIATED COMPANIES.

COPYRIGHT (C) 1973, 1978 BY DIGITAL EQUIPMENT CORPORATION

THE FOLLOWING ARE TRADEMARKS OF DIGITAL EQUIPMENT CORPORATION:

DIGITAL	PDP	UNIBUS	MASSBUS
DEC	DECUS	DECTAPE	

CONTENTS

1. ABSTRACT
 2. REQUIREMENTS
 - 2.1 EQUIPMENT
 - 2.2 STORAGE
 - 2.3 PRELIMINARY PROGRAMS
 3. LOADING PROCEDURE
 4. STARTING PROCEDURE
 - 4.1 CONTROL SWITCH SETTINGS
 - 4.2 STARTING ADDRESS
 - 4.3 PROGRAM & OPERATOR ACTION
 5. OPERATING PROCEDURE
 - 5.1 OPERATIONAL SWITCH SETTINGS
 - 5.2 SUBROUTINE ABSTRACTS
 6. ERRORS
 7. RESTRICTIONS
 8. MISCELLANEOUS
 - 8.1 EXECUTION TIME
 - 8.2 STACK POINTER
 - 8.3 PASS COUNTER
 - 8.4 ITERATIONS
 - 8.5 SPECIAL REGISTERS
 9. PROGRAM DESCRIPTION
-
1. ABSTRACT

THIS PROGRAM CONTAINS A SERIES OF TESTS THAT CHECK THE TU60 DRIVE FOR PROPER OPERATION.
 2. REQUIREMENTS
 - 2.1 EQUIPMENT

PDP-11 COMPUTER WITH OR WITHOUT HARDWARE SWITCH REGISTER WITH CONSOLE TELETYPE, AND A TA11 CASSETTE
 - 2.2 STORAGE

THIS PROGRAM REQUIRES APPROX. 4K STORAGE.
 - 2.3 PRELIMINARY PROGRAMS

CZTAA

CZTAB
CZTAC

3. LOADING PROCEDURE

USE STANDARD PROCEDURE FOR LOADING .ABS TAPES
OR A CASSETTE TAPE.

4. STARTING PROCEDURE

4.1 CONTROL SWITCH SETTINGS

SEE 5.1.

4.2 STARTING ADDRESSES

200 NORMAL STARTING ADDRESS
204 SELECT DRIVE(S) BEFORE STARTING TEST
210 SELECT DRIVE(S) AND ADDRESSES BEFORE STARTING TEST
214 SETUP FOR MANUAL LOOPING
220 WRITE FILE GAP FROM BOT TO EOT
224 WRITE CONTINOUS BLOCKS OF DATA
230 READ CONTINOUS BLOCKS OF DATA
234 WRITE FILE GAP AND A BLOCK OF DATA
240 READ BLOCK OF DATA AND INTO A FILE GAP
244 SPACE FWD FILE GAP FROM BOT TO EOT
250 BACK SPACE FILE GAPS

4.3 PROGRAM & OPERATOR ACTION

1. LOAD PROGRAM INTO MEMORY (SEE SECTION 3.)
2. LOAD A WRITE ENABLED CASSETTE IN BOTH DRIVES
3. REWIND BOTH DRIVES
4. LOAD ADDRESS 200.
5. SET SWITCHES (SEE SECTION 5.1)
6. PRESS START.
7. THE PROGRAM WILL LOOP & TTY BELL WILL RING ONCE EVERY PASS, IF SW<10>=0.

*** NOTE: IF USING THE SOFTWARE SWITCH REGISTER THE PROGRAM WILL TYPE "SWR=XXXXXX NEW=" AFTER TYPING THE NAME OF THE PROGRAM.

4.3.1 DRIVE SELECTION

STARTING THE PROGRAM AT 200 WILL RESULT IN AUTOMATIC SELECTION OF DRIVES "A" AND "B" TO BE TESTED.

NOTE: IF LOAD MEDIUM IS CASSETTE WITH STANDARD VECTOR PROGRAM WILL RESPOND AS IF STARTED AT 210.

STARTING THE PROGRAM AT 204, 210, OR 214 ALLOWS THE OPERATOR TO SELECT THE DRIVE(S) TO BE TESTED.

THE PROGRAM WILL TYPE "DRIVE(S)?".

EITHER OR BOTH DRIVES CAN BE SELECTED BY TYPING "A" AND/OR "B" FOLLOWED BY A CARRIAGE RETURN.

4.3.1.1 DRIVE SELECTION EXAMPLES

DRIVE(S)? A,B
DRIVE(S)? AB
DRIVE(S)? B,A
DRIVE(S)? B

4.3.2 ADDRESS SELECTION

STARTING THE PROGRAM AT 210 OR 214 ALLOWS THE OPERATOR TO CHANGE THE "CONTROL AND STATUS" AND "DATA BUFFER" REGISTER ADDRESSES, THE VECTOR ADDRESS AND THE PRIORITY LEVEL.

THE PROGRAM WILL ASK FOR THE DRIVES TO BE TESTED AS PER 4.3.1. AFTER THE DRIVES HAVE BEEN SELECTED IT WILL ASK FOR:

1. BUS ADDRESS OF THE CONTROL AND STATUS REGISTER (TACS)
2. VECTOR ADDRESS
3. PRIORITY LEVEL

AND THE OPERATOR MUST RESPOND WITH THE DESIRED PARAMETER OR A CARRIAGE RETURN (WHICH IMPLIES LEAVE AS IS). WHEN ALL PARAMETERS HAVE BEEN DEFINED THE PROGRAM WILL TYPE THEM BACK OUT AND ASK IF THEY ARE OK AT WHICH TIME THE OPERATOR RESPONDES WITH A "Y" OR A "CARRIAGE RETURN" FOR "YES" ANYTHING ELSE IS A "NO".

4.3.2.1 ADDRESS SELECTION EXAMPLES

DRIVES(S) A
TACS? 177500
VECTOR? 260
PRIORITY? 6
TACS=177500 TADB=177502 VECTOR=000260 PRIORITY=000300
OK?

DRIVES(S) A,B
TACS? 470
VECTOR?
PRIORITY?
TACS=177470 TADB=177472 VECTOR=000260 PRIORITY=000300
OK?

4.3.3 SUBTEST LOOPING

THE SCOPE ROUTINE (REFER 5.2.1), PROVIDES A MEANS BY WHICH THE OPERATOR CAN SPECIFY THE FIRST ADDRESS OF A SCOPE LOOP.

THE OPERATOR TYPES A "CONTROL C" (^C) AND WHEN THE NEXT SCOPE STATEMENT IS EXECUTED THE PROGRAM WILL ASK FOR:

1. TEST PC--- THE FIRST ADDRESS OF THE TEST (MUST BE A SCOPE)
2. LOOP PC--- THE ADDRESS TO LOOP BACK TO

4.3.3.1 SUBTEST LOOPING EXAMPLES

```
;OPERATOR TYPES "^C"  
TEST PC? 2242          :OPERATOR TYPES "2242" "CARRIAGE RETURN "(CR)"  
LOOP PC?              ;OPERATOR TYPES "CR" WHICH  
                      ;IMPLIES "LOOP PC"="TEST PC"
```

```
;OPERATOR TYPES "^C"  
TEST PC? 3000          ;OPERATOR TYPES "3000" "CR"  
LOOP PC? 3020          ;OPERATOR TYPES "3020" "CR"  
                      ;PROGRAM USES THIS AS THE  
                      ;FIRST ADDRESS OF THE SCOPE  
                      ;LOOP
```

```
;OPERATOR TYPES "^C"  
TEST PC?              ;OPERATOR TYPES "CR"  
                      ;PROGRAM CONTINUES  
                      ;FROM THIS POINT
```

5. OPERATING PROCEDURE
5.1 OPERATIONAL SWITCH SETTINGS

IF THE DIAGNOSTIC IS RUN ON A CPU WITHOUT A SWITCH REGISTER THEN A SOFTWARE SWITCH REGISTER IS USED WHICH ALLOWS THE USER THE SAME SWITCH OPTIONS AS THE HARDWARE SWITCH REGISTER. IF THE HARDWARE SWITCH REGISTER DOES NOT EXIST OR IF ONE DOES AND IT CONTAINS ALL ONES (177777) THEN THE SOFTWARE SWITCH REGISTER (LOC. 176) IS USED.

CONTROL:

THIS PROGRAM ALSO SUPPORTS THE DYNAMIC LOADING OF THE SOFTWARE SWITCH REGISTER (LOC. 176) FROM THE TTY. THIS CAN BE ACCOMPLISHED BY DOING THE FOLLOWING:

- 1) TYPE CONTROL G <^G>; THIS WILL ALLOW THE TTY TO ENTER DATA INTO LOC. 176 AT SELECTED POINTS WITHIN THE PROGRAM.
- 2) THE MACHINE WILL THEN TYPE: SWR=XXXXXXNEW= (XXXXXX IS THE OCTAL CONTENTS OF THE SOFTWARE SWITCH REGISTER.)
- 3) AFTER THE 'NEW=' HAS BEEN TYPED THEN THE OPERATOR CAN DO ONE OF THE FOLLOWING AT THE TTY:
 - A) TYPE A NUMBER TO BE LOADED INTO LOC. 176 FOLLOWED BY A <CR>. (ONLY NUMBERS BETWEEN 0-7 WILL BE ACCEPTED AND ONLY 6 NUMBERS WILL BE ALLOWED)
IF A <CR> IS THE FIRST KEY DEPRESSED THE SOFTWARE SWITCH REGISTER CONTENTS WILL NOT BE CHANGED.
 - B) IF A CONTROL U <^U> IS DEPRESSED THEN THE PROGRAM WILL SEND YOU BACK TO STEP 2.

WITH SW<15:08>=0 THE PROGRAM WILL PRINT OUT ON ERRORS AND CONTINUE IN TEST. BELL WILL RING AT COMPLETION OF A PASS.
THE SWITCH SETTINGS ARE:

SW<15>=1...HALT ON ERROR
SW<14>=1...LOOP ON TEST
SW<13>=1...INHIBIT ERROR TYPEOUTS
SW<11>=1...INHIBIT ITERATIONS
SW<10>=1...RING BELL ON ERROR
SW<10>=0...RING BELL ON PASS COMPLETE
SW<09>=1...LOOP ON ERROR
SW<07>=1...LOCK ON CURRENT DRIVE
SW<06>=1...DELAY AT END OF EACH FUNCTION
SW<05>=1...RUN WITHOUT INTERRUPTS
SW<04>=1...IGNORE BLOCK CHECK ERRORS
SW<03>=1...INHIBIT DATA COMPARE

5.2 SUBROUTINE ABSTRACTS

5.2.1 SCOPE

THIS SUBROUTINE CALL (VIA AN IOT INSTRUCTION) IS PLACED BETWEEN EACH TEST IN THE INSTRUCTION SECTION. IT RECORDS THE STARTING ADDRESS OF EACH TEST IN LOCATION "\$LPADR" AND "\$LPERR" AS IT IS BEING ENTERED.

THIS ROUTINE SUPPORTS THE S/W SWITCH REG FUNCTIONS
NOTE: THIS ROUTINE CHECKS THE TTY INPUT BUFFER FOR A "CONTROL C" (REFER TO 4.3.3)

5.2.2 TRAPCATCHER

A ".+2" - "HALT" SEQUENCE IS REPEATED FROM LOC. 0 TO LOC. 776 TO CATCH ANY UNEXPECTED TRAPS. THUS, ANY UNEXPECTED TRAPS WILL HALT AT THE DEVICE TRAP VECTOR +2.

5.2.3 ERROR

THIS SUBROUTINE CALL (VIA A EMT INSTRUCTION) IS USED TO REPORT ALL ERRORS. (REFER TO 6.)

*** THIS ROUTINE SUPPORTS THE S/W SWITCH REG FUNCTIONS
*** IF THE PROCESSOR HALTS (BIT 15=1), OPERATOR CAN RESET S/W SWITCH REGISTER BY HITTING A "CONTROL G" <^G> BEFORE HITTING CONTINUE.

5.2.4 TRAP

A NUMBER OF SUBROUTINES ARE CALLED BY THE TRAP INSTRUCTION. FOLLOWING IS THE CALLS USED AND THE STARTING ADDRESS OF THE ROUTINE.

5.2.4.1 TYPE (\$TYPE)

TYPE AN ASCIZ STRING ON THE TTY

5.2.4.2 RDCHR (\$RDCHR)

READ A SINGLE ASCII CHARACTER FROM THE TTY

5.2.4.3 RDLIN (\$RDLIN)

READ AN ASCII STRING FROM THE TTY

5.2.4.4 SETLOOP (T.SETLOOP)

SETUP TO LOOP AS PER THE TTY

5.2.5 THE FOLLOWING "TRAP" CALLS ARE WHAT ARE USED TO PERFORM THE TESTS.

THE ROUTINES THAT ARE CALLED IS WHAT MAKES UP THE HEART OF THIS PROGRAM.

5.2.5.1 WFG (T.WFG) WRITE A FILE GAP

5.2.5.2 WRITE (T.WRIT) WRITE A BLOCK OF DATA

5.2.5.3 READ (T.READ) READ A BLOCK OF DATA

5.2.5.4 BSFG (T.BSFG) BACK SPACE A FILE GAP

5.2.5.5 BSBG (T.BSBG) BACK SPACE A BLOCK GAP

5.2.5.6 SFFG (T.SFFG) SPACE FORWARD A FILE GAP

5.2.5.7 SFBG (T.SFBG) SPACE FORWARD A BLOCK GAP

5.2.5.8 REWIND (T.RWND) REWIND THE TAPE TO BOT

5.2.5.9 SELDRV (T.SELDRV) SELECT A DRIVE

5.2.5.10 BLKCMP (T.BLKCMP) COMPARE READ AND WRITE BUFFERS

5.2.6 THE FOLLOWING SUBROUTINES ARE CALLED BY A JSR

5.2.6.1 DO.CMD

THIS ROUTINE WILL LOAD THE LOW BYTE OF THE "TACS" WITH THE FIRST BYTE FOLLOWING THE CALL.

WHEN THE FUNCTION IS TO BE PERFORMED WITH "INTERRUPT ENABLE"=1 THE TA11 VECTOR IS SET TO "SERV". WHEN THE FUNCTION IS TO BE PERFORMED WITH "INTERRUPT ENABLE"=0 THE VECTOR IS SET TO "BADINT"

NOTE SWR<5> PROVIDES OVERRIDE CAPABILITIES OF "INTERRUPT ENABLE"=1.

5.2.6.2 WAITFLAG

THIS ROUTINE IS CALLED AFTER A COMMAND HAS BEEN SENT TO THE TA11. IT WAITS A PREDETERMINED AMOUNT OF TIME A TAKES ONE OF THREE EXITS.

THE EXITS FOLLOW THE CALL AND ARE:

1. ERROR NO FLAGS OCCURRED
2. ERROR NO INTERRUPT OCCURRED
3. NORMAL RETURN

5.2.6.3 FLAGS

THIS ROUTINE IS CALLED TO DETERMINE WHAT FLAGS ARE UP. THIS ROUTINE WILL TAKE ONE OF FOUR RETURNS DEPENDING ON THE FLAGS.

THE RETURNS FOLLOW THE CALL AND ARE:

1. "TRANSFER REQUEST"=0 AND "READY"=0
2. "TRANSFER REQUEST"=1
3. "READY"=1 AND "ERROR"=0
4. "READY"=1 AND "ERROR"=1

5.2.6.3 DO.CRC

THIS ROUTINE IS USED TO CALCULATE "CRC". IT WORKS ON ONE BYTE AT A TIME WHICH MUST BE IN R0 WHEN CALLED.

5.2.6.4 A2OCT

THIS ROUTINE CHANGES AN ASCII STRING TO AN OCTAL NUMBER.

5.2.6.5 GETDRV

THIS ROUTINE IS USED TO ASK THE OPERATOR WHICH DRIVE(S)
ARE TO BE TESTED

5.2.6.6 ASKADR

THIS ROUTINE IS USED TO INPUT THE ADDRESSES FOR THE "TACS",
"TADB" AND THE VECTOR AND THE PRIORITY LEVEL TO USE.

5.2.6.7 TYPERR

THIS ROUTINE IS USED TO TYPE OUT THE "ERROR" DATA

5.2.6.8 EXAM

THIS ROUTINE IS USED TO DETERMINE WHICH DRIVE(S) ARE AVAILABLE
FOR TESTING.

5.2.7 THE FOLLOW ROUTINES ARE USED TO MAKE ADJUSTMENTS TO
THE TU60. BEFORE USING ANY OF THEM LOAD AND START 214.

5.2.7.1 WFGSUB

WRITE FILE GAPS FROM "BOT" TO "EOT"
START AT 220
THIS ROUTINE CAN BE USED TO ADJUST THE "WRITE GAP MONO" AND
THE "WRITE DELAY MONO".

5.2.7.2 WRTSUB

WRITE CONTINUOUS BLOCKS OF DATA
START AT 224
THE PROGRAM WILL HALT THREE(3) TIMES
AFTER EACH HALT SET THE SWR AND PRESS CONTINUE
HALT 1 --- SWR<7:0> = NUMBER OF BYTES PER BLOCK
HALT 2 ---SWR<7:0> = PATTERN DESIRED
HALT 3 --- SWR<15:0> = OPERATIONAL SWITCH SETTINGS
THIS ROUTINE CAN BE USED TO ADJUST THE "GAP TIME MONO"
** IF USING SOFTWARE SWITCH REGISTER, AFTER
EACH HALT OPERATOR WILL BE PROMPTED
FOR THE VALUE WITH "SWR=XXXXXX NEW="

5.2.7.3 RDSUB

READ CONTINUOUS BLOCKS OF DATA
START AT 230
THIS ROUTINE CAN BE USED TO ADJUST THE "SIGNAL MONO"
AND THE "THRESHOLD POT"

5.2.7.4 WGPBLK

WRITE A FILE GAP AND A BLOCK OF DATA FROM BOT TO EOT
START AT 234
THE PROGRAM WILL HALT THREE (3) TIMES
AFTER EACH HALT SET THE SWR AND PRESS CONTINUE
HALT 1 --- SWR<7:0> = NUMBER OF BYTES PER BLOCK
HALT 2 --- SWR<7:0> = PATTERN DESIRED
HALT 3 --- SWR<15:0> = OPERATIONAL SWITCH SETTINGS
THIS ROUTINE CAN BE USED TO ADJUST THE "WRITE GAP MONO"
AND THE "GAP TIME MONO".

** IF USING SOFTWARE SWITCH REGISTER, AFTER
EACH HALT OPERATOR WILL BE PROMPTED
FOR THE VALUE WITH "SWR=XXXXXX NEW="

5.2.7.5 RGBLK

READ A BLOCK OF DATA AND A FILE GAP
START AT 240
THIS ROUTINE IS USED AFTER "WRITE A BLOCK AND A FILE GAP" ROUTINE
IT CAN BE USED TO ADJUST THE "SIGNAL MONO". THE THRESHOLD POT"
AND THE "TAPE BLANK MONO".

5.2.7.6 SFFGSB

SPACE FORWARD FILE GAP FROM "BOT" TO "EOT"
START AT 244
THIS ROUTINE CAN BE USED AFTER "WRITE FILE GAP" FOR LOW SPEED
SPACE FORWARD (TAPE BLANK MONO CAN BE ADJUSTED). OR AFTER READ OR
WRITE A FILE GAP AND A BLOCK OF DATA FOR HIGH SPEED SPACE FORWARD
(SIGNAL MONO CAN BE CHECKED).

5.2.7.7 BSFGSB

BACK SPACE FILE GAP
START AT 250
THIS ROUTINE CAN BE USED TO ADJUST OR CHECK THE "SIGNAL MONO".

6. ERRORS

THERE ARE A NUMBER OF ERRORS THAT CAN OCCUR IN THIS PROGRAM. WHEN AN ERROR IS ENCOUNTERED THE CALL TO THE ERROR (ERROR) ROUTINE IS MADE AND IF SW<13> IS NOT SET AN ERROR MESSAGE PERTAINING TO THE ERROR WILL BE TYPED. EACH ERROR TYPE OUT WILL CONTAIN THE FOLLOWING:

1. THE FUNCTION BEING PERFORM
2. AN ERROR MESSAGE
3. A DATA HEADER
4. A DATA STRING

REFER TO THE LISTING UNDER \$ERRTB FOR THE DIFFERENT ERRORS THAT CAN OCCUR.

7. RESTRICTIONS

BEFORE STARTING THE PROGRAM THE OPERATOR MUST INSURE THAT A CASSETTE IS LOADED IN THE DRIVE(S) TO BE TESTED AND IS WRITE ENABLED.

8. MISCELLANEOUS

8.1 EXECUTION TIME

THE FIRST PASS TAKES APPROXIMATELY 4 MINUTES ALL SUBSEQUENT PASSES TAKE APPROXIMATELY 8 MINUTES

8.2 STACK POINTER

STACK IS INITIALLY SET TO 1100.

8.3 PASS COUNT

A PROGRAM PASS THRU COUNT IS KEPT IN "\$PASS".

8.4 ITERATIONS

THE FIRST PASS OF THE PROGRAM WILL AUTOMATICALLY INHIBIT ITERATIONS. ALL SUBSEQUENT PASSES WILL PERFORM FULL, (ONE PER DRIVE), ITERATIONS.

8.5 SPECIAL REGISTERS

R4 AND R5 ARE RESERVED FOR "TACS" AND "TADB" THROUGH OUT THE PROGRAM.

9. PROGRAM DESCRIPTION

THIS PROGRAM IS A SEQUENCE OF INDEPENDENT TESTS THAT CHECK THE TA11 FOR PROPER OPERATION.

EACH TESTS IS A SERIES OF "TRAP" CALLS TO ROUTINES THAT PERFORM THE DESIRED FUNCTION.

THE PROGRAM STARTS WITH A SIMPLE SEQUENCE OF FUNCTIONS AND BUILTS IN COMPLEXITY INTRODUCING ONE NEW FUNCTION AT A TIME, UNTIL ALL LEGAL COMBINATIONS HAVE BEEN PERFORMED. THEN, MULTI SPACING IS PERFORMED TO TRY AND GENERATE NOISE THAT MIGHT CAUSE PROBLEMS DUE TO SPEED CHANGES AND FREQUENT START STOPPING.

```

582 .TITLE TA11 MOTION TEST CZTAD-D
583 ;*COPYRIGHT (C) 1973,1978
584 ;*DIGITAL EQUIPMENT CORP.
585 ;*MAYNARD, MASS. 01754
586 ;*
587 ;*PROGRAM BY JIM LACEY
588 ;*
589 ;*THIS PROGRAM WAS ASSEMBLED USING THE PDP-11 MAINDEC SYSMAC
590 ;*PACKAGE (MAINDEC-11-DZQAC-C3), JAN 19, 1977.
591 ;*
592 ;*****
593 ;*****
594 ;*****
595 .REM!
    
```

GENERAL INFORMATION ABOUT THE TA11/TU60 CASSETTE

ADDRESS MNEMONIC DESCRIPTION

ADDRESS	MNEMONIC	DESCRIPTION
777500	TACS	CONTROL AND STATUS REGISTER
777502	TADB	DATA BUFFER REGISTER
260	TAVEC	INTERRUPT VECTOR

TACS REGISTER DESCRIPTION

BIT	NAME	INIT STATE	READ AND/OR WRITE?
15	ERROR	?	READ ONLY
14	BLOCK CHECK ERROR	0	READ ONLY
13	CLEAR LEADER	?	READ ONLY
12	WRITE LOCK	?	READ ONLY
11	FILE GAP	0	READ ONLY
10	TIMING ERROR	0	READ ONLY

620	09	OFF LINE	?	READ ONLY
621	08	UNIT SELECT	0	READ/WRITE
622	07	TRANSFER REQUEST	0	READ ONLY
623	06	INTERRUPT ENABLE	0	READ/WRITE
624	05	READY	1	READ ONLY
625	04	ILBS	0	READ/WRITE
626	03	FUNCTION BIT 02	0	READ/WRITE
627	02	FUNCTION BIT 01	0	READ/WRITE
628	01	FUNCTION BIT 00	0	READ/WRITE
629		0=WRITE-FILE-GAP		
630		1=WRITE		
631		2=READ		
632		3=BACK SPACE FILE GAP		
633		4=BACK SPACE BLOCK GAP		
634		5=SPACE FORWARD FILE GAP		
635		6=SPACE FORWARD BLOCK GAP		
636		7=REWIND		
637	00	GO BIT	0	WRITE ONLY!

```

638 .SBTTL OPERATIONAL SWITCH SETTINGS
639 ;*
640 ;* SWITCH USE
641 ;* -----
642 ;* 15 HALT ON ERROR
643 ;* 14 LOOP ON TEST
644 ;* 13 INHIBIT ERROR TYPEOUTS
645 ;* 11 INHIBIT ITERATIONS
646 ;* 10 BELL ON ERROR
647 ;* 9 LOOP ON ERROR
648 ;* 7 LOCK ON CURRENT DRIVE
649 ;* 6 DELAY AT END OF EACH FUNCTION
650 ;* 5 RUN WITHOUT INTERRUPTS
651 ;* 4 IGNORE BLOCK CHECK ERRORS
652 ;* 3 INHIBIT DATA COMPARE
653
654
655
656 .SBTTL BASIC DEFINITIONS
657 ;*INITIAL ADDRESS OF THE STACK POINTER *** 1100 ***
658 STACK= 1100
659 001100
660 .EQUIV EMT,ERROR ;;BASIC DEFINITION OF ERROR CALL
661 .EQUIV IOT,SCOPE ;;BASIC DEFINITION OF SCOPE CALL
662
663 ;*MISCELLANEOUS DEFINITIONS
664 000011 HT= 11 ;;CODE FOR HORIZONTAL TAB
665 000012 LF= 12 ;;CODE FOR LINE FEED
666 000015 CR= 15 ;;CODE FOR CARRIAGE RETURN
667 000200 CRLF= 200 ;;CODE FOR CARRIAGE RETURN-LINE FEED
668 177776 PS= 177776 ;;PROCESSOR STATUS WORD
669 .EQUIV PS,PSW
670 177774 STKLMT= 177774 ;;STACK LIMIT REGISTER
671 177772 PIRQ= 177772 ;;PROGRAM INTERRUPT REQUEST REGISTER
672 177570 DSWR= 177570 ;;HARDWARE SWITCH REGISTER
673 177570 DDISP= 177570 ;;HARDWARE DISPLAY REGISTER
674
675 ;*GENERAL PURPOSE REGISTER DEFINITIONS
676 000000 R0= %0 ;;GENERAL REGISTER
677 000001 R1= %1 ;;GENERAL REGISTER
678 000002 R2= %2 ;;GENERAL REGISTER
679 000003 R3= %3 ;;GENERAL REGISTER
680 000004 R4= %4 ;;GENERAL REGISTER
681 000005 R5= %5 ;;GENERAL REGISTER
682 000006 R6= %6 ;;GENERAL REGISTER
683 000007 R7= %7 ;;GENERAL REGISTER
684 000006 SP= %6 ;;STACK POINTER
685 000007 PC= %7 ;;PROGRAM COUNTER
686
687 ;*PRIORITY LEVEL DEFINITIONS
688 000000 PR0= 0 ;;PRIORITY LEVEL 0
689 000040 PR1= 40 ;;PRIORITY LEVEL 1
690 000100 PR2= 100 ;;PRIORITY LEVEL 2
691 000140 PR3= 140 ;;PRIORITY LEVEL 3
692 000200 PR4= 200 ;;PRIORITY LEVEL 4
693 000240 PR5= 240 ;;PRIORITY LEVEL 5
  
```

```

694 000300 PR6= 300 ;;PRIORITY LEVEL 6
695 000340 PR7= 340 ;;PRIORITY LEVEL 7
696
697 ;*"SWITCH REGISTER" SWITCH DEFINITIONS
698 100000 SW15= 100000
699 040000 SW14= 40000
700 020000 SW13= 20000
701 010000 SW12= 10000
702 004000 SW11= 4000
703 002000 SW10= 2000
704 001000 SW09= 1000
705 000400 SW08= 400
706 000200 SW07= 200
707 000100 SW06= 100
708 000040 SW05= 40
709 000020 SW04= 20
710 000010 SW03= 10
711 000004 SW02= 4
712 000002 SW01= 2
713 000001 SW00= 1
714 .EQUIV SW09,SW9
715 .EQUIV SW08,SW8
716 .EQUIV SW07,SW7
717 .EQUIV SW06,SW6
718 .EQUIV SW05,SW5
719 .EQUIV SW04,SW4
720 .EQUIV SW03,SW3
721 .EQUIV SW02,SW2
722 .EQUIV SW01,SW1
723 .EQUIV SW00,SW0
724
725 ;*DATA BIT DEFINITIONS (BIT00 TO BIT15)
726 100000 BIT15= 100000
727 040000 BIT14= 40000
728 020000 BIT13= 20000
729 010000 BIT12= 10000
730 004000 BIT11= 4000
731 002000 BIT10= 2000
732 001000 BIT09= 1000
733 000400 BIT08= 400
734 000200 BIT07= 200
735 000100 BIT06= 100
736 000040 BIT05= 40
737 000020 BIT04= 20
738 000010 BIT03= 10
739 000004 BIT02= 4
740 000002 BIT01= 2
741 000001 BIT00= 1
742 .EQUIV BIT09,BIT9
743 .EQUIV BIT08,BIT8
744 .EQUIV BIT07,BIT7
745 .EQUIV BIT06,BIT6
746 .EQUIV BIT05,BIT5
747 .EQUIV BIT04,BIT4
748 .EQUIV BIT03,BIT3
749 .EQUIV BIT02,BIT2
  
```



```

750 .EQUIV BIT01,BIT1
751 .EQUIV BIT00,BIT0
752
753 ;*BASIC "CPU" TRAP VECTOR ADDRESSES
754 ERRVEC= 4 ;:TIME OUT AND OTHER ERRORS
755 RESVEC= 10 ;:RESERVED AND ILLEGAL INSTRUCTIONS
756 TBITVEC=14 ;:"T" BIT
757 TRTVEC= 14 ;:TRACE TRAP
758 BPTVEC= 14 ;:BREAKPOINT TRAP (BPT)
759 IOTVEC= 20 ;:INPUT/OUTPUT TRAP (IOT) **SCOPE**
760 PWRVEC= 24 ;:POWER FAIL
761 EMTVEC= 30 ;:EMULATOR TRAP (EMT) **ERROR**
762 TRAPVEC=34 ;:"TRAP" TRAP
763 TKVEC= 60 ;:TTY KEYBOARD VECTOR
764 TPVEC= 64 ;:TTY PRINTER VECTOR
765 PIRQVEC=240 ;:PROGRAM INTERRUPT REQUEST VECTOR
766 ;:*****
767
768 ;#####TA11 FUNCTIONS#####
769 XWFG= 0 ;WRITE FILE GAP FUNCTION
770 XWRITE= 2 ;WRITE FUNCTION
771 XREAD= 4 ;READ FUNCTION
772 XBSFG= 6 ;BACK SPACE FILE GAP FUNCTION
773 XBSBG= 10 ;BACK SPACE BLOCK GAP FUNCTION
774 XSFFG= 12 ;SPACE FWD FILE GAP FUNCTION
775 XSFBG= 14 ;SPACE FWD BLOCK GAP FUNCTION
776 XRWND= 16 ;REWIND FUNCTION
777
778 ;#####TA11 BIT ASSIGNMENT#####
779 ERROR= BIT15
780 CRCERR= BIT14
781 LEADER= BIT13
782 WRTLOCK=BIT12
783 FGAP= BIT11
784 TIMERR= BIT10
785 OFFLINE=BIT09
786 UNIT= BIT08
787 TR.REQ= BIT07
788 INT.EN= BIT06
789 READY= BIT05
790 ILBS= BIT04
791 FUNC2= BIT03
792 FUNC1= BIT02
793 FUNC0= BIT01
794 GO= BIT00
795 FUNCTION= FUNC2+FUNC1+FUNC0
796
797 ;////////////////////////////////////
798 ;////////////////////////////////////
799 ;SPECIAL REGISTERS
800
801 TACS= %4 ;R4 IS USED AS A POINTER TO THE TACS REGISTER
802 TADB= %5 ;R5 IS USED AS A POINTER TO THE TADB REGISTER.
803 ;////////////////////////////////////
    
```

```

804 .SBTTL TRAP CATCHER
805
806 .=0
807 ;*ALL UNUSED LOCATIONS FROM 4 - 776 CONTAIN A ".+2,HALT"
808 ;*SEQUENCE TO CATCH ILLEGAL TRAPS AND INTERRUPTS
809 ;*LOCATION 0 CONTAINS 0 TO CATCH IMPROPERLY LOADED VECTORS
810 .=174
811 DISPREG: .WORD 0 ;:SOFTWARE DISPLAY REGISTER
812 SWREG: .WORD 0 ;:SOFTWARE SWITCH REGISTER
813
814 .SBTTL STARTING ADDRESS(ES)
815 JMP @#BEGIN1 ;:JUMP TO STARTING ADDRESS OF PROGRAM
816 JMP @#BEGIN2 ;:SELECT DRIVE(S) BEFORE STARTING TEST
817 JMP @#BEGIN3 ;:SELECT DRIVE(S) AND ADDRESSES BEFORE TESTING
818 JMP @#BEGINX ;:SETUP FOR MANUAL LOOPING
819 JMP @#WFGSUB ;:WRITE FILE GAP FROM BOT TO EOT
820 JMP @#WFSUB ;:WRITE CONTINUOUS BLOCKS OF DATA
821 JMP @#RDSUB ;:READ CONTINUOUS BLOCKS OF DATA
822 JMP @#WGPBLK ;:WRITE FILE GAP AND A BLOCK OF DATA
823 JMP @#RGPBLK ;:READ BLOCK OF DATA AND INTO A FILE GAP
824 JMP @#SFFGSB ;:SPACE FWD FILE GAP FROM BOT TO EOT
825 JMP @#BSFGSB ;:BACK SPACE FILE GAPS
826 ;:*****
    
```

```

827 .SBTTL COMMON TAGS
828
829 ;;*****
830 ;*THIS TABLE CONTAINS VARIOUS COMMON STORAGE LOCATIONS
831 ;*USED IN THE PROGRAM.
832
833 .=1100
834 001100 001100 $CMTAG: .WORD 0 ;;START OF COMMON TAGS
835 001100 000000 $PASS: .WORD 0 ;;CONTAINS PASS COUNT
836 001102 000 $STNM: .BYTE 0 ;;CONTAINS THE TEST NUMBER
837 001103 000 $ERFLG: .BYTE 0 ;;CONTAINS ERROR FLAG
838 001104 000000 $ICNT: .WORD 0 ;;CONTAINS SUBTEST ITERATION COUNT
839 001106 000000 $LPADR: .WORD 0 ;;CONTAINS SCOPE LOOP ADDRESS
840 001110 000000 $LPERR: .WORD 0 ;;CONTAINS SCOPE RETURN FOR ERRORS
841 001112 000000 $ERTTL: .WORD 0 ;;CONTAINS TOTAL ERRORS DETECTED
842 001114 000 $ITEMB: .BYTE 0 ;;CONTAINS ITEM CONTROL BYTE
843 001115 001 $ERMAX: .BYTE 1 ;;CONTAINS MAX. ERRORS PER TEST
844 001116 000000 $ERRPC: .WORD 0 ;;CONTAINS PC OF LAST ERROR INSTRUCTION
845 001120 000000 $GDADR: .WORD 0 ;;CONTAINS ADDRESS OF 'GOOD' DATA
846 001122 000000 $BDADR: .WORD 0 ;;CONTAINS ADDRESS OF 'BAD' DATA
847 001124 000000 $GDDAT: .WORD 0 ;;CONTAINS 'GOOD' DATA
848 001126 000000 $BDDAT: .WORD 0 ;;CONTAINS 'BAD' DATA
849 001130 000000 .WORD 0 ;;RESERVED--NOT TO BE USED
850 001132 000000 .WORD 0
851 001134 000 $AUTDB: .BYTE 0 ;;AUTOMATIC MODE INDICATOR
852 001135 000 $INTAG: .BYTE 0 ;;INTERRUPT MODE INDICATOR
853 001136 000000 .WORD 0
854 001140 177570 $SWR: .WORD DSWR ;;ADDRESS OF SWITCH REGISTER
855 001142 177570 $DISP: .WORD DDISP ;;ADDRESS OF DISPLAY REGISTER
856 001144 177560 $TKS: 177560 ;;TTY KBD STATUS
857 001146 177562 $TKB: 177562 ;;TTY KBD BUFFER
858 001150 177564 $TPS: 177564 ;;TTY PRINTER STATUS REG. ADDRESS
859 001152 177566 $TPB: 177566 ;;TTY PRINTER BUFFER REG. ADDRESS
860 001154 000 $NULL: .BYTE 0 ;;CONTAINS NULL CHARACTER FOR FILLS
861 001155 002 $FILLS: .BYTE 2 ;;CONTAINS # OF FILLER CHARACTERS REQUIRED
862 001156 012 $FILLC: .BYTE 12 ;;INSERT FILL CHARS. AFTER A "LINE FEED"
863 001157 000 $TPFLG: .BYTE 0 ;;"TERMINAL AVAILABLE" FLAG (BIT<07>=0=YES)
864 001160 000000 $REGAD: .WORD 0 ;;CONTAINS THE ADDRESS FROM
865 ;;WHICH ($REGO) WAS OBTAINED
866 001162 000000 $REGO: .WORD 0 ;;CONTAINS (($REGAD)+0)
867 001164 000000 $REGI: .WORD 0 ;;CONTAINS (($REGAD)+2)
868 001166 000000 $TMPO: .WORD 0 ;;USER DEFINED
869 001170 000000 $TIMES: 0 ;;MAX. NUMBER OF ITERATIONS
870 001172 000000 $ESCAPE: 0 ;;ESCAPE ON ERROR ADDRESS
871 001174 177607 000377 $BELL: .ASCIZ <207><377><377> ;;CODE FOR BELL
872 001200 077 $QUES: .ASCIZ /? ;;QUESTION MARK
873 001201 015 $CRLF: .ASCIZ <15> ;;CARRIAGE RETURN
874 001202 000012 $LF: .ASCIZ <12> ;;LINE FEED
875 ;;*****
876 001204 000000 $AVPC: .WORD 0 ;;STORAGE FOR THE PC
877 001206 000000 $BYNUM: .WORD 0 ;;THE NUMBER OF BYTES "READ" OR "WRITTEN"
878 001210 000000 $RCRC: .WORD 0 ;;CRC CALCULATED FOR "WRITE"
879 001212 000000 $RCRC1: .WORD 0 ;;CRC CALCULATED FOR "READ"
880 001214 000000 $RCRC2: .WORD 0 ;;CRC FROM THE TA11 FOR "READ"
881
882 001216 000001 $MXCNT: 1 ;;MAX. NUMBER OF ITERATIONS
    
```

```

883 001220 177500 TACSL: 177500 ;;LOW BYTE ADDRESS OF TACS
884 001222 177501 TACSH: 177501 ;;HIGH BYTE ADDRESS OF TACS
885 001224 177502 TADBL: 177502 ;;LOW BYTE ADDRESS OF TADB
886 001226 177503 TADBH: 177503 ;;HIGH BYTE ADDRESS OF TADB
887 001230 000262 000262 TAVEC: 260,262 ;;TA11 VECTOR ADDRESS
888 001234 000300 TAPRID: 300 ;;TA11 BR LEVEL 6
889 001236 000000 DRIVE: 0 ;;NEXT DRIVE TO TEST
890 001240 000000 000000 $DRVKEY: 0,0 ;;DRIVE SELECT KEY:
891 001244 001240 $DRVPT: DRVKEY
892 001246 000000 $ASKKEY: 0
893 001250 177777 000000 $CURDRV: -1,0 ;;CURRENT DRIVE BEING TESTED
894 001254 000000 $WAITKEY: 0 ;;WAIT ON INTERRUPT KEY
895 001256 001260 $RWDFLG: RWDA 0 ;;REWIND FLAG POINTER
896 001260 000000 $RWDA: 0 ;;DRIVE "A" REWIND FLAG
897 001262 000000 $RWDB: 0 ;;DRIVE "B" REWIND FLAG
898 001264 000000 000000 $STALL: 0,0 ;;STALL TIME
    
```

```

899 .SBTTL ERROR POINTER TABLE
900
901 ;*THIS TABLE CONTAINS THE INFORMATION FOR EACH ERROR THAT CAN OCCUR.
902 ;*THE INFORMATION IS OBTAINED BY USING THE INDEX NUMBER FOUND IN
903 ;*LOCATION $ITEMB. THIS NUMBER INDICATES WHICH ITEM IN THE TABLE IS PERTINENT.
904 ;*NOTE1: IF $ITEMB IS 0 THE ONLY PERTINENT DATA IS ($ERRPC).
905 ;*NOTE2: EACH ITEM IN THE TABLE CONTAINS 4 POINTERS EXPLAINED AS FOLLOWS:
906
907 ;* EM ;;POINTS TO THE ERROR MESSAGE
908 ;* DH ;;POINTS TO THE DATA HEADER
909 ;* DT ;;POINTS TO THE DATA
910 ;* DF ;;POINTS TO THE DATA FORMAT
911
912
913 001270
914 $ERRTB:
915 ;NOTE: ALL NUMBERS WILL BE TYPED AS 6 DIGIT OCTAL NUMBERS
916
917 ;ITEM 1
918 EM1 ;IMPROPER FLAG SETTING
919 DH1 ;TEST ERROR
920 ;PC PC TACS TADB
921 ;SAVPC $ERRPC $REGO $REG1
922 0
923
924 ;ITEM 2
925 EM2 ;IMPROPER FLAG OCCURRED
926 DH1 ;TEST ERROR
927 ;PC PC TACS TADB
928 ;SAVPC $ERRPC $REGO $REG1
929 0
930
931 ;ITEM 3
932 EM3 ;MISSED A FLAG
933 DH1 ;TEST ERROR
934 ;PC PC TACS TADB
935 ;SAVPC $ERRPC $REGO $REG1
936 0
937
938 ;ITEM 4
939 EM4 ;INTERRUPT FAILED
940 DH1 ;TEST ERROR
941 ;PC PC TACS TADB
942 ;SAVPC $ERRPC $REGO $REG1
943 0
944
945 ;ITEM 5
946 EM5 ;PREMATURE READY OCCURRED
947 DH1 ;TEST ERROR
948 ;PC PC TACS TADB
949 ;SAVPC $ERRPC $REGO $REG1
950 0
951
952 ;ITEM 6
953 EM6 ;DIDN'T STOP IN A FILE GAP
954 DH1 ;TEST ERROR
955 ;PC PC TACS TADB
    
```

```

955 001344 015044 DT1 ;SAVPC $ERRPC $REGO $REG1
956 001346 000000 0
957
958 ;ITEM 7
959 EM7 ;DIDN'T STOP ON CLEAR LEADER
960 001352 016102 DH1 ;TEST ERROR
961 ;PC PC TACS TADB
962 001354 015044 DT1 ;SAVPC $ERRPC $REGO $REG1
963 001356 000000 0
964
965 ;ITEM 10
966 EM10 ;BAD DATA READ
967 001362 016162 DH2 ;TEST ERROR
968 ;PC PC TACS EXPT'D RCV'D BYTE
969 001364 015056 DT2 ;SAVPC $ERRPC $REGO $GDDAT $BDDAT NUMBER
970 001366 000000 0 BYTNUM
971
972 ;ITEM 11
973 001370 016011 EM11 ;ILLEGAL BUFFER
974 001372 016601 DH5 ;TEST ERROR
975 ;PC PC TACS
976 001374 015126 DT5 ;SAVPC $ERRPC $REGO
977 001376 000000 0
978
979 ;ITEM 12
980 EM12 ;CRC ERROR
981 001402 016323 DH3 ;TEST ERROR
982 ;PC PC TACS WRITE READ TU60
983 001404 015074 DT3 ;SAVPC $ERRPC $REGO CRC CRC CRC
984 001406 000000 0 RCRC0 RCRC1 RCRC2
985
986 ;ITEM 13
987 001410 016047 EM13 ;SHORT RECORD
988 001412 016461 DH4 ;TEST ERROR
989 ;PC PC TACS TADB BYTES
990 001414 015112 DT4 ;SAVPC $ERRPC $REGO $REG1 LEFT
991 001416 000000 0 $TMP0
992
993 ;ITEM 14
994 001420 016064 EM14 ;BAD INTERRUPT
995 001422 016601 DH5 ;TEST ERROR
996 ;PC PC TACS
997 001424 015126 DT5 ;SAVPC $ERRPC $REGO
998 001426 000000 0
999
1000 001430 ITEMS2: ;ITEMS 201-202
1001
1002 001430 016664 EM201 ;TA11 FAILED TO RESPOND
1003 001432 016736 DH201 ;PC TACS
1004 001434 016652 DT201 ;$ERRPC TACS
1005 001436 000000 0 ;BOTH NUMBERS ARE TYPED AS OCTAL NUMBERS
1006
1007 001440 016713 EM202 ;NO DRIVES AVAILABLE
1008 001442 016753 DH202 ;PC
1009 001444 016660 DT202 ;$ERRPC
1010 001446 000000 0
    
```

```

1011 ////////////////////////////////////////////////////
1012 ////////////////////////////////////////////////////
1013 ////////////////////////////////////////////////////
1014 ////////////////////////////////////////////////////
1015 ;BEGIN1 IS FOR NORMAL START
1016 ;BEGIN2 IS FOR DRIVE SELECTION
1017 ;BEGIN3 IS FOR DRIVE & ADDRESS SELECTION
1018 ;BEGIN4 IS FOR MANUAL OPERATION
1019
1020 ;*****
1021
1022 001450 005005          BEGIN1: CLR      R5          ;NORMAL START
1023 001452 012737 041101 001240      MOV     #*AB,@#DRVKEY
1024 001460 122737 000005 000041      CMPB   #5,@#41          ;CASSETTE ODP?
1025 001466 001015          BNE    BGNCMN          ;GO BEGIN COMMON CODE IF NO
1026 001470 022737 000260 001230      CMP     #260,@#TAVEC    ;STANDARD VECTOR?
1027 001476 001011          BNE    BGNCMN          ;GO BEGIN COMMON CODE IF NO
1028 001500 000403          BR     BEGIN3          ;GET DRIVES AND ADDRESSES
1029 001502 012705 000001          MOV     #1,R5          ;ASK FOR DRIVES FLAG
1030 001506 000405          BR     BGNCMN          ;BEGIN COMMON CODE
1031 001510 012705 000002          MOV     #2,R5          ;ASK FOR DRIVES AND ADDRESSES
1032 001514 000402          BR     BGNCMN
1033 001516 012705 000003          BEGIN4: MOV    #3,R5
1034 001522          BGNCMN:
1035 .SBTTL INITIALIZE THE COMMON TAGS
1036 ;:CLEAR THE COMMON TAGS ($CMTAG) AREA
1037 001522 012706 001100      MOV     #CMTAG,R6      ;:FIRST LOCATION TO BE CLEARED
1038 001526 005026          CLR     (R6)+          ;:CLEAR MEMORY LOCATION
1039 001530 022706 001140      CMP     #SWR,R6 ;:DONE?
1040 001534 001374          BNE    -,B            ;:LOOP BACK IF NO
1041 001536 012706 001100      MOV     #STACK,SP     ;:SETUP THE STACK POINTER
1042 ;:INITIALIZE A FEW VECTORS
1043 001542 012737 006570 000020      MOV     #SCOPE,@#IGTVEC ;:IOT VECTOR FOR SCOPE ROUTINE
1044 001550 012737 000340 000022      MOV     #340,@#IOTVEC+2 ;:LEVEL 7
1045 001556 012737 007046 000030      MOV     #ERROR,@#EMTVEC ;:EMT VECTOR FOR ERROR ROUTINE
1046 001564 012737 000340 000032      MOV     #340,@#EMTVEC+2 ;:LEVEL 7
1047 001572 012737 014554 000034      MOV     #STRAP,@#TRAPVEC ;:TRAP VECTOR FOR TRAP CALLS
1048 001600 012737 000340 000036      MOV     #340,@#TRAPVEC+2 ;:LEVEL 7
1049 001606 012737 014662 000024      MOV     #PWRDN,@#PWRVEC ;:POWER FAILURE VECTOR
1050 001614 012737 000340 000026      MOV     #340,@#PWRVEC+2 ;:LEVEL 7
1051 001622 013737 006406 006400      MOV     #ENDCT,@#EOPT  ;:SETUP END-OF-PROGRAM COUNTER
1052 001630 005037 001170      CLR     #TIMES        ;:INITIALIZE NUMBER OF ITERATIONS
1053 001634 005037 001172      CLR     #ESCAPE       ;:CLEAR THE ESCAPE ON ERROR ADDRESS
1054 001640 112737 000001 001115      MOVB   #1,#ERMAX      ;:ALLOW ONE ERROR PER TEST
1055 001646 012737 001646 001106      MOV     #.,$LPADR     ;:INITIALIZE THE LOOP ADDRESS FOR SCOPE
1056 001654 012737 001654 001110      MOV     #.,$LPERR     ;:SETUP THE ERROR LOOP ADDRESS
1057 ;:SIZE FOR A HARDWARE SWITCH REGISTER IF NOT FOUND OR IT IS
1058 ;:EQUAL TO A "-1", SETUP FOR A SOFTWARE SWITCH REGISTER.
1059 001662 013746 000004          MOV     @#ERRVEC,-(SP) ;:SAVE ERROR VECTOR
1060 001666 012737 001722 000004          MOV     #64$,@#ERRVEC ;:SET UP ERROR VECTOR
1061 001674 012737 177570 001140          MOV     #DSWR,SWR     ;:SETUP FOR A HARDWARE SWICH REGISTER
1062 001702 012737 177570 001142          MOV     #DDISP,DISPLAY ;:AND A HARDWARE DISPLAY REGISTER
1063 001710 022777 177777 177222          CMP     #-1,@SWR     ;:TRY TO REFERENCE HARDWARE SWR
1064 001716 001012          BNE    66$          ;:BRANCH IF NO TIMEOUT TRAP OCCURRED
1065 001720 000403          BR     65$          ;:AND THE HARDWARE SWR IS NOT = -1
1066 ;:BRANCH IF NO TIMEOUT

```

```

1067 001722 012716 001730      64$: MOV     #65$,(SP) ;:SET UP FOR TRAP RETURN
1068 001726 000002          RTI
1069 001730 012737 000176 001140      65$: MOV     #SWREG,SWR ;:POINT TO SOFTWARE SWR
1070 001736 012737 000174 001142      MOV     #DISPREG,DISPLAY
1071 001744 012637 000004      66$: MOV     (SP)+,@#ERRVEC ;:RESTORE ERROR VECTOR
1072
1073 .SBTTL TYPE PROGRAM NAME
1074 ;:TYPE THE NAME OF THE PROGRAM IF FIRST PASS
1075 001750 005227 177777          INC     #-1          ;:FIRST TIME?
1076 001754 001030          BNE    HERE          ;:BRANCH IF NO
1077 001756 022737 006432 000042          CMP     #SENDAD,@#42 ;:ACT-11?
1078 001764 001424          BEQ    HERE          ;:BRANCH IF YES
1079 001766 104401 002024          TYPE   ,MSGID        ;:TYPE ASCIZ STRING
1080 .SBTTL GET VALUE FOR SOFTWARE SWITCH REGISTER
1081 001772 005737 000042          TST    @#42          ;:ARE WE RUNNING UNDER XXDP/ACT?
1082 001776 001006          BNE    67$          ;:BRANCH IF YES
1083 002000 023727 001140 000176          CMP     SWR,#SWREG   ;:SOFTWARE SWITCH REG SELECTED?
1084 002006 001005          BNE    68$          ;:BRANCH IF NO
1085 002010 104405          GTSWR ;:GET SOFT-SWR SETTINGS
1086 002012 000403          BR     68$
1087 002014 112737 000001 001134      67$: MOVB   #1,$AUTOB  ;:SET AUTO-MODE INDICATOR
1088 002022          68$:
1089 002022 000405          BR     HERE          ;:GET OVER THE ASCIZ
1090 ;:MSGID: .ASCIZ <CRLF>/CZTAD-D/<CRLF>
1091 002036          HERE:

```

```
1092 ;*****  
1093 ;*****  
1094 ;  
1095 ;THE CONTENTS OF R5 DETERMINES WHAT WILL BE DONE  
1096 ;  
1097 ; R5=3 MANUAL OPERATIONS  
1098 ; R5=2 ASK FOR DRIVE(S) AND ADDRESSES (TACS AND VECTOR)  
1099 ; R5=1 ASK FOR DRIVE(S)  
1100 ; R5=0 DON'T ASK FOR ANYTHING  
1101 ;  
1102 ;*****  
1103 002036 010504 BEGINX: MOV R5,R4 ;COPY R5  
1104 002040 005305 DEC R5 ;ASK FOR DRIVES?  
1105 002042 002406 BLT CHKADR ;BR IF NO  
1106 002044 004737 007422 JSR PC,@#ASKDRV ;GO GET DRIVES TO BE TESTED  
1107 002050 005305 DEC R5 ;ASK FOR ADDRESSES?  
1108 002052 002402 BLT CHKADR ;BR IF NO  
1109 002054 004737 007532 JSR PC,@#ASKADR ;GO GET TA11 ADDRESSES  
1110 ;*****  
1111 ;*****  
1112 ;  
1113 ;CHECK THAT "TACS" WILL RESPOND TO ADDRESSING  
1114 ;  
1115 ;I. TIMEOUT OCCURRED  
1116 ; A. TYPE ERROR MESSAGE  
1117 ; B. EXAMINE R4  
1118 ; 1. R4>0 GOTO BEGINX  
1119 ; 2. R4=0 EXAMINE (42)  
1120 ; A. (42)=0 GOTO BEGINX  
1121 ; B. (42)>0 GOTO SENDAD  
1122 ;  
1123 ;II. TIMEOUT DIDN'T OCCUR  
1124 ; A. CONTINUE  
1125 ;  
1126 ;*****  
1127 002060 012737 002076 000004 CHKADR: MOV #1$,@#ERRVEC ;IN CASE OF TIMEOUTS  
1128 002066 005000 CLR R0 ;USE AS A SWITCH  
1129 002070 005777 177124 TST @TACSL ;SEE IF TA11 RESPONDS  
1130 002074 000402 BR 2$ ;BR IF NO TIMEOUT  
1131 002076 005200 1$: INC R0 ;COME HERE ON TIMEOUT  
1132 002100 022626 CMP (SP)+,(SP)+ ;CLEANUP THE STACK  
1133 002102 012737 000006 000004 2$: MOV #ERRVEC+2,@#ERRVEC ;RESTORE TIMEOUT VECTOR  
1134 002110 005700 TST R0 ;DID A TIMEOUT OCCUR?  
1135 002112 001412 BEQ 3$ ;BR IF NO  
1136 002114 104201 ERROR 201 ;TA11 FAILED TO RESPOND  
1137 002116 012705 000002 MOV #2,R5 ;DRIVES & ADDRESSES  
1138 002122 005704 TST R4 ;OPERATOR INPUTS?  
1139 002124 001344 BNE BEGINX ;BR IF YES  
1140 002126 013700 000042 MOV @#42,R0 ;GET MONITOR RETURN ADDRESS  
1141 002132 001741 BEQ BEGINX ;BR IF NO MONITOR  
1142 002134 000137 006432 JMP @#SENDAD ;GO TO END  
1143 002140 3$:
```

```
1144 ;*****  
1145 ;*****  
1146 ;  
1147 ;MAKE SURE THE DRIVES IN THE DRIVE TABLE CAN BE TESTED  
1148 ;  
1149 ;I. DESIRED DRIVES CAN NOT BE TESTED  
1150 ; A. TYPE ERROR MESSAGE  
1151 ; B. EXAMINE R4  
1152 ; 1. R4>0 GOTO BEGINX  
1153 ; 2. R4=0 EXAMINE (42)  
1154 ; A. (42)=0 GOTO BEGINX  
1155 ; B. (42)>0 GOTO SENDAD  
1156 ;  
1157 ;II. BOTH DRIVES IN THE TABLE BUT ONLY ONE OF THEM CAN BE TESTED  
1158 ; A. CLEAR BAD DRIVE FROM THE DRIVE TABLE  
1159 ; B. CONTINUE IN PROGRAM  
1160 ;  
1161 ;III. DESIRED DRIVE(S) CAN BE TESTED  
1162 ; A. CONTINUE IN PROGRAM  
1163 ;  
1164 ;*****  
1165 002140 012700 001240 CHKDRV: MOV #DRVKEY,R0 ;PICKUP ADDRESS OF ASCII DRIVE KEY  
1166 002144 004737 006464 JSR PC,@#EXAM ;GO EXAMINE FIRST DRIVE  
1167 002150 000410 BR 1$ ;OK TO TEST---GO CHECK NEXT  
1168 002152 116010 000001 MOV 1(R0),(R0) ;REPLACE 1ST WITH 2ND  
1169 002156 001412 BEQ 2$ ;BR IF NO 2ND DRIVE SELECTED  
1170 002160 004737 006464 JSR PC,@#EXAM ;GO EXAMINE DRIVE  
1171 002164 000407 BR 2$ ;OK TO TEST  
1172 002166 005010 CLR (R0) ;CLEAR DRIVE CODES  
1173 002170 000405 BR 2$  
1174 002172 005200 1$: INC R0 ;POINT TO 2ND  
1175 002174 004737 006464 JSR PC,@#EXAM ;GO EXAMINE DRIVE  
1176 002200 000401 BR 2$ ;OK TO TEST  
1177 002202 105010 CLR 2(R0) ;CLEAR 2ND  
1178 002204 012700 001240 2$: MOV #DRVKEY,R0 ;RESET ADDRESS POINTERS  
1179 002210 010037 001244 MOV R0,@#DRVPT  
1180 002214 121060 000001 CMPB (R0),1(R0) ;1ST = 2ND?  
1181 002220 001002 BNE 3$ ;BR IF NO  
1182 002222 105060 000001 CLR 1(R0) ;YES---CLEAR 2ND  
1183 002226 005710 3$: TST (R0) ;ANY DRIVES?  
1184 002230 001401 BEQ 5$ ;BR IF NO  
1185 002232 000412 BR MANUAL  
1186 002234 104202 5$: ERROR 202 ;NO DRIVES AVAILABLE  
1187 002236 012705 000002 MOV #2,R5 ;DRIVES & ADDRESS  
1188 002242 005704 TST R4 ;OPERATOR INPUTS?  
1189 002244 001274 BNE BEGINX ;BR IF YES  
1190 002246 013700 000042 MOV @#42,R0 ;GET MONITOR RETURN ADDRESS  
1191 002252 001671 BEQ BEGINX ;NO MONITOR  
1192 002254 000137 006432 JMP @#SENDAD ;GO TO END  
1193 002260 020427 000003 MANUAL: CMP R4,#3  
1194 002264 001002 BNE OK  
1195 002266 013704 177777 MOV -1,R4  
1196 002272 010437 001246 OK: MOV R4,@#ASKKEY  
1197 002276 000405 BR START  
1198 002300 104401 002024 PWRST: TYPE #MSGID ;POWER FAIL RESTART  
1199 002304 012737 001240 001244 MOV #DRVKEY,@#DRVPT
```

```

1200 002312 012777 012356 176710 START: MOV #BADINT,@TAVEC ;SETUP TA11 TRAP VECTOR
1201 002320 013777 001234 176704 MOV @#TAPRID,@TAVEC+2 ;LOCKOUT ALL I/O INT
1202 002325 012737 000340 177776 MOV #340,@#PS ;LOCKOUT ALL I/O INT
1203 002334 013704 001220 MOV @#TACSL,TACS ;SETUP TACS
1204 002340 013705 001224 MOV @#TADBL,TADB ;SETUP TADB
1205 002344 005037 001102 CLR @#STSTNM ;ZERO THE TEST NUMBER
1206 002350 005037 006614 CLR @#LOOPKEY ;CLEAR THE LOOP UNDER TTY CONTROL KEY
1207 002354 012737 000001 001216 MOV #1,@#SMXCNT ;SET FOR ONE ITERATION PER TEST
1208 002362 013701 001244 MOV @#DRVPNT,R1 ;GET DRIVE POINTER
1209 002366 010137 001236 MOV R1,DRIVE ;SET DRIVE TO POINTER
1210 ;////////////////////////////////////
1211 ;TYPE THE DRIVE(S) THAT WILL BE TESTED
1212 002372 111137 001250 MOV (R1),@#CURDRV ;GET CURRENT DRIVE FOR TYPE-OUT
1213 002376 104401 015261 TYPE ,MSTDRV ;TYPE "TESTING DRIVE"
1214 002402 104401 001250 TYPE ,CURDRV ;TYPE THE CURRENT DRIVE
1215 002406 032777 000200 176524 BIT #SW07,@SWR ;LOCK ON ONE DRIVE?
1216 002414 001021 BNE 2$ ;BR IF YES
1217 002416 105737 001241 TSTB @#DRVKEY+1 ;TWO DRIVES AVAILABLE?
1218 002422 001416 BEQ 2$ ;BR IF NO
1219 002424 005237 001216 INC @#SMXCNT ;SET FOR TWO ITERATIONS PER TEST (ONE PER DRIVE)
1220 002430 005201 INC R1 ;INCREMENT THE POINTER
1221 002432 111137 001250 MOV (R1),@#CURDRV ;SET SECOND DRIVE FOR TYPE-OUT
1222 002436 001004 BNE 1$ ;GO TYPE IT
1223 002440 012701 001240 MOV #DRVKEY,R1 ;RESET POINTER
1224 002444 111137 001250 MOV (R1),@#CURDRV ;NOW GET THE SECOND DRIVE
1225 002450 104401 015302 1$: TYPE ,MANDRV ;TYPE "AND DRIVE"
1226 002454 104401 001250 TYPE ,CURDRV ;TYPE DRIVE
1227 002460 010137 001244 2$: MOV R1,@#DRVPNT ;SAVE POINTER FOR NEXT TRIP THRU
1228 002464 012737 002664 001106 MOV #5$,@#LPADR ;SETUP THE SCOPE LOOP ADDRESS
1229 002472 005737 001100 TST @#SPASS ;ONCE ONLY
1230 002476 001131 BNE TS1
1231 ;////////////////////////////////////
1232 ;ON THE FIRST PASS OF THE PROGRAM DETERMINE THE AMOUNT OF TIME TO
1233 ;WAIT ON A FLAG ("READY"/"TRANSFER REQUEST") AND THE STALL TIME TO USE
1234 ;WHEN STALLING AFTER A FUNCTION IS COMPLETED
1235 002500 104422 SELDRV ;SELECT DRIVE
1236 002502 012737 002702 001172 MOV #FATAL,@#SESCAPE ;SETUP ESCAPE ON ERROR
1237 002510 005077 176542 CLR @#RWDFLG ;SET FOR NO REWIND ERRORS
1238 002514 012737 077777 012012 MOV #^CBIT15,@#MAXCNT ;SETUP IMPOSSIBLE COUNT
1239 002522 112714 000016 MOVB #XRWND,@TACS ;INSURE NO ERROR DUE TO "CLEAR LEADER"
1240 002526 104421 REWIND ;GO TO BOT
1241 002530 104412 WFG ;NOW TIME A WFG
1242 002532 163737 012010 012012 SUB @#HICNT,@#MAXCNT ;GET THE TIME IT TOOK TO WFG
1243 002540 005237 012012 INC @#MAXCNT ;MAKE IT BIGGER
1244 002544 006137 012012 ROL @#MAXCNT
1245 002550 006137 012012 ROL @#MAXCNT
1246 002554 005000 CLR R0
1247 002556 005001 CLR R1
1248 002560 012777 002616 176442 MOV #4$,@TAVEC ;SETUP TA11 VECTOR
1249 002566 112714 000101 MOVB #XWFGINT.ENIG0,@TACS ;START A "WFG"
1250 002572 005037 177776 CLR @#PS ;ALLOW INTERRUPTS
1251 002576 162700 000001 3$: SUB #1,R0 ;START TIMING HOW LONG
1252 002602 005601 SBC R1 ; IT TAKES TO WRITE A FILE GAP
1253 002604 001374 BNE 3$
1254 002606 012737 000340 177776 MOV #340,@#PS ;LOCK OUT INTERRUPTS
1255 002614 000432 BR FATAL ;IT TOOK TO LONG
    
```

```

1256 002616 006201 4$: ASR R1 ;DIVIDE THE TIME BY 2
1257 002620 006000 ROR R0
1258 002622 010037 001264 MOV R0,@#STALL ;AND SAVE IT AS THE STALL TIME
1259 002626 010137 001266 MOV R1,@#STALL+2
1260 002632 012777 012356 176370 MOV #BADINT,@TAVEC ;SET TRAP CATCHER
1261 002640 105737 001241 TSTB @#DRVKEY+1 ;TWO DRIVES?
1262 002644 001407 BEQ 5$ ;BR IF NO
1263 002646 104422 SELDRV ;SELECT THE OTHER DRIVE
1264 002650 005077 176402 CLR @#RWDFLG ;SET REWIND FLAG
1265 002654 112714 000016 MOVB #XRWND,@TACS ;AVOID "CLEAR LEADER" ERROR
1266 002660 104421 REWIND ;GO TO BOT
1267 002662 104412 WFG ;GO TO OXIDE
1268 002664 005737 001246 5$: TST @#ASKKEY ;GO START TESTING IF NO MANUAL
1269 002670 002034 TST1 ; OPERATIONS REQUESTED
1270 002672 005000 CLR R0
1271 002674 006137 012012 ROL @#MAXCNT ;INCREASE THE WAIT TIME
1272 002700 000000 HALT ;GIVE CONTROL TO THE OPERATOR
1273
1274 FATAL:
1275 002702 104401 002710 TYPE ,65$ ;TYPE ASCIZ STRING
1276 002706 000414 BR 64$ ;GET OVER THE ASCIZ
1277 ;:65$: .ASCIZ <15><12>*FATAL ERROR ON DRIVE *
1278 64$:
1279 002740 TYPE ,CURDRV ;CURRENT DRIVE
1280 002744 013700 000042 MOV @#42,R0 ;CHECK FOR A MONITOR
1281 002750 001402 BEQ 1$ ;BR IF NONE
1282 002752 000137 006432 JMP @#SENDAD ;LEAVE
1283 002756 000000 1$: HALT ;ERROR OCCURRED BEFORE TESTING STARTED
1284 002760 000776 BR 1$ ;HANGUP
    
```

```
1285 ;*****
1286 ;*TEST 1 REWIND,WRITE,REWIND,READ
1287 ;*****
1288 TST1: SCOPE
1289 MOV #TST2,$ESCAPE ;;ESCAPE TO TEST 2 ON ERROR
1290 SELDRV ;SELECT DRIVE FOR TESTING
1291 REWIND ;GO TO "CLEAR LEADER"
1292 WRITE ,WLNK1 ;WRITE ON TAPE
1293 REWIND ;GO TO BEGINNING OF TAPE
1294 READ ,RLNK1 ;READ
1295 BLKCMP ;COMPARE THE READ AND WRITE BUFFERS
1296 RLNK1 ;LINK TO THE READ BUFFER
1297 WLNK1 ;LINK TO THE WRITE BUFFER
1298 ;*****
1299 ;*TEST 2 TEST BSBG AFTER WRITE AND READ AFTER BSBG
1300 ;*****
1301 TST2: SCOPE
1302 MOV #TST3,$ESCAPE ;;ESCAPE TO TEST 3 ON ERROR
1303 SELDRV ;SELECT DRIVE FOR TESTING
1304 REWIND ;GO TO "BOT"
1305 WRITE ,WLNK1 ;WRITE ONE BLOCK
1306 BSBG ;BACK OVER THE BLOCK
1307 READ ,RLNK1 ;NOW READ
1308 BLKCMP ;COMPARE THE READ AND WRITE BUFFERS
1309 RLNK1 ;LINK TO THE READ BUFFER
1310 WLNK1 ;LINK TO THE WRITE BUFFER
1311 ;*****
1312 ;*TEST 3 TEST BSBG AFTER WRITE AND READ AFTER BSBG
1313 ;*****
1314 TST3: SCOPE
1315 MOV #TST4,$ESCAPE ;;ESCAPE TO TEST 4 ON ERROR
1316 SELDRV ;SELECT DRIVE FOR TESTING
1317 REWIND ;GO TO "BOT"
1318 WRITE ,WLNK1 ;WRITE ONE BLOCK
1319 BSBG ;BACK OVER THE BLOCK
1320 READ ,RLNK1 ;NOW READ
1321 BLKCMP ;COMPARE THE READ AND WRITE BUFFERS
1322 RLNK1 ;LINK TO THE READ BUFFER
1323 WLNK1 ;LINK TO THE WRITE BUFFER
1324 ;*****
1325 ;*TEST 4 TEST BSBG AFTER READ
1326 ;*****
1327 TST4: SCOPE
1328 MOV #TST5,$ESCAPE ;;ESCAPE TO TEST 5 ON ERROR
1329 SELDRV ;SELECT DRIVE FOR TESTING
1330 REWIND ;GO TO "BOT"
1331 WRITE ,WLNK1 ;WRITE ONE BLOCK
1332 REWIND ;GO TO "BOT"
1333 READ ,RLNK1 ;READ
1334 BLKCMP ;COMPARE THE READ AND WRITE BUFFERS
1335 RLNK1 ;LINK TO THE READ BUFFER
1336 WLNK1 ;LINK TO THE WRITE BUFFER
1337 BSBG ;BACK UP
1338 READ ,RLNK1 ;READ
1339 BLKCMP ;COMPARE THE READ AND WRITE BUFFERS
1340 RLNK1 ;LINK TO THE READ BUFFER
```

```
1341 WLNK1 ;LINK TO THE WRITE BUFFER
1342 ;*****
1343 ;*TEST 5 TEST BSBG AFTER READ
1344 ;*****
1345 TST5: SCOPE
1346 MOV #TST6,$ESCAPE ;;ESCAPE TO TEST 6 ON ERROR
1347 SELDRV ;SELECT DRIVE FOR TESTING
1348 REWIND ;GO TO "BOT"
1349 WRITE ,WLNK1 ;WRITE A BLOCK
1350 REWIND ;GO TO "BOT"
1351 READ ,RLNK1 ;READ A BLOCK
1352 BLKCMP ;COMPARE THE READ AND WRITE BUFFERS
1353 RLNK1 ;LINK TO THE READ BUFFER
1354 WLNK1 ;LINK TO THE WRITE BUFFER
1355 BSBG ;BACK OVER THE DATA
1356 READ ,RLNK1 ;NOW READ THE DATA
1357 BLKCMP ;COMPARE THE READ AND WRITE BUFFERS
1358 RLNK1 ;LINK TO THE READ BUFFER
1359 WLNK1 ;LINK TO THE WRITE BUFFER
1360 ;*****
1361 ;*TEST 6 TEST SFBG AFTER REWIND AND BSBG AFTER SFBG
1362 ;*****
1363 TST6: SCOPE
1364 MOV #TST7,$ESCAPE ;;ESCAPE TO TEST 7 ON ERROR
1365 SELDRV ;SELECT DRIVE FOR TESTING
1366 REWIND ;GO TO "BOT"
1367 WRITE ,WLNK1 ;WRITE ONE BLOCK OF DATA
1368 REWIND ;GO TO "BOT"
1369 SFBG ;SPACE OVER THE DATA
1370 BSBG ;BACK OVER THE DATA
1371 READ ,RLNK1 ;READ THE BLOCK
1372 BLKCMP ;COMPARE THE READ AND WRITE BUFFERS
1373 RLNK1 ;LINK TO THE READ BUFFER
1374 WLNK1 ;LINK TO THE WRITE BUFFER
1375 ;*****
1376 ;*TEST 7 TEST WRITE AFTER READ
1377 ;*****
1378 TST7: SCOPE
1379 MOV #TST10,$ESCAPE ;;ESCAPE TO TEST 10 ON ERROR
1380 SELDRV ;SELECT DRIVE FOR TESTING
1381 REWIND ;GO TO "CLEAR LEADER"
1382 WRITE ,WLNK1 ;WRITE ONE BLOCK
1383 BSBG ;BACK OVER THE DATA BLOCK
1384 READ ,RLNK1 ; AND READ IT
1385 BLKCMF ;COMPARE THE READ AND WRITE BUFFERS
1386 RLNK1 ;LINK TO THE READ BUFFER
1387 WLNK1 ;LINK TO THE WRITE BUFFER
1388 WRITE ,WLNK2 ;WRITE A SECOND BLOCK
1389 BSBG ;BACK OVER IT
1390 READ ,RLNK2 ;AND READ IT
1391 BLKCMP ;COMPARE THE READ AND WRITE BUFFERS
1392 RLNK2 ;LINK TO THE READ BUFFER
1393 WLNK2 ;LINK TO THE WRITE BUFFER
1394 ;*****
1395 ;*TEST 10 TEST WRITE AFTER WRITE AND READ AFTER READ
1396 ;*****
```

```

1397 003342 000004
1398 003344 012737 003406 001172
1399 003352 104422
1400 003354 104421
1401 003355 104413 017012
1402 003362 104413 017016
1403 003366 104421
1404 003370 104414 016756
1405 003374 104414 016762
1406 003400 104423
1407 003402 016762
1408 003404 017016
1409
1410
1411
1412 003406 000004
1413 003410 012737 003450 001172
1414 003416 104422
1415 003420 104421
1416 003422 104413 017012
1417 003426 104413 017016
1418 003432 104416
1419 003434 104416
1420 003436 104414 016756
1421 003442 104423
1422 003444 016756
1423 003446 017012
1424
1425
1426
1427 003450 000004
1428 003452 012737 003512 001172
1429 003460 104422
1430 003462 104421
1431 003464 104413 017012
1432 003470 104413 017016
1433 003474 104421
1434 003476 104420
1435 003500 104414 016762
1436 003504 104423
1437 003506 016762
1438 003510 017016
1439
1440
1441
1442 003512 000004
1443 003514 012737 003556 001172
1444 003522 104422
1445 003524 104421
1446 003526 104413 017012
1447 003532 104413 017016
1448 003536 104416
1449 003540 104416
1450 003542 104420
1451 003544 104414 016762
1452 003550 104423

TST10: SCOPE
MOV #TST11,$ESCAPE ;;ESCAPE TO TEST 11 ON ERROR
SELDRV ;SELECT DRIVE FOR TESTING
REWIND ;GO TO "CLEAR LEADER"
WRITE ,WLNK1 ;WRITE TWO(2) BLOCKS
WRITE ,WLNK2
REWIND ;GO TO BOT
READ ,RLNK1 ;READ BOTH BLOCKS
READ ,RLNK2
BLKCMP ;COMPARE THE READ AND WRITE BUFFERS
RLNK2 ;LINK TO THE READ BUFFER
WLNK2 ;LINK TO THE WRITE BUFFER
*****
;TEST 11 TEST BSBG AFTER BSBG
*****
TST11: SCOPE
MOV #TST12,$ESCAPE ;;ESCAPE TO TEST 12 ON ERROR
SELDRV ;SELECT DRIVE FOR TESTING
REWIND ;GO TO "CLEAR LEADER"
WRITE ,WLNK1 ;WRITE TWO(2) BLOCKS
WRITE ,WLNK2
BSBG ;BACK OVER THE 2ND BLOCK
BSBG ;BACK OVER THE 1ST BLOCK
READ ,RLNK1 ;READ THE 1ST BLOCK
BLKCMP ;COMPARE THE READ AND WRITE BUFFERS
RLNK1 ;LINK TO THE READ BUFFER
WLNK1 ;LINK TO THE WRITE BUFFER
*****
;TEST 12 TEST READ AFTER SFBG
*****
TST12: SCOPE
MOV #TST13,$ESCAPE ;;ESCAPE TO TEST 13 ON ERROR
SELDRV ;SELECT DRIVE FOR TESTING
REWIND ;GO TO "CLEAR LEADER"
WRITE ,WLNK1 ;WRITE TWO(2) BLOCKS
WRITE ,WLNK2
REWIND ;BOT
SFBG ;SPACE OVER THE 1ST BLOCK
READ ,RLNK2 ;READ THE 2ND BLOCK
BLKCMP ;COMPARE THE READ AND WRITE BUFFERS
RLNK2 ;LINK TO THE READ BUFFER
WLNK2 ;LINK TO THE WRITE BUFFER
*****
;TEST 13 TEST SFBG AFTER BSBG
*****
TST13: SCOPE
MOV #TST14,$ESCAPE ;;ESCAPE TO TEST 14 ON ERROR
SELDRV ;SELECT DRIVE FOR TESTING
REWIND ;GO TO "CLEAR LEADER"
WRITE ,WLNK1 ;WRITE TWO(2) BLOCKS
WRITE ,WLNK2
BSBG ;BACK SPACE OVER BOTH BLOCKS
BSBG
SFBG ;SPACE FWD OVER 1ST BLOCK
READ ,RLNK2 ;READ 2ND BLOCK
BLKCMP ;COMPARE THE READ AND WRITE BUFFERS

```

```

1453 003552 016762 ;LINK TO THE READ BUFFER
1454 003554 017016 ;LINK TO THE WRITE BUFFER
1455
1456
1457
1458 003556 000004
1459 003560 012737 003620 001172
1460 003566 104422
1461 003570 104421
1462 003572 104413 017012
1463 003576 104413 017016
1464 003602 104415
1465 003604 104420
1466 003606 104414 016762
1467 003612 104423
1468 003614 016762
1469 003616 017016
1470
1471
1472
1473 003620 000004
1474 003622 012737 004012 001172
1475 003630 104422
1476 003632 104421
1477 003634 104413 017012
1478 003640 104413 017016
1479 003644 104416
1480 003646 104416
1481 003650 104414 016756
1482 003654 104423
1483 003656 016756
1484 003660 017012
1485 003662 104414 016762
1486 003666 104423
1487 003670 016762
1488 003672 017016
1489 003674 104416
1490 003676 104413 017022
1491 003702 104416
1492 003704 104414 016766
1493 003710 104423
1494 003712 016766
1495 003714 017022
1496 003716 104416
1497 003720 104413 017026
1498 003724 104416
1499 003726 104414 016772
1500 003732 104423
1501 003734 016772
1502 003736 017026
1503 003740 104416
1504 003742 104413 017016
1505 003746 104416
1506 003750 104414 016762
1507 003754 104423
1508 003756 016762

RLNK2 ;LINK TO THE READ BUFFER
WLNK2 ;LINK TO THE WRITE BUFFER
*****
;TEST 14 TEST SFBG AFTER BSBG
*****
TST14: SCOPE
MOV #TST15,$ESCAPE ;;ESCAPE TO TEST 15 ON ERROR
SELDRV ;SELECT DRIVE FOR TESTING
REWIND ;GO TO "CLEAR LEADER"
WRITE ,WLNK1 ;WRITE TWO BLOCKS
WRITE ,WLNK2
SFBG ;SPACE REV FILE
SFBG ;SPACE FWD BLOCK
READ ,RLNK2 ;READ THE 2ND BLOCK
BLKCMP ;COMPARE THE READ AND WRITE BUFFERS
RLNK2 ;LINK TO THE READ BUFFER
WLNK2 ;LINK TO THE WRITE BUFFER
*****
;TEST 15 REWRITE THE LAST BLOCK 3 TIMES AFTER DOING A WRITE AFTER WRITE
*****
TST15: SCOPE
MOV #TST16,$ESCAPE ;;ESCAPE TO TEST 16 ON ERROR
SELDRV ;SELECT DRIVE FOR TESTING
REWIND ;GO TO "CLEAR LEADER"
WRITE ,WLNK1 ;WRITE 2 BLOCKS
WRITE ,WLNK2
BSBG ;BACK OVER BOTH OF THEM
BSBG
READ ,RLNK1 ;READ THE FIRST ONE
BLKCMP ;COMPARE THE READ AND WRITE BUFFERS
RLNK1 ;LINK TO THE READ BUFFER
WLNK1 ;LINK TO THE WRITE BUFFER
READ ,RLNK2 ;NOW READ THE 2ND ONE
BLKCMP ;COMPARE THE READ AND WRITE BUFFERS
RLNK2 ;LINK TO THE READ BUFFER
WLNK2 ;LINK TO THE WRITE BUFFER
BSBG ;BACK OVER THE 2ND ONE
WRITE ,WLNK3 ;WRITE OVER THE 2ND BLOCK
BSBG ;NOW BACK UP AND
READ IT
BLKCMP ;COMPARE THE READ AND WRITE BUFFERS
RLNK3 ;LINK TO THE READ BUFFER
WLNK3 ;LINK TO THE WRITE BUFFER
BSBG ;BACK OVER IT AGAIN
WRITE ,WLNK4 ;AND WRITE OVER IT AGAIN
BSBG ;BACK UP AND
READ ,RLNK4 ;READ THE BLOCK
BLKCMP ;COMPARE THE READ AND WRITE BUFFERS
RLNK4 ;LINK TO THE READ BUFFER
WLNK4 ;LINK TO THE WRITE BUFFER
BSBG ;BACK OVER THE BLOCK AGAIN
WRITE ,WLNK2 ;AND WRITE OVER IT AGAIN
BSBG ;NOW BACK UP
READ ,RLNK2 ;AND READ IT
BLKCMP ;COMPARE THE READ AND WRITE BUFFERS
RLNK2 ;LINK TO THE READ BUFFER

```



```
1509 003760 017016          ;LINK TO THE WRITE BUFFER
1510 003762 104416          ;BACK OVER BOTH BLOCKS
1511 003764 104416          ;
1512 003766 104414 016756  ;AND READ THE 1ST ONE
1513 003772 104423          ;COMPARE THE READ AND WRITE BUFFERS
1514 003774 016756          ;LINK TO THE READ BUFFER
1515 003776 017012          ;LINK TO THE WRITE BUFFER
1516 004000 104414 016762  ;AND THE 2ND ONE
1517 004004 104423          ;COMPARE THE READ AND WRITE BUFFERS
1518 004006 016762          ;LINK TO THE READ BUFFER
1519 004010 017016          ;LINK TO THE WRITE BUFFER
1520
1521
1522
1523 004012 000004          ;*****
1524 004014 012737 004170 001172 ;*TEST 16 REWRITE THE LAST BLOCK 3 TIMES AFTER DOING A WRITE AFTER READ
1525 004022 104422          ;*****
1526 004024 104421          ;*****
1527 004026 104413 017012  TST16: SCOPE
1528 004032 104416          MOV #TST17,$ESCAPE ;;ESCAPE TO TEST 17 ON ERROR
1529 004034 104414 016756  SELDRV ;SELECT DRIVE FOR TESTING
1530 004040 104423          REWIND ;GO TO "CLEAR LEADER"
1531 004042 016756          WRITE ,WLNK1 ;WRITE A BLOCK OF DATA
1532 004044 017012          BSBG ;BACK OVER IT
1533 004046 104413 017016  READ ,RLNK1 ;AND READ IT
1534 004052 104416          BLKCMP ;COMPARE THE READ AND WRITE BUFFERS
1535 004054 104414 016762  RLNK1 ;LINK TO THE READ BUFFER
1536 004060 104423          WLNK1 ;LINK TO THE WRITE BUFFER
1537 004062 016762          WRITE ,WLNK2 ;WRITE 2ND BLOCK
1538 004064 017016          BSBG ;BACK OVER IT
1539 004066 104416          READ ,RLNK2 ;AND READ IT
1540 004070 104413 017026  BLKCMP ;COMPARE THE READ AND WRITE BUFFERS
1541 004074 104416          RLNK2 ;LINK TO THE READ BUFFER
1542 004076 104414 016772  WLNK2 ;LINK TO THE WRITE BUFFER
1543 004102 104423          BSBG ;BACK OVER IT AND
1544 004104 016772          WRITE ,WLNK4 ;WRITE OVER 2ND BLOCK
1545 004106 017026          BSBG ;BACK UP AND
1546 004110 104416          READ ,RLNK4 ;READ IT
1547 004112 104413 017032  BLKCMP ;COMPARE THE READ AND WRITE BUFFERS
1548 004116 104416          RLNK4 ;LINK TO THE READ BUFFER
1549 004120 104414 016776  WLNK4 ;LINK TO THE WRITE BUFFER
1550 004124 104423          BSBG ;BACK OVER IT AGAIN
1551 004126 016776          WRITE ,WLNK5 ;REWRITE 2ND BLOCK
1552 004130 017032          BSBG ;
1553 004132 104416          READ ,RLNK5 ;READ 2ND BLOCK
1554 004134 104413 017022  BLKCMP ;COMPARE THE READ AND WRITE BUFFERS
1555 004142 104416          RLNK5 ;LINK TO THE READ BUFFER
1556 004144 104414 016756  WLNK5 ;LINK TO THE WRITE BUFFER
1557 004146 104416          BSBG ;BACK OVER IT AGAIN
1558 004150 104423          WRITE ,WLNK3 ;WRITE ANOTHER BLOCK OVER IT
1559 004152 016756          BSBG ;BACK OVER 2 BLOCKS
1560 004154 017012          READ ,RLNK1 ;READ THE 1ST BLOCK
1561 004156 104414 016766  BLKCMP ;COMPARE THE READ AND WRITE BUFFERS
1562 004162 104423          RLNK1 ;LINK TO THE READ BUFFER
1563 004164 016766          WLNK1 ;LINK TO THE WRITE BUFFER
1564 004166 017022          READ ,RLNK3 ;READ 2ND BLOCK
1565 004168 104416          BLKCMP ;COMPARE THE READ AND WRITE BUFFERS
1566 004170 104413 017026  RLNK3 ;LINK TO THE READ BUFFER
1567 004172 104416          WLNK3 ;LINK TO THE WRITE BUFFER
```

```
1565
1566
1567
1568 004170 000004          ;*****
1569 004172 012737 004226 001172 ;*TEST 17 TEST WFG AFTER WRITE AND BSBG AFTER WFG
1570 004200 104422          ;*****
1571 004202 104421          ;*****
1572 004204 104413 017012  TST17: SCOPE
1573 004210 104412          MOV #TST20,$ESCAPE ;;ESCAPE TO TEST 20 ON ERROR
1574 004212 104415          SELDRV ;SELECT DRIVE FOR TESTING
1575 004214 104414 016756  REWIND ;GO TO "BOT"
1576 004220 104423          WRITE ,WLNK1 ;WRITE ONE BLOCK
1577 004222 016756          WFG ;FOLLOWED BY A FILE GAP
1578 004224 017012          BSBG ;BACK OVER THE DATA BLOCK
1579
1580
1581
1582 004226 000004          ;*****
1583 004230 012737 004264 001172 ;*TEST 20 TEST BSBG AFTER WFG
1584 004236 104422          ;*****
1585 004240 104421          ;*****
1586 004242 104413 017012  TST20: SCOPE
1587 004250 104416          MOV #TST21,$ESCAPE ;;ESCAPE TO TEST 21 ON ERROR
1588 004252 104414 016756  SELDRV ;SELECT DRIVE FOR TESTING
1589 004256 104423          REWIND ;GO TO BOT
1590 004260 016756          WRITE ,WLNK1 ;WRITE ONE BLOCK OF DATA
1591 004262 017012          WFG ;WRITE A FILE GAP
1592
1593
1594
1595
1596 004264 000004          ;*****
1597 004266 012737 004342 001172 ;*TEST 21 TEST WRITE AFTER WFG
1598 004274 104422          ;*****
1599 004276 104421          ;*****
1600 004300 104413 017012  TST21: SCOPE
1601 004304 104421          MOV #TST22,$ESCAPE ;;ESCAPE TO TEST 22 ON ERROR
1602 004306 104414 016756  SELDRV ;SELECT DRIVE FOR TESTING
1603 004312 104423          REWIND ;GO TO BOT
1604 004314 016756          WRITE ,WLNK1 ;WRITE ONE BOCK
1605 004316 017012          REWIND ;GO TO BOT
1606 004320 104412          READ ,RLNK1 ;READ ONE BLOCK
1607 004322 104413 017016  BLKCMP ;COMPARE THE READ AND WRITE BUFFERS
1608 004326 104416          RLNK1 ;LINK TO THE READ BUFFER
1609 004330 104414 016762  WLNK1 ;LINK TO THE WRITE BUFFER
1610 004334 104423          WFG ;WRITE A FILE GAP
1611 004336 016762          WRITE ,WLNK2 ;WRITE ANOTHER BLOCK
1612 004340 017016          BSBG ;BACK OVER THE LAST BLOCK
1613
1614
1615
1616 004342 000004          ;*****
1617 004344 012737 004420 001172 ;*TEST 22 TEST WFG AFTER READ AND BSBG AFTER WRITE
1618 004352 104422          ;*****
1619 004354 104421          ;*****
1620 004356 104413 017012  TST22: SCOPE
1621 004358 104416          MOV #TST23,$ESCAPE ;;ESCAPE TO TEST 23 ON ERROR
1622 004360 104422          SELDRV ;SELECT DRIVE FOR TESTING
1623 004362 104421          REWIND ;GO TO "BOT"
1624 004364 104413          WRITE ,WLNK1 ;WRITE ONE BLOCK
```

```
1621 004362 104421 REWIND ;GO TO "BOT"
1622 004364 104414 016756 READ ,RLNK1 ;READ ONE BLOCK
1623 004370 104423 BLKCMP ;COMPARE THE READ AND WRITE BUFFERS
1624 004372 016756 RLNK1 ;LINK TO THE READ BUFFER
1625 004374 017012 WLNK1 ;LINK TO THE WRITE BUFFER
1626 004376 104412 WFG ;WRITE A FILE GAP
1627 004400 104413 017016 WRITE ,WLNK2 ;WRITE A BLOCK
1628 004404 104415 BSFG ;BACK OVER THE DATA
1629 004406 104414 016762 READ ,RLNK2 ;READ SECOND BLOCK
1630 004412 104423 BLKCMP ;COMPARE THE READ AND WRITE BUFFERS
1631 004414 016762 RLNK2 ;LINK TO THE READ BUFFER
1632 004416 017016 WLNK2 ;LINK TO THE WRITE BUFFER
1633 ;*****
1634 ;*TEST 23 TEST SFFG AFTER REWIND AND READ AFTER SFFG
1635 ;*****
1636 SCOPE
1637 004422 012737 004464 001172 MOV #TST24,$ESCAPE ;;ESCAPE TO TEST 24 ON ERROR
1638 004430 104422 SELDRV ;SELECT DRIVE FOR TESTING
1639 004432 104421 REWIND ;GO TO "BOT"
1640 004434 104413 017012 WRITE ,WLNK1 ;WRITE A BLOCK OF DATA
1641 004440 104412 WFG ;WRITE A FILE GAP
1642 004442 104413 017016 WRITE ,WLNK2 ;WRITE A BLOCK OF DATA
1643 004446 104421 REWIND ;GO TO "BOT"
1644 004450 104417 BSFG ;SPACE OVER FIRST BLOCK
1645 004452 104414 016762 READ ,RLNK2 ;READ THE 2ND BLOCK
1646 004456 104423 BLKCMP ;COMPARE THE READ AND WRITE BUFFERS
1647 004460 016762 RLNK2 ;LINK TO THE READ BUFFER
1648 004462 017016 WLNK2 ;LINK TO THE WRITE BUFFER
1649 ;*****
1650 ;*TEST 24 TEST BSBG AFTER SFFG
1651 ;*****
1652 SCOPE
1653 004464 000004 TST24: MOV #TST25,$ESCAPE ;;ESCAPE TO TEST 25 ON ERROR
1654 004466 012737 004532 001172 SELDRV ;SELECT DRIVE FOR TESTING
1655 004474 104422 REWIND ;GO TO "BOT"
1656 004500 104413 017012 WRITE ,WLNK1 ;WRITE DATA
1657 004504 104412 WFG ;WRITE FILE GAP
1658 004506 104413 017016 WRITE ,WLNK2 ;WRITE DATA
1659 004512 104421 REWIND ;GO TO "BOT"
1660 004514 104417 SFFG ;SPACE OVER FIRST FILE
1661 004516 104416 BSBG ;BACKUP TO FIRST BLOCK
1662 004520 104414 016756 READ ,RLNK1 ;READ THE BLOCK
1663 004524 104423 BLKCMP ;COMPARE THE READ AND WRITE BUFFERS
1664 004526 016756 RLNK1 ;LINK TO THE READ BUFFER
1665 004530 017012 WLNK1 ;LINK TO THE WRITE BUFFER
1666 ;*****
1667 ;*TEST 25 TEST SFBG AFTER SFFG
1668 ;*****
1669 SCOPE
1670 004532 000004 TST25: MOV #TST26,$ESCAPE ;;ESCAPE TO TEST 26 ON ERROR
1671 004534 012737 004606 001172 SELDRV ;SELECT DRIVE FOR TESTING
1672 004542 104422 REWIND ;GO TO "BOT"
1673 004544 104421 WRITE ,WLNK1 ;WRITE A BLOCK OF DATA
1674 004546 104413 017012 WFG ;FOLLOWED BY A FILE GAP
1675 004552 104412 017016 WRITE ,WLNK2 ;FOLLOWED BY 2 BLOCKS OF DATA
1676 004560 104413 017022 WRITE ,WLNK3
```

```
1677 004564 104421 REWIND ;GO TO "BOT"
1678 004566 104417 SFFG ;SPACE OVER 1ST FILE
1679 004570 104420 SFBG ;SPACE OVER BLOCK
1680 004572 104416 BSFG ;BACK OVER THE BLOCK
1681 004574 104414 016762 READ ,RLNK2 ;READ THE LAST BLOCK
1682 004600 104423 BLKCMP ;COMPARE THE READ AND WRITE BUFFERS
1683 004602 016762 RLNK2 ;LINK TO THE READ BUFFER
1684 004604 017016 WLNK2 ;LINK TO THE WRITE BUFFER
1685 ;*****
1686 ;*TEST 26 TEST SFBG AFTER SFBG
1687 ;*****
1688 SCOPE
1689 004606 000004 TST26: MOV #TST27,$ESCAPE ;;ESCAPE TO TEST 27 ON ERROR
1690 004610 012737 004666 001172 SELDRV ;SELECT DRIVE FOR TESTING
1691 004616 104422 REWIND ;GO TO "BOT"
1692 004620 104421 WFG ;WRITE A BLOCK OF DATA
1693 004622 104413 017012 WRITE ,WLNK1 ;WRITE A FILE GAP
1694 004626 104412 WLNK2 ;WRITE 3 BLOCKS OF DATA
1695 004630 104413 017016 WRITE ,WLNK3
1696 004634 104413 017022 WRITE ,WLNK4
1697 004640 104413 017026 WRITE ,WLNK4
1698 004644 104421 REWIND ;GO TO "BOT"
1699 004646 104417 SFFG ;SPACE OVER THE 1ST FILE
1700 004650 104420 SFBG ;SPACE OVER TWO BLOCK
1701 004652 104420 SFBG
1702 004654 104414 016772 READ ,RLNK4 ;READ LAST BLOCK OF DATA
1703 004660 104423 BLKCMP ;COMPARE THE READ AND WRITE BUFFERS
1704 004662 016772 RLNK4 ;LINK TO THE READ BUFFER
1705 004664 017026 WLNK4 ;LINK TO THE WRITE BUFFER
1706 ;*****
1707 ;*TEST 27 TEST BSBG AFTER SFBG AND BSFG AFTER BSFG
1708 ;*****
1709 SCOPE
1710 004666 000004 TST27: MOV #TST30,$ESCAPE ;;ESCAPE TO TEST 30 ON ERROR
1711 004670 012737 004740 001172 SELDRV ;SELECT DRIVE FOR TESTING
1712 004676 104422 REWIND ;GO TO "BOT"
1713 004700 104421 WRITE ,WLNK1 ;WRITE ONE BLOCK OF DATA
1714 004702 104413 017012 WFG ;WRITE A FILE GAP
1715 004706 104412 017016 WRITE ,WLNK2 ;WRITE A BLOCK OF DATA
1716 004710 104413 017016 REWIND ;GO TO "BOT"
1717 004714 104421 SFFG ;SPACE OVER 1ST FILE
1718 004720 104420 BSFG ;SPACE OVER 1ST BLOCK OF 2ND FILE
1719 004722 104415 BSFG ;BACK TO BEGINNING OF 2ND FILE
1720 004724 104415 BSFG ;BACK TO BEGINNING OF 1ST FILE
1721 004726 104414 016756 READ ,RLNK1 ;READ 1ST BLOCK OF 1ST FILE
1722 004732 104423 BLKCMP ;COMPARE THE READ AND WRITE BUFFERS
1723 004734 016756 RLNK1 ;LINK TO THE READ BUFFER
1724 004736 017012 WLNK1 ;LINK TO THE WRITE BUFFER
1725 ;*****
1726 ;*TEST 30 TEST BSBG THRU A FILE GAP
1727 ;*****
1728 SCOPE
1729 004740 000004 TST30: MOV #TST31,$ESCAPE ;;ESCAPE TO TEST 31 ON ERROR
1730 004742 012737 005016 001172 SELDRV ;SELECT DRIVE FOR TESTING
1731 004750 104422 REWIND ;GO TO "BOT"
1732 004752 104421 WRITE ,WLNK1 ;WRITE ONE BLOCK OF DATA
1733 004754 104413 017012 WFG ;WRITE A FILE GAP
```

```
1733 004762 104413 017016 WRITE ,WLNK2 ;WRITE TWO BLOCKS OF DATA
1734 004766 104413 017022 WRITE ,WLNK3
1735 004772 104421 REWIND ;GO TO "BOT"
1736 004774 104417 SFFG ;SPACE OVER 1ST FILE
1737 004776 104420 SFBG ;SPACE OVER 1ST BLOCK OF 2ND FILE
1738 005000 104416 BSBG ;BACK OVER 1 BLOCK
1739 005002 104416 BSBG ;BACK OVER 1 BLOCK
1740 005004 104414 016756 READ ,RLNK1 ;READ
1741 005010 104423 BLKCMP ;COMPARE THE READ AND WRITE BUFFERS
1742 005012 016756 RLNK1 ;LINK TO THE READ BUFFER
1743 005014 017012 WLNK1 ;LINK TO THE WRITE BUFFER
1744 *****
1745 ;*TEST 31 TEST BSBG AFTER BSBG
1746 *****
1747 005016 000004 TST31: SCOPE
1748 005020 012737 005070 001172 MOV #TST32,$ESCAPE ;;ESCAPE TO TEST 32 ON ERROR
1749 005026 104422 SELDRV ;SELECT DRIVE FOR TESTING
1750 005030 104421 REWIND ;GO TO "BOT"
1751 005032 104413 017012 WRITE ,WLNK1 ;WRITE ONE BLOCK OF DATA
1752 005036 104412 WFC ;WRITE A FILE GAP
1753 005040 104413 017016 WRITE ,WLNK2 ;WRITE A BLOCK OF DATA
1754 005044 104421 REWIND ;GO TO "BOT"
1755 005046 104417 SFFG ;SPACE OVER FILE
1756 005050 104420 SFBG ;SPACE OVER 1ST BLOCK OF 2ND FILE
1757 005052 104416 BSBG ;BACK OVER BLOCK
1758 005054 104415 BSBG ;BACK OVER FILE
1759 005056 104414 016756 READ ,RLNK1 ;READ 1ST BLOCK ON TAPE
1760 005062 104423 BLKCMP ;COMPARE THE READ AND WRITE BUFFERS
1761 005064 016756 RLNK1 ;LINK TO THE READ BUFFER
1762 005066 017012 WLNK1 ;LINK TO THE WRITE BUFFER
1763 *****
1764 ;*TEST 32 TEST BSBG AFTER BSBG
1765 *****
1766 005070 000004 TST32: SCOPE
1767 005072 012737 005134 001172 MOV #TST33,$ESCAPE ;;ESCAPE TO TEST 33 ON ERROR
1768 005100 104422 SELDRV ;SELECT DRIVE FOR TESTING
1769 005102 104421 REWIND ;GO TO "CLEAR LEADER"
1770 005104 104413 017012 WRITE ,WLNK1 ;WRITE BLOCK
1771 005110 104412 WFG ;WRITE A FILE GAP
1772 005112 104413 017016 WRITE ,WLNK2 ;FOLLOW WITH ANOTHER BLOCK
1773 005116 104415 BSBG ;BACK UP 1 FILE
1774 005120 104416 BSBG ;BACK UP 1 BLOCK
1775 005122 104414 016756 READ ,RLNK1 ;READ 1ST BLOCK ON TAPE
1776 005126 104423 BLKCMP ;COMPARE THE READ AND WRITE BUFFERS
1777 005130 016756 RLNK1 ;LINK TO THE READ BUFFER
1778 005132 017012 WLNK1 ;LINK TO THE WRITE BUFFER
1779 *****
1780 ;*TEST 33 TEST BSBG AFTER SFFG AND SFFG AFTER READ
1781 *****
1782 005134 000004 TST33: SCOPE
1783 005136 012737 005216 001172 MOV #TST34,$ESCAPE ;;ESCAPE TO TEST 34 ON ERROR
1784 005144 104422 SELDRV ;SELECT DRIVE FOR TESTING
1785 005146 104421 REWIND ;GO TO "BOT"
1786 005150 104413 017012 WRITE ,WLNK1 ;WRITE A BLOCK OF DATA
1787 005154 104412 WFG ;WRITE A FILE GAP
1788 005156 104413 017016 WRITE ,WLNK2 ;WRITE A BLOCK OF DATA
```

```
1789 005162 104421 REWIND ;GO TO "BOT"
1790 005164 104417 SFFG ;SPACE OVER 1ST FILE
1791 005166 104415 BSBG ;BACK TO BEGINNING OF 1ST FILE
1792 005170 104414 016756 READ ,RLNK1 ;READ FIRST DATA BLOCK
1793 005174 104423 BLKCMF ;COMPARE THE READ AND WRITE BUFFERS
1794 005176 016756 RLNK1 ;LINK TO THE READ BUFFER
1795 005200 017012 WLNK1 ;LINK TO THE WRITE BUFFER
1796 005202 104417 SFFG ;SPACE TO BEGINNING ON 2ND FILE
1797 005204 104414 016762 READ ,RLNK2 ;READ 1ST BLOCK OF 2ND FILE
1798 005210 104423 BLKCMP ;COMPARE THE READ AND WRITE BUFFERS
1799 005212 016762 RLNK2 ;LINK TO THE READ BUFFER
1800 005214 017016 WLNK2 ;LINK TO THE WRITE BUFFER
1801 *****
1802 ;*TEST 34 TEST SFFG AFTER SFFG
1803 *****
1804 005216 000004 TST34: SCOPE
1805 005220 012737 005274 001172 MOV #TST35,$ESCAPE ;;ESCAPE TO TEST 35 ON ERROR
1806 005226 104422 SELDRV ;SELECT DRIVE FOR TESTING
1807 005230 104421 REWIND ;GO TO BOT
1808 005232 104413 017012 WRITE ,WLNK1 ;WRITE A BLOCK
1809 005236 104412 WFG ;WRITE FILE GAP
1810 005240 104413 017016 WRITE ,WLNK2 ;WRITE A BLOCK
1811 005244 104412 WFG ;WRITE A FILE GAP
1812 005246 104413 017022 WRITE ,WLNK3 ;WRITE A BLOCK
1813 005252 104412 WFG ;WRITE A FILE GAP
1814 005254 104421 REWIND ;GO TO "BOT"
1815 005256 104417 SFFG ;SPACE OVER 1ST FILE
1816 005260 104417 SFFG ;SPACE OVER 2ND FILE
1817 005262 104414 016766 READ ,RLNK3 ;READ BLOCK OF 3RD FILE
1818 005266 104423 BLKCMP ;COMPARE THE READ AND WRITE BUFFERS
1819 005270 016766 RLNK3 ;LINK TO THE READ BUFFER
1820 005272 017022 WLNK3 ;LINK TO THE WRITE BUFFER
1821 *****
1822 ;*TEST 35 TEST SFFG AFTER SFFG
1823 *****
1824 005274 000004 TST35: SCOPE
1825 005276 012737 005350 001172 MOV #TST36,$ESCAPE ;;ESCAPE TO TEST 36 ON ERROR
1826 005304 104422 SELDRV ;SELECT DRIVE FOR TESTING
1827 005306 104421 REWIND ;GO TO "BOT"
1828 005310 104413 017012 WRITE ,WLNK1 ;WRITE A BLOCK
1829 005314 104413 017016 WRITE ,WLNK2 ;WRITE A BLOCK
1830 005320 104412 WFG ;WRITE A GAP
1831 005322 104413 017022 WRITE ,WLNK3 ;WRITE A BLOCK
1832 005326 104412 WFG ;WRITE A GAP
1833 005330 104421 REWIND ;GO TO "BOT"
1834 005332 104420 SFBG ;SPACE OVER THE 1ST BLOCK(AND 1ST FILE)
1835 005334 104417 SFFG ;SPACE TO BEGINNING OF 2ND FILE
1836 005336 104414 016766 READ ,RLNK3 ;READ 1ST BLOCK OF 2RD FILE
1837 005342 104423 BLKCMP ;COMPARE THE READ AND WRITE BUFFERS
1838 005344 016766 RLNK3 ;LINK TO THE READ BUFFER
1839 005346 017022 WLNK3 ;LINK TO THE WRITE BUFFER
1840 *****
1841 ;*TEST 36 TEST WFG AFTER SFFG
1842 *****
1843 005350 000004 TST36: SCOPE
1844 005352 012737 005422 001172 MOV #TST37,$ESCAPE ;;ESCAPE TO TEST 37 ON ERROR
```

```

1845 005360 104422 SELDRV ;SELECT DRIVE FOR TESTING
1846 005362 104421 REWIND
1847 005364 104413 017012 WRITE ,WLNK1 ;WRITE 2 BLOCKS
1848 005370 104413 017016 WRITE ,WLNK2
1849 005374 104421 REWIND ;GO TO "BOT"
1850 005376 104420 SFBG ;GET OVER THE 1ST BLOCK
1851 005400 104412 WFG ;WRITE A GAP OVER 2ND BLOCK
1852 005402 104413 017022 WRITE ,WLNK3 ;WRITE A BLOCK
1853 005406 104415 BSFG ;BACK OVER THE BLOCK
1854 005410 104414 016766 READ ,RLNK3 ;AND READ IT
1855 005414 104423 BLKCMP ;COMPARE THE READ AND WRITE BUFFERS
1856 005416 016766 RLNK3 ;LINK TO THE READ BUFFER
1857 005420 017022 WLNK3 ;LINK TO THE WRITE BUFFER
1858 ;*****
1859 ;*TEST 37 TEST WRITE AFTER SFBG
1860 ;*****
1861 005422 000004 TST37: SCOPE
1862 005424 012737 005474 001172 MOV #TST40,$ESCAPE ;;ESCAPE TO TEST 40 ON ERROR
1863 005432 104422 SELDRV ;SELECT DRIVE FOR TESTING
1864 005434 104421 REWIND ;GO TO BOT
1865 005436 104413 017012 WRITE ,WLNK1 ;WRITE 2 BLOCK
1866 005442 104413 017016 WRITE ,WLNK2
1867 005446 104421 REWIND ;GO TO BOT
1868 005450 104420 SFBG ;SPACE OVER 1ST BLOCK
1869 005452 104413 017022 WRITE ,WLNK3 ;WRITE OVER 2ND BLOCK
1870 005456 104415 BSFG ;GO TO BEGINNING OF FILE
1871 005460 104420 SFBG ;SPACE OVER 1ST BLOCK
1872 005462 104414 016766 READ ,RLNK3 ;READ THE NEW 2ND BLOCK
1873 005466 104423 BLKCMP ;COMPARE THE READ AND WRITE BUFFERS
1874 005470 016766 RLNK3 ;LINK TO THE READ BUFFER
1875 005472 017022 WLNK3 ;LINK TO THE WRITE BUFFER
1876 ;*****
1877 ;*TEST 40 3 ONE BLOCK FILES---MULTI SPACING & TEST SFFG AFTER BSFG
1878 ;*****
1879 005474 000004 TST40: SCOPE
1880 005476 012737 005564 001172 MOV #TST41,$ESCAPE ;;ESCAPE TO TEST 41 ON ERROR
1881 005504 104422 SELDRV ;SELECT DRIVE FOR TESTING
1882 005506 104421 REWIND ;GO TO "BOT"
1883 005510 104413 017012 WRITE ,WLNK1 ;WRITE A BLOCK
1884 005514 104412 WFG ;FILE GAP
1885 005516 104413 017016 WRITE ,WLNK2 ;BLOCK
1886 005522 104412 WFG ;FILE GAP
1887 005524 104413 017022 WRITE ,WLNK3 ;BLOCK
1888 005530 104412 WFG ;FILE GAP
1889 005532 104421 REWIND ;GO TO "BOT"
1890 005534 104417 SFFG ;SPACE OVER 1ST FILE
1891 005536 104417 SFFG ;SPACE OVER 2ND FILE
1892 005540 104417 SFFG ;SPACE OVER 3RD FILE
1893 005542 104415 BSFG ;BACK OVER 3RD FILE
1894 005544 104415 BSFG ;BACK OVER 2ND FILE
1895 005546 104415 BSFG ;BACK OVER 1ST FILE
1896 005550 104417 SFFG ;GO TO BEGINNING OF 2ND FILE
1897 005552 104414 016762 READ ,RLNK2 ;READ THE BLOCK
1898 005556 104423 BLKCMP ;COMPARE THE READ AND WRITE BUFFERS
1899 005560 016762 RLNK2 ;LINK TO THE READ BUFFER
1900 005562 017016 WLNK2 ;LINK TO THE WRITE BUFFER

```

```

C2TADD.P11 23-MAR-78 08:34 T41 TWO BLOCK FILES---MULTI SPACING FUNCTIONS SEQ 0041
1901 ;*****
1902 ;*TEST 41 TWO BLOCK FILES---MULTI SPACING FUNCTIONS
1903 ;*****
1904 005564 000004 TST41: SCOPE
1905 005566 012737 005672 001172 MOV #TST42,$ESCAPE ;;ESCAPE TO TEST 42 ON ERROR
1906 005574 104422 SELDRV ;SELECT DRIVE FOR TESTING
1907 005576 104421 REWIND ;GO TO "BOT"
1908 005600 104413 017012 WRITE ,WLNK1 ;WRITE A 2 BLOCK FILE
1909 005604 104413 017016 WRITE ,WLNK2
1910 005610 104412 WFG ;FILE GAP
1911 005612 104413 017022 WRITE ,WLNK3 ;WRITE A 2 BLOCK FILE
1912 005616 104413 017026 WRITE ,WLNK4
1913 005622 104412 WFG ;FILE GAP
1914 005624 104413 017032 WRITE ,WLNK5 ;WRITE A 2 BLOCK FILE
1915 005630 104413 017036 WRITE ,WLNK6
1916 005634 104412 WFG ;FILE GAP
1917 005636 104421 REWIND ;GO TO "BOT"
1918 005640 104417 SFFG ;SPACE OVER 1ST FILE
1919 005642 104417 SFFG ;SPACE OVER 2ND FILE
1920 005644 104414 016776 READ ,RLNK5 ;READ 1ST BLOCK OF 3RD FILE
1921 005650 104423 BLKCMP ;COMPARE THE READ AND WRITE BUFFERS
1922 005652 016776 RLNK5 ;LINK TO THE READ BUFFER
1923 005654 017032 WLNK5 ;LINK TO THE WRITE BUFFER
1924 005656 104415 BSFG ;BACK TO BEGINNING OF 3RD FILE
1925 005660 104414 016778 READ ,RLNK5 ;READ 1ST BLOCK OF 3RD FILE
1926 005664 104423 BLKCMP ;COMPARE THE READ AND WRITE BUFFERS
1927 005666 016776 RLNK5 ;LINK TO THE READ BUFFER
1928 005670 017032 WLNK5 ;LINK TO THE WRITE BUFFER
1929 ;*****
1930 ;*TEST 42 MULTI SPACING & TEST SFBG AFTER READ
1931 ;*****
1932 005672 000004 TST42: SCOPE
1933 005674 012737 006042 001172 MOV #TST43,$ESCAPE ;;ESCAPE TO TEST 43 ON ERROR
1934 005702 104422 SELDRV ;SELECT DRIVE FOR TESTING
1935 005704 104421 REWIND ;GO TO "BOT"
1936 005706 104413 017012 WRITE ,WLNK1 ;WRITE A 3 BLOCK FILE
1937 005712 104413 017016 WRITE ,WLNK2
1938 005716 104413 017022 WRITE ,WLNK3
1939 005722 104412 WFG ;FILE GAP
1940 005724 104413 017026 WRITE ,WLNK4 ;WRITE A 2 BLOCK FILE
1941 005730 104413 017032 WRITE ,WLNK5
1942 005734 104412 WFG ;FILE GAP
1943 005736 104421 REWIND ;GO TO "BOT"
1944 005740 104417 SFFG ;SPACE OVER THE 1ST FILE
1945 005742 104417 SFFG ;SPACE OVER THE 2ND FILE
1946 005744 104415 BSFG ;BACK TO BEGINNING OF 2 FILE
1947 005746 104414 016772 READ ,RLNK4 ;READ 1ST BLOCK OF 2ND FILE
1948 005752 104423 BLKCMP ;COMPARE THE READ AND WRITE BUFFERS
1949 005754 016772 RLNK4 ;LINK TO THE READ BUFFER
1950 005756 017026 WLNK4 ;LINK TO THE WRITE BUFFER
1951 005760 104415 BSFG ;BACK TO BEGINNING OF 2ND FILE
1952 005762 104415 BSFG ;BACK OVER 1ST FILE
1953 005764 104414 016756 READ ,RLNK1 ;READ 1ND BLOCK OF 1ST FILE
1954 005770 104423 BLKCMP ;COMPARE THE READ AND WRITE BUFFERS
1955 005772 016756 RLNK1 ;LINK TO THE READ BUFFER
1956 005774 017012 WLNK1 ;LINK TO THE WRITE BUFFER

```

```

1957 005776 104415          BSBG          ;GO TO BEGINNING OF 1ST FILE
1958 006000 104414 016756  READ ,RLNK1    ;READ 1ST BLOCK
1959 006004 104423          BLKCMP        ;COMPARE THE READ AND WRITE BUFFERS
1960 006006 016756          RLNK1         ;LINK TO THE READ BUFFER
1961 006010 017012          WLNK1        ;LINK TO THE WRITE BUFFER
1962 006012 104420          SFBG         ;GET OVER 2ND BLOCK
1963 006014 104414 016766  READ ,RLNK3    ;READ 3RD BLOCK
1964 006020 104423          BLKCMP        ;COMPARE THE READ AND WRITE BUFFERS
1965 006022 016766          RLNK3        ;LINK TO THE READ BUFFER
1966 006024 017022          WLNK3        ;LINK TO THE WRITE BUFFER
1967 006026 104417          SFFG         ;GO TO BEGINNING OF 2ND FILE
1968 006030 104414 016772  READ ,RLNK4    ;READ 1ST BLOCK OF 2ND FILE
1969 006034 104423          BLKCMP        ;COMPARE THE READ AND WRITE BUFFERS
1970 006036 016772          RLNK4        ;LINK TO THE READ BUFFER
1971 006040 017026          WLNK4        ;LINK TO THE WRITE BUFFER
1972                                     ;*****
1973 *TEST 43 TWO BLOCK FILES--MULTI SPACING & TEST SFFG AFTER BSBG
1974 ;*****
1975 006042 000004          TST43: SCOPE
1976 006044 012737 006162 001172  MOV #TST44,$ESCAPE ;;ESCAPE TO TEST 44 ON ERROR
1977 006052 104422          SELDRV      ;SELECT DRIVE FOR TESTING
1978 006054 104421          REWIND      ;GO TO BOT
1979 006056 104413 017012  WRITE ,WLNK1   ;WRITE A 2 BLOCK FILE
1980 006062 104413 017016  WRITE ,WLNK2   ;
1981 006066 104412          WFG         ;
1982 006070 104413 017022  WRITE ,WLNK3   ;WRITE A 2 BLOCK FILE
1983 006074 104413 017026  WRITE ,WLNK4   ;
1984 006100 104412          WFG         ;
1985 006102 104413 017032  WRITE ,WLNK5   ;WRITE A 2 BLOCK FILE
1986 006106 104413 017036  WRITE ,WLNK6   ;
1987 006112 104412          WFG         ;
1988 006114 104421          REWIND      ;BOT
1989 006116 104417          SFFG         ;SPACE OVER 3 FILES
1990 006120 104417          SFFG         ;
1991 006122 104417          SFFG         ;
1992 006124 104415          BSBG         ;BACK OVER 2 FILES
1993 006126 104415          BSBG         ;
1994 006130 104416          BSBG         ;BACK TO 2ND BLOCK OF 1ST FILE
1995 006132 104417          SFFG         ;GO TO BEGINNING OF 2ND FILE
1996 006134 104414 016766  READ ,RLNK3    ;READ 1ST RECORD OF 2ND FILE
1997 006140 104423          BLKCMP        ;COMPARE THE READ AND WRITE BUFFERS
1998 006142 016766          RLNK3        ;LINK TO THE READ BUFFER
1999 006144 017022          WLNK3        ;LINK TO THE WRITE BUFFER
2000 006146 104417          SFFG         ;GO TO 3RD FILE
2001 006150 104414 016776  READ ,RLNK5    ;READ 1ST RECORD OF 3RD FILE
2002 006154 104423          BLKCMP        ;COMPARE THE READ AND WRITE BUFFERS
2003 006156 016776          RLNK5        ;LINK TO THE READ BUFFER
2004 006160 017032          WLNK5        ;LINK TO THE WRITE BUFFER
2005                                     ;*****
2006 *TEST 44 6 ONE BLOCK FILES--MULTI SPACING
2007 ;*****
2008 006162 000004          TST44: SCOPE
2009 006164 012737 006352 001172  MOV #SEOP,$ESCAPE ;;ESCAPE TO SEOP ON ERROR
2010 006172 104422          SELDRV      ;SELECT DRIVE FOR TESTING
2011 006174 104421          REWIND      ;GO TO BOT
2012 006176 104413 017012  WRITE ,WLNK1   ;WRITE A 1 RECORD FILE
    
```

```

2013 006202 104412          WFG         ;
2014 006204 104413 017016  WRITE ,WLNK2   ;WRITE A 1 BLOCK FILE
2015 006210 104412          WFG         ;
2016 006212 104413 017022  WRITE ,WLNK3   ;WRITE A 1 BLOCK FILE
2017 006216 104412          WFG         ;
2018 006220 104413 017026  WRITE ,WLNK4   ;WRITE A 1 BLOCK FILE
2019 006224 104412          WFG         ;
2020 006226 104413 017032  WRITE ,WLNK5   ;WRITE A 1 BLOCK FILE
2021 006232 104412          WFG         ;
2022 006234 104413 017036  WRITE ,WLNK6   ;WRITE A 1 BLOCK FILE
2023 006240 104412          WFG         ;
2024 006242 104421          REWIND      ;BOT
2025 006244 104417          SFFG         ;SPACE OVER 1ST FILE
2026 006246 104417          SFFG         ;SPACE OVER 2ND FILE
2027 006250 104417          SFFG         ;SPACE OVER 3RD FILE
2028 006252 104417          SFFG         ;SPACE OVER 4TH FILE
2029 006254 104417          SFFG         ;SPACE OVER 5TH FILE
2030 006256 104417          SFFG         ;SPACE OVER 6TH FILE
2031 006260 104415          BSBG         ;NOW BACK UP AND READ IT
2032 006262 104414 017002  READ ,RLNK6    ;
2033 006266 104423          BLKCMP        ;COMPARE THE READ AND WRITE BUFFERS
2034 006270 017002          RLNK6        ;LINK TO THE READ BUFFER
2035 006272 017036          WLNK6        ;LINK TO THE WRITE BUFFER
2036 006274 104415          BSBG         ;BACK UP TO 5TH FILE
2037 006276 104415          BSBG         ;
2038 006300 104414 016776  READ ,RLNK5    ;AND READ IT
2039 006304 104423          BLKCMP        ;COMPARE THE READ AND WRITE BUFFERS
2040 006306 016776          RLNK5        ;LINK TO THE READ BUFFER
2041 006310 017032          WLNK5        ;LINK TO THE WRITE BUFFER
2042 006312 104415          BSBG         ;BACK UP TO 3RD FILE
2043 006314 104415          BSBG         ;
2044 006316 104415          BSBG         ;
2045 006320 104414 016786  READ ,RLNK3    ;AND READ IT
2046 006324 104423          BLKCMP        ;COMPARE THE READ AND WRITE BUFFERS
2047 006326 016766          RLNK3        ;LINK TO THE READ BUFFER
2048 006330 017022          WLNK3        ;LINK TO THE WRITE BUFFER
2049 006332 104415          BSBG         ;BACK UP TO 1ST FILE
2050 006334 104415          BSBG         ;
2051 006336 104415          BSBG         ;
2052 006340 104414 016756  READ ,RLNK1    ;AND READ IT
2053 006344 104423          BLKCMP        ;COMPARE THE READ AND WRITE BUFFERS
2054 006346 016756          RLNK1        ;LINK TO THE READ BUFFER
2055 006350 017012          WLNK1        ;LINK TO THE WRITE BUFFER
    
```

```

2056 .SBTTL END OF PASS ROUTINE
2057 ;*****
2058 ;*INCREMENT THE PASS NUMBER ($PASS)
2059 ;*TYPE "END PASS"
2060 ;*IF THERES A MONITOR GO TO IT
2061 ;*IF THERE ISN'T JUMP TO START
2062 ;*IF IT IS DESIRED TO HAVE A BELL INDICATE THE "END OF PASS" LOCATION
2063 ;*$ENDMG CAN BE CHANGED TO 7.
2064
2065
2066 006352 SEOP:
2067 006352 000004 SCOPE
2068 006354 005037 001102 CLR $STSNM ;;ZERO THE TEST NUMBER
2069 006360 005037 001170 CLR $TIMES ;;ZERO THE NUMBER OF ITERATIONS
2070 006364 005237 001100 INC $PASS ;;INCREMENT THE PASS NUMBER
2071 006370 042737 100000 001100 BIC #100000,$PASS ;;DON'T ALLOW A NEG. NUMBER
2072 006376 005327 DEC (PC)+ ;;LOOP?
2073 006400 000001 SEOPCT: .WORD 1
2074 006402 003017 BGT $DOAGN ;;YES
2075 006404 012737 MOV (PC)+,@(PC)+ ;;RESTORE COUNTER
2076 006406 000001 SENDCT: .WORD 1
2077 006410 006400 SEOPCT
2078 006412 104401 006451 TYPE $SENDMG ;;TYPE "END PASS"
2079 006416 104401 006446 TYPE $ENULL ;;TYPE A NULL CHARACTER
2080 006422 013700 000042 $GET42: MOV @#42,RO ;;GET MONITOR ADDRESS
2081 006426 001405 BEQ $DOAGN ;;BRANCH IF NO MONITOR
2082 006430 000005 RESET ;;CLEAR THE WORLD
2083 006432 004710 SENDAD: JSR PC,(RO) ;;GO TO MONITOR
2084 006434 000240 NOP ;;SAVE ROOM
2085 006436 000240 NOP ;;FOR
2086 006440 000240 NOP ;;ACT11
2087 006442 $DOAGN:
2088 006442 000137 JMP @(PC)+ ;;RETURN
2089 006444 002312 $RTNAD: .WORD START
2090 006446 377 000 $ENULL: .BYTE -1,-1,0 ;;NULL CHARACTER STRING
2091 006451 015 042412 042116 $ENDMG: .ASCIZ <15><12>/END PASS/
2092 006456 050040 051501 000123
    
```

```

2093 ;*****
2094 ;
2095 .SBTTL ROUTINE TO EXAMINE DRIVE(S) FOR AVAILABILITY
2096
2097 ;CALL:
2098 ; MOV #DRVKEY,RO
2099 ; JSR PC,@#EXAM ;R1 IS DESTROYED
2100 ; NORMAL RETURN
2101 ; ERROR RETURN
2102
2103 006464 013701 001220 EXAM: MOV @#TACSL,R1 ;PICKUP THE "CONTROL & STATUS" REG. ADR.
2104 006470 005011 CLR (R1) ;DRIVE="A", FUNCTION="WFG"
2105 006472 122710 000101 CMPB #1A,(RO) ;EXAMINE DRIVE "A"?
2106 006476 001402 BEQ 1$ ;BR IF YES
2107 006500 052711 000400 BIS #UNIT,(R1) ;SELECT DRIVE "B"
2108 006504 032711 000040 1$: BIT #READY,(R1) ;WAIT ON READY
2109 006510 001775 BEQ 1$
2110 006512 005711 TST (R1) ;ANY ERROR?
2111 006514 100024 BPL 4$ ;BR IF NO
2112 006516 032711 001000 BIT #OFFLINE,(R1) ;ERROR DUE TO "OFF LINE"?
2113 006522 001017 BNE 3$ ;BR IF YES
2114 006524 032711 010000 BIT #WRTLOCK,(R1) ;ERROR DUE TO "WRITE LOCK"?
2115 006530 001411 BEQ 2$ ;BR IF NO
2116 006532 122777 000201 172400 CMPB #BIT071BIT00,@SWR ;"READONLY" SELECTED? (RD1PAS)
2117 006540 001412 BEQ 4$ ;BR IF YES
2118 006542 122777 000203 172370 CMPB #BIT071BIT011BIT00,@SWR ;(RD2PAS)?
2119 006550 001406 BEQ 4$ ;BR IF YES
2120 006552 000403 BR 3$ ;TAKE THE ERROR EXIT
2121 006554 032711 020000 2$: BIT #LEADER,(R1) ;ERROR DUE TO "CLEAR LEADER"?
2122 006560 001002 BNE 4$ ;BR IF YES
2123 006562 062716 000002 3$: ADD #2,(SP) ;TAKE ERROR RETURN
2124 006566 000207 4$: RTS PC ;RETURN
    
```

```

2125 .SBTTL SCOPE HANDLER ROUTINE
2126
2127 ;;*****
2128 ;*THIS ROUTINE CONTROLS THE LOOPING OF SUBTESTS. IT WILL INCREMENT
2129 ;*AND LOAD THE TEST NUMBER($STNM) INTO THE DISPLAY REG.(DISPLAY<7:0>)
2130 ;*AND LOAD THE ERROR FLAG ($ERFLG) INTO DISPLAY<15:08>
2131 ;*THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:
2132 ;*SW14=1 LOOP ON TEST
2133 ;*SW11=1 INHIBIT ITERATIONS
2134 ;*SW09=1 LOOP ON ERROR
2135 ;*CALL
2136 ;* SCOPE ;;SCOPE=IDT
2137
2138 $SCOPE:
2139 006570 CКСWR ;;TEST FOR CHANGE IN SOFT-SWR
2140 006570 104406 TSTB @STKS ;TTY FLAG UP?
2141 006572 105777 172346 BPL 100$ ;BR IF NO
2142 006576 100005 RDCHR ;GO GET ONE CHARACTER FROM TTY
2143 006600 104407 000003 CMPB (SP)+,#3 ;IS IT A CONTROL/C ?
2144 006602 122627 BNE 100$ ;BR IF NO
2145 006606 001001 SETLOOP ;GO GET "TEST" AND "SCOPE LOOP" ADDRESSES
2146 006610 104424 100$: TST (PC)+ ;LOOP ON TEST?
2147 006612 005727 LOOPKEY: 0
2148 006616 001105 BNE $OVER ;BR IF YES
2149 006620 032777 040000 172312 1$: BIT #BIT14,@SWR ;;LOOP ON PRESENT TEST?
2150 006626 001101 BNE $OVER ;;YES IF SW14=1
2151 ;####START OF CODE FOR THE XOR TESTER####
2152 006630 000416 $XTSTR: BR 6$ ;;IF RUNNING ON THE "XOR" TESTER CHANGE
2153 ;THIS INSTRUCTION TO A "NOP" (NOP=240)
2154 006632 013746 000004 MOV @ERRVEC,-(SP) ;;SAVE THE CONTENTS OF THE ERROR VECTOR
2155 006636 012737 006656 000004 MOV #5$,@ERRVEC ;;SET FOR TIMEOUT
2156 006644 005737 177060 TST @#177060 ;;TIME OUT ON XOR?
2157 006650 012637 000004 MOV (SP)+,@ERRVEC ;;RESTORE THE ERROR VECTOR
2158 006654 000453 BR $SVLAD ;GO TO THE NEXT TEST
2159 006656 022626 5$: CMP (SP)-,(SP)+ ;;CLEAR THE STACK AFTER A TIME OUT
2160 006660 012637 000004 MOV (SP)+,@ERRVEC ;;RESTORE THE ERROR VECTOR
2161 006664 000413 BR 7$ ;;LOOP ON THE PRESENT TEST
2162 006666 6$:####END OF CODE FOR THE XOR TESTER####
2163 006666 105737 001103 2$: TSTB $ERFLG ;;HAS AN ERROR OCCURRED?
2164 006672 001421 BEQ 3$ ;;BR IF NO
2165 006674 123737 001115 001103 CMPB $ERMAX,$ERFLG ;;MAX. ERRORS FOR THIS TEST OCCURRED?
2166 006702 101015 BHI 3$ ;;BR IF NO
2167 006704 032777 001000 172226 BIT #BIT09,@SWR ;;LOOP ON ERROR?
2168 006712 001404 BEQ 4$ ;;BR IF NO
2169 006714 013737 001110 001106 7$: MOV $LPERR,$LPADR ;;SET LOOP ADDRESS TO LAST SCOPE
2170 006722 000443 BR $OVER
2171 006724 105037 001103 4$: CLRB $ERFLG ;;ZERO THE ERROR FLAG
2172 006730 005037 001170 CLR $TIMES ;;CLEAR THE NUMBER OF ITERATIONS TO MAKE
2173 006734 000415 BR 1$ ;;ESCAPE TO THE NEXT TEST
2174 006736 032777 004000 172174 3$: BIT #BIT11,@SWR ;;INHIBIT ITERATIONS?
2175 006744 001011 BNE 1$ ;;BR IF YES
2176 006746 005737 001100 TST $PASS ;;IF FIRST PASS OF PROGRAM
2177 006752 001406 BEQ 1$ ;; INHIBIT ITERATIONS
2178 006754 005237 001104 INC $ICNT ;;INCREMENT ITERATION COUNT
2179 006760 023737 001170 001104 CMP $TIMES,$ICNT ;;CHECK THE NUMBER OF ITERATIONS MADE
2180 006766 002021 BGE $OVER ;;BR IF MORE ITERATION REQUIRED
    
```

```

2181 006770 012737 000001 001104 1$: MOV #1,$ICNT ;;REINITIALIZE THE ITERATION COUNTER
2182 006776 013737 001216 001170 MOV $MXCNT,$TIMES ;;SET NUMBER OF ITERATIONS TO DO
2183 007004 105237 001102 $SVLAD: INCB $STNM ;;COUNT TEST NUMBERS
2184 007010 011637 001106 MOV (SP),$LPADR ;;SAVE SCOPE LOOP ADDRESS
2185 007014 011637 001110 MOV (SP),$LPERR ;;SAVE ERROR LOOP ADDRESS
2186 007020 005037 001172 CLR $ESCAPE ;;CLEAR THE ESCAPE FROM ERROR ADDRESS
2187 007024 112737 000001 001115 MOVB #1,$ERMAX ;;ONLY ALLOW ONE(1) ERROR ON NEXT TEST
2188 007032 013777 001102 172102 $OVER: MOV $STNM,@DISPLAY ;;DISPLAY TEST NUMBER
2189 007040 013716 001106 MOV $LPADR,(SP) ;;FUDGE RETURN ADDRESS
2190 007044 000002 RTI ;;FIXES PS
    
```

```

2191 .SBTTL ERROR HANDLER ROUTINE
2192
2193 *****
2194 ;THIS ROUTINE WILL INCREMENT THE ERROR FLAG AND THE ERROR COUNT,
2195 ;SAVE THE ERJNR ITEM NUMBER AND THE ADDRESS OF THE ERROR CALL
2196 ;AND GO TO TYPERR ON ERROR
2197 ;THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:
2198 ;*SW15=1 HALT ON ERROR
2199 ;*SW13=1 INHIBIT ERROR TYPEDUTS
2200 ;*SW10=1 BELL ON ERROR
2201 ;*SW09=1 LOOP ON ERROR
2202 ;CALL
2203 ;* ERROR N ;;ERROR=EMT AND N=ERROR ITEM NUMBER
2204
2205 $ERROR:
2206 007046 104406 CKSWR ;;TEST FOR CHANGE IN SOFT-SWR
2207 007050 011437 001162 MOV @TACS,@#$REG0 ;SAVE THE TA11 STATUS
2208 007054 011537 001164 @TADB,@#$REG1 ;SAVE THE DATA BUFFER
2209 007060 105714 TSTB @TACS ;IF "XFER REQ" IS UP KNOCK IT DOWN
2210 007062 100003 BPL 100$
2211 007064 112714 000020 MOV #1LBS,@TACS
2212 007070 000406 BR 101$
2213 007072 032714 000040 100$: BIT #READY,@TACS ;IS READY SET?
2214 007076 001003 BNE 101$ ;BR IF YES
2215 007100 000005 RESET ;REGAIN CONTROL
2216 007102 013714 001162 MOV @#$REG0,@TACS ;RESTORE THE TACS
2217 007106 022626 101$: CMP (SP)+,(SP)+ ;POP THE STACK
2218 007110 005737 001246 TST ASKKEY ;MANUAL LOOPING?
2219 007114 002002 BGE 102$ ;BR IF NO
2220 007116 011637 001172 MOV (SP), $ESCAPE ;SETUP FOR MANUAL ESCAPE
2221 007122 016616 177774 102$: MOV -4(SP), (SP) ;GET PC+2 OF ERROR
2222 007126 105237 001103 7$: INCB $ERFLG ;;SET THE ERROR FLAG
2223 007132 001775 BEQ 7$ ;;DON'T LET THE FLAG GO TO ZERO
2224 007134 013777 001102 172000 MOV $TSTNM,@DISPLAY ;;DISPLAY TEST NUMBER AND ERROR FLAG
2225 007142 032777 002000 171770 BIT #BIT0,@SWR ;;BELL ON ERROR?
2226 007150 001402 BEQ 1$ ;;NO - SKIP
2227 007152 104401 001174 TYPE $BELL ;;RING BELL
2228 007156 005237 001112 1$: INC $ERTTL ;;COUNT THE NUMBER OF ERRORS
2229 007162 011637 001116 MOV (SP), $ERRPC ;;GET ADDRESS OF ERROR INSTRUCTION
2230 007166 162737 000002 001116 SUB #2,$ERRPC
2231 007174 117737 171716 001114 MOV @SERRPC,$ITEMB ;;STRIP AND SAVE THE ERROR ITEM CODE
2232 007202 032777 020000 171730 BIT #BIT13,@SWR ;;SKIP TYPEDOUT IF SET
2233 007210 001004 BNE 20$ ;;SKIP TYPEDUTS
2234 007212 004737 007276 JSR PC,TYPERR ;;GO TO USER ERROR ROUTINE
2235 007216 104401 001201 TYPE $CRLF
2236 007222
2237 007222 005777 171712 20$: TST @SWR ;;HALT ON ERROR
2238 007226 100002 BPL 3$ ;;SKIP IF CONTINUE
2239 007230 000000 HALT ;;HALT ON ERROR!
2240 007232 104406 CKSWR ;;TEST FOR CHANGE IN SOFT-SWR
2241 007234 032777 001000 171676 3$: BIT #BIT09,@SWR ;;LOOP ON ERROR SWITCH SET?
2242 007242 001402 BEQ 4$ ;;BR IF NO
2243 007244 013716 001110 MOV $LPERR,(SP) ;;FUDGE RETURN FOR LOOPING
2244 007250 005737 001172 4$: TST $ESCAPE ;;CHECK FOR AN ESCAPE ADDRESS
2245 007254 001402 BEQ 5$ ;;BR IF NONE
2246 007256 013716 001172 MOV $ESCAPE,(SP) ;;FUDGE RETURN ADDRESS FOR ESCAPE
    
```

```

2247 007262 5$:
2248 007262 022737 006432 000042 CMP # $ENDAD,@#42 ;;ACT-11 AUTO-ACCEPT?
2249 007270 001001 BNE 6$ ;;BRANCH IF NO
2250 007272 000000 HALT ;;YES
2251 007274 6$:
2252 007274 000002 RTI ;;RETURN
    
```



```

2253 ;:*****
2254 ;THIS ROUTINE WILL TYPEOUT THE ERROR MESSAGES
2255 007276 104401 001201 TYPERR: TYPE ,SCRLF ;TYPE A CARRIAGE RETURN & LINE FEED
2256 007302 104401 MFUNC: 0 ;TYPE THE FUNCTION BEING PERFORMED
2257 007304 000000 ;MESSAGE POINTER GOES HERE
2258 007306 104401 001201 TYPE ,SCRLF
2259 007312 162737 000002 001204 SUB #2,@#SAVPC ;ADJUST THE MAIN FLOW PC
2260 007320 010046 MOV RO,-(SP) ;SAVE RO
2261 007322 113700 001114 MOV @#$ITEMB,RO ;PICKUP THE ITEM INDEX
2262 007326 005300 DEC RO ;ADJUST THE INDEX
2263 007330 006300 ASL RO ;SO IT WILL WORK FOR
2264 007332 006300 ASL RO ;THE ERROR TABLE
2265 007334 006300 ASL RO
2266 007336 062700 001270 ADD #SERRTB,RO ;FORM THE TABLE POINTER
2267 007342 012037 007350 MOV (RO)+,1$ ;PICKUP "ERROR MESSAGE" POINTER
2268 007346 104401 TYPE ;TYPE "ERROR MESSAGE"
2269 007350 000000 1$: 0 ;"ERROR MESSAGE POINTER" GOES HERE
2270 007352 012037 007362 MOV (RO)+,2$ ;PICKUP "DATA HEADER" POINTER
2271 007356 001402 BEQ 3$ ;IF "0" DON'T TYPE
2272 007360 104401 TYPE ;TYPE "DATA HEADER"
2273 007362 000000 2$: 0 ;"DATA HEADER" POINTER GOES HERE
2274 007364 012000 3$: MOV (RO)+,RO ;PICKUP "DATA POINTER"
2275 007366 001004 BNE 5$ ;IF THERE IS DATA TO TYPE GO DO IT
2276 007370 012600 4$: MOV (SP)+,RO ;RESTORE RO
2277 007372 104401 001201 TYPE ,SCRLF ;TYPE A CARRIAGE RETURN&LINE FEED
2278 007376 000207 RTS PC ;RETURN
2279 007400 5$:
2280 007400 013046 MOV @ (RO)+,-(SP) ;:SAVE @ (RO)+ FOR TYPEOUT
2281 ;:TYPE DATA
2282 007402 104402 TYPOC ;:GO TYPE--OCTAL ASCII(ALL DIGITS)
2283 007404 005710 TST (RO) ;TERMINATOR?
2284 007406 001770 BEQ 4$ ;BR IF YES
2285 007410 104401 007416 TYPE ,6$ ;TYPE 2 SPACES.
2286 007414 000771 BR 5$ ;LOOP
2287 007416 020040 000 6$: .ASCIZ / / ;ASCII STRING OF 2 SPACES
2288 007422 .EVEN
    
```

```

2289 ;:*****
2290 .SBTTL ROUTINE TO ASK THE OPERATOR WHAT DRIVE(S) TO TEST
2291 ;CALL
2292 ;
2293 JSR PC,@#ASKDRV ;NOTE: RO AND R1 ARE DESTROYED
2294 RETURN
2295 ;
2296
2297 007422 104401 015136 ASKDRV: TYPE ,MSGDRV ;<CRLF>"DRIVE(S)? "
2298 007426 005037 001240 CLR DRVKEY
2299 007432 104410 RDLIN ;GO GET A DRIVE
2300 007434 012600 MOV (SP)+,RO ;SETUP TO CHECK FOR VALID DRIVE(S)
2301 007436 105710 TSTB @RO ;WAS A DRIVE SELECTED?
2302 007440 001425 BEQ NOTLGL ;BR IF NO
2303 007442 012701 001240 MOV #DRVKEY,R1
2304 007446 122710 000101 LOOP: CMPB #'A,@RO ;WAS DRIVE "A" SELECTED?
2305 007452 001002 BNE NOTA ;BR IF NO
2306 007454 112021 MOV (RO)+,(R1)+ ;SET KEY FOR DRIVE "A"
2307 007456 000411 BR NEXT
2308 007460 122710 000102 NOTA: CMPB #'B,@RO ;WAS DRIVE "B" SELECTED?
2309 007464 001002 BNE NOTB ;BR IF NO
2310 007466 112021 MOV (RO)+,(R1)+ ;SET KEY FOR DRIVE "B"
2311 007470 000404 BR NEXT
2312 007472 122710 000054 NOTB: CMPB #54,@RO ;WAS A COMMA TYPED?
2313 007476 001006 BNE NOTLGL ;BR IF NO
2314 007500 105720 TSTB (RO)+ ;DUMP THE COMMA
2315 007502 105710 NEXT: TSTB @RO ;TERMINATOR?
2316 007504 001406 BEQ EXIT ;BR IF YES
2317 007506 022701 001242 CMP #DRVKEY+2,R1 ;TWO DRIVES SELECTED?
2318 007512 101355 BHI LOOP ;BR IF NO
2319 007514 104401 001200 NOTLGL: TYPE ,SQUES ;ILLEGAL INPUT DETECTED
2320 007520 000740 BR ASKDRV ;GO TRY AGAIN
2321 007522 005737 001240 EXIT: TST DRVKEY ;ANY DRIVE SELECTED?
2322 007526 001772 BEQ NOTLGL ;BR IF NO
2323 007530 000207 RTS PC
2324
2325 ;:*****
2326 ;CALL
2327 JSR PC,@#ASKADR
2328
2329 007532 010046 ASKADR: MOV RO,-(SP) ;SAVE RO
2330 007534 104401 015152 1$: TYPE ,MSGASK ;"TACS?"
2331 007540 104411 RDOCT ;GET VALUE
2332 007542 012600 MOV (SP)+,RO ;PICK UP THE OCTAL NUMETR
2333 007544 001423 BEQ 3$ ;IF "0" USE OLD VALUES
2334 007546 020027 160000 CMP RO,#160000 ;MAKE SURE IT IS A BUS ADDRESS
2335 007552 103770 BLD 1$
2336 007554 010037 001220 MOV RO,@#TACSL ;SAVE TOE TACS
2337 007560 062700 000002 ADD #2,RO ;STEP TO TADB ADDRESS
2338 007564 010037 001224 MBV RO,@#TADBL ;AND SAVE IT
2339 007570 013737 001220 001222 MOV @#TACSL,@#TACSH ;SET UP TACS UPPER
2340 007576 005237 001222 INC @#TACSH ;BYTE POINTER
2341
2342 007602 013737 001224 001226 MOV @#TADBL,@#TADBH ;SET UP TADB UPPER
2343 007610 005237 001226 INC @#TADBH ;BYTE POINTER
2344 007614 104401 015162 3$: TYPE ,MSGVEC ;"VECTOR?"
    
```

```

2345 007620 104411          RDOCT
2346 007622 012600          MOV      (SP)+,RO
2347 007624 001411          BEQ      5$
2348 007626 020027 001000    CMP      RO,#1000          ;MAKE SURE ADDRESS IS IN VECTOR AREA
2349 007632 103370          BHIS     3$
2350 007634 010037 001230    MOV      RO,@#TAVEC      ;SAVE AS VECTOR ADDRESS
2351 007640 062700 000002    ADD      #2,RO
2352 007644 010037 001232    MOV      RO,@#TAVEC+2
2353 007650 104401 015172    5$:     TYPE    ,MSGPRI          ;ASK FOR PRIORITY
2354 007654 104411          RDOCT
2355 007656 012600          MOV      (SP)+,RO
2356 007660 001413          BEQ      6$
2357 007662 020027 000007    CMP      RO,#7          ;IF "0" USE OLD /ALUE
2358 007666 101370          BHI      5$
2359 007670 000300          SWAB     RO              ;PUT INTO HIGH BYTE
2360 007672 006200          ASR      RO              ;AND SHIFT
2361 007674 006200          ASR      RO              ;INTO PROPER
2362 007676 006200          ASR      RO              ;POSITION
2363 007700 042700 177437    BIC      #^C<340>,RO     ;SAVE ONLY PRIORITY BITS
2364 007704 010037 001234    MOV      RO,@#TAPRIO     ;STORE IT AWAY
2365 007710 104401 015204    6$:     TYPE    ,MTACS          ;TACS=
2366 007714 013746 001220    MOV      TACSL,-(SP)     ;;SAVE TACSL FOR TYPEOUT
2367 007720 104402          TYPDC    ,MTADB          ;;GO TYPE--OCTAL ASCII(ALL DIGITS)
2368 007722 104401 015213    MOV      TADBL,-(SP)     ;"TADB="
2369 007726 013746 091224    TYPDC    ,TADBL,-(SP)   ;;SAVE TADBL FOR TYPEOUT
2370 007732 104402          TYPDC    ,MTAVEC        ;;GO TYPE--OCTAL ASCII(ALL DIGITS)
2371 007734 104401 015222    MOV      TAVEC,-(SP)    ;"VECTOR="
2372 007740 013746 001230    TYPDC    ,TAVEC,-(SP)   ;;SAVE TAVEC FOR TYPEOUT
2373 007744 104402          TYPDC    ,MTAPRI        ;;GO TYPE--OCTAL ASCII(ALL DIGITS)
2374 007746 104401 015233    TYPE     ,MTAPRI        ;"PRIORITY="
2375 007752 013746 001234    MOV      TAPRIO,-(SP)   ;;SAVE TAPRIO FOR TYPEOUT
2376 007756 104402          TYPDC    ,MSGOK         ;;GO TYPE--OCTAL ASCII(ALL DIGITS)
2377 007760 104401 015246    TYPE     ,MSGOK         ;"OK?"
2378 007764 104407          RDCHR    (SP)-,RO       ;GO READ ONE CHARACTER
2379 007766 012600          MOV      (SP)-,RO       ;GET IT
2380 007770 022700 000015    CMP      #15,RO         ;IS IT "CR"?
2381 007774 001406          BEQ      7$             ;BRANCH IF YES
2382 007776 022700 000131    CMP      #'Y,RO        ;IS IT "Y"?
2383 010002 001403          BEQ      7$             ;IT WAS
2384 010004 104401 001200    TYPE     ,%QUES        ;TYPE "2"
2385 010010 000651          BR       1$             ;AND LET HIM CORRECT THEM
2386 010012 104401 015254    7$:     TYPE     ,MYES        ;TYPE OUT "YES"
2387 010016 012600          MOV      (SP)+,RO      ;RESTORE RO
2388 010020 000207          RTS      PC             ;AND RETURN
2389
2390
2391 ;*****
2392 ;THIS ROUTINE WILL CHANGE AN .ASCII STRING TO AN OCTAL NUMBER
2393 ;
2394 ;REGISTER R1 MUST BE INITIALIZED BEFORE ENTERING
2395 ;
2396 ;CALL:
2397 JSR      R3,@#A2OCT     ;CALL THE ROUTINE
2398 POINTER ;ADDRESS OF THE FIRST CHARACTER IN THE STRING
2399 ;STRING MUST BE TERMINATED BY A BYTE OF ALL 0'S
2400 ;ERROR RETURN ;RETURN HERE IF ILLEGAL CHARACTER
    
```

```

2401 ;
2402 ;
2403 ;
2404 010022 010046          A2OCT: MOV      RO,-(SP)          ;SAVE RO
2405 010024 012300          MOV      (R3)+,RO       ;PICK UP THE POINTER
2406 010026 012737 000006 010042    MOV      #6,2$          ;MAX. NUMBER OF CHAR.'S ALLOWED
2407 010034 105710          1$:     TSTB     (RO)       ;TERMINATOR?
2408 010036 001420          BEQ      3$             ;BR IF YES
2409 010040 005327          DEC      (PC)+         ;COUNT THIS CHARACTER
2410 010042 000000          2$:     0
2411 010044 002416          BLT      4$             ;BR IF TO MANY CHARACTERS IN THE STRING
2412 010046 121027 000060          CMPB     (RO),#'0       ;CHECK THIS CHAR. IS BETWEEN
2413 010052 002413          BLT      4$             ;0 AND 7
2414 010054 121027 000067          CMPB     (RO),#'7
2415 010060 003010          BGT      4$
2416 010062 142710 177770          BICB     #^C7,(RO)     ;STRIP AWAY THE ASCII CODE
2417 010066 006301          ASL      R1             ;POSITION THE FOR THIS CHAR
2418 010070 006301          ASL      R1
2419 010072 006301          ASL      R1
2420 010074 152001          BISB     (R0)+,R1      ;SET IN THIS DIGIT
2421 010076 000756          BR       1$             ;GO GET THE NEXT CHARACTER
2422 010100 005723          3$:     TST      (R3)+     ;INCREMENT FOR NORMAL RETURN
2423 010102 012600          4$:     MOV      (SP)+,RO   ;RESTORE RO
2424 010104 000203          RTS      R3             ;RETURN TO USER
    
```

```

2425 ;*****
2426 ;THIS ROUTINE WILL INPUT THE ADDRESSES OF "TEST" AND "SCOPE LOOP" FROM THE TTY
2427
2428 T.SETLOOP:
2429     TYPE      ,MTEST      ;TYPE "TEST PC?"
2430     RDLIN     ;GET AN ASCII STRING
2431     MOV      (SP)+,11$    ;GET FIRST ADDRESS OF INPUT BUFFER
2432     TSTB    @11$        ;FIRST CHAR. A "CR" ?
2433     BEQ     3$          ;BR IF YES---GO CLEAR THE LOOP KEY
2434     CMP     (SP)+,(SP)+  ;POP POP
2435     MOV     R1,SAVR1    ;SAVE R1
2436     CLR     R1          ;SET PARTIAL TO ZERO
2437     JSR     R3,@#A2OCT  ;GO CHANGE ASCII TO OCTAL
2438     11$:    0           ;POINTER TO STRING
2439     BR     T.SETLOOP   ;ERROR RETURN---GO TRY AGAIN
2440     TST     (R1)+       ;JUST INCREMENTING
2441     MOV     R1,(SP)     ;PUT "TEST PC"; ON THE STACK
2442     5$:    TYPE      ,MLOOP ;TYPE "LOOP PC ?"
2443     RDLIN     ;GET A STRING OF ASCII
2444     MOV     (SP)+,12$    ;GET FIRST ADDRESS OF INPUT BUFFER
2445     TSTB    @12$        ;JUST A "CR" ?
2446     BEQ     1$          ;BR IF YES
2447     CLR     R1          ;CLEAR PARTIAL
2448     JSR     R3,@#A2OCT  ;CHANGE TO OCTAL
2449     12$:    0           ;
2450     BR     5$          ;
2451     MOV     R1,@#SLPADR ;SAVE SCOPE LOOP ADDRESS
2452     BR     2$          ;GO SET LOOP KEY
2453     MOV     (SP),@#SLPADR ;SAVE SCOPE LOOP ADDRESS
2454     2$:    MOV     (SP),@#SLPERR ;ERROR LOOP SAME AS THE TEST ADDRESS
2455     MOV     #-1,@#LOOPKEY ;SET THE LOOP KEY
2456     BR     4$          ;
2457     CLR     @#LOOPKEY   ;CLEAR THE LOOP KEY
2458     4$:    MOV     SAVR1,R1 ;RESTORE R1
2459     RTI     ;BYE BYE
2460     SAVR1:  0           ;HOLD R1 HERE
    
```

```

2461 ;*****
2462 ;THIS ROUTINE WILL SELECT THE NEXT DRIVE TO TEST
2463
2464 T.SELDRV:
2465     BIT     #SW07,@SWR   ;LOCK ON CURRENT DRIVE?
2466     BNE     5$          ;BR IF YES
2467     MOV     R1,-(SP)     ;SAVE R1 ON THE STACK
2468     MOV     DRIVE,R1    ;GET THE DRIVE
2469     MOV     (R1),@#CURDRV ;SAVE CURRENT DRIVE
2470     CMPB   (R1),#'A    ;IS IT DRIVE "A"?
2471     BEQ     1$          ;BR IF YES
2472     BIS     #UNIT,@TACS ;SELECT DRIVE "B"
2473     MOV     #RWDB,@#RWDFLG ;SET REWIND POINTER TO "B"
2474     BR     2$          ;
2475     1$:    BIC     #UNIT,@TACS ;SELECT DRIVE "A"
2476     MOV     #RWDA,@#RWDFLG ;SET REWIND POINTER TO "A"
2477     INC     R1          ;INCREMENT TO THE NEXT DRIVE
2478     2$:    TSTB   (R1)    ;OUT OF DRIVES TO TEST?
2479     BNE     3$          ;BR IF NO
2480     MOV     #DRVKEY,R1  ;RESET TO THE FIRST DRIVE
2481     MOV     R1,DRIVE    ;SAVE FOR NEXT TIME
2482     BIT     #SW09,@SWR  ;IS SWITCH 9=1?
2483     BNE     4$          ;BR IF YES
2484     CLR     @#SERFLG    ;CLEAR THE ERROR INDICATOR
2485     4$:    MOV     (SP)+,R1 ;RESTORE R1
2486     5$:    RTI
    
```

```

2488 ;:*****
2489 ;THIS ROUTINE WILL COMPARE THE READ AND WRITE BUFFERS
2490 010362 T.BLKCMP:
2491 010362 011600 MOV (SP),R0 ;GET THE PC OF THE CALL
2492 010364 010037 001204 MOV RO,@$SAVPC ;SAVE THE PC OF THE CALL
2493 010370 012737 015521 007304 MOV #MBUFCK,@$MFUNC ;POINTER FOR .ASCIZ MESSAGE
2494 010376 012003 MOV (R0)+,R3 ;PICKUP THE READ LINK ADDRESS
2495 010400 012301 MOV (R3)+,R1 ;PICKUP THE READ BUFFER ADDRESS
2496 010402 011303 MOV (R3),R3 ;PICKUP THE READ BUFFER SIZE
2497 010404 013002 MOV @(R0)+,R2 ;PICKUP THE WRITE BUFFER ADDRFS
2498 010406 005037 010446 CLR 2$+2 ;ZERO THE OFFSET
2499 010412 010016 MOV RO,(SP) ;SET THE RETURN
2500 010414 005037 001206 CLR @BYTNUM ;ZERO THE BYTE NUMBER
2501 010420 032777 000010 170512 BIT #SW03,@$SWR ;COMPARE DATA BUFFERS?
2502 010426 001401 BEQ 1$ ;BR IF YES
2503 010430 000002 RTI ;NO--GO BACK
2504 010432 005303 1$: DEC R3 ;CHECK FOR THE TERMINATION
2505 010434 002001 BGE 4$ ;BR IF MORE BYTES TO COMPARE
2506 010436 000002 RTI ;RETURN
2507 010440 005237 001206 4$: INC @BYTNUM ;COUNT THIS BYTE
2508 010444 122162 000000 2$: CMPB (R1)+,O(R2) ;COMPARE READ AND WRITE BUFFER
2509 010450 001006 BNE 3$ ;BR IF NOT EQUAL
2510 010452 005237 010446 INC 2$+2 ;INCREMENT WRITE BUFFER INDEX
2511 010456 042737 177774 010446 BIC #'C3,2$+2 ;DON'T LET IT GET BIGGER THAN 3
2512 010464 000762 BR 1$
2513 010466 114137 001126 3$: MOVB -(R1),@$BDDAT ;GET THE RECEIVED BYTE
2514 010472 063702 010446 ADD 2$+2,R2 ;FORM ADDRESS
2515 010476 111237 001124 MOVB (R2),@$GGDAT ;GET THE EXPECTED BYTE
2516 010502 104010 ERROR 10 ;RECEIVED AND EXPECTED DATA NOT EQUAL
2517 ;:*****
2518 ;THIS ROUTINE WILL WRITE A FILE GAP ON THE TAPE
2519 010504 011637 001204 T.WFG: MOV (SP),@$SAVPC ;SAVE THE PC OF THE CALL
2520 010510 012737 015502 007304 MOV #MXWFG,@$MFUNC ;SET MESSAGE POINTER FOR "WFG"
2521 010516 004037 012224 1$: JSR RO,@$DO.CMD ;GO START A "WFG"
2522 010522 000101 XWFGIINT.EN!GO
2523 010524 005037 177776 CLR @PS ;ALLOW INTERRUPTS
2524 010530 004037 011716 JSR RO,@$WAITFLAG ;GO WAIT FOR A FLAG
2525 010534 104003 ERROR 3 ;NO FLAGS OCCURRED
2526 010536 104004 ERROR 4 ;NO INTERRUPT
2527 010540 004037 012014 JSR RO,@$FLAGS ;NORMAL RETURN---FIND OUT WHAT FLAG
2528 010544 104002 ERROR 2 ;RETURN HERE IF "XFER REQ" AND "READY" =0
2529 010546 104002 ERROR 2 ;RETURN HERE IF "XFER REQ" =1
2530 010550 000002 RTI ;"RETURN HERE IF "READY"=1 AND "ERROR" =0
2531 010552 104002 ERROR 2 ;"READY"=1 AND "ERROR"=1
    
```

```

2532 ;:*****
2533 ;THIS ROUTINE WILL WRITE A RECORD ON THE TAPE
2534 010554 011637 001204 T.WRIT: MOV (SP),@$SAVPC ;SAVE PC OF CALL
2535 010560 012737 015353 007304 MOV #MXWRIT,@$MFUNC ;POINTER FOR .ASCIZ OF "WRITE"
2536 010566 017602 000000 MOV @$(SP),R2 ;GET THE WRITE LINK POINTER
2537 010572 062716 000002 ADD #2,(SP) ;ADJUST THE RETURN
2538 010576 012201 MOV (R2)+,R1 ;GET FIRST ADDRESS OF WRITE BUFFER
2539 010600 005037 012222 CLR @CRC.WD ;CLEAR THE CRC WORD
2540 010604 005037 010676 CLR 6$+2 ;ZERO THE INDEX
2541 010610 012202 MOV (R2)+,R2 ;GET NUMBER OF BYTE TO WRITE
2542 010612 003001 SGT 2$ ;CHECK FOR LEGAL NUMBER
2543 010614 104011 ERROR 11 ;BAD NUMBER OF BYTES
2544 010616 004037 012224 2$: JSR RO,@$DO.CMD ;GO START A "WRITE"
2545 010622 000103 XWRITEIINT.EN!GO
2546 010624 005037 177776 3$: CLR @PS ;ALLOW INTERRUPTS
2547 010630 004037 011716 JSR RO,@$WAITFLAG ;WAIT FOR A FLAG
2548 010634 104003 ERROR 3 ;NO FLAGS OCCURRED
2549 010636 104004 ERROR 4 ;INTERRUPT FAILED
2550 010640 005037 001254 CLR @WAITKEY ;CLEAR THE WAIT FOR INTERRUPT KEY
2551 010644 012737 000340 177776 MOV #340,@$PS ;LOCK OUT THE WORLD
2552 010652 004037 012014 JSR RO,@$FLAGS ;WAIT FLAG OCCURRED?
2553 010656 104002 ERROR 2 ;"READY"=0 & "XFER REQ" =0
2554 010660 000402 BR 4$ ;"XFER REQ"=1
2555 010662 104005 ERROR 5 ;"READY"=1 & "ERROR"=0
2556 010664 104002 ERROR 2 ;"READY"=1 & "ERROR"=1
2557 010666 005302 4$: DEC R2 ;NEED TO WRITE A BYTE ON TAPE
2558 010670 002417 BLT 5$ ;BR IF NO
2559 010672 005000 CLR RO
2560 010674 156100 000000 6$: BISB O(R1),RO ;PICKUP BYTE FOR TRANSFER
2561 010700 110015 MOVB RO,@TADB ;TRANSFER A BYTE TO THE TA11
2562 010702 004737 012102 JSR PC,@$DO.CRC ;CALCULATE CRC FOR THIS BYTE
2563 010706 005237 010676 INC 6$+2 ;INCREASE THE INDEX
2564 010712 042737 177774 010676 BIC #'C3,6$+2 ;KEEP IT LESS THAN 4
2565 010720 012777 012340 170302 MOV #SERV,@TAVEC ;SETUP TO SERVICE THE INTERRUPT
2566 010726 000736 BR ;LOOP
2567 010730 013761 012222 000004 5$: MOV @CRC.WD,4(R1) ;SAVE THE CRC WORD
2568 010736 004037 012224 JSR RO,@$DO.CMD ;START A "ILBS"
2569 010742 000122 XWRITEIINT.EN!ILBS
2570 010744 005037 177776 CLR @PS ;ALLOW INTERRUPTS
2571 010750 004037 011716 JSR RO,@$WAITFLAG ;WAIT FOR A FLAG
2572 010754 104003 ERROR 3 ;NO FLAG
2573 010756 104004 ERROR 4 ;NO INTERRUPT
2574 010760 004037 012014 JSR RO,@$FLAGS ;WHAT FLAG IS SET?
2575 010764 104002 ERROR 2 ;NONE ("XFER REQ"=0 & "READY"=0)
2576 010766 104002 ERROR 2 ;"XFER REQ"
2577 010770 000002 RTI ;"READY"
2578 010772 104002 ERROR 2 ;"READY" & "ERROR"
    
```

```

2579
2580
2581 010774 011637 001204
2582 011000 012737 015361 007304
2583 011006 017602 000000
2584 011012 062716 000002
2585 011016 010200
2586 011020 016000 000034
2587 011024 016037 000004 001210
2588 011032 012201
2589 011034 012202
2590 011036 003001
2591 011040 104011
2592 011042 005037 012222 2$:
2593 011046 004037 012224 JSR
2594 011052 000105 XREADINT,ENIGO
2595 011054 005037 177776 3$:
2596 011060 105011 CLR
2597 011062 004037 011716 JSR
2598 011066 104003 ERROR
2599 011070 104004 ERROR
2600 011072 005037 001254 CLR
2601 011076 012737 000340 177776 MOV
2602 011104 004037 012014 JSR
2603 011110 104002 ERROR
2604 011112 000402 BR
2605 011114 104005 ERROR
2606 011116 000413 BR
2607 011120 005302 4$: DEC
2608 011122 002431 BLT
2609 011124 005000 CLR
2610 011126 151500 BISB
2611 011130 110021 MOV
2612 011132 004737 012102 JSR
2613 011136 012777 012340 170064 MOV
2614 011144 000743 BR
2615 011146 010237 001166 8$: MOV
2616 011152 001414 BEQ
2617 011154 013746 MOV
2618 011160 005037 001172 CLR
2619 011164 016646 000004 MOV
2620 011170 016646 000004 MOV
2621 011174 104013 ERROR
2622 011176 012637 001172 MOV
2623 011202 000002 RTI
2624 011204 104002 9$: ERROR
2625 011206 013737 012222 001212 5$: MOV
2626 011214 004037 012224 JSR
2627 011220 000124 XREADINT,ENIILBS
2628 011222 111537 001214 MOV
2629 011226 005037 177776 CLR
2630 011232 004037 011716 JSR
2631 011236 104003 ERROR
2632 011240 104004 ERROR
2633 011242 111537 001215 MOV
2634 011246 004037 012014 JSR

```

```

2635 011252 104002 ERROR 2 ;UNKNOWN FLAG
2636 011254 104002 ERROR 2 ;"XFER REQ"
2637 011256 000002 RTI ;"READY"
2638 011260 032714 037000 BIT #LEADERIWRLOCKIFGAPITMERR:OFFLINE,@TACS
2639 011264 001401 BEQ 6$ ;BR IF CRC ERROR
2640 011266 104002 ERROR 2 ;ERROR OCCURRED
2641 011270 032777 000020 167642 6$: BIT #SW04,@SWR ;IGNORE CRC ERRORS?
2642 011276 001001 BNE 7$ ;BR IF YES
2643 011300 104012 ERROR 12 ;"READY" AND "CRC ERROR
2644 011302 000002 7$: RTI ;IT WAS A CRC ERROR AND WE ARE IGNORING THEM
2645 ; SD RETURN TO CALLER

```

```
2646 ;*****  
2647 ;THIS ROUTINE WILL BACK SPACE ONE FILE GAP  
2648 011304 011637 001204 T.BSFG: MOV (SP),@SAVPC ;SAVE PC OF CALL  
2649 011310 012737 015433 007304 MOV #MXBSFG,@MFFUNC ;SAVE POINTER OF .ASCIZ NAME  
2650 011316 004037 012224 1$: JSR RO,@DD.CMD ;START A "BSFG"  
2651 011322 000107 XBSFGIINT.ENIGO  
2652 011324 005037 177776 CLR @#PS ;ALLOW INTERRUPTS  
2653 011330 004037 011716 JSR RO,@#WAITFLAG ;WAIT ON FLAG  
2654 011334 104003 ERROR 3 ;NO FLAG  
2655 011336 104004 ERROR 4 ;FLAG DIDN'T INTERRUPT  
2656 011340 004037 012014 JSR RO,@#FLAGS ;FIND OUT WHAT FLAG OCCURRED  
2657 011344 104002 ERROR 2 ;UNKNOWN  
2658 011346 104002 ERROR 2 ;"XFER REQ"  
2659 011350 000401 BR 2$ ;"READY"  
2660 011352 104002 ERROR 2 ;"READY" & "ERROR"  
2661 011354 032714 004000 2$: BIT #FGAP,@TACS ;IN A FILE GAP?  
2662 011360 001401 BEQ 3$ ;BR IN NO  
2663 011362 000002 RTI ;GO BACK  
2664 011364 104005 3$: ERROR 6 ;"BSFG" DIDN'T STOP IN A FILE GAP  
2665  
2666 ;*****  
2667 ;THIS ROUTINE WILL BACK SPACE ONE BLOCK GAP  
2668 T.BSBG: MOV (SP),@SAVPC ;SAVE THE PC OF THE CALL  
2669 011366 011637 001204 007304 MOV #MXBSBG,@MFFUNC ;MESSAGE POINTER  
2670 011372 012737 015457 1$: JSR RO,@DD.CMD ;START A "BSBG"  
2671 011400 004037 012224 XBSBG!INT.ENIGO  
2672 011404 000111 CLR @#PS ;ALLOW INTERRUPTS  
2673 011406 005037 177776 JSR RO,@#WAITFLAG ;WAIT FOR A FLAG  
2674 011412 004037 011716 ERROR 3 ;NO FLAG OCCURRED  
2675 011416 104003 ERROR 4 ;FLAG DIDN'T INTERRUPT  
2676 011420 104004 JSR RO,@#FLAGS ;WHAT FLAG OCCURRED  
2677 011422 004037 012014 ERROR 2 ;UNKNOWN  
2678 011426 104002 ERROR 2 ;"XFER REQ"  
2679 011430 104002 RTI ;"READY"-- GO BACK TO USER  
2680 011432 000002 ERROR 2 ;"READY" & "ERROR"  
2681 011434 104002
```

```
2682 ;*****  
2683 ;THIS ROUTINE WILL SPACE FORWARD FOR ONE FILE GAP  
2684 011436 011637 001204 007304 T.SFFG: MOV (SP),@SAVPC ;SAVE PC OF CALL  
2685 011442 012737 015366 MOV #MXSFFG,@MFFUNC ;POINTER TO .ASCIZ MESSAGE  
2686 011450 004037 012224 1$: JSR RO,@DD.CMD ;START A "SFFG"  
2687 011454 000113 XSFFGIINT.ENIGO  
2688 011456 005037 177776 CLR @#PS ;ALLOW INTERRUPTS  
2689 011462 004037 011716 JSR RO,@#WAITFLAG ;WAIT FOR A FLAG  
2690 011466 104003 ERROR 3 ;FLAG FAILED TO OCCUR  
2691 011470 104004 ERROR 4 ;FLAG DIDN'T INTERRUPT  
2692 011472 004037 012014 JSR RO,@#FLAGS ;WHAT FLAG OCCURRED  
2693 011476 104002 ERROR 2 ;UNKNOWN  
2694 011500 104002 ERROR 2 ;"XFER REQ"  
2695 011502 000401 BR 2$ ;"READY"  
2696 011504 104002 ERROR 2 ;"READY" AND "ERROR"  
2697 011506 032714 004000 2$: BIT #FGAP,@TACS ;DID "SFFG" STOP IN A "FILE GAP"?  
2698 011512 001401 BEQ 3$ ;BR IF NO  
2699 011514 000002 RTI ;RETURN TO CALLER  
2700 011516 104006 3$: ERROR 6 ;"SFFG" DIDN'T STOP IN A FILE GAP  
2701  
2702 ;*****  
2703 ;THIS ROUTINE WILL SPACE FORWARD ONE BLOCK GAP  
2704 T.SFBG: MOV (SP),@SAVPC ;SAVE PC OF CALL  
2705 011520 011637 001204 007304 MOV #MXSFBG,@MFFUNC ;POINTER TO .ASCIZ MESSAGE  
2706 011524 012737 015411 1$: JSR RO,@DD.CMD ;START A "SFBG"  
2707 011532 004037 012224 XSFBGIINT.ENIGO  
2708 011536 000115 CLR @#PS ;ALLOW INTERRUPTS  
2709 011540 005037 177776 JSR RO,@#WAITFLAG ;WAIT FOR A FLAG  
2710 011544 004037 011716 ERROR 3 ;NO FLAG  
2711 011550 104003 ERROR 4 ;NO INTERRUPT  
2712 011552 104004 JSR RO,@#FLAGS ;FIND OUT WHAT FLAG  
2713 011554 004037 012014 ERROR 2 ;UNKNOWN  
2714 011560 104002 ERROR 2 ;"XFER REQ"  
2715 011562 104002 RTI ;"READY"  
2716 011564 000002 RTI ;"READY" AND "ERROR"  
2717 011566 005737 001246 TST @#ASKKEY ;RUNNING UNDER MANUAL LOOPING?  
2718 011572 002001 BGE 2$ ;BR IF NO  
2719 011574 000002 RTI ;RETURN  
2720 011576 104002 2$: ERROR 2 ;"READY" AND "ERROR"
```

```

2721 ;*****
2722 ;THIS ROUTINE WILL REWIND THE TAPE
2723 T.RWIND: MOV (SP),@#SAVPC ;SAVE PC OF CALL
2724 011600 011637 001204 007304 MOV #MXRWIND,@#MFUNC ;POINTER TO .ASCIZ MESSAGE
2725 011612 004037 012014 JSR RO,@#FLAGS ;CHECK THE FLAGS
2726 011616 104001 ERROR 1 ;NO FLAGS
2727 011620 104001 ERROR 1 ;"XFER REQ"
2728 011622 000411 BR 1$ ;NORMAL RETURN
2729 011624 005777 167426 TST @RWDFLG ;WAS LAST FUNCTION A REWIND?
2730 011630 001406 BEQ 1$ ;BR IF YES
2731 011632 032714 020000 BIT #LEADER,@TACS ;ON CLEAR LEADER?
2732 011636 001403 BEQ 1$ ;BR IF NO
2733 011640 005077 167412 CLR @RWDFLG ;ALLOW THIS ERROR ONLY ONE TIME
2734 011644 104001 ERROR 1 ;ON CLEAR LEADER BUT SHOULDN'T BE
2735 011646 004037 012224 1$: JSR RO,@#DO.CMD ;GO START A "REWIND"
2736 011652 000117 XRWIND:INT.ENIGD
2737 011654 005037 177776 CLR @#PS ;ALLOW INTERRUPTS
2738 011660 004037 011716 JSR RO,@#WAITFLAG ;WAIT ON FLAG
2739 011664 104003 ERROR 3 ;NO FLAG OCCURRED
2740 011666 104004 ERROR 4 ;NO INTERRUPT
2741 011670 004037 012014 JSR RO,@#FLAGS ;WHAT FLAG OCCURRED
2742 011674 104002 ERROR 2 ;UNKNOWN
2743 011676 104002 ERROR 2 ;"XFER REQ"
2744 011700 000401 BR 2$ ;"READY"
2745 011702 104002 ERROR 2 ;"READY" & "ERROR"
2746 011704 032714 020000 2$: BIT #LEADER,@TACS ;ON "CLEAR LEADER"?
2747 011710 001401 BEQ 3$ ;BR IF NO
2748 011712 000002 RTI ;YES---RETURN
2749 011714 104007 3$: ERROR 7 ;"REWIND" FAILED TO GO TO "CLEAR LEADER"
    
```

```

2750 ;*****
2751 ;THIS ROUTINE IS USED TO WAIT ON A FLAG
2752 ;
2753 ;CALL:
2754 ; JSR RO,@#WAITFLAG
2755 ; RETURN FOR NO FLAGS
2756 ; RETURN FOR NO INTERRUPT
2757 ; NORMAL RETURN
2758 ;
2759 011716 WAITFLAG:
2760 011716 005037 012006 CLR LOCNT ;ZERO THE LOW COUNTER
2761 011722 013737 012012 012010 MOV MAXCNT,HICNT ;SET THE HIGH COUNTER TO MAX.COUNT
2762 011730 032777 000040 167202 BIT #SW05,@SWR ;RUNNING WITH INTERRUPTS?
2763 011736 001403 BEQ 1$ ;BR IF YES
2764 011740 012737 177777 001254 MOV #-1,WAITKEY ;SET THE INTERRUPT OCCURRED FLAG
2765 011746 032714 000240 1$: BIT #TR.REQ:READY,@TACS ;TEST FOR FLAGS
2766 011752 001007 BNE 2$ ;BR IF A FLAG IS UP
2767 011754 005237 012006 INC LOCNT ;COUNT THE LOW COUNTER
2768 011760 001372 BNE 1$ ;LOOP IF NOT ZERO
2769 011762 005337 012010 DEC HICNT ;COUNT THE HIGH COUNTER
2770 011766 100367 BPL 1$ ;LOOP IF NOT NEG.
2771 011770 000405 BR 3$ ;LEAVE
2772 011772 005720 2$: TST (RO)+ ;INCREMENT THE RETURN ADDRESS
2773 011774 005737 001254 TST WAITKEY ;LOOK AT THE WAIT ON INT. KEY
2774 012000 001401 BEQ 3$ ;BR IF NOT SET
2775 012002 005720 TST (RO)+ ;INCREMENT THE RETURN ADDRESS
2776 012004 000200 3$: RTS RO ;RETURN TO USER
2777 012006 000000 LOCNT: 0
2778 012010 000000 HICNT: 0
2779 012012 000000 MAXCNT: 0
    
```

```

2780
2781 ;*****
2782 ;THIS ROUTINE IS USED TO DETERMINE WHAT FLAG IS SET
2783 ;
2784 ;CALL:
2785 ;
2786 JSR R0,@#FLAGS
2787 RETURN FOR UNKNOWN FLAG
2788 RETURN FOR "TRANSFER REQUEST"
2789 RETURN FOR "READY"
2790 RETURN FOR "READY" & "ERROR"
2791 ;
2792 012014 032714 000240 FLAGS: BIT #TR.REQ|READY,@TACS ;CHECK FOR "XFER REQ" OR "READY"
2793 012020 001427 BEQ LVFLAG ;BR IF NO FLAGS
2794 012022 005720 TST (R0)+ ;INCREMENT RETURN ADDRESS
2795 012024 105714 TSTB @TACS ;CHECK FOR "XFER REQ"
2796 012026 100424 BMI LVFLAG ;BR IF SET
2797 012030 005720 TST (R0)+ ;INCREMENT RETURN ADDRESS
2798 012032 032777 000100 167100 BIT #SW06,@SWR ;STALL?
2799 012040 001414 BEQ 3$ ;BR IF NO
2800 012042 010046 MOV R0,-(SP) ;;PUSH R0 ON STACK
2801 012044 010146 MOV R1,-(SP) ;;PUSH R1 ON STACK
2802 012046 013700 001264 MOV @#STALL,R0 ;GET STALL TIME
2803 012052 013701 001266 MOV @#STALL+2,R1
2804 012056 062700 020001 1$: ADD #1,R0 ;STALL
2805 012062 005501 ADC R1
2806 012064 001374 BNE 1$ ;LOOP
2807 012066 012601 MOV (SP)+,R1 ;;POP STACK INTO R1
2808 012070 012600 MOV (SP)+,R0 ;;POP STACK INTO R0
2809 012072 005714 3$: TST @TACS ;IS "ERROR" SET
2810 012074 100001 BPL LVFLAG ;BR IN NO "ERROR"
2811 012076 005720 TST (R0)+ ;INCREMENT RETURN ADDRESS
2812 012100 000200 LVFLAG: RTS R0
    
```

```

2813 ;*****
2814 ;THIS ROUTINE WILL CALCULATE THE CRC
2815 ;CALL:
2816 ; JSR PC,@#DD.CRC ;R0=1 BYTE OF DATA
2817 ;
2818 DD.CRC:
2819 012102 MOV R0,-(SP) ;;PUSH R0 ON STACK
2820 012104 010046 MOV R1,-(SP) ;;PUSH R1 ON STACK
2821 012106 010146 MOV R2,-(SP) ;;PUSH R2 ON STACK
2822 012110 010346 MOV R3,-(SP) ;;PUSH R3 ON STACK
2823 012112 010446 MOV R4,-(SP) ;;PUSH R4 ON STACK
2824 012114 012737 000010 012176 MOV #8,3$ ;MAKE EIGHT ITERATIONS
2825 012122 013703 012222 1$: MOV CRC.WD,R3 ;PICKUP THE CRC WORD
2826 012126 005001 CLR R1
2827 012130 010302 MOV R3,R2 ;GET THE PARTIAL CRC WORD
2828 012132 042702 177776 BIC #^CBIT00,R2 ;STRIP AWAY EVERYTHING BUT BIT00
2829 012136 006000 ROR R0 ;PULL OFF THIS BIT
2830 012140 006101 ROL R1 ;AND SETUP TO XOR IT
2831 012142 010104 MOV R1,R4 ;FORM THE XOR OF "R1" AND "R2"
2832 012144 040204 SIC R2,R4
2833 012146 040102 BIC R1,R2
2834 012150 050402 BIS R4,R2 ;RESULTS TO "R2"
2835 012152 006002 ROR R2
2836 012154 103006 BCC 2$
2837 012156 012701 040002 MOV #BIT14|BIT01,R1
2838 012162 010104 MOV R1,R4 ;FORM THE XOR OF "R1" AND "R3"
2839 012164 040304 BIC R3,R4
2840 012166 040103 BIC R1,R3
2841 012170 050403 BIS R4,R3 ;RESULTS TO "R3"
2842 012172 006003 2$: ROR R3
2843 012174 005327 3$: DEC (PC)+
2844 012176 000000 0
2845 012200 003352 BGT 1$ ;BR IF MORE BITS TO DO
2846 012202 010337 012222 MOV R3,CRC.WD
2847 012206 012604 MOV (SP)+,R4 ;;POP STACK INTO R4
2848 012210 012603 MOV (SP)+,R3 ;;POP STACK INTO R3
2849 012212 012602 MOV (SP)+,R2 ;;POP STACK INTO R2
2850 012214 012601 MOV (SP)+,R1 ;;POP STACK INTO R1
2851 012216 012600 MOV (SP)+,R0 ;;POP STACK INTO R0
2852 012220 000207 RTS PC
2853 012222 000000 CRC.WD: 0 ;CRC WORD
    
```



```
2854 ;*****  
2855 ;THIS ROUTINE WILL LOAD THE LOW BYTE OF TACS WITH THE DESIRED FUNCTION  
2856 ;  
2857 ;CALL:  
2858 ; JSR RO,@#DO,CMD  
2859 ; DESIRED FUNCTION  
2860 ; RETURN  
2861 ;  
2862 012224 010146 DO.CMD: MOV R1,-(SP) ;SAVE R1  
2863 012226 012737 000340 177776 MOV #340,@#PS ;LOCK OUT ALL INERRUPTS  
2864 012234 012001 MOV (RO)+,R1 ;GET THE COMMAND  
2865 012236 042701 177640 BIC #^C<INT.ENIILBSIFUNCTION:GO>,R1 ;STRIP AWAY JUNK  
2866 012242 032777 000040 166670 BIT #SWOS,@SWR ;WITH OR WITHOUT INTERRUPTS  
2867 012250 001405 BEQ 4$ ;BR IF WITH  
2868 012252 042701 000100 BIC #INT.EN,R1 ;CLEAR INTERRUPT ENABLE IF SET  
2869 012256 012777 012356 166744 MOV #BADINT,@TAVEC ;SETUP TO CATCH BAD INTERRUPT  
2870 012264 005037 001254 4$: CLR WAITKEY ;ZERO THE WAIT ON INTERRUPT KEY  
2871 012270 032701 000100 BIT #INT.EN,R1 ;RUNNING WITH INTERRUPTS?  
2872 012274 001403 BEQ 3$ ;BR IF NO  
2873 012276 012777 012340 166724 MOV #SERV,@TAVEC ;SETUP TO SERVICE THE INTERRUPT  
2874 012304 110114 3$: MOVB R1,@TACS ;LOAD THE COMMAND  
2875 012306 032701 000001 BIT #GO,R1 ;IS GO BIT ON A "1"?  
2876 012312 001403 BEQ 2$ ;BR IF GO =0  
2877 012314 032714 000040 1$: BIT #READY,@TACS ;WAIT FOR "READY" TO CLEAR  
2878 012320 001375 BNE 1$  
2879 012322 005101 2$: COM R1 ;SET OR CLEAR REWIND FLAG  
2880 012324 042701 177761 BIC #^C<FUNCTION>,R1 ;EXTRACT FUNCTION BITS  
2881 012330 010177 166722 MOV R1,@RWDFLG ;AND SAVE AS THE REWIND FLAG  
2882 012334 012601 MOV (SP)+,R1 ;GET R1 BACK  
2883 012336 000200 RTS RO ;RETURN TO USER  
2884 ;  
2885 ;*****  
2886 ;THIS ROUTINE WILL SERVICE ALL LEGAL INTERRUPTS  
2887 ;  
2888 012340 012737 177777 001254 SERV: MOV #-1,@WAITKEY ;SET THE WAIT KEY  
2889 012346 012777 012356 166654 MOV #BADINT,@TAVEC ;SET TO CATCH ILLEGAL INTERRUPTS  
2890 012354 000002 RTI  
2891 ;  
2892 ;*****  
2893 ;THIS ROUTINE WILL CATCH ILLEGAL INTERRUPTS FROM THE TA11  
2894 ;  
2895 012356 011637 001204 BADINT: MOV (SP),@#SAVPC ;SAVE WHERE WE WERE AT  
2896 012362 104014 ERROR 14 ;ILLEGAL INTERRUPT OCCURRED  
2897 ;
```

```
2898 ;*****  
2899 ;THE FOLLOWING ROUTINES CAN BE USED TO MAKE ADJUSTMENTS TO THE TUGO  
2900 ;NOTE: ### BEFORE USING ANY OF THE ROUTINES LOAD AND START AT 214 ###  
2901 ;** NOTE: IF USING SOFTWARE SWITCH REGISTER THE  
2902 ; PROGRAM MUST HAVE BEEN STARTED AT A  
2903 ; NORMAL STARTING ADDRESS FIRST SO THAT  
2904 ; THE AUTO-SIZING ROUTINE CAN SET UP ADDRESS  
2905 ; 176 AS THE SOFTWARE SWITCH REGISTER  
2906 ; PLACE VALUE INTO 176  
2907 ;  
2908 ;*****  
2909 ;  
2910 ;  
2911 ;*****  
2912 ; WRITE FILE GAPS FROM "BOT" TO "EOT"  
2913 ; START AT 220  
2914 ; THIS ROUTINE CAN BE USED TO ADJUST THE "WRITE GAP MONO" AND  
2915 ; THE "WRITE DELAY MONO".  
2916 ;*****  
2917 WFGSUB: MOV #STACK,SP ;KEEP THE STACK OUT OF THE WAY  
2918 012364 012706 001100 MOV @#TACSL,TACS ;SETUP THE TA11 STATUS AND  
2919 012370 013704 001220 MOV @#TADBL,TADB ;DATA BUFFER REGISTERS  
2920 012374 013705 001224 RESET ;RESET THE WORLD  
2921 012400 000005 ;RESET THE LOOP ON ERROR ADDRESS  
2922 012402 012737 012364 001110 MOV #WFGSUB,@#SLPERR ;SETUP THE LOOP ON ERROR ADDRESS  
2923 012410 104422 SELDRV ;SELECT THE DRIVE  
2924 012412 112714 000017 MOVB #XRWD!GO,@TACS ;SEND TAPE TO "BOT"  
2925 012416 032714 000040 100$: BIT #READY,@TACS ;WAIT ON READY  
2926 012422 001775 BEQ 100$  
2927 012424 104412 1$: WFG ;WRITE A FILE GAP  
2928 012426 032714 020000 BIT #LEADER,@TACS ;AT "CLEAR LEADER"?  
2929 012432 001774 BEQ 1$ ;BR IF NO  
2930 012434 000000 HALT ;STOP IF YES  
2931 012436 000752 BR WFGSUB ;LOOP ON CONT.  
2932 ;  
2933 ;*****  
2934 ; WRITE CONTINUOUS BLOCKS OF DATA  
2935 ; START AT 224  
2936 ; THE PROGRAM WILL HALT THREE(3) TIMES  
2937 ; AFTER EACH HALT SET THE SWR AND PRESS CONTINUE  
2938 ; HALT 1 --- SWR<7:0> = NUMBER OF BYTES PER BLOCK  
2939 ; HALT 2 --- SWR<7:0> = PATTERN DESIRED  
2940 ; HALT 3 --- SWR<15:0> = OPERATIONAL SWITCH SETTINGS  
2941 ; THIS ROUTINE CAN BE USED TO ADJUST THE "GAP TIME MONO"  
2942 ; THIS ROUTINE SUPPORTS THE S/W SWITCH REG FUNCTIONS  
2943 ;*****  
2944 ;  
2945 012440 004737 013106 WRTSUB: JSR PC,@#SETBUF ;GET BLOCK SIZE AND PATTERN  
2946 012444 012706 001100 WLOOP: MOV #STACK,SP ;KEEP THE STACK OUT OF THE WAY  
2947 012450 013704 001220 MOV @#TACSL,TACS ;SETUP THE TA11 STATUS AND  
2948 012454 013705 001224 MOV @#TADBL,TADB ;DATA BUFFER REGISTERS  
2949 012460 000005 RESET ;RESET THE WORLD  
2950 012462 012737 012444 001110 MOV #WLOOP,@#SLPERR ;SETUP THE LOOP ON ERROR ADDRESS  
2951 012470 104422 SELDRV ;SELECT THE DRIVE  
2952 012472 112714 000017 MOVB #XRWD!GO,@TACS ;SEND TAPE TO "BOT"  
2953 012476 032714 000040 100$: BIT #READY,@TACS ;WAIT ON READY
```

```
2954 012502 001775          BEQ      100$
2955 012504 104413          WRITE    ,WLNKX          ;WRITE A BLOCK
2956 012510 032714 020000   BIT      #LEADER,@TACS  ;AT "CLEAR LEADER"?
2957 012514 001773          BEQ      1$              ;BR IF NO
2958 012516 000000          HALT
2959 012520 000751          BR       WLOOP          ;STOP IF "EOT"
                              ;LOOP IF CONT.
2960
2961
2962 ;*****
2963 ; READ AND COMPARE CONTINUOUS BLOCKS OF DATA
2964 ; START AT 230
2965 ; THIS ROUTINE CAN BE USED TO ADJUST THE "SIGNAL MONO"
2966 ; AND THE "THRESHOLD POT".
2967 ;*****
2968 012522 012706 001100   RDSUB:  MOV    #STACK,SP          ;KEEP THE STACK OUT OF THE WAY
2969 012526 013704 001220   MOV     @#TACSL,TACS          ;SETUP THE TA11 STATUS AND
2970 012532 013705 001224   MOV     @#TADBL,TADB         ;DATA BUFFER REGISTERS
2971 012536 000005          RESET          ;RESET THE WORLD
2972 012540 012737 012522 001110  MOV     #RDSUB,@#SLPERR ;SETUP THE LOOP ON ERROR ADDRESS
2973 012546 104422          SELDRV        ;SELECT THE DRIVE
2974 012550 112714 000017   MOV     #XRWDIGO,@TACS       ;SEND TAPE TO "BOT"
2975 012554 032714 000040   100$:  BIT      #READY,@TACS     ;WAIT ON READY
2976 012560 001775          BEQ      100$
2977 012562 104414 017006   1$:    READ    ,RLNKX          ;READ A BLOCK
2978 012566 012706 001100   MOV     #STACK,SP           ;INIT. IN CASE OF ERROR
2979 012572 032714 020000   BIT      #LEADER,@TACS      ;AT "CLEAR LEADER"?
2980 012576 001351          BNE      RDSUB              ;BR IF YES---LOOP
2981 012600 104423          BLKCMP        ;COMPARE THE READ AND WRITE BUFFERS
2982 012602 017006          RLNKX         ;LINK TO THE READ BUFFER
2983 012604 017042          WLNKX         ;LINK TO THE WRITE BUFFER
2984 012606 000765          BR       1$
2985
2986 ;*****
2987 ; WRITE A FILE GAP AND A BLOCK OF DATA FROM BOT TO EOT
2988 ; START AT 234
2989 ; THE PROGRAM WILL HALT THREE(3) TIMES
2990 ; AFTER EACH HALT SET THE SWR AND PRESS CONTINUE
2991 ; HALT 1 --- SWR<7:0> = NUMBER OF BYTES PER BLOCK
2992 ; HALT 2 --- SWR<7:0> = PATTERN DESIRED
2993 ; HALT 3 --- SWR<15:0> = OPERATIONAL SWITCH SETTINGS
2994 ; THIS ROUTINE CAN BE USED TO ADJUST THE "WRITE GAP MONO"
2995 ; AND THE "GAP TIME MONO".
2996
```

```
2997 ;THIS ROUTINE SUPPORTS THE S/W SWITCH REG FUNCTIONS
2998 ;*****
2999 012610 004737 013106   WGPBLK: JSR    PC,@#SETBUF    ;GET BLOCK SIZE AND PATTERN
3000 012614 012706 001100   WGBLOP: MOV     #STACK,SP     ;KEEP THE STACK OUT OF THE WAY
3001 012620 013704 001220   MOV     @#TACSL,TACS        ;SETUP THE TA11 STATUS AND
3002 012624 013705 001224   MOV     @#TADBL,TADB        ;DATA BUFFER REGISTERS
3003 012630 000005          RESET          ;RESET THE WORLD
3004 012632 012737 012614 001110  MOV     #WGBLOP,@#SLPERR    ;SETUP THE LOOP ON ERROR ADDRESS
3005 012640 104422          SELDRV        ;SELECT THE DRIVE
3006 012642 112714 000017   MOV     #XRWDIGO,@TACS      ;SEND TAPE TO "BOT"
3007 012646 032714 000040   100$:  BIT      #READY,@TACS     ;WAIT ON READY
3008 012652 001775          BEQ      100$
3009 012654 104412          WFG          ;WRITE A FILE GAP
3010 012656 032714 020000   BIT      #LEADER,@TACS      ;AT "CLEAR LEADER"?
3011 012662 001005          BNE      2$              ;BR IF YES
3012 012664 104413 017042   WRITE    ,WLNKX          ;WRITE A BLOCK
3013 012670 032714 020000   BIT      #LEADER,@TACS      ;AT "CLEAR LEADER"?
3014 012674 001767          BEQ      1$              ;BR IF NO
3015 012676 000000          HALT          ;STOP AT "EOT"
3016 012700 000745          BR       WGBLOP        ;START OVER ON CONT.
3017
3018 ;*****
3019 ; READ AND COMPARE A BLOCK OF DATA AND A FILE GAP
3020 ; START AT 240
3021 ; THIS ROUTINE IS USED AFTER "WRITE A BLOCK AND A FILE GAP" ROUTINE
3022 ; IT CAN BE USED TO ADJUST THE "SIGNAL MONO", THE THRESHOLD POT"
3023 ; AND THE "TAPE BLANK MONO".
3024 ;*****
3025 ;*****
3026 012702 012706 001100   RGPBLK: MOV     #STACK,SP     ;KEEP THE STACK OUT OF THE WAY
3027 012706 013704 001220   MOV     @#TACSL,TACS        ;SETUP THE TA11 STATUS AND
3028 012712 013705 001224   MOV     @#TADBL,TADB        ;DATA BUFFER REGISTERS
3029 012716 000005          RESET          ;RESET THE WORLD
3030 012720 012737 012702 001110  MOV     #RGPBLK,@#SLPERR    ;SETUP THE LOOP ON ERROR ADDRESS
3031 012726 104422          SELDRV        ;SELECT THE DRIVE
3032 012730 112714 000017   MOV     #XRWDIGO,@TACS      ;SEND TAPE TO "BOT"
3033 012734 032714 000040   100$:  BIT      #READY,@TACS     ;WAIT ON READY
3034 012740 001775          BEQ      100$
3035 012742 104414 017006   1$:    READ    ,RLNKX          ;READ A BLOCK OF DATA
3036 012746 012706 001100   MOV     #STACK,SP           ;KEEP OUT OF THE WAY
3037 012752 032714 020000   BIT      #LEADER,@TACS      ;AT "CLEAR LEADER"?
3038 012756 001351          BNE      RGPBLK          ;BR IF YES
3039 012760 104423          BLKCMP        ;COMPARE THE READ AND WRITE BUFFERS
3040 012762 017006          RLNKX         ;LINK TO THE READ BUFFER
3041 012764 017042          WLNKX         ;LINK TO THE WRITE BUFFER
3042 012766 104420          SFBG          ;GET INTO FILE GAP
3043 012770 032714 020000   BIT      #LEADER,@TACS      ;AT "CLEAR LEADER"?
3044 012774 001342          BNE      RGPBLK          ;BR IF YES
3045 012776 000761          BR       1$              ;LOOP
3046
3047 ;*****
3048 ; SPACE FORWARD FILE GAP FROM "BOT" TO "EOT"
3049 ; START AT 244
3050 ; THIS ROUTINE CAN BE USED AFTER "WRITE FILE GAP" FOR LOW SPEED
3051 ; SPACE FOWARD (TAPE BLANK MONO CAN BE ADJUSTED). OR AFTER READ OR
3052
```

```

3053 ;WRITE A FILE GAP AND A BLOCK OF DATA FOR HIGH SPEED SPACE FORWARD
3054 ;(SIGNAL MONO CAN BE CHECKED).
3055 ;*****
SFFGSB: MOV #STACK,SP ;KEEP THE STACK OUT OF THE WAY
MOV @#TACSL,TACS ;SETUP THE TA11 STATUS AND
MOV @#TADBL,TADB ;DATA BUFFER REGISTERS
RESET ;RESET THE WORLD
MOV #SFFGSB,@#SLPERR ;SETUP THE LOOP ON ERROR ADDRESS
SELDV ;SELECT THE DRIVE
MOV #XRWDIG0,@TACS ;SEND TAPE TO "BOT"
100$: BIT #READY,@TACS ;WAIT ON READY
BEQ 100$
1$: SFFG ;SPACE INTO A FILE GAP
BIT #LEADER,@TACS ;AT "CLEAR LEADER"?
BEQ 1$ ;BR IF NO
HALT 1$ ;STOP AT "EOT"
BR SFFGSB ;LOOP ON CONT.

3070
3071 ;*****
3072 ; BACK SPACE FILE GAP
3073 ;
3074 ;START AT 250
3075 ;THIS ROUTINE CAN BE USED TO ADJUST OR CHECK THE "SIGNAL MONO".
3076 ;*****
BSFGS: RESET ;RESET THE WORLD
MOV #BSFGS,@#SLPERR ;LOOP ON ERROR ADDRESS
CLR $ESCAPE ;DON'T ESCAPE ON ERROR
SELDV ;SELECT THE DRIVE
1$: BSFG ;BACK SPACE A FILE GAP
BIT #LEADER,@TACS ;AT "CLEAR LEADER"?
BEQ 1$ ;BR IF NO
HALT ;STOP AT BOT
BR BSFGS ;START OVER ON CONT.

3086
3087 ;*****
3088 ; SETUP READ AND WRITE LINKS FOR SUBROUTINES
3089 ;
3090 013106 005000 ;SETBUF: CLR R0
3091 013110 000000 ;OPERATOR PUTS BYTE COUNT IN THE SWR
3092 013112 022737 000176 001140 ;CMP #SWREG,SWR ;USING S/W SWITCH REG?
3093 013120 001001 ;BNE 20$ ;NO- GET OUT
3094 013122 104405 ;GTSWR ;GET VALUE
3095 013124 ;CONTINUE
3096 013124 157700 166010 ;BISB @SWR,R0 ;PICKUP THE BYTE COUNT
3097 013130 001006 ;BNE 2$ ;BR IF NON-ZERO
3098 013132 105777 166003 ;TSTB @SWR+1 ;CHECK IF GREATER THAN 377
3099 013136 001402 ;BEQ 1$ ;BR IF NO
3100 013140 012700 000376 ;MOV #376,R0 ;SET FOR MAX ALLOWED
3101 013144 005200 ;INC R0 ;MAKE IT 377 OR 1
3102 013146 010037 017010 ;2$: MOV R0,@#RLNKX+2 ;SETUP READ LINK
3103 013152 010037 017044 ;MOV R0,@#WLNKX+2 ;SETUP WRITE LINK
3104 013156 000000 ;HALT ;SET PATTERN INTO THE SWR
3105 013160 022737 000176 001140 ;CMP #SWREG,SWR ;USING S/W SWITCH REG?
3106 013166 001001 ;BNE 21$ ;NO- GET OUT
3107 013170 104405 ;GTSWR ;GET VALUE
3108 013172 ;21$: ;CONTINUE
    
```

```

3109 013172 017700 165742 ;MOV @SWR,R0 ;PICKUP THE PATTERN
3110 013176 012701 017112 ;MOV #WBUF,R1 ;PICKUP FIRST ADDRESS OF BUFFER
3111 013202 110021 ;MOVB R0,(R1)+ ;FILL THE BUFFER
3112 013204 110021 ;MOVB R0,(R1)+
3113 013206 110021 ;MOVB R0,(R1)+
3114 013210 110021 ;MOVB R0,(R1)+
3115 013212 000000 ;HALT ;SET OPERATIONAL SWITCHES
3116 013214 022737 000176 001140 ;CMP #SWREG,SWR ;USING S/W SWITCH REG?
3117 013222 001001 ;BNE 22$ ;NO- GET OUT
3118 013224 104405 ;GTSWR ;GET VALUE
3119 013226 ;22$: ;CONTINUE
3120 013226 000207 ;RTS PC ;RETURN
    
```

```

3121 .SBTTL TYPE ROUTINE
3122
3123 ;*****
3124 ;*ROUTINE TO TYPE ASCIZ MESSAGE. MESSAGE MUST TERMINATE WITH A 0 BYTE.
3125 ;*THE ROUTINE WILL INSERT A NUMBER OF NULL CHARACTERS AFTER A LINE FEED.
3126 ;*NOTE1: $NULL CONTAINS THE CHARACTER TO BE USED AS THE FILLER CHARACTER.
3127 ;*NOTE2: $FILLS CONTAINS THE NUMBER OF FILLER CHARACTERS REQUIRED.
3128 ;*NOTE3: $FILLC CONTAINS THE CHARACTER TO FILL AFTER.
3129 ;*
3130 ;*CALL:
3131 ;*1) USING A TRAP INSTRUCTION
3132 ;* TYPE ,MESADR ;;MESADR IS FIRST ADDRESS OF AN ASCIZ STRING
3133 ;*
3134 ;*OR
3135 ;* TYPE
3136 ;* MESADR
3137 ;*
3138 $TYPE: TSTB $TFPLG ;;IS THERE A TERMINAL?
3139 BPL 1$ ;;BR IF YES
3140 HALT ;;HALT HERE IF NO TERMINAL
3141 BR 3$ ;;LEAVE
3142 1$: MOV RO,-(SP) ;;SAVE RO
3143 MOV @2(SP),RO ;;GET ADDRESS OF ASCIZ STRING
3144 2$: MOVB (RO)+,-(SP) ;;PUSH CHARACTER TO BE TYPED ONTO STACK
3145 BNE 4$ ;;BR IF IT ISN'T THE TERMINATOR
3146 TST (SP)+ ;;IF TERMINATOR POP IT OFF THE STACK
3147 60$: MOV (SP)+,RO ;;RESTORE RO
3148 3$: ADD #2,(SP) ;;ADJUST RETURN PC
3149 RTI ;;RETURN
3150 4$: CMPB #HT,(SP) ;;BRANCH IF <HT>
3151 BEQ 8$
3152 CMPB #CRLF,(SP) ;;BRANCH IF NOT <CRLF>
3153 BNE 5$
3154 TST (SP)+ ;;POP <CR><LF> EQUIV
3155 TYPE ;;TYPE A CR AND LF
3156 $CRLF
3157 CLRB $CHARCNT ;;CLEAR CHARACTER COUNT
3158 BR 2$ ;;GET NEXT CHARACTER
3159 5$: JSR PC,$TYPEC ;;GO TYPE THIS CHARACTER
3160 6$: CMPB $FILLC,(SP)+ ;;IS IT TIME FOR FILLER CHARS.?
3161 BNE 2$ ;;IF NO GO GET NEXT CHAR.
3162 MOV $NULL,-(SP) ;;GET # OF FILLER CHARS. NEEDED
3163 ;;AND THE NULL CHAR.
3164 7$: DECB 1(SP) ;;DOES A NULL NEED TO BE TYPED?
3165 BLT 6$ ;;BR IF NO--GO POP THE NULL OFF OF STACK
3166 JSR PC,$TYPEC ;;GO TYPE A NULL
3167 DECB $CHARCNT ;;DO NOT COUNT AS A COUNT
3168 BR 7$ ;;LOOP
3169
3170 ;HORIZONTAL TAB PROCESSOR
3171
3172 8$: MOVB #' ,(SP) ;;REPLACE TAB WITH SPACE
3173 9$: JSR PC,$TYPEC ;;TYPE A SPACE
3174 BITB #7,$CHARCNT ;;BRANCH IF NOT AT
3175 BNE 9$ ;;TAB STOP
3176 TST (SP)+ ;;POP SPACE OFF STACK
    
```

```

3177 013376 000724 BR 2$ ;;GET NEXT CHARACTER
3178 013400 105777 165544 $TYPEC: TSTB @STPS ;;WAIT UNTIL PRINTER IS READY
3179 013404 100375 BPL $TYPEC
3180 013406 116677 000002 165536 MOVB 2(SP),@STPB ;;LOAD CHAR TO BE TYPED INTO DATA REG.
3181 013414 122766 000015 000002 CMPB (CR),2(SP) ;;IS CHARACTER A CARRIAGE RETURN?
3182 013422 001003 BNE 1$ ;;BRANCH IF NO
3183 013424 105037 013444 CLRB $CHARCNT ;;YES--CLEAR CHARACTER COUNT
3184 013430 000406 BR $TYPEX ;;EXIT
3185 013432 122766 000012 000002 1$: CMPB #LF,2(SP) ;;IS CHARACTER A LINE FEED?
3186 013440 001402 BEQ $TYPEX ;;BRANCH IF YES
3187 013442 105227 INCB (PC)+ ;;COUNT THE CHARACTER
3188 013444 000000 $CHARCNT: .WORD 0 ;;CHARACTER COUNT STORAGE
3189 013446 000207 $TYPEX: RTS PC
3190
3191 .SBTTL TTY INPUT ROUTINE
3192
3193 ;*****
3194 .ENABL LSB
3195
3196 ;*****
3197 ;*SOFTWARE SWITCH REGISTER CHANGE ROUTINE.
3198 ;*ROUTINE IS ENTERED FROM THE TRAP HANDLER, AND WILL
3199 ;*SERVICE THE TEST FOR CHANGE IN SOFTWARE SWITCH REGISTER TRAP CALL
3200 ;*WHEN OPERATING IN TTY FLAG MODE.
3201 013450 022737 000176 001140 $CKSWR: CMP #SWREG,SWR ;;IS THE SOFT-SWR SELECTED?
3202 013456 001074 BNE 15$ ;;BRANCH IF NO
3203 013460 105777 165460 TSTB @STKS ;;CHAR THERE?
3204 013464 100071 BPL 15$ ;;IF NO, DON'T WAIT AROUND
3205 013466 117746 165454 MOVB @STKB,-(SP) ;;SAVE THE CHAR
3206 013472 042716 177600 BIC #^C177,(SP) ;;STRIP-OFF THE ASCII
3207 013476 022726 000007 CMP #7,(SP)+ ;;IS IT A CONTROL G?
3208 013502 001062 BNE 15$ ;;NO, RETURN TO USER
3209 013504 123727 001134 000001 CMPB $AUTOB,#1 ;;ARE WE RUNNING IN AUTO-MODE?
3210 013512 001456 BEQ 15$ ;;BRANCH IF YES
3211
3212 013514 104401 014175 $GTSWR: TYPE $CNTLG ;;ECHO THE CONTROL-G (^G)
3213 013520 104401 014202 TYPE $MSWR ;;TYPE CURRENT CONTENTS
3214 013524 013746 000176 MOV SWREG,-(SP) ;;SAVE SWREG FOR TYPEDOUT
3215 013530 104402 TYPDC ;;GO TYPE--OCTAL ASCII(ALL DIGITS)
3216 013532 104401 014213 TYPE $MNEW ;;PROMPT FOR NEW SWR
3217 013536 005046 19$: CLR -(SP) ;;CLEAR COUNTER
3218 013540 005046 CLR -(SP) ;;THE NEW SWR
3219 013542 105777 165376 7$: TSTB @STKS ;;CHAR THERE?
3220 013546 100375 BPL 7$ ;;IF NOT TRY AGAIN
3221
3222 013550 117746 165372 MOVB @STKB,-(SP) ;;PICK UP CHAR
3223 013554 042716 177600 BIC #^C177,(SP) ;;MAKE IT 7-BIT ASCII
3224
3225
3226
3227 013560 021627 000025 9$: CMP (SP),#25 ;;IS IT A CONTROL-U?
3228 013564 001005 BNE 10$ ;;BRANCH IF NOT
3229 013566 104401 014170 TYPE $CNTLU ;;YES, ECHO CONTROL-U (^U)
3230 013572 062706 000006 20$: ADD #6,SP ;;IGNORE PREVIOUS INPUT
3231 013576 000757 BR 19$ ;;LET'S TRY IT AGAIN
3232
    
```

```

3233
3234 013600 021627 000015 10$: CMP (SP),#15 ;;IS IT A <CR>?
3235 013604 001022 BNE 16$ ;;BRANCH IF NO
3236 013605 005766 000004 TST 4(SP) ;;YES, IS IT THE FIRST CHAR?
3237 013612 001403 BEQ 11$ ;;BRANCH IF YES
3238 013614 016677 000002 165316 MOV 2(SP),@SWR ;;SAVE NEW SWR
3239 013622 062706 000006 11$: ADD #6,SP ;;CLEAR UP STACK
3240 013626 104401 001201 14$: TYPE ,$CRLF ;;ECHO <CR> AND <LF>
3241 013632 123727 001135 000001 $INTAG,#1 ;;RE-ENABLE TTY KBD INTERRUPTS?
3242 013640 001003 BNE 15$ ;;BRANCH IF NOT
3243 013642 012777 000100 165274 MOV #100,@$TKS ;;RE-ENABLE TTY KBD INTERRUPTS
3244 013650 000002 RTI ;;RETURN
3245 013652 004737 013400 16$: JSR PC,$TYPEC ;;ECHO CHAR
3246 013656 021627 000060 CMP (SP),#60 ;;CHAR < 0?
3247 013662 002420 BLT 18$ ;;BRANCH IF YES
3248 013664 021627 000067 CMP (SP),#67 ;;CHAR > ??
3249 013670 003015 BGT 18$ ;;BRANCH IF YES
3250 013672 042726 000060 BIC #60,(SP)+ ;;STRIP-OFF ASCII
3251 013676 005766 000002 TST 2(SP) ;;IS THIS THE FIRST CHAR
3252 013702 001403 BEQ 17$ ;;BRANCH IF YES
3253 013704 006316 ASL (SP) ;;NO, SHIFT PRESENT
3254 013706 006316 ASL (SP) ;; CHAR OVER TO MAKE
3255 013710 006316 ASL (SP) ;; ROOM FOR NEW ONE.
3256 013712 005266 000002 17$: INC 2(SP) ;;KEEP COUNT OF CHAR
3257 013716 056616 177776 BIS -2(SP),(SP) ;;SET IN NEW CHAR
3258 013722 000707 BR 7$ ;;GET THE NEXT ONE
3259 013724 104401 001200 18$: TYPE , $QUES ;;TYPE ?<CR><LF>
3260 013730 000720 BR 20$ ;;SIMULATE CONTROL-U
3261
3262
3263
3264
3265
3266
3267
3268
3269
3270
3271
3272 013732 011646 $RDCHR: MOV (SP),-(SP) ;;PUSH DOWN THE PC
3273 013734 016666 000004 000002 MOV 4(SP),2(SP) ;;SAVE THE PS
3274 013742 105777 165176 1$: TSTB @$TKS ;;WAIT FOR
3275 013746 100375 BPL 1$ ;;A CHARACTER
3276 013750 117766 165172 000004 MOVVB @$TKB,4(SP) ;;READ THE TTY
3277 013755 042766 177600 000004 BIC #'C<177>,4(SP) ;;GET RID OF JUNK IF ANY
3278 013764 026627 000004 000023 CMP 4(SP),#23 ;;IS IT A CONTROL-S?
3279 013772 001013 BNE 3$ ;;BRANCH IF NO
3280 013774 105777 165144 2$: TSTB @$TKS ;;WAIT FOR A CHARACTER
3281 014000 100375 BPL 2$ ;;LOOP UNTIL ITS THERE
3282 014002 117746 165140 MOVVB @$TKB,-(SP) ;;GET CHARACTER
3283 014006 042716 177600 BIC #'C<177>,(SP) ;;MAKE IT 7-BIT ASCII
3284 014012 022627 000021 CMP (SP)+,#21 ;;IS IT A CONTROL-Q?
3285 014016 001366 BNE 2$ ;;IF NOT DISCARD IT
3286 014020 000750 BR 1$ ;;YES, RESUME
3287 014022 026627 000004 000140 3$: CMP 4(SP),#140 ;;IS IT UPPER CASE?
3288 014030 002407 BLT 4$ ;;BRANCH IF YES
    
```

```

3289 014032 026627 000004 000175 CMP 4(SP),#175 ;;IS IT A SPECIAL CHAR?
3290 014040 003003 BGT 4$ ;;BRANCH IF YES
3291 014042 042766 000040 000004 BIC #40,4(SP) ;;MAKE IT UPPER CASE
3292 014050 000002 4$: RTI ;;GO BACK TO USER
3293
3294
3295
3296
3297
3298
3299
3300 014052 010346 $RDLIN: MOV R3,-(SP) ;;SAVE R3
3301 014054 012703 014160 1$: MOV #$TTYIN,R3 ;;GET ADDRESS
3302 014060 022703 014170 2$: CMP #$TTYIN+8,,R3 ;;BUFFER FULL?
3303 014064 101405 BLOS 4$ ;;BR IF YES
3304 014066 104407 RDCHR ;;GO READ ONE CHARACTER FROM THE TTY
3305 014070 112613 MOVVB (SP)+,(R3) ;;GET CHARACTER
3306 014072 122713 000177 10$: CMPB #177,(R3) ;;IS IT A RUBOUT
3307 014076 001003 BNE 3$ ;;SKIP IF NOT
3308 014100 104401 001200 4$: TYPE , $QUES ;;TYPE A '?'
3309 014104 000763 BR 1$ ;;CLEAR THE BUFFER AND LOOP
3310 014106 111337 014156 3$: MOVVB (R3),9$ ;;ECHO THE CHARACTER
3311 014112 104401 014156 TYPE ,9$
3312 014116 122723 000015 CMPB #15,(R3)+ ;;CHECK FOR RETURN
3313 014122 001356 BNE 2$ ;;LOOP IF NOT RETURN
3314 014124 105063 177777 CLRB -1(R3) ;;CLEAR RETURN (THE 15)
3315 014130 104401 001202 TYPE , $LF ;;TYPE A LINE FEED
3316 014134 012603 MOV (SP)+,R3 ;;RESTORE R3
3317 014136 011646 MOV (SP),-(SP) ;;ADJUST THE STACK AND PUT ADDRESS OF THE
3318 014140 016666 000004 000002 MOV 4(SP),2(SP) ;; FIRST ASCII CHARACTER ON IT
3319 014146 012766 014160 000004 MOV #$TTYIN,4(SP)
3320 014154 000002 RTI ;;RETURN
3321 014156 000 .BYTE 0 ;;STORAGE FOR ASCII CHAR. TO TYPE
3322 014157 000 .BYTE 0 ;;TERMINATOR
3323 014160 000010 $TTYIN: .BLKB B. ;;RESERVE B BYTES FOR TTY INPUT
3324 014170 052536 000 .ASCIZ /'U/<15><12> ;;CONTROL 'U'
3325 014175 136 006507 000012 $CNTLG: .ASCIZ /'G/<15><12> ;;CONTROL 'G'
3326 014202 005015 053523 020122 $MSWR: .ASCIZ <15><12>/SWR = /
3327 014210 020075 000
3328 014213 040 047040 $MNEW: .ASCIZ / NEW = /
3329 014220 036440 000040 .SBTTL READ AN OCTAL NUMBER FROM THE TTY
3330
3331
3332
3333
3334
3335
3336
3337
3338
3339
3340 014224 011646 $RDOCT: MOV (SP),-(SP) ;;PROVIDE SPACE FOR THE
3341 014226 016666 000004 000002 MOV 4(SP),2(SP) ;;INPUT NUMBER
3342 014234 010046 MOV R0,-(SP) ;;PUSH R0 ON STACK
3343 014236 010146 MOV R1,-(SP) ;;PUSH R1 ON STACK
3344 014240 010246 MOV R2,-(SP) ;;PUSH R2 ON STACK
    
```

```

3345 014242 104410      1$:  RDLIN          ;;READ AN ASCIZ LINE
3346 014244 012600      MOV   (SP)+,R0      ;;GET ADDRESS OF 1ST CHARACTER
3347 014246 005001      CLR   R1            ;;CLEAR DATA WORD
3348 014250 005002      CLR   R2
3349 014252 112046      2$:  MOVB   (R0)+,-(SP) ;;PICKUP THIS CHARACTER
3350 014254 001412      BEQ   3$           ;;IF ZERO GET OUT
3351 014256 006301      ASL   R1            ;;*2
3352 014260 006102      ROL   R2
3353 014262 006301      ASL   R1            ;;*4
3354 014264 006102      ROL   R2
3355 014266 006301      ASL   R1            ;;*8
3356 014270 006102      ROL   R2
3357 014272 042716 177770 BIC   #'C7,(SP)    ;;STRIP THE ASCII JUNK
3358 014276 062601      ADD   (SP)+,R1    ;;ADD IN THIS DIGIT
3359 014300 000764      BR    2$           ;;LOOP
3360 014302 005726      3$:  TST   (SP)+     ;;CLEAN TERMINATOR FROM STACK
3361 014304 010166      MOV   R1,12(SP)   ;;SAVE THE RESULT
3362 014310 010237 014324 MOV   R2,$HI OCT
3363 014314 012602      MOV   (SP)+,R2    ;;POP STACK INTO R2
3364 014316 012601      MOV   (SP)+,R1    ;;POP STACK INTO R1
3365 014320 012600      MOV   (SP)+,R0    ;;POP STACK INTO R0
3366 014322 000002      RTI
3367 014324 000000      $HI OCT: .WORD    0 ;;HIGH ORDER BITS GO HERE
    
```

```

3368                                     .SBTTL BINARY TO OCTAL (ASCII) AND TYPE
3369
3370                                     ;*****
3371                                     ;THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 6-DIGIT
3372                                     ;OCTAL (ASCII) NUMBER AND TYPE IT.
3373                                     ;*$TYPOS---ENTER HERE TO SETUP SUPPRESS ZEROS AND NUMBER OF DIGITS TO TYPE
3374                                     ;*CALL:
3375                                     ;*   MOV   NUM,-(SP)          ;;NUMBER TO BE TYPED
3376                                     ;*   TYPOS          ;;CALL FOR TYPEOUT
3377                                     ;*   .BYTE  N            ;;N=1 TO 6 FOR NUMBER OF DIGITS TO TYPE
3378                                     ;*   .BYTE  M            ;;M=1 OR 0
3379                                     ;*                                     ;;1=TYPE LEADING ZEROS
3380                                     ;*                                     ;;0=SUPPRESS LEADING ZEROS
3381                                     ;*
3382                                     ;*$TYPON----ENTER HERE TO TYPE OUT WITH THE SAME PARAMETERS AS THE LAST
3383                                     ;*$TYPOS OR $TYPOC
3384                                     ;*CALL:
3385                                     ;*   MOV   NUM,-(SP)          ;;NUMBER TO BE TYPED
3386                                     ;*   TYPON          ;;CALL FOR TYPEOUT
3387                                     ;*
3388                                     ;*$TYPOC---ENTER HERE FOR TYPEOUT OF A 16 BIT NUMBER
3389                                     ;*CALL:
3390                                     ;*   MOV   NUM,-(SP)          ;;NUMBER TO BE TYPED
3391                                     ;*   TYPOC          ;;CALL FOR TYPEOUT
3392
3393 014326 017646 000000      $TYPOS: MOV   @ (SP),-(SP)      ;;PICKUP THE MODE
3394 014332 116637 000001 014551 MOVB   1(SP),$OFILL    ;;LOAD ZERO FILL SWITCH
3395 014340 112637 014553      MOVB   (SP)+,$SOMODE+1 ;;NUMBER OF DIGITS TO TYPE
3396 014344 062716 000002      ADD   #2,(SP)        ;;ADJUST RETURN ADDRESS
3397 014350 000406      BR    $TYPON
3398 014352 112737 000001 014551 $TYPOC: MOVB   #1,$OFILL    ;;SET THE ZERO FILL SWITCH
3399 014360 112737 000006 014553      MOVB   #6,$SOMODE+1  ;;SET FOR SIX(6) DIGITS
3400 014366 112737 000005 014550 $TYPON: MOVB   #5,$SCNT     ;;SET THE ITERATION COUNT
3401 014374 010346      MOV   R3,-(SP)      ;;SAVE R3
3402 014376 010446      MOV   R4,-(SP)      ;;SAVE R4
3403 014400 010546      MOV   R5,-(SP)      ;;SAVE R5
3404 014402 113704 014553      MOVB   $SOMODE+1,R4 ;;GET THE NUMBER OF DIGITS TO TYPE
3405 014406 005404      NEG   R4
3406 014410 062704 000006      ADD   #6,R4         ;;SUBTRACT IT FOR MAX. ALLOWED
3407 014414 110437 014552      MOVB   R4,$SOMODE   ;;SAVE IT FOR USE
3408 014420 113704 014551      MOVB   $OFILL,R4    ;;GET THE ZERO FILL SWITCH
3409 014424 016605 000012      MOV   12(SP),R5     ;;PICKUP THE INPUT NUMBER
3410 014430 005003      CLR   R3            ;;CLEAR THE OUTPUT WORD
3411 014432 006105      1$:  ROL   R5           ;;ROTATE MSB INTO "C"
3412 014434 000404      BR    3$           ;;GO DO MSB
3413 014436 006105      2$:  ROL   R5           ;;FORM THIS DIGIT
3414 014440 006105      ROL   R5
3415 014442 006105      ROL   R5
3416 014444 010503      MOV   R5,R3
3417 014446 006103      3$:  ROL   R3           ;;GET LSB OF THIS DIGIT
3418 014450 105337 014552      DECB  $SOMODE       ;;TYPE THIS DIGIT?
3419 014454 100016      BPL   7$           ;;BR IF NO
3420 014456 042703 177770      BIC   #177770,R3    ;;GET RID OF JUNK
3421 014462 001002      BNE   4$           ;;TEST FOR 0
3422 014464 005704      TST   R4            ;;SUPPRESS THIS 0?
3423 014466 001403      BEQ   5$           ;;BR IF YES
    
```

```

3424 014470 005204      45:  INC  R4          ;;DON'T SUPPRESS ANYMORE 0'S
3425 014472 052703 000060      BIS  #'0,R3        ;;MAKE THIS DIGIT ASCII
3426 014476 052703 000040      55:  BIS  #' ,R3        ;;MAKE ASCII IF NOT ALREADY
3427 014502 110337 014546      MOV  R3,R8$       ;;SAVE FOR TYPING
3428 014506 104401 014546      TYPE ,R8$         ;;GO TYPE THIS DIGIT
3429 014512 105337 014550      7$:  DECB $OCNT     ;;COUNT BY 1
3430 014516 003347      BGT  2$           ;;BR IF MORE TO DO
3431 014520 002402      BLT  6$           ;;BR IF DONE
3432 014522 005204      INC  R4           ;;INSURE LAST DIGIT ISN'T A BLANK
3433 014524 000744      BR   2$          ;;GO DO THE LAST DIGIT
3434 014526 012605      65:  MOV  (SP)+,R5   ;;RESTORE R5
3435 014530 012604      MOV  (SP)+,R4     ;;RESTORE R4
3436 014532 012603      MOV  (SP)+,R3     ;;RESTORE R3
3437 014534 016666 000002 000004  MOV  2(SP),4(SP)  ;;SET THE STACK FOR RETURNING
3438 014542 012616      MOV  (SP)+,(SP)
3439 014544 000002      RTI              ;;RETURN
3440 014546 000      8$:  .BYTE 0        ;;STORAGE FOR ASCII DIGIT
3441 014547 000      .BYTE 0        ;;TERMINATOR FOR TYPE ROUTINE
3442 014550 000      $OCNT: .BYTE 0   ;;OCTAL DIGIT COUNTER
3443 014551 000      $OFILL: .BYTE 0  ;;ZERO FILL SWITCH
3444 014552 000000      $OMODE: .WORD 0  ;;NUMBER OF DIGITS TO TYPE
    
```

```

3445      .SBTTL TRAP DECODER
3446
3447      ;;*****
3448      ;;THIS ROUTINE WILL PICKUP THE LOWER BYTE OF THE "TRAP" INSTRUCTION
3449      ;;AND USE IT TO INDEX THROUGH THE TRAP TABLE FOR THE STARTING ADDRESS
3450      ;;OF THE DESIRED ROUTINE. THEN USING THE ADDRESS OBTAINED IT WILL
3451      ;;GO TO THAT ROUTINE.
3452
3453 014554 010046      $TRAP: MOV  R0,-(SP)  ;;SAVE R0
3454 014556 016600 000002  MOV  2(SP),R0       ;;GET TRAP ADDRESS
3455 014562 005740      TST  -(R0)         ;;BACKUP BY 2
3456 014564 111000      MOV  (R0),R0       ;;GET RIGHT BYTE OF TRAP
3457 014566 006300      ASL  R0            ;;POSITION FOR INDEXING
3458 014570 016000 014610  MOV  $TRPAD(R0),R0  ;;INDEX TO TABLE
3459 014574 000200      RTS  R0            ;;GO TO ROUTINE
3460
3461
3462      ;;THIS IS USE TO HANDLE THE "GETPRI" MACRO
3463
3464 014576 011646      $TRAP2: MOV  (SP)-,(SP)  ;;MOVE THE PC DOWN
3465 014600 016666 000004 000002  MOV  4(SP),2(SP)   ;;MOVE THE PSW DOWN
3466 014606 000002      RTI              ;;RESTORE THE PSW
3467
3468      .SBTTL TRAP TABLE
3469
3470      ;;*THIS TABLE CONTAINS THE STARTING ADDRESSES OF THE ROUTINES CALLED
3471      ;;BY THE "TRAP" INSTRUCTION.
3472
3473      ;      ROUTINE
3474      ;      -----
3475 014610 014576      $TRPAD: .WORD $TRAP2
3476 014612 013230      $TYPE  ;;CALL=TYPE TRAP+1(104401) TTY TYPEOUT ROUTINE
3477 014614 014352      $TYPOC ;;CALL=TYPOC TRAP+2(104402) TYPE OCTAL NUMBER (WITH LEADING ZEROS)
3478 014616 014326      $TYPOS ;;CALL=TYPOS TRAP+3(104403) TYPE OCTAL NUMBER (NO LEADING ZEROS)
3479 014620 014366      $TYPON ;;CALL=TYPON TRAP+4(104404) TYPE OCTAL NUMBER (AS PER LAST CALL)
3480
3481 014622 013520      $GTSWR ;;CALL=GTSWR TRAP+5(104405) GET SOFT-SWR SETTING
3482
3483 014624 013450      $CKSWR ;;CALL=CKSWR TRAP+6(104406) TEST FOR CHANGE IN SOFT-SWR
3484 014626 013732      $RDCHR ;;CALL=RDCHR TRAP+7(104407) TTY TYPEIN CHARACTER ROUTINE
3485 014630 014052      $RDLIN ;;CALL=RDLIN TRAP+10(104410) TTY TYPEIN STRING ROUTINE
3486 014632 014224      $RDOCT ;;CALL=RDOCT TRAP+11(104411) READ AN OCTAL NUMBER FROM TTY
3487 014634 010504      T.WFG  ;;CALL=WFG TRAP+12(104412) ROUTINE TO WRITE A FILE GAP
3488 014636 010554      T.WRIT ;;CALL=WRIT TRAP+13(104413) ROUTINE TO WRITE A BLOCK OF DATA
3489 014640 010774      T.READ  ;;CALL=READ TRAP+14(104414) ROUTINE TO READ A BLOCK OF DATA
3490 014642 011304      T.BSFG ;;CALL=BSFG TRAP+15(104415) ROUTINE TO BACK SPACE A FILE GAP
3491 014644 011366      T.BSBG ;;CALL=BSBG TRAP+16(104416) ROUTINE TO BACK SPACE A BLOCK GAP
3492 014646 011436      T.SFFG ;;CALL=SFFG TRAP+17(104417) ROUTINE TO SPACE FWD A FILE GAP
3493 014650 011520      T.SFBG ;;CALL=SFBG TRAP+20(104420) ROUTINE TO SPACE FWD A BLOCK GAP
3494 014652 011600      T.RWMD  ;;CALL=REWIND TRAP+21(104421) ROUTINE TO REWIND THE TAPE
3495 014654 010246      T.SELDRV ;;CALL=SELDRV TRAP+22(104422) ROUTINE TO SELECT THE NEXT DRIVE
3496 014656 010362      T.BLKCOMP ;;CALL=BLKCOMP TRAP+23(104423) COMPARE READ AND WRITE BUFFERS
3497 014660 010106      T.SETLOOP ;;CALL=SETLOOP TRAP+24(104424) SETUP TO LOOP AS PER THE TTY
    
```

```

3498 .SBTTL POWER DOWN AND UP ROUTINES
3499
3500 ;*****
3501 ;POWER DOWN ROUTINE
3502 014662 012737 015026 000024 $PWRDN: MOV #SILLUP,@#PWRVEC ;;SET FOR FAST UP
3503 014670 012737 000340 000026 MOV #340,@#PWRVEC+2 ;;PRIO:7
3504 014676 010046 MOV R0,-(SP) ;;PUSH R0 ON STACK
3505 014700 010146 MOV R1,-(SP) ;;PUSH R1 ON STACK
3506 014702 010246 MOV R2,-(SP) ;;PUSH R2 ON STACK
3507 014704 010346 MOV R3,-(SP) ;;PUSH R3 ON STACK
3508 014706 010446 MOV R4,-(SP) ;;PUSH R4 ON STACK
3509 014710 010546 MOV R5,-(SP) ;;PUSH R5 ON STACK
3510 014712 017746 164222 MOV @SWR,-(SP) ;;PUSH @SWR ON STACK
3511 014716 010637 015032 MOV SP,$SAVR6 ;;SAVE SP
3512 014722 012737 014734 000024 MOV #SPWRUP,@#PWRVEC ;;SET UP VECTOR
3513 014730 000000 HALT
3514 014732 000776 BR .-2 ;;HANG UP
3515
3516 ;*****
3517 ;POWER UP ROUTINE
3518 014734 012737 015026 000024 $PWRUP: MOV #SILLUP,@#PWRVEC ;;SET FOR FAST DOWN
3519 014742 013706 015032 MOV $SAVR6,SP ;;GET SP
3520 014746 005037 015032 CLR $SAVR6 ;;WAIT LOOP FOR THE TTY
3521 014752 005237 015032 15: INC $SAVR6 ;;WAIT FOR THE INC
3522 014756 001375 BNE 15 ;;OF WORD
3523 014760 012677 164154 MOV (SP)+,@SWR ;;POP STACK INTO @SWR
3524 014764 012605 MOV (SP)+,R5 ;;POP STACK INTO R5
3525 014766 012604 MOV (SP)+,R4 ;;POP STACK INTO R4
3526 014770 012603 MOV (SP)+,R3 ;;POP STACK INTO R3
3527 014772 012602 MOV (SP)+,R2 ;;POP STACK INTO R2
3528 014774 012601 MOV (SP)+,R1 ;;POP STACK INTO R1
3529 014776 012600 MOV (SP)+,R0 ;;POP STACK INTO R0
3530 015000 012737 014662 000024 MOV #SPWRDN,@#PWRVEC ;;SET UP THE POWER DOWN VECTOR
3531 015006 012737 000340 000026 MOV #340,@#PWRVEC+2 ;;PRIO:7
3532 015014 104401 TYPE REPORT THE POWER FAILURE
3533 015016 015034 $PWRMG: .WORD $POWER ;;POWER FAIL MESSAGE POINTER
3534 015020 012716 MOV (PC)+,(SP) ;;RESTART AT PWRST
3535 015022 002300 $PWRAD: .WORD PWRST ;;RESTART ADDRESS
3536 015024 000002 RTI
3537 015026 000000 $ILLUP: HALT ;;THE POWER UP SEQUENCE WAS STARTED
3538 015030 000776 BR .-2 ;; BEFORE THE POWER DOWN WAS COMPLETE
3539 015032 000000 $SAVR6: 0 ;;PUT THE SP HERE
3540 015034 005015 047520 042527 $POWER: .ASCIZ <15><12>"POWER"
3541 015042 000122 .EVEN
3542
    
```

```

3543 ;*****
3544 ;DATA POINTERS
3545
3546
3547 015044 001204 001116 001162 DT1: .WORD SAVPC,$ERRPC,$REG0,$REG1,0
3548 015052 001164 000000
3549
3550 015056 001204 001116 001162 DT2: .WORD SAVPC,$ERRPC,$REG0,$GDDAT,$BDDAT,BYTNUM,0
3551 015064 001124 001126 001206
3552 015072 000000
3553
3554 015074 001204 001116 001162 DT3: .WORD SAVPC,$ERRPC,$REG0,RCRC0,RCRC1,RCRC2,0
3555 015102 001210 001212 001214
3556 015110 000000
3557
3558 015112 001204 001116 001162 DT4: .WORD SAVPC,$ERRPC,$REG0,$REG1,$TMP0,0
3559 015120 001164 001166 000000
3560
3561 015126 001204 001116 001162 DT5: .WORD SAVPC,$ERRPC,$REG0,0
3562 015134 000000
3563
    
```



```
3564 ;*****
3565 ;
3566 ;MESSAGES
3567
3568 015136 042200 044522 042526 MSGDRV: .ASCIZ <CRLF>"DRIVE(S)? "
3569 015144 051450 037451 000040
3570 015152 005015 040524 051503 MSGASK: .ASCIZ <15><12>/TACS?/
3571 015160 000077
3572 015162 042526 052103 051117 MSGVEC: .ASCIZ /VECTOR?/
3573 015170 000077
3574 015172 051120 047511 044522 MSGPRI: .ASCIZ /PRIORITY?/
3575 015200 054524 000077
3576 015204 052040 041501 036523 MTACS: .ASCIZ / TACS=/
3577 015212 000
3578 015213 040 040524 041104 MTADB: .ASCIZ / TADB=/
3579 015220 000075
3580 015222 053040 041505 047524 MTAVEC: .ASCIZ / VECTOR=/
3581 015230 036522 000
3582 015233 040 051120 047511 MTAPRI: .ASCIZ / PRIORITY=/
3583 015240 044522 054524 000075
3584 015246 005015 045517 000077 MSGDK: .ASCIZ <15><12>/QK?/
3585 015254 042531 100123 000 MYES: .ASCIZ /YES/<CRLF>
3586 015261 015 052012 051505 MTSTDRV: .ASCIZ <15><12>/TESTING DRIVE /
3587 015266 044524 043516 042040
3588 015274 044522 042526 000040
3589 015302 040440 042116 042040 MANDRV: .ASCIZ / AND DRIVE /
3590 015310 044522 042526 000040
3591 015316 005015 042524 052123 MTEST: .ASCIZ <15><12>/TEST PC?/
3592 015324 050040 037503 000
3593 015331 015 046012 047517 MLOOP: .ASCIZ <15><12>/LOOP PC?/
3594 015336 020120 041520 000077
3595 015344 042522 044527 042116 MXRWND: .ASCIZ /REWIND/
3596 015352 000
3597 015353 127 044522 042524 MXWRIT: .ASCIZ /WRITE/
3598 015360 000
3599 015361 122 040505 000104 MXREAD: .ASCIZ /READ/
3600 015366 050123 041501 026505 MXSFFG: .ASCIZ /SPACE-FWD-FILE-GAP/
3601 015374 053506 026504 044506
3602 015402 042514 043455 050101
3603 015410 000
3604 015411 123 040520 042503 MXSFBG: .ASCIZ /SPACE-FWD-BLK-GAP/
3605 015416 043055 042127 041055
3606 015424 045514 043455 050101
3607 015432 000
3608 015433 102 041501 026513 MXBSFG: .ASCIZ /BACK-SPACE-FILE-GAP/
3609 015440 050123 041501 026505
3610 015446 044506 042514 043455
3611 015457 050101 000
3612 015457 102 041501 026513 MXBSBG: .ASCIZ /BACK-SPACE-BLK-GAP/
3613 015464 050123 041501 026505
3614 015472 046102 026513 040507
3615 015500 000120
3616 015502 051127 052111 026505 MXWFG: .ASCIZ /WRITE-FILE-GAP/
3617 015510 044506 042514 043455
3618 015516 050101 000
3619 015521 102 043125 042506 MBUFCK: .ASCIZ /BUFFER COMPARE/
```

```
3620 015526 020122 047503 050115
3621 015534 051101 000105
3622 015540 045511 051120 050117 EM1: .ASCIZ /IMPROPER FLAG SETTING/
3623 015546 051105 043040 040514
3624 015554 020107 042523 052124
3625 015562 047111 000107
3626 015566 046511 051120 050117 EM2: .ASCIZ /IMPROPER FLAG OCCURRED/
3627 015574 051105 043040 040514
3628 015602 020107 041517 052503
3629 015610 051122 042105 000
3630 015615 115 051511 042523 EM3: .ASCIZ /MISSED A FLAG/
3631 015622 020104 020101 046106
3632 015630 043501 000
3633 015633 111 052116 051105 EM4: .ASCIZ /INTERRUPT FAILED/
3634 015640 052522 052120 043040
3635 015646 044501 042514 000104
3636 015654 051120 046505 052101 EM5: .ASCIZ /PREMATURE READY OCCURRED/
3637 015662 051125 020105 042522
3638 015670 042101 020131 041517
3639 015676 052503 051122 042105
3640 015704 000
3641 015705 104 042111 023516 EM6: .ASCIZ /DIDN'T STOP IN A FILE GAP/
3642 015712 020124 052123 050117
3643 015720 044440 020116 020101
3644 015726 044506 042514 043440
3645 015734 050101 000
3646 015737 104 042111 023516 EM7: .ASCIZ /DIDN'T STOP ON CLEAR LEADER/
3647 015744 020124 052123 050117
3648 015752 047440 020116 046103
3649 015760 040505 020122 042514
3650 015766 042101 051105 000
3651 015773 102 042101 042040 EM10: .ASCIZ /BAD DATA READ/
3652 016000 052101 020101 042522
3653 016006 042101 000
3654 016011 111 046114 043505 EM11: .ASCIZ /ILLEGAL BUFFER SIZE/
3655 016016 046101 041040 043125
3656 016024 042506 020122 044523
3657 016032 042532 000
3658 016035 103 041522 042440 EM12: .ASCIZ /CRC ERROR/
3659 016042 051122 051117 000
3660 016047 123 047510 052122 EM13: .ASCIZ /SHORT RECORD/
3661 016054 051040 041505 051117
3662 016062 000104
3663 016064 040502 020104 047111 EM14: .ASCIZ /BAD INTERRUPT/
3664 016072 042524 051122 050125
3665 016100 000124
3666 016102 005015 DH1: .ASCIZ <15><12>
3667 016104 042524 052123 020040 .ASCIZ /TEST ERROR/<15><12>
3668 016112 020040 051105 047522
3669 016120 006522 012
3670 016123 120 020103 020040 .ASCIZ /PC PC TACS TADB/<15><12>
3671 016130 020040 050040 020103
3672 016136 020040 020040 052040
3673 016144 041501 020123 020040
3674 016152 052040 042101 006502
3675 016160 000012
```



```

3752
3753 ;BUFFER LINKS
3754 ;THESE LINKS POINT TO THE STARTING ADDRESS OF THE BUFFERS
3755 ;AND ALSO INDICATE HOW MANY BYTES TO READ OR WRITE
3756
3757 016756 017120 000200 RLNK1: RBUF1,128.
3758 016762 017322 000200 RLNK2: RBUF2,128.
3759 016766 017524 000010 RLNK3: RBUF3,8.
3760 016772 017726 000040 RLNK4: RBUF4,32.
3761 016776 020130 000020 RLNK5: RBUF5,16.
3762 017002 020332 000100 RLNK6: RBUF6,64.
3763 017006 017120 000000 RLNKX: RBUF1,0
3764 017012 017046 000200 WLNK1: WBUF1,128.
3765 017016 017054 000200 WLNK2: WBUF2,128.
3766 017022 017062 000010 WLNK3: WBUF3,8.
3767 017026 017070 000040 WLNK4: WBUF4,32.
3768 017032 017076 000020 WLNK5: WBUF5,16.
3769 017036 017104 000100 WLNK6: WBUF6,64.
3770 017042 017112 000000 WLNKX: WBUF6,0
3771
3772 ;BUFFERS
3773
3774 017046 000002 WBUF1:
3775 017046 314 .BYTE ^B11001100
3776 017047 063 .BYTE ^B00110011
3777 017050 314 .BYTE ^B11001100
3778 017051 063 .BYTE ^B00110011
3779 017052 000000 WCRC1: .WORD 0 ;CRC STORAGE FOR WBUF1
3780
3781 017054 000002 WBUF2:
3782 017054 377 .BYTE ^B11111111
3783 017055 000 .BYTE ^B00000000
3784 017056 377 .BYTE ^B11111111
3785 017057 000 .BYTE ^B00000000
3786 017060 000000 WCRC2: .WORD 0 ;CRC STORAGE FOR WBUF2
3787
3788 017062 000002 WBUF3:
3789 017062 231 .BYTE ^B10011001
3790 017063 146 .BYTE ^B01100110
3791 017064 231 .BYTE ^B10011001
3792 017065 146 .BYTE ^B01100110
3793 017066 000000 WCRC3: .WORD 0 ;CRC STORAGE FOR WBUF3
3794
3795 017070 000002 WBUF4:
3796 017070 360 .BYTE ^B11110000
3797 017071 017 .BYTE ^B00001111
3798 017072 360 .BYTE ^B11110000
3799 017073 017 .BYTE ^B00001111
3800 017074 000000 WCRC4: .WORD 0 ;CRC STORAGE FOR WBUF4
3801
3802 017076 000002 WBUF5:
3803 017076 252 .BYTE ^B10101010
3804 017077 125 .BYTE ^B01010101
3805 017100 252 .BYTE ^B10101010
3806 017101 125 .BYTE ^B01010101
3807 017102 000000 WCRC5: .WORD 0 ;CRC STORAGE FOR WBUF5
    
```

```

3808
3809 017104 000001 WBUF6:
3810 017104 377 .BYTE ^B11111111
3811 017105 377 .BYTE ^B11111111
3812 017106 000 .BYTE ^B00000000
3813 017107 000 .BYTE ^B00000000
3814 017110 000000 WCRC6: .WORD 0 ;CRC STORAGE FOR WBUF6
3815
3816 017112 000004 WBUF7:
3817 017112 000 .BYTE 0
3818 017113 000 .BYTE 0
3819 017114 000 .BYTE 0
3820 017115 000 .BYTE 0
3821 017116 000000 WCRCX: .WORD 0
3822
3823
3824 017120 000202 RBUF1: .BLKB 130.
3825 017322 000202 RBUF2: .BLKB 130.
3826 017524 000202 RBUF3: .BLKB 130.
3827 017726 000202 RBUF4: .BLKB 130.
3828 020130 000202 RBUF5: .BLKB 130.
3829 020332 000202 RBUF6: .BLKB 130.
3830
3831 020534 LASTADDRESS=
3832
3833 000001 .END
    
```


T.SETL	010246	2465#	3495														
T.SETL	010106	2428#	2439	3497													
T.SFBG	011520	2705#	3493														
T.SFFG	011436	2684#	3492														
T.WFG	010504	2519#	3487														
T.WRIT	010554	2534#	3488														
UNIT =	000400	786#	2107	2473	2476												
WAITFL	011716	2524	2547	2571	2597	2630	2653	2674	2689	2710	2738	2759#					
WAITKE	001254	894#	2550*	2600*	2764*	2773	2870*	2888*									
WBUF	017112	3110	3770	3816#													
WBUF1	017046	3764	3774#														
WBUF2	017054	3765	3781#														
WBUF3	017062	3766	3788#														
WBUF4	017070	3767	3795#														
WBUF5	017076	3768	3802#														
WBUF6	017104	3769	3809#														
WCRCX	017116	3821#															
WCRC1	017052	3779#															
WCRC2	017060	3786#															
WCRC3	017066	3793#															
WCRC4	017074	3800#															
WCRC5	017102	3807#															
WCRC6	017110	3814#															
WFG =	104412	1241	1267	1573	1587	1606	1626	1641	1657	1674	1693	1713	1732	1752			
		1771	1787	1809	1811	1813	1830	1832	1851	1884	1886	1888	1910	1913			
		1916	1939	1942	1981	1984	1987	2013	2015	2017	2019	2021	2023	2927			
		3009	3487#														
WFGSUB	012364	818	2916#	2922	2931												
WGBLOP	012614	3000#	3004	3016													
WGPBLK	012610	821	2999#														
WLNKX	017042	2955	2983	3012	3041	3103*	3770#										
WLNK1	017012	1292	1297	1305	1310	1318	1323	1331	1336	1341	1349	1354	1359	1367			
		1374	1382	1387	1401	1416	1423	1431	1446	1462	1477	1484	1515	1527			
		1532	1560	1572	1578	1586	1592	1600	1605	1620	1625	1640	1656	1665			
		1673	1692	1712	1723	1731	1743	1751	1762	1770	1778	1786	1795	1808			
		1828	1847	1865	1883	1908	1936	1956	1961	1979	2012	2055	2586	3764#			
WLNK2	017016	1388	1393	1402	1408	1417	1432	1438	1447	1454	1463	1469	1478	1488			
		1504	1509	1519	1533	1538	1607	1612	1627	1632	1642	1646	1658	1675			
		1684	1694	1714	1733	1753	1772	1788	1800	1810	1829	1848	1866	1885			
		1900	1909	1937	1980	2014	3765#										
WLNK3	017022	1490	1495	1554	1564	1676	1695	1734	1812	1820	1831	1839	1852	1857			
		1869	1875	1887	1911	1938	1966	1982	1999	2016	2048	3766#					
WLNK4	017026	1497	1502	1540	1545	1696	1704	1912	1940	1950	1971	1983	2018	3767#			
WLNK5	017032	1547	1552	1914	1923	1928	1941	1985	2004	2020	2041	3768#					
WLNK6	017036	1915	1986	2022	2035	3769#											
WLODP	012444	2946#	2950	2959													
WRITE =	104413	1292	1305	1318	1331	1349	1367	1382	1388	1401	1402	1416	1417	1431			
		1432	1446	1447	1462	1463	1477	1478	1490	1497	1504	1527	1533	1540			
		1547	1554	1572	1586	1600	1607	1620	1627	1640	1642	1656	1656	1673			
		1675	1676	1692	1694	1695	1696	1712	1714	1731	1733	1734	1751	1753			
		1770	1772	1786	1788	1808	1810	1812	1828	1829	1831	1847	1848	1852			
		1865	1866	1869	1883	1885	1887	1908	1909	1911	1912	1914	1915	1936			
		1937	1938	1940	1941	1979	1980	1982	1983	1985	1986	2012	2014	2016			
		2018	2020	2022	2955	3012	3488#										
WRTLOC=	010000	782#	2114	2638													
WRTSUB	012440	819	2945#														

XBSBG =	000010	773#	2672														
XBSFG =	000006	772#	2651														
XREAD =	000004	771#	2594	2627													
XRWND =	000016	776#	1239	1265	2736	2924	2952	2974	3006	3032	3062						
XSFBSG =	000014	775#	2708														
XSFFG =	000012	774#	2687														
XWFG =	000000	769#	1249	2522													
XWRITE =	000002	770#	2545	2569													
XAUTDB	001134	851#	1087*	3209	3330												
XBADDR	001122	846#															
XBDDAT	001126	848#	2513*	3550													
XBELL	001174	871#	2227	2253													
XCHARC	013444	3157*	3167*	3174	3183*	3188#											
XCKSWR	013450	3201#	3483														
XCMTAG	001100	834#	1036	1037	1045	1051	1052	1053									
SCM1 =	000002	866#	867#	868#													
SCM2 =	000004	866#	867#	868#													
SCM3 =	000002	864#	866														
SCM4 =	000001	868#	869#														
SCNTLG	014175	3212	3325#														
SCNTLU	014170	3229	3324#														
SCRLF	001201	873#	2235	2253	2255	2258	2277	3156	3191	3240	3324						
SDDAGN	006442	2074	2081	2087#													
SENDAD	006432	1077	1142	1192	1282	2083#	2248										
SENDCT	006406	1051	2076#														
SENDMG	006451	2078	2091#														
SENULL	006446	2079	2090#														
SEOP	006352	2009	2066#														
SEOPCT	006400	1051*	2073#	2077													
SERFLG	001103	837#	2130	2163	2165	2171*	2191	2222*	2253	2485*							
SERMAX	001115	843#	1054*	2165	2187*	2191											
SERROR	007046	1045	2205#														
SERRPC	001116	845#	2229*														
SERRTB	001270	913#	2266	2230*	2231	2253	3547	3550	3554	3558	3561	3735	3737				
SERTTL	001112	841#	2228*	2253													
SESCAP	001172	870#	1053*	1236*	1289*	1302*	1315*	1328*	1346*	1364*	1379*	1398*	1413*	1428*			
		1443*	1459*	1474*	1524*	1589*	1583*	1597*	1617*	1637*	1653*	1670*	1689*	1709*			
		1728*	1748*	1767*	1783*	1805*	1825*	1844*	1862*	1880*	1905*	1933*	1976*	2009*			
		2186*	2220*	2244	2246	2253	2617	2618*	2622*	3079*							
		862#	3160	3191													
\$FILLC	001156	861#	3191														
\$FILLS	001155	845#															
\$GDADR	001120	847#	2515*	3550													
\$GDDAT	001124	2080#															
\$GET42	006422	3213#	3481														
\$GTSWR	013520	592															
\$HD =	000000	3362*	3367#														
\$HI OCT	014324	838#	2178*	2179	2181*	2191											
\$ICNT	001104	3502	3518	3537#													
\$ILLUP	015026	852#	3241														

\$MNEW 014213	3216	3328#																	
\$MSWR 014202	3213	3326#																	
\$MXCNT 001216	882#	1207*	1219*	2182	2191														
\$NULL 001154	860#	3162	3191																
\$NWTST= 000001	1285#	1298#	1311#	1324#	1342#	1360#	1375#	1394#	1409#	1424#	1439#	1455#	1470#						
	1520#	1565#	1579#	1593#	1613#	1633#	1649#	1666#	1685#	1705#	1724#	1744#	1763#						
	1779#	1801#	1821#	1840#	1858#	1876#	1901#	1929#	1972#	2005#									
\$OCNT 014550	3400#	3429*	3442#																
\$OMODE 014552	3395*	3399*	3404	3407*	3418*	3444#													
\$OVER 007032	2148	2150	2170	2183	2188#														
\$PASS 001100	835#	1229	2070*	2071*	2090	2176	2191												
\$POWER 015034	3533	3540#																	
\$PWRAD 015022	3535#																		
\$PWRDN 014662	1049	3502#	3530																
\$PWRMG 015016	3533#																		
\$PWUP 014734	3512	3518#																	
\$QUES 001200	872#	2253	2319	2384	3191	3259	3308	3324											
\$RDCHR 013732	3272#	3484																	
\$RDDEC= ***** U	3497																		
\$RDLIN 014052	3300#	3485																	
\$RDDCT 014224	3340#	3486																	
\$RDSZ = 000010	3293#																		
\$REGAD 001160	864#																		
\$REGO 001162	866#	2207*	2216	3547	3550	3554	3558	3561											
\$REG1 001164	867#	2208*	3547	3558															
\$RTNAD 006444	2089#																		
\$R2A = ***** U	3487																		
\$SAVRE= ***** U	3487																		
\$SAVR6 015032	3511*	3519	3520*	3521*	3539#														
\$SCOPE 006570	1043	2138#																	
\$SETUP= 000137	1022#	1042	1043	1045	1047	1049	1051	1052	1053	1055	1077	1080	2068						
	2139	2206	2240	2248	3196	3330													
\$SS = 000000	1285#																		
\$STUP = 177777	1022#																		
\$SVLAD 007004	2158	2183#																	
\$SWR = 167000	582#	592	642	643	644	645	646	647	648	869	870	871	1052						
	1053	1055	1056	1289	1302	1315	1328	1346	1364	1379	1398	1413	1428						
	1443	1459	1474	1524	1569	1583	1597	1617	1637	1653	1670	1689	1709						
	1728	1748	1767	1783	1805	1825	1844	1852	1880	1905	1933	1976	2009						
	2061	2069	2082	2088	2090	2131	2132	2133	2134	2135	2149	2161	2163						
	2164	2165	2172	2173	2174	2185	2188	2191	2197	2198	2199	2200	2201						
	2225	2232	2237	2241	2253	2483	3536												
\$SWRMK= 000000	2135																		
\$TIMES 001170	869#	1052*	2069*	2172*	2179	2182*	2191												
\$TKB 001146	857#	3194	3205	3222	3276	3282													
\$TKS 001144	856#	2140	3194	3203	3219	3243*	3274	3280											
\$TMPO 001166	868#	2615*	3558																
\$TN = 000045	582#	592	1285	1289#	1298	1302#	1311	1315#	1324	1328#	1342	1346#	1360						
	1366#	1375	1379#	1394	1398#	1409	1413#	1424	1428#	1439	1443#	1455	1459#						
	1470	1474#	1520	1524#	1565	1569#	1579	1583#	1593	1597#	1613	1617#	1633						
	1637#	1649	1653#	1666	1670#	1685	1689#	1705	1709#	1724	1728#	1744	1748#						
	1763	1767#	1779	1783#	1801	1805#	1821	1825#	1840	1844#	1858	1862#	1876						
	1880#	1901	1905#	1929	1933#	1972	1976#	2005	2009#										
\$TPB 001152	859#	3180*	3191																
\$TPFLG 001157	863#	3138	3191																
\$TPS 001150	858#	3178	3191																

\$TRAP 014554	1047	3453#																	
\$TRAP2 014576	3464#	3475																	
\$TRP = 000025	3468#	3477#	3478#	3479#	3480#	3481	3482#	3483	3484#	3485#	3486#	3487#	3488#						
	3489#	3490#	3491#	3492#	3493#	3494#	3495#	3496#	3497#	3498#									
\$TRPAD 014610	3458	3475#																	
\$TSTNM 001102	836#	1205*	2068*	2130	2183*	2188	2191	2224	2253										
\$TTYIN 014160	3301	3302	3319	3323#															
\$TYPBN= ***** U	3480																		
\$TYPDS= ***** U	3480																		
\$TYPE 013230	3138#	3468	3476																
\$TYPEC 013400	3159	3166	3173	3178#	3179	3245													
\$TYPEX 013446	3184	3186	3189#																
\$TYPC 014352	3398#	3477																	
\$TYPCN 014366	3397	3400#	3479																
\$TYPCN 014366	3393#	3478																	
\$TYPOS 014326	2152#																		
\$XTSTR 006530	2082#																		
\$SET4= 000000	3394*																		
\$FILL 014551	2149	3398*	3408	3443#															
\$OCAT= ***** U	806#	810#	833#	875	1040	1055	1056	2090	2093	2191	2253	2288#	3191						
. = 020534	3194	3323#	3324	3330	3514	3538	3734#	3824#	3825#	3826#	3827#	3828#	3829#						
	3831																		

. ABS. 020534 000

ERRORS DETECTED: 0

DSKZ: CZTADD, DSKZ: CZTADD, SEQ=DSKZ: CZTADD.P11
 RUN-TIME: 20 14 1 SECONDS
 RUN-TIME RATIO: 213/36=5.8
 CORE USED: 23K (45 PAGES)

DOCUMENT PAGES: 97