

# **MB86290 Series Graphics Driver Users Manual Rev.2.3**

---

1. The contents of this document are subject to change without notice. Therefore, please confirm that information given in this document is the newest in Fujitsu Limited sales representatives in the case of using.
2. Fujitsu Limited is unable to assume responsibility for infringement of any patent rights or other rights of third parties arising from the use of this information or figures.
3. No part of the publication may be copied reproduced in any form or by any means, or transferred to any third party without prior written consent of Fujitsu Limited.
4. If any products described in this document represent goods or technologies subject to certain restrictions on export under the Foreign Exchange and Foreign Trade Law of Japan, the prior authorization by Japanese government will be required for export of those products from Japan.

<b>Revision history</b>			
Date	Rev.	Page	Change
Feb. 23,2000	1.0	87	(1)First release
May 18, 2001	1.3	116	(1)Adds API for object coordinates (for MB86291) (2)Adds API for video capture (for MB86291) (3)Adds API for I <sup>2</sup> C control (for MB86291S)
Jun. 18, 2001	1.4	118	(1)Adds GdcCapSetLPFMode command (2)The number of transmission byte is set as the return value of GdcFlush, GdcSync, GdcVFlush, and GdcVSync (3)Adds GdcVerticalSync command
Aug. 15, 2001	1.5	113	(1)Deletes GdcGeoSync,GdcGeoInterrupt,GdcGeoGetFIFOStatus,GdcGetGetFIFORe- main,GdcGeoGetFIFOErrorStatus,andGdcGeoClearFIFOErrorStatus command
Sept. 13, 2001	1.6	113	(1)Adds argument (gdc_type) to the GdcGeoInitialize command

(Revision history:1/3)

<b>Revision history</b>			
Date	Rev.	Page	Change
June, 13, 2002	1.7	169	<p>(1) Adds GDC_TYPE_MB86291A macro to appoint with an argument of the GdcGeoInitialize command</p> <p>(2) Changes the font</p> <p>(3) Adds commands for MB86293</p> <p>(4) Adds the GdcClipMode command, and delete the GdcSetAttrMisc command of the same function</p> <p>(5) Added argument (gdc_type) to the GdcInitialize command</p> <p>(6) Deleted argument (gdc_type) from the GdcGeoInitialize command</p> <p>(7) Changed argument name (dma_request) of the GdcSetDMAMode command</p> <p>(8) Added the GdcCancelDisplayList command</p> <p>(9) Added a drawing order control mode setting function of main / border / shadow primitive to the GdcGeoSetAttrLine command</p> <p>(10) Changed a sentence of notes</p> <p>(11) Updated by an abstract description of the "Graphics Driver"</p> <p>(12) Added a description of the GdcCapSetVideoCaptureScale command</p> <p>(13) Updated from GDC_COL32 to GDC_COLOR32 by a type description of an argument used with the following commands</p> <ul style="list-style-type: none"> <li>- GdcColorTransparent command</li> <li>- GdcColor command</li> <li>- GdcBackColor command</li> <li>- GdcGeoShadowColor command</li> <li>- GdcGeoShadowBackColor command</li> <li>- GdcGeoBorderColor command</li> <li>- GdcGeoBorderBackColor command</li> </ul> <p>(14) Deleted the GdcColorI command and the GdcBackColorI command (8 bits and 16 bits color can be set by the GdcColor and the GdcBackColor respectively)</p> <p>(15) Changed a type of an argument used with the following commands from the GDC_COL16 to the GDC_COLOR32</p> <ul style="list-style-type: none"> <li>- GdcSetTextureBorder command</li> <li>- GdcBlitColorTransparent command</li> </ul> <p>(16) Because could clear a Display List FIFO error only by reset, deleted the GdcClearFIFOErrorStatus command</p>

<b>Revision history</b>			
<b>Date</b>	<b>Rev.</b>	<b>Page</b>	<b>Change</b>
June, 13, 2002	1.7	169	(17)The following commands used in order to delete the GdcSync and a GdcVSync command and to check drawing end instead are added. <ul style="list-style-type: none"> <li>- GdcGetPixelEngineStatus</li> <li>- GdcGeoGetPixelEngineStatus</li> <li>- GdcGetLocalDisplayListTransferStatus</li> </ul>
June, 27, 2002	2.3	171	(1)Description of GdcGeoLoadMatrix command is corrected.

(Revision history:3/3)

# Introduction

## \*A purpose and a target reader of this document

This document describes the mechanisms of MB86290 Series Graphics Driver (the “Graphics Driver”) and application interfaces.

This document is written for an engineer developing a graphics application using the “Graphics Driver”.

A description of this document has premised the reader who has understood specification of MB86290 Series Graphics Controller (the “Graphics Controller”) and technology about graphics.

If needed refer to the specification of Graphics Controller, or graphics-related books.

## \*Graphics-related technology which will be the requisite for an understanding of this document

Device coordinate system, object coordinate system, coordinate transformation, conversion matrix, clipping, polygon, shading, Z-buffer method, shade surface elimination, texture mapping, tiling, anti-aliasing, alpha blending, chrome-key composition, palette color, etc.

## \*Specifications of the “Graphics Controller”

For hardware specifications of the “Graphics Controller” and programming, refer to the following documents.

- Graphics Controller Specifications
- Application Note

These documents are prepared for every “Graphics Controller”.

Each “Graphics Controller” and document names are described in the table 1.

Table 1. List of documents

Graphics Controller	Document title
MB86290A	MB86290A Graphics Controller Hardware Specifications
	Cremson Application Note
MB86291/86291S	MB86291 <SCARLET> Graphics Controller Specifications
	MB86291 <SCARLET> Application Note
	I <sup>2</sup> C Interface Specification
MB86291A	MB86291A <SCARLET2> Graphics Controller Specifications
	MB86291 <SCARLET> Application Note
MB86292/86292S	MB86292 <ORCHID> Graphics Controller Specifications
	MB86292 <ORCHID> Application Note
	I <sup>2</sup> C Interface Specification
MB86293	MB86293 <CORAL-LQ> Graphics Controller Specifications

A specific “Graphics Controller” group may be shown as follows in this document.

MB86291 or later : MB86291/86291S/86291A/86292/86292S/86293 Graphics Controller

MB86291/86292 : MB86291/86291S/86291A/86292/86292S Graphics Controller

MB86293 or later : MB86293 Graphics Controller or later

# Index

<b>1 MB86290 SERIES GRAPHICS DRIVER OVERVIEW .....</b>	<b>1</b>
<b>1.1 OVERVIEW .....</b>	<b>1</b>
<b>2 OPERATION OF MB86290 SERIES GRAPHICS DRIVER .....</b>	<b>2</b>
<b>2.1 RENDERING SCHEME .....</b>	<b>2</b>
<b>2.2 MANAGEMENT OF DISPLAY LIST.....</b>	<b>3</b>
<b>2.3 TRANSFER OF DISPLAY LIST .....</b>	<b>5</b>
2.3.1 Methods of Display List transfer .....	5
2.3.2 Trigger of Display List transfer.....	5
<b>2.4 SYNC MODE AND ASYNC MODE .....</b>	<b>6</b>
<b>2.5 SYSTEM DEPENDENT COMMANDS .....</b>	<b>7</b>
<b>3 FOR APPLICATION PROGRAM DEVELOPMENT .....</b>	<b>9</b>
<b>3.1 MANDATORY OPERATIONS.....</b>	<b>9</b>
3.1.1 Header files .....	9
3.1.2 Gets Display List buffer.....	9
3.1.3 Creates system dependent commands .....	9
<b>3.2 REMINDER.....</b>	<b>10</b>
3.2.1 Prohibition of re-entrant .....	10
<b>4 DRIVER COMMANDS .....</b>	<b>11</b>
<b>4.1 SYSTEM CONTROL COMMANDS.....</b>	<b>12</b>
<b>4.2 DISPLAY COMMANDS.....</b>	<b>14</b>
<b>4.3 COLOR CONTROL COMMANDS .....</b>	<b>15</b>
<b>4.4 CURSOR CONTROL COMMANDS .....</b>	<b>16</b>
<b>4.5 DRAWING FRAME CONTROL COMMANDS.....</b>	<b>17</b>
<b>4.6 PRIMITIVE DRAWING CONTROL COMMANDS FOR DEVICE COORDINATES .....</b>	<b>18</b>
<b>4.7 PRIMITIVE DRAWING CONTROL COMMANDS FOR OBJECT COORDINATES .....</b>	<b>19</b>
<b>4.8 DRAWING ATTRIBUTE CONTROL COMMANDS.....</b>	<b>20</b>
<b>4.9 ATTRIBUTE CONTROL COMMANDS FOR OBJECT COORDINATE .....</b>	<b>21</b>
<b>4.10 TEXTURE PATTERN MANAGEMENT COMMANDS .....</b>	<b>23</b>
<b>4.11 BINARY PATTERN DRAWING COMMANDS.....</b>	<b>24</b>
<b>4.12 BLT COMMANDS.....</b>	<b>25</b>
<b>4.13 VIDEO CAPTURE CONTROL COMMANDS .....</b>	<b>26</b>
<b>4.14 I<sup>2</sup>C CONTROL COMMANDS .....</b>	<b>27</b>
<b>5 DATA FORMAT .....</b>	<b>28</b>
<b>5.1 DATA TYPE .....</b>	<b>28</b>

<b>5.2 DATA STRUCTURE</b> .....	<b>29</b>
5.2.1 GDC_FIXED32 [32 bits fixed point] .....	29
5.2.2 GDC_FIXED_SCALE [Capture scale] .....	29
5.2.3 GDC_COLOR32 [32 bits color].....	30
5.2.4 GDC_COL32 [Palette color].....	30
5.2.5 GDC_COL16 [16 bits color] .....	31
5.2.6 GDC_COL8 [8 bits color] .....	31
5.2.7 GDC_VERTEX [GDC_SFLOAT format vertex data structure] .....	32
<b>6 DRIVER COMMAND REFERENCE</b> .....	<b>33</b>
<b>6.1 EXPLANATORY NOTES</b> .....	<b>33</b>
<b>6.2 SYSTEM CONTROL COMMANDS</b> .....	<b>34</b>
6.2.1 GdcInitialize ["Graphics driver" initialization].....	34
6.2.2 GdcQueryVersion [Version number check] .....	35
6.2.3 GdcSetInternalClock [Changes internal clock frequency] .....	36
6.2.4 GdcInitDevice [Initializes the "Graphics Controller"] .....	37
6.2.5 GdcGeoInitialize [Initialize geometry engine].....	38
6.2.6 GdcFlush [Drawing by Display List (Async)].....	38
6.2.7 GdcVFlush [Vertical blanking interval palling (Async)] .....	39
6.2.8 GdcVerticalSync [Adds vertical blanking interval command].....	39
6.2.9 GdcInterrupt [Interrupt request to host CPU].....	40
6.2.10GdcExecMode [Sets execution mode].....	40
6.2.11GdcSetDMAMode [Sets DMA mode].....	41
6.2.12GdcGetFIFOStatus [Gets Display List FIFO status] .....	42
6.2.13GdcGetFIFORemain [Gets number of Display List FIFO open entries] .....	42
6.2.14GdcGetFIFOErrorStatus [Gets Display List FIFO error status] .....	43
6.2.15GdcGetInterruptStatus [Gets interrupt status] .....	44
6.2.16GdcGeoGetInterruptStatus [Gets interrupt status for MB86291 or later] .....	45
6.2.17GdcClearInterruptStatus [Clears interrupt status for MB86290A].....	46
6.2.18GdcGeoClearInterruptStatus [Clears interrupt status for MB86291 or later].....	47
6.2.19GdcSetInterruptMask [Sets interrupt mask for MB86290A].....	48
6.2.20GdcGeoSetInterruptMask [Sets interrupt mask for MB86291 or later].....	49
6.2.21GdcGeoGetFIFOStatus [Gets geometry Display List FIFO status] .....	50
6.2.22GdcGeoGetFIFORemain [Gets number of geometry Display List FIFO open entries] .....	50
6.2.23GdcSetMemoryMode [Sets memory interface mode].....	51
6.2.24GdcSoftwareReset [Resets by software] .....	51
6.2.25GdcGetErrCode [Gets error code] .....	52
6.2.26GdcSetRegisterLocation [Changes address of registers location] .....	53
6.2.27GdcSetBurstMode [Sets burst transfer mode of drawing] .....	53



6.2.28GdcQueryChipID [Queries about chip ID].....	54
6.2.29GdcCancelDisplayList [Cancels Display List] .....	54
6.2.30GdcGetPixelEngineStatus [Gets pixel engine status].....	55
6.2.31 GdcGeoGetPixelEngineStatus [Gets geometry pixel engine status].....	56
6.2.32GdcGetLocalDisplayListTransferStatus [Gets Local Display List transfer status].....	56
<b>6.3 DISPLAY COMMANDS.....</b>	<b>57</b>
6.3.1 GdcDispClock [Sets display clock mode] .....	57
6.3.2 GdcDispTiming [Sets display timing parameters].....	57
6.3.3 GdcDispTimingWindow [Sets W-layer display position] .....	58
6.3.4 GdcDispDividePos [Sets border position of screen partition] .....	58
6.3.5 GdcDispDimension [Sets display frame attribute] .....	59
6.3.6 GdcDispOn [Asserts video signal output] .....	61
6.3.7 GdcDispOff [Negates video signal output].....	61
6.3.8 GdcDispLayerOn [Asserts screen display] .....	62
6.3.9 GdcDispLayerOff [Negates screen display].....	63
6.3.10GdcDispPos [Sets display start position].....	64
6.3.11GdcDispDoFlip [Flips display bank] .....	65
6.3.12GdcOverlayPriorityMode [Sets overlay display mode] .....	65
6.3.13GdcOverlayBlend [Sets blend parameter for overlay blend] .....	66
6.3.14GdcDispDisplayMode [Sets display mode].....	67
6.3.15GdcDispDisplayLayerMode [Sets layer display mode].....	68
6.3.16GdcDispSetBackColor [Sets background color] .....	69
6.3.17GdcDispSetLayerWindow [Sets position and size of the window mode layer].....	69
6.3.18GdcLayerOverlayPriorityMode [Sets overlay display mode in every layer].....	70
6.3.19GdcLayerOverlayBlend [Sets blend mode in every layer].....	71
6.3.20GdcDispLayerOrder [Sets layer display order] .....	73
<b>6.4 COLOR CONTROL COMMANDS .....</b>	<b>74</b>
6.4.1 GdcColorPalette [Sets palette colors].....	74
6.4.2 GdcColorTransparent [Sets transparent color] .....	75
6.4.3 GdcColorZeroMode [Sets color code 0 mode] .....	76
6.4.4 GdcChromaKeyMode [Sets Chroma-key mode] .....	76
6.4.5 GdcColorKey [Sets key color for Chroma-key].....	77
6.4.6 GdcColorPaletteOffset [Sets of the color palette offset] .....	77
<b>6.5 CURSOR CONTROL COMMANDS .....</b>	<b>79</b>
6.5.1 GdcCursorAddress [Sets cursor pattern memory address].....	79
6.5.2 GdcCursorPattern [Sets cursor pattern] .....	79
6.5.3 GdcCursorDisplay [Controls cursor display] .....	80
6.5.4 GdcCursorPos [Sets cursor display position] .....	80
6.5.5 GdcCursorPriority [Sets cursor display priority mode].....	81

6.5.6	GdcCursorColorTransparent [Sets cursor transparent color]	81
6.5.7	GdcCursorColorZeroMode [Sets cursor color code 0 mode]	82
<b>6.6</b>	<b>DRAWING FRAME CONTROL COMMANDS</b>	<b>83</b>
6.6.1	GdcDrawDimension [Sets drawing frame]	83
6.6.2	GdcSetZPrecision [Sets precision of Z value]	83
6.6.3	GdcBufferCreateZ [Sets Z buffer base address]	84
6.6.4	GdcBufferCreateC [Sets base address of polygon drawing flag buffer]	84
6.6.5	GdcBufferClearZ [Clears Z buffer]	84
6.6.6	GdcBufferClearC [Clears polygon drawing flag buffer]	85
6.6.7	GdcDrawClipFrame [Sets drawing clip border]	85
6.6.8	GdcSetAlphaMapBase [Sets base address of alpha map area]	86
<b>6.7</b>	<b>PRIMITIVE DRAWING COMMANDS FOR DEVICE COORDINATES</b>	<b>87</b>
6.7.1	GdcPrimType [Starts drawing procedure]	87
6.7.2	GdcPrimEnd [Completes drawing procedure]	87
6.7.3	GdcTexCoord2D / 2Df / 2DNf [Sets coordinates of 2D texture]	88
6.7.4	GdcTexCoord3D / 3Df / 3DNf [Sets coordinates of 3D texture]	89
6.7.5	GdcDrawVertex2D / 2Di [Sets coordinates of 2D vertex]	90
6.7.6	GdcDrawVertex3D / 3Df [Sets coordinates of 3D vertex]	91
6.7.7	GdcDrawPrimitive [Draws multiple 3D triangles]	92
<b>6.8</b>	<b>PRIMITIVE DRAWING CONTROL COMMANDS FOR OBJECT COORDINATES</b>	<b>93</b>
6.8.1	GdcGeoPrimType [Starts drawing procedure]	93
6.8.2	GdcGeoPrimEnd [Completes drawing procedure]	93
6.8.3	GdcGeoDrawVertex2D / 2Df / 2Di [Sets XY coordinates of vertex]	94
6.8.4	GdcGeoDrawVertex3D / 3Df / 3Di [Sets XYZ coordinates of vertex]	95
6.8.5	GdcGeoTexCoord2DN / 2DNf [Sets texture coordinates]	96
6.8.6	GdcVertexColor3f / 32 [Sets color of vertex]	97
<b>6.9</b>	<b>DRAWING ATTRIBUTE CONTROL COMMANDS</b>	<b>98</b>
6.9.1	GdcColor [Sets vertex color/foreground color]	98
6.9.2	GdcBackColor [Sets background color]	99
6.9.3	GdcClipMode [Sets clipping mode]	99
6.9.4	GdcSetAttrLine [Sets line drawing attribute]	100
6.9.5	GdcSetAttrSurf [Sets surface drawing attribute]	104
6.9.6	GdcSetAttrTexture [Sets texture mapping attribute]	108
6.9.7	GdcSetAttrBlit [Sets BitBlit attribute]	110
6.9.8	GdcSetAlpha [Sets alpha blend ratio]	111
6.9.9	GdcSetLinePattern [Sets broken line pattern]	111
6.9.10	GdcSetTextureBorder [Sets texture border color]	112
6.9.11	GdcSetRop [Sets logical calculation mode]	113
<b>6.10</b>	<b>ATTRIBUTE CONTROL COMMANDS FOR OBJECT COORDINATES</b>	<b>114</b>

6.10.1GdcGeoSetAttrMisc [Sets miscellaneous attribute].....	114
6.10.2GdcGeoSetAttrLine [Sets line drawing attribute for object coordinates] .....	116
6.10.3GdcGeoSetAttrSurf [Sets surface drawing attribute for object coordinates] .....	119
6.10.4GdcGeoLoadMatrix[f] [Sets matrix].....	121
6.10.5GdcGeoNdcDcViewportCoef[f] [Sets coefficients of NdcDc transformation for XY].....	122
6.10.6GdcGeoNdcDcDepthCoef[f] [Sets coefficients of NdcDc transformation for Z].....	122
6.10.7GdcGeoViewVolumeXYClip[f] [Sets view volume boundary for XY] .....	123
6.10.8GdcGeoViewVolumeZClip[f] [Sets view volume boundary for Z] .....	123
6.10.9GdcGeoViewVolumeWminClip[f] [Sets view volume boundary for w].....	124
6.10.10 GdcGeoSetLogOutBase [Sets base address for log output of device coordinates] .....	125
6.10.11 GdcGeoSetLogOutMode [Sets log output mode of the device coordinates] .....	126
6.10.12 GdcGeoShadowXY [Sets xy offset of shadow].....	127
6.10.13 GdcGeoOverlapZ [Sets Z value of primitives (body / shadow / border / correction in top-left rule non-applicable mode)].....	128
6.10.14 GdcGeoShadowColor [Sets color or shadow].....	129
6.10.15 GdcGeoShadowBackColor [Sets background color of shadow].....	130
6.10.16 GdcGeoBorderColor [Sets color or border].....	131
6.10.17 GdcGeoBorderBackColor [Sets background color of border].....	132
<b>6.11 TEXTURE PATTERN CONTROL COMMANDS .....</b>	<b>133</b>
6.11.1GdcTextureMemoryMode [Sets texture memory mode].....	133
6.11.2GdcTextureLoadInt [Loads texture/tile pattern to internal texture memory] .....	133
6.11.3GdcTextureLoadExt [Loads texture pattern to the graphics memory].....	134
6.11.4GdcTextureLoadExt8 [Loads 8bpp texture pattern to the graphics memory].....	134
6.11.5GdcTextureLoadExt16 [Loads 16bpp texture pattern to the graphics memory].....	135
6.11.6GdcTextureLoadExt24 [Loads 24bpp texture pattern to the graphics memory].....	135
6.11.7GdcTextureLoadInt16Fast [Loads texture pattern to internal texture memory].....	136
6.11.8GdcTextureLoadExt16Fast [Loads texture pattern to the graphics memory].....	136
6.11.9GdcTextureDimension [Sets texture / tile information] .....	137
6.11.10 GdcBlitTexture [Loads Blt texture to internal texture memory for MB86290A] .....	139
6.11.11 GdcGeoBlitTexture [Loads Blt texture to internal texture memory for MB86291 or later] ..	140
<b>6.12 BINARY PATTERN DRAWING COMMANDS.....</b>	<b>141</b>
6.12.1GdcBitPatternDraw [Draws binary pattern].....	141
6.12.2GdcBitPatternMode [Sets enlarge/shrink mode] .....	142
<b>6.13 BLT COMMANDS.....</b>	<b>143</b>
6.13.1GdcBltCopy [Copies BitBlt pattern in current drawing frame].....	143
6.13.2GdcBltCopyAlt, GdcBltCopyAltSync [Copies BitBlt pattern between any drawing frame] .....	144
6.13.3GdcBltDraw [Draws BitBlt pattern].....	145
6.13.4GdcBltFill [Fills BitBlt field] .....	145
6.13.5GdcBltColorTransparent [Sets transparent color of transparent BitBlt].....	146

- 6.13.6GdcBlitCopyAltAlpha [Copies BitBlit pattern with alpha blending] ..... 147
- 6.14 VIDEO CAPTURE COMMANDS ..... 148**
- 6.14.1GdcCapSetVideoCaptureMode [Sets mode of video capture] ..... 148
- 6.14.2GdcCapGetErrorStatus [Gets error status of video capture] ..... 149
- 6.14.3GdcCapClearErrorStatus [Clears error status of video capture] ..... 149
- 6.14.4GdcCapSetVideoCaptureBuffer [Sets video capture buffer] ..... 150
- 6.14.5GdcCapSetImageArea [Sets range of image] ..... 151
- 6.14.6GdcCapSetWindowMode [Sets w-layer mode]..... 152
- 6.14.7GdcCapSetVideoCaptureScale [Sets scale of video capture]..... 153
- 6.14.8GdcCapSetAttrMisc [Sets attribute of video capture] ..... 155
- 6.14.9GdcCapSetInputDataCountNTSC [Sets the video capture buffer for NTSC]..... 156
- 6.14.10 GdcCapSetInputDataCountPAL [Sets the video capture buffer for PAL] ..... 156
- 6.14.11 GdcCapSetLPFMode [Sets low pass filter mode]..... 157
- 6.15 I<sup>2</sup>C CONTROL COMMANDS ..... 158**
- 6.15.1Gdcl2CGetBusStatus [Gets I<sup>2</sup>C bus status] ..... 158
- 6.15.2Gdcl2CSetBusControl [Controls I<sup>2</sup>C bus] ..... 159
- 6.15.3Gdcl2CGetBusControlStatus [Gets I<sup>2</sup>C bus control status]..... 160
- 6.15.4Gdcl2CSetClock [Sets I<sup>2</sup>C clock]..... 161
- 6.15.5Gdcl2CSetData [Sets transfer data] ..... 161
- 7 SYSTEM DEPENDENT COMMANDS..... 162**
- 7.1 SYSTEM DEPENDENT COMMANDS ..... 162**
- 8 SYSTEM DEPENDENT COMMANDS INTERFACE ..... 163**
- 8.1 EXPLANATORY NOTES ..... 163**
- 8.2 COMMAND INTERFACE ..... 164**
- 8.2.1 GdcSetDisplayListBuffer [Sets Display List buffer]..... 164
- 8.2.2 GdcFlushDisplayList [Transfers a Display List] ..... 166
- 8.2.3 GdcGetHostRegisterAddress [Gets host interface register area address]..... 171
- 8.2.4 GdcGetDispRegisterAddress [Gets display control register area address]..... 171
- 8.2.5 GdcGetDrawRegisterAddress [Gets drawing control register area address]..... 171

# 1 MB86290 Series Graphics Driver Overview

This section describes abstract of the MB86290 Series Graphics Driver.

## 1.1 Overview

The MB86290 Series Graphics Driver (the “Graphics Driver”) is a set of commands to assist graphics application programs utilizing the MB86290 Series Graphics Controller (the “Graphics Controller”). Each command to use the “Graphics Driver” from a graphics application program is called driver command. Abstract of the “Graphics Driver” is shown by figure 1.1.

By using this Graphics Driver, graphics application programs can be made without concerning the code to access to hardware registers and management of Display List (refer to “2.1 Rendering Scheme”).




Figure 1.1 Overview of the “Graphics Driver”

## 2 Operation of MB86290 Series Graphics Driver

This section describes rendering scheme by the “Graphics Driver”.

### 2.1 Rendering Scheme

Drawing operation of the “Graphics Controller” is started by sending respective command and it’s parameters. To draw one object, multiple commands need to be sent. Typically a bunch of commands to be required to draw one object are set together and transferred consecutively in effective ways such as DMA transfer or transfer of Local Display List. This bunch of commands is called Display List.

Rendering scheme is shown in the figure 2.1. The drawing function of the “Graphics Driver” once stores the generated Display List in Display List buffer (refer to "2.2 Management of Display List") in order to transmit a Display List collectively by DMA etc (1). Then, transferring to the “Graphics Controller” is started with Display List transferring command (2).




Figure 2.1 Rendering scheme

## 2.2 Management of Display List

The “Graphics Driver” stores generated Display List to Display List buffer and manages them. The Display List buffer is a certain amount of memory area allocated on either the local memory (the graphics memory) of the “Graphics Controller” or the host CPU memory. Acquisition of this area is done by graphics application program. Created Display List is stored in the Display List buffer till either obvious transfer order of it is made by the application program or no more open space will be available in the Display List buffer. (The trigger timing of Display List transfer is referred to “2.3.2 Trigger of a Display List transfer”).

Display List buffer has the method of using the whole as one area, and the method of dividing two and using (refer to figure 2.2). 1 block configuration and 2 blocks configuration are described in the following.


### (1) 1 block configuration

In 1 block configuration, the whole Display List buffer is used as one area. If the Display List buffer is configured in 1 block, once the Display List transfer is started, following Display List creation cannot be started until current transfer operation will complete and the buffer will be open.

### (2) 2 blocks configuration

In 2 blocks configuration, each block is used alternatively. In 2 blocks configuration, when 1 block is completely full of Display List, transfer is started. But prior to wait this transfer start, following Display List can be stored into the alternative block.

The biggest advantage of this 2 blocks configuration is that the host CPU can create a new Display List while the “Graphics Controller” executes rendering operations according to the current Display List. To make this scheme, the Display List needs to be transferred to the “Graphics Controller” via DMA or transfer of Local Display List.





## **2.3 Transfer of Display List**

### **2.3.1 Methods of Display List transfer**

For the Display List transfer, the following three options are available. Depends on the target system configuration, each application designer should choose the most appropriate option:

- DMA transfer
- Transfer of Local Display List
- Display List write by host CPU

### **2.3.2 Trigger of Display List transfer**

Display List transfer is started by the following events:

- GdcFlush command call
- GdcVFlush command call
- Not enough space available in the Display List buffer to fill the Display List to be generated at the execution of respective driver command

## 2.4 Sync Mode and Async Mode

The “Graphics Driver” has two operation modes, Sync mode and Async mode. Default mode is async mode. Switching of Sync mode and Async mode is performed by the GdcExecMode command.

### (1) Async mode

In Async mode, each driver command returns back to the application right after it's set of Display List to the Display List buffer. Display List transfer is performed in the condition as described in “2.3.2 Trigger of Display List transfer”. In this mode, Display List creation by the “Graphics Driver”, Display List transfer to the “Graphics Controller” and rendering, and it's execution work independently.

### (2) Sync mode

In Sync mode, regardless the method of the Display List transfer, each driver command transfers it's generated Display List to the “Graphics Controller” immediately, and returns back to the application after the completion of the “Graphics Controller” rendering operations according to the Display List. This mode is mainly used in the debug of graphics application programs.

## 2.5 System Dependent Commands

The system dependents command is a command to process procedures such as DMA transfer that depends on a target system and a graphics application program in the "Graphics Driver". The relationship between system dependent commands and the "Graphics Driver" is shown in the figure 2.5.

The system dependent commands must be designed by each application designer according to the command interface specified by the "Graphics Driver". (the command interface of the system dependent commands is referred to "8. System Dependent Commands Interface".)

The following procedures must be implemented in the system depend commands.

(1) Acquisition of the mapping address of the "Graphics Controller" register areas

Gets the address allocation information of the "Graphics Controller" register areas and feed these information back to the "Graphics Driver" to access to various registers of the "Graphics Controller".

(2) Setting of the Display List buffer

Informs the address allocation and size of the Display List buffer created by the application program to the "Graphics Driver".

(3) Display List transfer

Transfers Display List to the "Graphics Controller" according to method of "2.3.1 Methods of Display List transfer."




Figure 2.5 System dependent commands and relation with the “Graphics Driver”

## **3 For Application Program Development**

This section describes mandatory operations and reminders in the application program development utilizing the “Graphics Driver”.

### **3.1 Mandatory Operations**

#### **3.1.1 Header files**

The “Graphics Driver” is prepared the following header files to application designers.

Whenever driver command is called, `gdc.h` must be included. Since the `gdctypes.h` is already included in the `gdc.h`, application designers do not need to include it directly.

- `gdc.h` : Declaration of driver command prototype
- `gdctypes.h` : Definition of the data type applied in the “Graphics Driver”

#### **3.1.2 Gets Display List buffer**

The Display List buffer must be acquired by the application program. The buffer size should be 32byte boundary. When DMA is applied to transfer Display List, the address allocation of the buffer and the block size must be aware. The address allocation and the buffer size should be defined not to conflict any source address restrictions of the DMA controller (if any).

When DMA is adopted, always the source address is the top address of each Display List buffer block (if the Display List buffer is configured in 2 blocks, DMA transfer source address of the 1st block is a top address of Display List buffer. And DMA transfer source address of the 2nd block is “top address+1/2 byte count of the total Display List buffer”).

#### **3.1.3 Creates system dependent commands**

The system dependent commands should be designed according to the command interface specified in “8. System Dependent Commands”.

## **3.2 Reminder**

### **3.2.1 Prohibition of re-entrant**

The “Graphics Driver” is not supported to re-entrant. NOT to call the “Graphics Driver” from multiple tasks. If multiple tasks call the “Graphics Driver” simultaneously, these calling conventions must be managed exclusively, and avoid driver command call from one task before the completion of the driver command operation called by the other task.

## **4 Driver Commands**

This section describes each “Graphics Controller” can use any driver commands.

Driver commands are shown in the following.

- System control commands
- Display commands
- Color control commands
- Cursor control commands
- Drawing frame control commands
- Primitive drawing control commands for device coordinates
- Primitive drawing control commands for object coordinates
- Drawing attribute control commands
- Attribute control commands for object coordinates
- Texture pattern management commands
- Binary pattern drawing commands
- Blt commands
- Video capture control commands
- I<sup>2</sup>C control commands

## 4.1 System Control Commands

System control commands list is shown in the table 4.1.

Table 4.1 System control commands list

No.	Command name	Function	Graphics Controller (*1)		
			290A	291/292	293
1	GdcInitialize	“Graphics Driver” initialization	Y	Y	Y
2	GdcQueryVersion	Version number check of the “Graphics Driver”	Y	Y	Y
3	GdcSetInternalClock	Changes internal clock frequency	N	N	Y
4	GdcInitDevice	Initializes the “Graphics Controller”	Y	Y	Y
5	GdcGeoInitialize	Initialize geometry engine	N	Y	Y
6	GdcFlush	Drawing by Display List (Async)	Y	Y	Y
7	GdcVFlush	Vertical blanking interval palling (Async)	Y	Y	Y
8	GdcVerticalSync	Adds vertical blanking interval command	Y	Y	Y
9	GdcInterrupt	Interrupts request to host CPU	Y	Y	Y
10	GdcExecMode	Sets execution mode of Display List operation	Y	Y	Y
11	GdcSetDMAMode	Sets DMA mode	Y	Y	Y
12	GdcGetFIFOStatus	Gets Display List FIFO status	Y	Y	Y
13	GdcGetFIFORemain	Gets number of Display List FIFO open entries	Y	Y	Y
14	GdcGetFIFOErrorStatus	Gets Display List FIFO error status	Y	Y	Y
15	GdcGetInterruptStatus	Gets interrupt status	Y	N	N
16	GdcGeoGetInterruptStatus	Gets interrupt status	N	Y	Y
17	GdcClearInterruptStatus	Clears interrupt status for MB86290A	Y	N	N

(\*1)290A:MB86290A, 291/292:MB86291/86291A/86291S/86292/86292S, 293:MB86293

Y : can be used

N : can not be used



No.	Command name	Function	Graphics Controller (*1)		
			290A	291/292	293
18	GdcGeoClearInterruptStatus	Clears interrupt status for MB86291 or later	N	Y	Y
19	GdcSetInterruptMask	Sets interrupt mask for MB86290A	Y	N	N
20	GdcGeoSetInterruptMask	Sets interrupt mask for MB86291 or later	N	Y	Y
21	GdcGeoGetFIFOStatus	Gets geometry Display List FIFO status	N	Y	Y
22	GdcGeoGetFIFORemain	Gets number of geometry Display List FIFO open entries	N	Y	Y
23	GdcSetMemoryMode	Sets memory interface mode	Y	Y	Y
24	GdcSoftwareReset	Resets by software	Y	Y	Y
25	GdcGetErrCode	Gets error code	Y	Y	Y
26	GdcSetRegisterLocation	Changes address of registers location	N	N	Y
27	GdcSetBurstMode	Sets burst transfer mode of drawing	N	N	Y
28	GdcQueryChipID	Queries about chip ID	N	N	Y
29	GdcCancelDisplayList	Cancels Display List	Y	Y	Y
30	GdcGetPixelEngineStatus	Gets pixel engine status	Y	N	N
31	GdcGeoGetPixelEngineStatus	Gets geometry pixel engine status	N	Y	Y
32	GdcGetLocalDisplayListTransferStatus	Gets transfer of Local Display List status	Y	Y	Y

(\*1)290A:MB86290A, 291/292:MB86291/86291A/86291S/86292/86292S, 293:MB86293

Y : can be used

N : can not be used

## 4.2 Display Commands

Display commands list is shown in the table 4.2.

Table 4.2 Display commands list

No.	Command name	Function	Graphics Controller (*1)		
			290A	291/292	293
1	GdcDispClock	Sets display clock mode	Y	Y	Y
2	GdcDispTiming	Sets display timing parameters	Y	Y	Y
3	GdcDispTimingWindow	Sets W-layer display position	Y	Y	Y
4	GdcDispDividePos	Sets border position of screen partition	Y	Y	Y
5	GdcDispDimension	Sets display frame attribute	Y	Y	Y
6	GdcDispOn	Asserts video signal output	Y	Y	Y
7	GdcDispOff	Negates video signal output	Y	Y	Y
8	GdcDispLayerOn	Asserts screen display	Y	Y	Y
9	GdcDispLayerOff	Negates screen display	Y	Y	Y
10	GdcDispPos	Sets display start position	Y	Y	Y
11	GdcDispDoFlip	Flips display bank	Y	Y	Y
12	GdcOverlayPriorityMode	Sets overlay display mode	Y	Y	Y
13	GdcOverlayBlend	Sets blend parameter for overlay blend	Y	Y	Y
14	GdcDispDisplayMode	Sets display mode	N	N	Y
15	GdcDispDisplayLayerMode	Sets layer display mode	N	N	Y
16	GdcDispSetBackColor	Sets background color	N	N	Y
17	GdcDispSetLayerWindow	Sets position and size of the window mode layer	N	N	Y
18	GdcLayerOverlayPriorityMode	Sets overlay display mode in every layer	N	N	Y
19	GdcLayerOverlayBlend	Sets blend mode in every layer	N	N	Y
20	GdcDisplLayerOrder	Sets layer display order	N	N	Y

(\*1)290A:MB86290A, 291/292:MB86291/86291A/86291S/86292/86292S, 293:MB86293

Y : can be used

N : can not be used

## 4.3 Color Control Commands

Color control commands list is shown in the table 4.3.

Table 4.3 Color control commands list

No.	Command name	Function	Graphics Controller (*1)		
			290A	291/292	293
1	GdcColorPalette	Sets palette colors	Y	Y	Y
2	GdcColorTransparent	Sets transparent color	Y	Y	Y
3	GdcColorZeroMode	Sets color code 0 mode	Y	Y	Y
4	GdcChromaKeyMode	Sets Chroma-key mode	Y	Y	Y
5	GdcColorKey	Sets key color for Chroma-key	Y	Y	Y
6	GdcColorPaletteOffset	Sets of the color palette offset	N	N	Y

(\*1)290A:MB86290A, 291/292:MB86291/86291A/86291S/86292/86292S, 293:MB86293

Y : can be used

N : can not be used

## 4.4 Cursor Control Commands

Cursor control commands list is shown in the table 4.4.

Table 4.4 Cursor control commands list

No.	Command name	Function	Graphics Controller (*1)		
			290A	291/292	293
1	GdcCursorAddress	Sets cursor pattern memory address	Y	Y	Y
2	GdcCursorPattern	Sets cursor pattern	Y	Y	Y
3	GdcCursorDisplay	Controls cursor display	Y	Y	Y
4	GdcCursorPos	Sets cursor display position	Y	Y	Y
5	GdcCursorPriority	Sets cursor display priority mode	Y	Y	Y
6	GdcCursorColorTransparent	Sets cursor transparent color	Y	Y	Y
7	GdcCursorColorZeroMode	Sets cursor color code 0 mode	Y	Y	Y

(\*1)290A:MB86290A, 291/292:MB86291/86291A/86291S/86292/86292S, 293:MB86293

Y : can be used

N : can not be used

## 4.5 Drawing Frame Control Commands

Drawing frame control commands list is shown in the table 4.5.

Table 4.5 Drawing frame control commands list

No.	Command name	Function	Graphics Controller (*1)		
			290A	291/292	293
1	GdcDrawDimension	Sets drawing frame	Y	Y	Y
2	GdcSetZPrecision	Sets precision of Z value	N	N	Y
3	GdcBufferCreateZ	Sets Z buffer start address	Y	Y	Y
4	GdcBufferCreateC	Sets start address of polygon drawing flag buffer	Y	Y	Y
5	GdcBufferClearZ	Clears Z buffer	Y	Y	Y
6	GdcBufferClearC	Clears polygon drawing flag buffer	Y	Y	Y
7	GdcDrawClipFrame	Sets drawing clip border	Y	Y	Y
8	GdcSetAlphaMapBase	Sets alpha map area start address	N	N	Y

(\*1)290A:MB86290A, 291/292:MB86291/86291A/86291S/86292/86292S, 293:MB86293

Y : can be used

N : can not be used

## 4.6 Primitive Drawing Control Commands for Device Coordinates

Primitive drawing control commands for device coordinates list is shown in the table 4.6.

Table 4.6 Primitive drawing control commands for device coordinates list

No.	Command name	Function	Graphics Controller (*1)		
			290A	291/292	293
1	GdcPrimType	Sets drawing procedure	Y	Y	Y
2	GdcPrimEnd	Completes drawing procedure	Y	Y	Y
3	GdcTexCoord2D	Sets coordinates of 2D texture (GDC_FIXED32 type)	Y	Y	Y
4	GdcTexCoord2Df	Sets coordinates of 2D texture (GDC_SFLOAT type)	Y	Y	Y
5	GdcTexCoord2DNf	Sets normalized coordinates of 2D texture (GDC_SFLOAT type)	Y	Y	Y
6	GdcTexCoord3D	Sets coordinates of 3D texture (GDC_FIXED32 type)	Y	Y	Y
7	GdcTexCoord3Df	Sets coordinates of 3D texture (GDC_SFLOAT type)	Y	Y	Y
8	GdcTexCoord3DNf	Sets normalized coordinates of 3D texture (GDC_SFLOAT type)	Y	Y	Y
9	GdcDrawVertex2D	Sets coordinates of 2D vertex (GDC_FIXED32 type)	Y	Y	Y
10	GdcDrawVertex2Di	Sets coordinates of 2D vertex (GDC_LONG type)	Y	Y	Y
11	GdcDrawVertex3D	Sets coordinates of 3D vertex (GDC_FIXED32 type)	Y	Y	Y
12	GdcDrawVertex3Df	Sets coordinates of 3D vertex (GDC_SFLOAT type)	Y	Y	Y
13	GdcDrawPrimitive	Draws multiple 3D triangles	Y	Y	Y

(\*1)290A:MB86290A, 291/292:MB86291/86291A/86291S/86292/86292S, 293:MB86293

Y : can be used

N : can not be used

## 4.7 Primitive Drawing Control Commands for Object Coordinates

Primitive drawing control commands for object coordinates list is shown in the table 4.7.

Table 4.7 Primitive drawing control commands for object coordinates list

No.	Command name	Function	Graphics Controller (*1)		
			290A	291/292	293
1	GdcGeoPrimType	Sets drawing procedure	N	Y	Y
2	GdcGeoPrimEnd	Completes drawing procedure	N	Y	Y
3	GdcGeoDrawVertex2D	Sets XY coordinates of vertex (GDC_FIXED32 type)	N	Y	Y
4	GdcGeoDrawVertex2Df	Sets XY coordinates of vertex (GDC_SFLOAT type)	N	Y	Y
5	GdcGeoDrawVertex2Di	Sets XY coordinates of vertex (GDC_LONG type)	N	Y	Y
6	GdcGeoDrawVertex3D	Sets XYZ coordinates of vertex (GDC_FIXED32 type)	N	Y	Y
7	GdcGeoDrawVertex3Df	Sets XYZ coordinates of vertex (GDC_SFLOAT type)	N	Y	Y
8	GdcGeoDrawVertex3Di	Sets XYZ coordinates of vertex (GDC_LONG type)	N	Y	Y
9	GdcGeoTexCoord2DN	Sets texture coordinates (GDC_FIXED32 type)	N	Y	Y
10	GdcGeoTexCoord2DNf	Sets texture coordinates (GDC_SFLOAT type)	N	Y	Y
11	GdcVertexColor3f	Sets color of vertex (GDC_SFLOAT type)	N	Y	Y
12	GdcVertexColor32	Sets color of vertex (GDC_COLOR32 type)	N	Y	Y

(\*1)290A:MB86290A, 291/292:MB86291/86291A/86291S/86292/86292S, 293:MB86293

Y : can be used

N : can not be used

## 4.8 Drawing Attribute Control Commands

Drawing attribute control commands list is shown in the table 4.8.

Table 4.8 Drawing attribute control commands list

No.	Command name	Function	Graphics Controller (*1)		
			290A	291/292	293
1	GdcColor	Sets vertex color/foreground color	Y	Y	Y
2	GdcBackColor	Sets background color	Y	Y	Y
3	GdcClipMode	Sets clipping mode	Y	Y	Y
4	GdcSetAttrLine	Sets line drawing attribute	Y	Y	Y
5	GdcSetAttrSurf	Sets surface drawing attribute	Y	Y	Y
6	GdcSetAttrTexture	Sets texture mapping attribute	Y	Y	Y
7	GdcSetAttrBlit	Sets BitBlit attribute	Y	Y	Y
8	GdcSetAlpha	Sets alpha blend ratio	Y	Y	Y
9	GdcSetLinePattern	Sets broken line pattern	Y	Y	Y
10	GdcSetTextureBorder	Sets texture border color	Y	Y	Y
11	GdcSetRop	Sets logical calculation mode	Y	Y	Y

(\*1)290A:MB86290A, 291/292:MB86291/86291A/86291S/86292/86292S, 293:MB86293

Y : can be used

N : can not be used



## 4.9 Attribute Control Commands for Object Coordinate

Attribute control commands for object coordinate list is shown in the table 4.9.

Table 4.9 Attribute control commands for object coordinate list

No.	Command name	Function	Graphics Controller (*1)		
			290A	291/292	293
1	GdcGeoSetAttrMisc	Sets miscellaneous attribute	N	Y	Y
2	GdcGeoSetAttrLine	Sets line drawing attribute for object coordinates	N	Y	Y
3	GdcGeoSetAttrSurf	Sets surface drawing attribute for object coordinates	N	Y	Y
4	GdcGeoLoadMatrix	Sets matrix (GDC_FIXED32 type)	N	Y	Y
5	GdcGeoLoadMatrixf	Sets matrix (GDC_SFLOAT type)	N	Y	Y
6	GdcGeoNdcDcViewportCoef	Sets coefficients of NdcDc transformation for xy (GDC_FIXED32 type)	N	Y	Y
7	GdcGeoNdcDcViewportCoeff	Sets coefficients of NdcDc transformation for xy (GDC_SFLOAT type)	N	Y	Y
8	GdcGeoNdcDcDepthCoef	Sets coefficients of NdcDc transformation for z (GDC_FIXED32 type)	N	Y	Y
9	GdcGeoNdcDcDepthCoeff	Sets coefficients of NdcDc transformation for z (GDC_SFLOAT type)	N	Y	Y
10	GdcGeoViewVolumeXYClip	Sets view volume boundary for xy (GDC_FIXED32 type)	N	Y	Y
11	GdcGeoViewVolumeXYClipf	Sets view volume boundary for xy (GDC_SFLOAT type)	N	Y	Y
12	GdcGeoViewVolumeZClip	Sets view volume boundary for z (GDC_FIXED32 type)	N	Y	Y

(\*1)290A:MB86290A, 291/292:MB86291/86291A/86291S/86292/86292S, 293:MB86293

Y : can be used

N : can not be used

No.	Command name	Function	Graphics Controller (*1)		
			290A	291/292	293
13	GdcGeoViewVolumeZClipf	Sets view volume boundary for z (GDC_SFLOAT type)	N	Y	Y
14	GdcGeoViewVolumeWminClip	Sets view volume boundary for w (GDC_FIXED32 type)	N	Y	Y
15	GdcGeoViewVolumeWminClipf	Sets view volume boundary for w (GDC_SFLOAT type)	N	Y	Y
16	GdcGeoSetLogOutBase	Sets top address for log output of device coordinate	N	N	Y
17	GdcGeoSetLogOutMode	Sets log output mode of the device coordinate	N	N	Y
18	GdcGeoShadowXY	Sets xy offset of shadow	N	N	Y
19	GdcGeoOverlapZ	Sets Z value of primitives (body / shadow / border / correction in top-left rule non-applicable mode)	N	N	Y
20	GdcGeoShadowColor	Sets color of shadow	N	N	Y
21	GdcGeoShadowBackColor	Sets background color of shadow	N	N	Y
22	GdcGeoBorderColor	Sets color of border	N	N	Y
23	GdcGeoBorderBackColor	Sets background color of border	N	N	Y

(\*1)290A:MB86290A, 291/292:MB86291/86291A/86291S/86292/86292S, 293:MB86293

Y : can be used

N : can not be used

## 4.10 Texture Pattern Management Commands

Texture pattern management commands list is shown in the table 4.10.

Table 4.10 Texture pattern management commands list

No.	Command name	Function	Graphics Controller (*1)		
			290A	291/292	293
1	GdcTextureMemoryMode	Sets texture memory mode	Y	Y	Y
2	GdcTextureLoadInt	Loads texture/tile pattern to internal texture memory	Y	Y	Y
3	GdcTextureLoadExt	Loads texture pattern to the graphics memory	Y	Y	Y
4	GdcTextureLoadExt8	Loads 8bpp texture pattern to the graphics memory	N	N	Y
5	GdcTextureLoadExt16	Loads 16bpp texture pattern to the graphics memory	Y	Y	Y
6	GdcTextureLoadExt24	Loads 24bpp texture pattern to the graphics memory	N	N	Y
7	GdcTextureLoadInt16Fast	Loads 16bpp texture pattern to internal texture memory	N	N	Y
8	GdcTextureLoadExt16Fast	Loads 16bpp texture pattern to the graphics memory	N	N	Y
9	GdcTextureDimension	Sets texture information	Y	Y	Y
10	GdcBltTexture	Loads Blt texture to internal texture memory for MB86290A	Y	N	N
11	GdcGeoBltTexture	Loads Blt texture to internal texture memory for MB86291	N	Y	Y

(\*1)290A:MB86290A, 291/292:MB86291/86291A/86291S/86292/86292S, 293:MB86293

Y : can be used

N : can not be used

## 4.11 Binary Pattern Drawing Commands

Binary pattern drawing commands list is shown in the table 4.11.

Table 4.11 Binary pattern drawing commands list

No.	Command name	Function	Graphics Controller (*1)		
			290A	291/292	293
1	GdcBitPatternDraw	Draws binary pattern	Y	Y	Y
2	GdcBitPatternMode	Sets enlarge/shrink mode	Y	Y	Y

(\*1)290A:MB86290A, 291/292:MB86291/86291A/86291S/86292/86292S, 293:MB86293

Y : can be used

N : can not be used

## 4.12 BLT Commands

Blt commands list is shown in the table 4.12.

Table 4.12 Blt commands list

No.	Command name	Function	Graphics Controller (*1)		
			290A	291292	293
1	GdcBltCopy	Copies BitBlt pattern within current drawing frame	Y	Y	Y
2	GdcBltCopyAlt	Copies BitBlt pattern between any drawing frame (Async)	Y	Y	Y
3	GdcBltCopyAltSync	Copies BitBlt pattern between any drawing frame (Sync)	Y	Y	Y
4	GdcBltDraw	Draws BitBlt pattern	Y	Y	Y
5	GdcBltFill	Fills BitBlt field	Y	Y	Y
6	GdcBltColorTransparent	Sets transparent color of transparent BitBlt	N	Y	Y
7	GdcBltCopyAltAlpha	Copies BitBlt pattern with alpha blending	N	N	Y

(\*1)290A:MB86290A, 291/292:MB86291/86291A/86291S/86292/86292S, 293:MB86293

Y : can be used

N : can not be used

## 4.13 Video Capture Control Commands

Video capture control commands list is shown in the table 4.13.

Table 4.13 Video capture control commands list

No.	Command name	Function	Graphics Controller (*1)		
			290A	291/292	293
1	GdcCapSetVideoCaptureMode	Sets mode of video capture	N	Y	Y
2	GdcCapGetErrorStatus	Gets error status of video capture	N	Y	Y
3	GdcCapClearErrorStatus	Clears error status of video capture	N	Y	Y
4	GdcCapSetVideoCaptureBuffer	Sets video capture buffer	N	Y	Y
5	GdcCapSetImageArea	Sets range of image	N	Y	Y
6	GdcCapSetWindowMode	Sets W layer mode	N	Y	Y
7	GdcCapSetVideoCaptureScale	Sets scale of video capture	N	Y	Y
8	GdcCapSetAttrMisc	Sets attribute of video capture	N	Y	Y
9	GdcCapSetInputDataCountNTSC	Sets number of video capture data for NTSC	N	Y	Y
10	GdcCapSetInputDataCountPAL	Sets number of video capture data for PAL	N	Y	Y
11	GdcCapSetLPFMode	Sets low pass filter mode	N	Y	Y

(\*1)290A:MB86290A, 291/292:MB86291/86291A/86291S/86292/86292S, 293:MB86293

Y : can be used

N : can not be used

## 4.14 I<sup>2</sup>C Control Commands

I<sup>2</sup>C control commands list is shown in the table 4.14.

Table 4.14 I<sup>2</sup>C control commands list

No.	Command name	Function	Graphics Controller (*1)		
			290A	291/292	293
1	GdcI2CGetBusStatus	Gets I <sup>2</sup> C bus status	N	y	y
2	GdcI2CSetBusControl	Controls I <sup>2</sup> C bus	N	y	y
3	GdcI2CGetBusControlStatus	Gets I <sup>2</sup> C bus control status	N	y	y
4	GdcI2CSetClock	Sets I <sup>2</sup> C clock	N	y	y
5	GdcI2CSetData	Sets transfer data	N	y	y

(\*1)290A:MB86290A, 291/292:MB86291/86291A/86291S/86292/86292S, 293:MB86293

y : These commands can be used only following Graphics Controllers.

MB86291S,MB86292S or MB86293 or later which supported video capture function.

N : can not be used

## 5 Data Format

This section describes the data types and data structures specified by “Graphics Driver”.

### 5.1 Data Type

Data types to define in the “Graphics Driver” is shown in the table 5.1.

Table 5.1 Data type list

Format	Description
GDC_FIXED32	32 bits signed fixed point (1 bits sign,15 bits integer and 16 bits fraction)
GDC_FIXED_SCALE	16 bits unsigned fixed point for Capture Scale (5 bits integer and 11 bits fraction)
GDC_SFLOAT	32 bits single precision float (IEEE754 compliant)
GDC_ULONG	32 bits unsigned integer
GDC_LONG	32 bits signed integer
GDC_USHORT	16 bits unsigned integer
GDC_SHORT	16 bits signed integer
GDC_UCHAR	8 bits signed integer
GDC_COLOR32	32 bits unsigned integer (32 bits color format)
GDC_COL32	32 bits unsigned integer (palette color format)
GDC_COL16	16 bits unsigned integer (16 bits color format)
GDC_COL8	8 bits unsigned integer (8 bits color format)
GDC_LPPCOL32	Pointer for GDC_COL32 format data
GDC_LPCOL24	Pointer for GDC_COLOR32 format data
GDC_LPCOL16	Pointer for GDC_COL16 format data
GDC_LPCOL8	Pointer for GDC_COL8 format data
GDC_LPLONG	Pointer for GDC_LONG format data
GDC_LPBINIMAGE	Pointer for 32 bits unsigned integer data (binary pattern data)
GDC_VERTEX	GDC_SFLOAT format vertex data structure
GDC_BOOL	True/false(value of GDC_TRUE / GDC_FALSE) [Note] It is not used as a type of the return value of the driver command




## 5.2 Data Structure

Data structures at to define in the “Graphics Driver” is shown in the following.

### 5.2.1 GDC\_FIXED32 [32 bits fixed point]

A fixed point data with sign described in sign 1 bit, integer 15 bits, fraction 16 bits.



S: Sign (1 bit)

0:Positive number or zero

1:Negative number

I: Integer (15 bits)


F: Fraction (16 bits)

Figure 5.2.1 GDC\_FIXED32 format

### 5.2.2 GDC\_FIXED\_SCALE [Capture scale]

A capture scale data described in integer 5 bits, fraction 11 bits.

It used by the GdcCapSetVideoCaptureScale command.



I: Integer (5 bits)

F: Fraction (11 bits)

Figure 5.2.2 GDC\_FIXED\_SCALE format

### 5.2.3 GDC\_COLOR32 [32 bits color]

A color data described in 8 bits per R, G and B respectively.

It used by the GdcVertexColor32 command.



**A:Alpha bit (8 bits)**

Sets blend ratio of vertex


**R,G,B:**

Color bit (8 bits)

Figure 5.2.3 GDC\_COLOR32 format

### 5.2.4 GDC\_COL32 [Palette color]

A color data described in 6 bits per R, G and B respectively. For C layer palette, bit 31 is an alpha bit.



**A:Alpha bit (1 bit)**

When blend mode is available, sets mode of blend

**0:Blending**

**1:Not blending**


**R,G,B:**

Color bit (6 bits)

Figure 5.2.4 GDC\_COL32 format

### 5.2.5 GDC\_COL16 [16 bits color]

A color data described in 5 bits per R, B and G respectively. When this color data format is applied to texture, bit 15 is used as an alpha bit.



A:Alpha bit (1 bit)

When blend mode is available, sets mode of blend or stencil processing

0:Blending or stencil processing

1:Not blending or stencil processing

R,G,B:

Color bit (5 bits)

Figure 5.2.5 GDC\_COL16 format

### 5.2.6 GDC\_COL8 [8 bits color]

A index code to refer to color palette in 8 bits.




Figure 5.2.6 GDC\_COL8 format

## 5.2.7 GDC\_VERTEX [GDC\_SFLOAT format vertex data structure]

GDC\_VERTEX structure is shown in the table 5.2.7.

A structure data is packed in vertex coordinates, texture coordinates and RGB value.

It used by the GdcDrawPrimitive command.

Table 5.2.7 GDC\_VERTEX structure

Type	Parameter	Description
GDC_SFLOAT	x	x coordinates of vertex (for device coordinates)
GDC_SFLOAT	y	y coordinates of vertex (for device coordinates)
GDC_SFLOAT	z	z coordinates of vertex (for device coordinates)
GDC_SFLOAT	r	r value of vertex color
GDC_SFLOAT	g	g value of vertex color
GDC_SFLOAT	b	b value of vertex color
GDC_SFLOAT	u	u texture coordinates of vertex
GDC_SFLOAT	v	v texture coordinates of vertex
GDC_SFLOAT	rw	Reciprocal w texture coordinates of vertex
long	work	Reserved

## 6 Driver Command Reference

This section describes calling conventions interface and processing contents of driver commands.

### 6.1 Explanatory notes

Each item of a driver command reference is described as below.

Format	Prototype declaration of a command.
Parameter	Description of a parameter.
Return value	The return values and the description of them.
Error code	The error code and a name of an error when a command ends abnormally. When the command ends normally, the error code is not set. In this case the error code just before is held. The error code is got by the GdcGetErrCode command. This item is omitted if the command has no return values. In some commands errors don't occur even if the commands have the return values.
Description	Description of the command.

## 6.2 System Control Commands

### 6.2.1 GdcInitialize [“Graphics driver” initialization]

Format	int GdcInitialize(int gdc_type)										
Parameter	<p>gdc_type      A type of the “Graphics Controller”</p> <table border="0" style="margin-left: 100px;"> <tr> <td>GDC_TYPE_MB86290A</td> <td>In case of using MB86290A</td> </tr> <tr> <td>GDC_TYPE_MB86291</td> <td>In case of using MB86291</td> </tr> <tr> <td>GDC_TYPE_MB86291A</td> <td>In case of using MB86291A</td> </tr> <tr> <td>GDC_TYPE_MB86292</td> <td>In case of using MB86292</td> </tr> <tr> <td>GDC_TYPE_MB86293</td> <td>In case of using MB86293</td> </tr> </table>	GDC_TYPE_MB86290A	In case of using MB86290A	GDC_TYPE_MB86291	In case of using MB86291	GDC_TYPE_MB86291A	In case of using MB86291A	GDC_TYPE_MB86292	In case of using MB86292	GDC_TYPE_MB86293	In case of using MB86293
GDC_TYPE_MB86290A	In case of using MB86290A										
GDC_TYPE_MB86291	In case of using MB86291										
GDC_TYPE_MB86291A	In case of using MB86291A										
GDC_TYPE_MB86292	In case of using MB86292										
GDC_TYPE_MB86293	In case of using MB86293										
Return value	<p>GDC_TRUE      Complete</p> <p>GDC_FALSE     Incomplete</p>										
Error code	<p>- GDC_ERR_DL_BUF_ALLOC (Failure of Display List buffer acquisition)</p> <p>- GDC_ERR_DL_SIZE (Incorrect buffer size)</p> <p>- GDC_ERR_DL_NUM (Not appropriate block count)</p>										
Description	<p>Initialize the “Graphics Driver”.</p> <p>This command precedes all driver commands, and call only once.</p> <p>If this command is called, the following system dependent commands will be called inside.</p> <ul style="list-style-type: none"> <li>- GdcSetDisplayListBuffer command</li> <li>- GdcGetHostRegisterAddress command</li> <li>- GdcGetDispRegisterAddress command</li> <li>- GdcGetDrawRegisterAddress command</li> </ul> <p>For details about initialization processing of the “Graphics Driver”, refer to "initialize.c" file in sample directory.</p> <p>This command can be used by all “Graphics Controller”.</p>										

## 6.2.2 GdcQueryVersion [Version number check]

**Format**            void GdcQueryVersion (int \*version, int \*level)

**Parameter**        **version**        Pointer to store version number

**level**            Pointer to store level number

**Return value**    None

**Description**     Indicates current version and level number of the "Graphics Driver".

Version number and level number are numerical value.

For example, when the version number is 1, and the level number is 9, the following numbers are stored in each parameter.

\*version = 1

\*level = 9

This command can be used by all "Graphics Controller".

### 6.2.3 GdcSetInternalClock [Changes internal clock frequency]

- Format**            `void GdcSetInternalClock(GDC_ULONG geo_clock, GDC_ULONG other_clock)`
- Parameter**        `geo_clock`            Clock frequency for geometry engine  
                              `GDC_CLOCK_166MHZ`    166MHz  
                              `GDC_CLOCK_133MHZ`    133MHz  
                              `GDC_CLOCK_100MHZ`    100MHz
- `other_clock`            Clock frequency for besides geometry engine  
                                      `GDC_CLOCK_133MHZ`    133MHz  
                                      `GDC_CLOCK_100MHZ`    100MHz
- Return value**      None
- Description**       Sets internal clock frequency. The combination of parameters are shown in the table 6.2.3.

Table 6.2.3 Internal clock frequency combinations

		geo_clock		
		166MHz	133MHz	100MHz
other_clock	133MHz	OK	OK	NG
	100MHz	OK	OK	OK

OK:Possible

NG:Impossible (not supported)

Be sure to execute this command just after initialization by the `GdcInitialize` command of the “Graphics Driver”.

In order to steady status of the “Graphics Controller”, 200 microsecond intervals are necessary after setting internal clock frequency before executing the following procedures.

This command is for MB86293 or later.



## 6.2.4 GdcInitDevice [Initializes the “Graphics Controller”]

**Format**            int GdcInitDevice (void)

**Parameter**        None

**Return value**     GDC\_TRUE            Complete  
                  GDC\_FALSE        Incomplete

**Description**     Initializes each register of the “Graphics Controller”.  
                      Be sure to execute this command once before calling other driver commands.  
                      However, be sure to execute the following commands before calling the GdcInitDevice command.

- GdcInitialize command
- GdcSetInternalClock command
- GdcSoftwareReset command
- GdcSetRegisterLocation command
- GdcSetMemoryMode command
- GdcSetBurstMode command

This command can be used by all “Graphics Controller”.

### 6.2.5 GdcGeoInitialize [Initialize geometry engine]

Format	int GdcGeoInitialize(void)
Parameter	None
Return value	GDC_TRUE Complete GDC_FALSE Incomplete
Error code	GDC_ERR_NOT_READY (“Graphics Driver” is not initialized)
Description	<p>Initializes internal resources in the geometric engine.</p> <p>When using drawing commands for object coordinates, be sure to call this command after initializing the “Graphics Driver”.</p> <p>However, be sure to execute the following commands before calling the GdcGeoInitialize command.</p> <ul style="list-style-type: none"> <li>- GdcInitialize command</li> <li>- GdcSetInternalClock command</li> <li>- GdcSoftwareReset command</li> <li>- GdcSetRegisterLocation command</li> <li>- GdcSetMemoryMode command</li> <li>- GdcSetBurstMode command</li> <li>- GdcInitDevice command</li> </ul> <p>This command is for MB86291 or later.</p>

### 6.2.6 GdcFlush [Drawing by Display List (Async)]

Format	GDC_ULONG GdcFlush(void)
Parameter	None
Return value	The transmitted number of byte
Description	<p>Transfers a Display List in the Display List buffer to the “Graphics Controller”. If DMA is applied, this command is completed without waiting for the end of the list transfer. If CPU writes the Display List to the “Graphics Controller”, this command is completed after the end of the list transfer.</p> <p>The transmitted number of byte is set to return value.</p> <p>This command can be used by all “Graphics Controller”.</p>

### 6.2.7 GdcVFlush [Vertical blanking interval palling (Async)]

Format	GDC_ULONG GdcVFlush(void)
Parameter	None
Return value	The transmitted number of byte
Description	<p>Transfers a Display List after attaching a command for waiting Sync command (*1) to the end of it.</p> <p>When the Sync command is executed, the “Graphics Controller” synchronize the next operation with the vertical blanking interval. By means of this function, disorder of display caused by flipping can be avoided when flipping of drawing frame (the GdcDispDoFlip command).</p> <p>Similar to the GdcFlush command, this command does not wait for the completion of MB86290 Series’ all Display List operations. Therefore, the completion of the Sync command is not guaranteed after returning from this command.</p> <p>In order to detect the completion of the Sync command, use an interrupt for termination of drawing and so on. The interrupt can be issued by executing GdcInterrupt before this GdcVFlush command.</p> <p>The transmitted number of byte is set to return value.</p> <p>This command can be used by all “Graphics Controller”.</p> <p>(*1) Sync command: It waits for drawing processing of the “Graphics Controller” until a vertical blanking interval period comes.</p>
Note	This command dose not guarantee the punctual synchronous ness with the vertical blanking interval. In order to detect the punctual vertical blanking interval, use VSYNC interrupt.

### 6.2.8 GdcVerticalSync [Adds vertical blanking interval command]

Format	int GdcVerticalSync(void)
Parameter	None
Return value	<p>GDC_TRUE Complete</p> <p>GDC_FALSE Incomplete</p>
Error code	GDC_ERR_NOT_READY (“Graphics Driver” is not initialized)
Description	<p>Attaches a command for waiting VSYNC (Sync command ) to the end of a Display List.</p> <p>Transmission of a Display List is not performed.</p> <p>This command can be used by all “Graphics Controller”.</p>

### 6.2.9 GdcInterrupt [Interrupt request to host CPU]

Format	int GdcInterrupt(void)
Parameter	None
Return value	GDC_TRUE          Complete GDC_FALSE        Incomplete
Error code	GDC_ERR_NOT_READY (“Graphics Driver” is not initialized)
Description	Generates an interrupt request. When the “Graphics Driver” works in sync mode, an interrupt request is generated immediately after the execution of this command. In async mode, a command to generate an interrupt request is put in a Display List. This command can be used by all “Graphics Controller”.

### 6.2.10 GdcExecMode [Sets execution mode]

Format	void GdcExecMode (GDC_UCHAR sync)
Parameter	sync          Sync/Async mode selection  GDC_EXECCODE_SYNC          Sync mode GDC_EXECCODE_ASYNC        Async mode
Return value	None
Description	Sets operation mode of the Display List execution. This command can be used by all “Graphics Controller”.

### 6.2.11 GdcSetDMAMode [Sets DMA mode]

Format	int GdcSetDMAMode(int tran_unit, int dma_request, int address_mode, int ack_mode)		
Parameter	tran_unit	Unit of DMA transfer	
		GDC_DMA_TRANUNIT_4	4 byte
		GDC_DMA_TRANUNIT_32	32 byte
	dma_request	DMA request	
		GDC_DMA_REQUEST_NEGATE	
		During transferring, when the “Graphics Controller” cannot receive data, DMA request is invalid (negate), and if it will be in the state where data is receivable, it will be valid (assert)	
		GDC_DMA_REQUEST_NO_NEGATE	
		Not negate while DMA is transferring Display List	
	address_mode	Address mode of external DMA request	
		GDC_DMA_ADDRMODE_DUAL	Dual address mode
		GDC_DMA_ADDRMODE_SINGLE	Single address mode
	ack_mode	ACK mode	
		GDC_DMA_ACKMODE	Uses ACK (detect DMA request at a low level signal)
		GDC_DMA_NO_ACKMODE	Not use ACK (detect DMA request at an edge)
Return value	GDC_TRUE	Complete	
	GDC_FALSE	Incomplete	
Error code	GDC_ERR_INVALID_PARAMETER(Invalid parameter is specified)		
Description	Sets DMA transfer mode to DSU (DMA Set Up) register. This command can be used by all “Graphics Controller”. However, “ack_mode” is available only for the MB86293 or later. In case of MB86290A/291/292, sets GDC_DMA_ACKMODE (uses ACK) to “ack_mode”.		

### 6.2.12 GdcGetFIFOStatus [Gets Display List FIFO status]

**Format** GDC\_ULONG GdcGetFIFOStatus(void)

**Parameter** None

**Return value** Display List FIFO status (IFSR register value) in the following format:

bit 31	---	2	1	0
0	---	x	x	x

**bit 0:** Valid data exists in Display List FIFO =0  
 Valid data not exists in Display List FIFO =1

**bit 1:** Display List FIFO is full =0  
 Display List FIFO is not full =1

**bit 2:** More than half entries of Display List FIFO are empty =0  
 More than half entries of Display List FIFO are not empty =1

All other bits:0

Figure 6.2.12 Display List FIFO status

**Description** Reads IFSR (Input FIFO Status Register) and returns current Display List FIFO status.  
 This command can be used by all “Graphics Controller”.

### 6.2.13 GdcGetFIFORemain [Gets number of Display List FIFO open entries]

**Format** GDC\_ULONG GdcGetFIFORemain(void)

**Parameter** None

**Return value** Number of open entries in the Display List FIFO


**Description** Reads IFCNT (Input FIFO CouNter) register and returns the number of open entries in the Display List FIFO.  
 This command can be used by all “Graphics Controller”.

### 6.2.14 GdcGetFIFOErrorStatus [Gets Display List FIFO error status]

**Format**            GDC\_ULONG GdcGetFIFOErrorStatus(void)

**Parameter**        None

**Return value**     Display List FIFO error status (IFSR register value) in the following format:



bit 0:    Command error (type code is not normal)    No=0,    Yes=1

bit 1:    Packet error (command code is not normal)    No=0,    Yes=1

bit 2:    FIFO overflow    No=0,    Yes=1

All other bits:0

Figure 6.2.14 Display List FIFO error status

**Description**     Reads EST (Error Status Register) and returns Display List FIFO error status.  
This command can be used by all "Graphics Controller".

### 6.2.15 GdcGetInterruptStatus [Gets interrupt status]

**Format** GDC\_UCHAR GdcGetInterruptStatus (void)

**Parameter** None

**Return value** Interrupts status (IST register value) in the following format:

bit 7	---	4	3	2	1	0
0	---	x	x	x	x	x

bit 0: Command execution error interrupt Yes=1, No=0

bit 1: Command complete interrupt Yes=1, No=0

bit 2: VSYNC interrupt Yes=1, No=0

bit 3: Frame sync interrupt Yes=1, No=0

bit 4: External sync error interrupt Yes=1, No=0

All other bits:0

Figure 6.2.15 Interrupt status

**Description** Reads IST (Interrupt Status Register) and return interrupt status.

This command is only for MB86290A.

When the "Graphics Controller" is MB86291 or later, GdcGeoGetInterruptStatus must be used.



### 6.2.16 GdcGeoGetInterruptStatus [Gets interrupt status for MB86291 or later]

**Format** GDC\_ULONG GdcGeoGetInterruptStatus(void)

**Parameter** None

**Return value** Interrupts status (IST register value) in the following format:

bit 31	---	4	3	2	1	0
0	---	x	x	x	x	x

- bit0: Command execution error interrupt Yes =1, No =0
- bit1: Command complete interrupt Yes =1, No =0
- bit2: VSYNC interrupt Yes =1, No =0
- bit3: Frame sync interrupt Yes =1, No =0
- bit4: External sync error interrupt Yes =1, No =0

All other bits:1

Figure 6.2.16 Interrupt status

**Description** Reads IST (Interrupt Status Register) and return interrupt status.  
 This command is for MB86291 or later.  
 When the "Graphics Controller" is MB86290A, GdcGetInterruptStatus must be used.

### 6.2.17 GdcClearInterruptStatus [Clears interrupt status for MB86290A]

**Format** void GdcClearInterruptStatus (GDC\_UCHAR clear)

**Parameter** clear Clear pattern (shown below)

bit 7	- - -	4	3	2	1	0
1	- - -	x	x	x	x	x

- bit 0: Command execution error interrupt Clear=0, Hold=1
- bit 1: Command complete interrupt Clear=0, Hold=1
- bit 2: VSYNC interrupt Clear=0, Hold=1
- bit 3: Frame sync interrupt Clear=0, Hold=1
- bit 4: External sync error interrupt Clear=0, Hold=1
- All other bits:1

Figure 6.2.17 Clear pattern format

**Return value** None

**Description** Clears the interrupt event indicated by 0-4 bits in ISR (Interrupt Status Register) by the clear pattern specified as above. To clear an interrupt event, respective bit in the clear pattern for that event is set to 0 and all other bits are set to 1.  
 This command is only for MB86290A.  
 When the “Graphics Controller” is MB86291 or later, the GdcGeoClearInterruptStatus command must be used.

### 6.2.18 GdcGeoClearInterruptStatus [Clears interrupt status for MB86291 or later]

**Format** void GdcGeoClearInterruptStatus(GDC\_ULONG clear)

**Parameter** clear Clear pattern (shown below)

**Return value**

bit 31	---	4	3	2	1	0
1	---	x	x	x	x	x

bit0: Command execution error interrupt Clear =0, Hold =1

bit1: Command complete interrupt Clear =0, Hold =1

bit2: VSYNC interrupt Clear =0, Hold =1

bit3: Frame sync interrupt Clear =0, Hold =1

bit4: External sync error interrupt Clear =0, Hold =1

All other bits:1

Figure 6.2.18 Clear pattern format

**Return value** None

**Description** Clears a request of interrupt, indicated by IST (Interrupt Status) register, with clear pattern.

To clear an interrupt event, respective bit in the clear pattern for that event is set to 0 and all other bits are set to 1.

This command is for MB86291 or later.

When the "Graphics Controller" is MB86290A, the GdcClearInterruptStatus command must be used.

### 6.2.19 GdcSetInterruptMask [Sets interrupt mask for MB86290A]

**Format** void GdcSetInterruptMask (GDC\_UCHAR mask)

**Parameter** mask Mask pattern (shown below)

bit 7	---	4	3	2	1	0
0	---	x	x	x	x	x

bit 0: Command error interrupt Mask=1, Enable=0

bit 1: Command complete interrupt Mask=1, Enable=0

bit 2: VSYNC interrupt Mask=1, Enable=0

bit 3: Frame sync interrupt Mask=1, Enable=0

bit 4: External sync error interrupt Mask=1, Enable=0

All other bits:0

Figure 6.2.19 Mask pattern format

**Return value** None

**Description** Sets interrupt mask pattern to IMASK (Interrupt MASK) register to disable interrupt requests generated by the respective events.

This command is only for MB86290A.

When the "Graphics Controller" is MB86291 or later, the GdcGeoSetInterruptMask command must be used.

### 6.2.20 GdcGeoSetInterruptMask [Sets interrupt mask for MB86291 or later]

**Format**            void GdcGeoSetInterruptMask(GDC\_ULONG mask)

**Parameter**        mask            Mask pattern (shown below)

bit 31	---	4	3	2	1	0
0	---	x	x	x	x	x

bit0:    Command execution error interrupt    Mask =0,    Enable =1

bit1:    Command complete interrupt        Mask =0,    Enable =1

bit2:    VSYNC interrupt                    Mask =0,    Enable =1

bit3:    Frame sync interrupt                Mask =0,    Enable =1

bit4:    External sync error interrupt        Mask =0,    Enable =1

All other bits:0

Figure 6.2.20 Mask pattern format

**Return value**    None

**Description**    Sets interrupt mask pattern to IMASK(Interrupt MASK) to disable interrupt requests generated by the respective events.

This command is for MB86291 or later.

When the "Graphics Controller" is MB86290A, the GdcSetInterruptMask command must be used.

### 6.2.21 GdcGeoGetFIFOStatus [Gets geometry Display List FIFO status]

**Format** GDC\_ULONG GdcGeoGetFIFOStatus(void)

**Parameter** None

**Return value** Geometry Display List FIFO status in the following format:

bit 31	---	2	1	0
0	---	x	x	x

**bit 0:** Valid data exists in geometry Display List FIFO =0  
 Valid data not exists in geometry Display List FIFO =1

**bit 1:** Geometry Display List FIFO is full =0  
 Geometry Display List FIFO is not full =1

**bit 2:** More than half entries of geometry Display List FIFO are empty =0  
 More than half entries of geometry Display List FIFO are not empty =1

All other bits:0

Figure 6.2.21 Display List FIFO status

**Description** Returns current geometry Display List FIFO status.  
 This command is for MB86291 or later.

### 6.2.22 GdcGeoGetFIFORemain [Gets number of geometry Display List FIFO open entries]

**Format** GDC\_ULONG GdcGeoGetFIFORemain(void)

**Parameter** None

**Return value** Number of open entries in the geometry Display List FIFO

**Description** Returns the number of open entries in the geometry Display List FIFO.  
 This command is for MB86291 or later.

### 6.2.23 GdcSetMemoryMode [Sets memory interface mode]

Format	void GdcSetMemoryMode (GDC_ULONG memorymode)
Parameter	memorymode Mode information of memory interface (MMR register set data)
Return value	None
Description	Sets memorymode value to MMR (Memory I/F Mode Register) and defines the operation mode of memory interface. Detail of the memorymode is referred to the MB86290 Series hardware specifications.  This command can be used by all "Graphics Controller".

### 6.2.24 GdcSoftwareReset [Resets by software]

Format	void GdcSoftwareReset (void)
Parameter	None
Return value	None
Description	Sets "1" to SRST (Software ReSet) register and execute software reset.  In addition, cancels Display List stored in Display List buffer.  In order to steady status of the "Graphics Controller", 32 bus clock cycles intervals are necessary after software reset before executing the following procedures.  This command can be used by all "Graphics Controller".

**6.2.25 GdcGetErrCode [Gets error code]**

Format           int   GdcGetErrCode (void)

Parameter       None

Return value    Error code

Description     Returns an error code when a driver command abnormally ends. Currently this command is applicable to GdcInitialize command only.

This command can be used by all "Graphics Controller".

**Error code**

GDC_ERR_DL_BUF_ALLOC	Failure of Display List buffer acquisition
GDC_ERR_DL_SIZE	Incorrect buffer size
	A Display List buffer size for 1 block is not a multiply of 32byte, or less than the minimum applicable size
GDC_ERR_DL_NUM	Not appropriate block count
GDC_ERR_DATA_TOO_BIG	Block count is other than 1, 2
GDC_ERR_INVALID_LAYER	Too large data
GDC_ERR_INVALID_BANK	Invalid layer is specified
GDC_ERR_INVALID_COLOR_MODE	Invalid bank is specified
GDC_ERR_INVALID_CURSOR_NUMBER	Invalid color mode is specified
GDC_ERR_ILLEGAL_DIMENSION	Invalid cursor number is specified
GDC_ERR_INVALID_ATTRIBUTE	Illegal vertical/horizontal size of pattern data
GDC_ERR_INVALID_PRIMITIVE	Invalid attribute is specified
GDC_ERR_CREMSON_OPEN_FAILED	Invalid primitive is specified
GDC_ERR_ILLEGAL_VERTEX_COUNT	Fail to initialize "Graphics Controller"
GDC_ERR_ILLEGAL_LINE_WIDTH	Illegal number of vertex
GDC_ERR_NOT_READY	Illegal width of line
GDC_ERR_INVALID_PARAMETER	"Graphics Driver" is not initialized
	Invalid parameter is specified



### 6.2.26 GdcSetRegisterLocation [Changes address of registers location]

Format	void GdcSetRegisterLocation (GDC_ULONG locate)		
Parameter	locate	Register location	
		GDC_REG_LOCATE_CENTER	Center location
		GDC_REG_LOCATE_BOTTOM	The last location
Return value	None		
Description	<p>In SH-3/SH-4 mode sets this parameter when changing the register location from center (0x1fc0000) to the last (0x3fc0000).</p> <p>Execute this command after having called the following commands.</p> <p>Be sure to execute the following commands before calling the GdcSetRegisterLocation command.</p> <ul style="list-style-type: none"> <li>- GdcInitialize command</li> <li>- GdcSetInternalClock command</li> <li>- GdcSoftwareReset command</li> </ul> <p>In order to steady status of the “Graphics Controller”, 20 bus clock cycles intervals are necessary after changes address of register location before executing the following procedures.</p> <p>This command is for MB86293 or later.</p>		

### 6.2.27 GdcSetBurstMode [Sets burst transfer mode of drawing]

Format	void GdcSetBurstMode(GDC_ULONG mode)		
Parameter	mode	Burst transfer mode	
		GDC_ENABLE	Enable
		GDC_DISABLE	Disable
Return value	None		
Description	<p>Sets burst transfer mode of drawing.</p> <p>If the bus occupation rate of drawing becomes high, all the 6 layers may not be displayed.</p> <p>In this case, sets burst transfer mode to disable.</p> <p>Be sure to execute the GdcSetMemoryMode commands before calling this command.</p> <p>This command is for MB86293 or later.</p>		

## 6.2.28 GdcQueryChipID [Queries about chip ID]

Format	void	GdcQueryChipID (int *chip_no, int *version)
Parameter	chip_no	Pointer to the area which stores chip number
	version	Pointer to the area which stores chip version number
Return value	None	
Description	Indicates chip number and chip version number. Chip number and chip version number are numerical value. For details about each number, refer to the hardware specification of the “Graphics Controller” of use. This command is for MB86293 or later.	

## 6.2.29 GdcCancelDisplayList [Cancels Display List]


Format	void	GdcCancelDisplayList (void)
Parameter	None	
Return value	None	
Description	Cancels the Display List stored in the Display List buffer. This command can be used by all “Graphics Controller”.	

### 6.2.30 GdcGetPixelEngineStatus [Gets pixel engine status]

**Format** GDC\_ULONG GdcGetPixelEngineStatus (void)

**Parameter** None

**Return value** Pixel engine status in the following format:



bit 1-0: Rendering is complete =00

Rendering is executing =01

All other bits: unsettled

Figure 6.2.30 Pixel engine status

**Description** Returns pixel engine status.

This command is only for MB86290A.


When the "Graphics Controller" is MB86291 or later, the GdcGeoGetPixelEngineStatus command must be used.

### 6.2.31 GdcGeoGetPixelEngineStatus [Gets geometry pixel engine status]

**Format** GDC\_ULONG GdcGeoGetPixelEngineStatus (void)

**Parameter** None

**Return value** Geometry pixel engine status in the following format:



bit 1-0: Rendering is complete =00

Rendering is executing =01

All other bits: unsettled

Figure 6.2.31 Geometry pixel engine status

**Description** Returns pixel engine status.

This command is only for MB86291 or later.


When the “Graphics Controller” is MB8629A, the GdcGetPixelEngineStatus command must be used.

### 6.2.32 GdcGetLocalDisplayListTransferStatus [Gets Local Display List transfer status]

**Format** GDC\_ULONG GdcGetLocalDisplayListTransferStatus (void)

**Parameter** None

**Return value** Transfer of Local Display List status in the following format:



bit 0: Transfer is complete =0

Transfer is executing =1

All other bits:0

Figure 6.2.32 Local Display List transfer status

**Description** Returns transfer of Local Display List status.

This command can be used by all “Graphics Controller”.

## 6.3 Display Commands

### 6.3.1 GdcDispClock [Sets display clock mode]

Format	void	GdcDispClock (GDC_ULONG mode)
Parameter	mode	Sets display clock mode. This parameter is directly set to the correlated hardware register of the "Graphics Controller". For details of the DCM register description, refer to the "Graphics Controller" hardware specification of use.
Return value	None	
Description	Controls display clock and sync mode by setting parameters to Display Control Mode (DCM) register. <ul style="list-style-type: none"> <li>- Sets display sync mode</li> <li>- Sets external sync mode</li> <li>- Sets signal type</li> <li>- Sets dot clock frequency</li> <li>- Sets dot clock source</li> </ul>	

This command can be used by all "Graphics Controller".

### 6.3.2 GdcDispTiming [Sets display timing parameters]

Format	void	GdcDispTiming (GDC_USHORT htp, GDC_USHORT hsp, GDC_USHORT hsw, GDC_USHORT hdp, GDC_USHORT vtr, GDC_USHORT vsp, GDC_USHORT vsw, GDC_USHORT vdp)
Parameter	htp	Total horizontal pixel count
	hsp	Hsync pulse timing
	hsw	Hsync pulse width
	hdp	Horizontal display pixel count
	vtr	Total vertical raster count
	vsp	Vsync pulse timing
	vsw	Vsync pulse width
	vdp	Vertical display raster count

Return value None

Description Sets display window size and display timing parameters.  
This command can be used by all "Graphics Controller".

### 6.3.3 GdcDispTimingWindow [Sets W-layer display position]

Format	void	GdcDispTimingWindow (GDC_USHORT x, GDC_USHORT y, GDC_USHORT w, GDC_USHORT h)
Parameter	x	x coordinate in the device coordinates
	y	y coordinate in the device coordinates
	w	Window width (pixel unit)
	h	Window height (pixel unit)
Return value	None	
Description	Sets display position of the W(Window) layer. x and y should specify the display position at the upper left of a window frame. This command can be used by all "Graphics Controller".	

### 6.3.4 GdcDispDividePos [Sets border position of screen partition]

Format	void	GdcDispDividePos (GDC_USHORT hdb)
Parameter	hdb	Horizontal pixel count of left window
Return value	None	
Description	Sets the border of left/right layers when screen partition mode is applied. When the value 0 is set, 1 line of right window is displayed as well as the value 1 is set. This command can be used by all "Graphics Controller".	

### 6.3.5 GdcDispDimension [Sets display frame attribute]

Format	int GdcDispDimension (GDC_UCHAR layer, GDC_UCHAR enable, GDC_UCHAR cmode, GDC_UCHAR fmode, GDC_ULONG loa0, GDC_ULONG loa1, GDC_USHORT lw, GDC_USHORT lh)	
Parameter	layer	Layer selection  GDC_DISP_LAYER_C C layer GDC_DISP_LAYER_W W layer GDC_DISP_LAYER_ML ML layer GDC_DISP_LAYER_MR MR layer GDC_DISP_LAYER_BL BL layer GDC_DISP_LAYER_BR BR layer  [When the "Graphics Controller" is MB86293 or later, following functions are available] GDC_DISP_LAYER_L0 L0 layer GDC_DISP_LAYER_L1 L1 layer GDC_DISP_LAYER_L2 L2 layer GDC_DISP_LAYER_L3 L3 layer GDC_DISP_LAYER_L4 L4 layer GDC_DISP_LAYER_L5 L5 layer
	enable	Layer display enable/disable  GDC_ENABLE Layer display enable GDC_DISABLE Layer display disable
	cmode	Color mode selection  GDC_24BPP_FORMAT 24 bits color mode (*1) GDC_16BPP_FORMAT 16 bits color mode GDC_8BPP_FORMAT 8 bits color mode
	fmode	Flipping mode selection  GDC_FLIPMODE_0 Display Bank 0 GDC_FLIPMODE_1 Display Bank 1 GDC_FLIPMODE_AUTO Display both banks alternately
	loa0	Base address of logical frame of bank 0
	loa1	Base address of logical frame of bank 1
	lw	Logical frame width (pixel unit)
	lh	Logical frame height (pixel unit)
Return value	GDC_TRUE	Complete
	GDC_FALSE	Incomplete
Error code	GDC_ERR_INVALID_LAYER (Invalid layer is specified)	
Description	Sets attributes of logical frame independently for C, W, ML, MR, BL and BR. In B and M layer, if either L(Left) or R(Right) layer is enables, the other side layer is also	

enabled automatically. For W layer, cmode, fmode, loa1 and lh are not applied.

When layer specification is W layer, each variable of cmode, fmode, and loa1 and lh is not used.

When the following macros are set to display or not to display layers, both ML and MR, both BL and BR layers are displayed simultaneously.

- GDC\_DISP\_LAYER\_ML
- GDC\_DISP\_LAYER\_MR
- GDC\_DISP\_LAYER\_BL
- GDC\_DISP\_LAYER\_BR

When the following macros are set to display or not to display layers, layers can be displayed or not displayed individually.

- GDC\_DISP\_LAYER\_L2
- GDC\_DISP\_LAYER\_L3
- GDC\_DISP\_LAYER\_L4
- GDC\_DISP\_LAYER\_L5

When the L5 layer is used as a blend coefficient layer, this layer must be displayed in 8 bits color mode.

In case of extend display mode, L4 and L5 layer are not available in 8 bits color mode.

When the L5 layer is used as a blend coefficient layer, this layer must be displayed in 8 bits color mode (except L5 layer is used as a blend coefficient layer).

This command can be used by all "Graphics Controller".

(\*1)The 24 bits color mode function is for MB86293 or later, and this mode can be used with the "Graphics Controller" supporting the 24 bits color mode option.



### 6.3.6 GdcDispOn [Asserts video signal output]

**Format**            void GdcDispOn (void)

**Parameter**        None

**Return value**     None

**Description**      Outputs video signals.

Screen display is started at this command call, so this command must be called after all the rest display parameters are set. Nothing is displayed prior to this command call.

This command can be used by all "Graphics Controller".

### 6.3.7 GdcDispOff [Negates video signal output]

**Format**            void GdcDispOff (void)

**Parameter**        None

**Return value**     None

**Description**      Disables screen display of video signals.

This command can be used by all "Graphics Controller".

### 6.3.8 GdcDispLayerOn [Asserts screen display]

**Format**            int GdcDispLayerOn (GDC\_UCHAR layer)

**Parameter**        layer                    Layer selection

GDC\_DISP\_LAYER\_C    C layer  
 GDC\_DISP\_LAYER\_W    W layer  
 GDC\_DISP\_LAYER\_M    M layer  
 GDC\_DISP\_LAYER\_B    B layer

[When the “Graphics Controller” is MB86293 or later,  
 following functions are available]

GDC\_DISP\_LAYER\_L0    L0 layer  
 GDC\_DISP\_LAYER\_L1    L1 layer  
 GDC\_DISP\_LAYER\_L2    L2 layer  
 GDC\_DISP\_LAYER\_L3    L3 layer  
 GDC\_DISP\_LAYER\_L4    L4 layer  
 GDC\_DISP\_LAYER\_L5    L5 layer

**Return value**    GDC\_TRUE            Complete  
                   GDC\_FALSE          Incomplete

**Error code**        GDC\_ERR\_INVALID\_LAYER (Invalid layer is specified)

**Description**      Displays the layer specified by the layer parameter.  
 When the following macros are set to display layers, both ML and MR, both BL and BR layers are displayed simultaneously.

- GDC\_DISP\_LAYER\_M
- GDC\_DISP\_LAYER\_B

When the L5 layer is used as a blend coefficient layer, this layer must be displayed.  
 This command can be used by all “Graphics Controller”.

### 6.3.9 GdcDispLayerOff [Negates screen display]

**Format**            int GdcDispLayerOff (GDC\_UCHAR layer)

**Parameter**        layer                    Layer selection

GDC\_DISP\_LAYER\_C    C layer  
 GDC\_DISP\_LAYER\_W    W layer  
 GDC\_DISP\_LAYER\_M    M layer  
 GDC\_DISP\_LAYER\_B    B layer

[When the “Graphics Controller” is MB86293 or later,  
 following functions are available]

GDC\_DISP\_LAYER\_L0    L0 layer  
 GDC\_DISP\_LAYER\_L1    L1 layer  
 GDC\_DISP\_LAYER\_L2    L2 layer  
 GDC\_DISP\_LAYER\_L3    L3 layer  
 GDC\_DISP\_LAYER\_L4    L4 layer  
 GDC\_DISP\_LAYER\_L5    L5 layer

**Return value**    GDC\_TRUE            Complete

GDC\_FALSE            Incomplete

**Error code**        GDC\_ERR\_INVALID\_LAYER (Invalid layer is specified)

**Description**      Stops the display of specified layer.

When the following macros are set to not display layers, both ML and MR, both BL and BR layers are not displayed simultaneously.

- GDC\_DISP\_LAYER\_M
- GDC\_DISP\_LAYER\_B

This command can be used by all “Graphics Controller”.

### 6.3.10 GdcDispPos [Sets display start position]

Format	int GdcDispPos (GDC_UCHAR layer, GDC_UCHAR bank, GDC_USHORT dx, GDC_USHORT dy)	
Parameter	layer	Layer selection  GDC_DISP_LAYER_C C layer GDC_DISP_LAYER_ML ML layer GDC_DISP_LAYER_MR MR layer GDC_DISP_LAYER_BL BL layer GDC_DISP_LAYER_BR BR layer
	bank	Logical frame bank selection  GDC_DISP_BANK_0 Bank 0 GDC_DISP_BANK_1 Bank 1
	dx	x coordinates of display start position
	dy	y coordinates of display start position
Return value	GDC_TRUE	Complete
	GDC_FALSE	Incomplete
Error code	- GDC_ERR_INVALID_LAYER (Invalid layer is specified) - GDC_ERR_INVALID_BANK (Invalid bank is specified)	
Description	Sets the display start position by the distance from the base position of logical frame. This command can be used by all "Graphics Controller".	

### 6.3.11 GdcDispDoFlip [Flips display bank]

Format	int GdcDispDoFlip (GDC_UCHAR layer, GDC_UCHAR bank)		
Parameter	layerq	Layer selection	
		GDC_DISP_LAYER_ML	ML layer
		GDC_DISP_LAYER_MR	MR layer
		GDC_DISP_LAYER_BL	BL layer
		GDC_DISP_LAYER_BR	BR layer
bank	Logical frame bank selection		
	GDC_DISP_BANK_0	Bank 0	
	GDC_DISP_BANK_1	Bank 1	
Return value	GDC_TRUE	Complete	
	GDC_FALSE	Incomplete	
Error code	- GDC_ERR_INVALID_LAYER (Invalid layer is specified)		
	- GDC_ERR_INVALID_BANK (Invalid bank is specified)		
Description	Switching displays (flipping).		
	This command can be used by all "Graphics Controller".		

### 6.3.12 GdcOverlayPriorityMode [Sets overlay display mode]

Format	int GdcOverlayPriorityMode (GDC_UCHAR mode)		
Parameter	mode	C layer overlay mode	
		GDC_OVERLAY_C_PRIORITY	Simple priority mode (default)
		GDC_OVERLAY_C_BLEND	Blend mode
Return value	GDC_TRUE	Complete	
	GDC_FALSE	Incomplete	
Error code	None		
Description	Sets overlay display mode. When simple priority mode is selected, C layer is displayed at the top of all the layers all the time. When blend mode is selected, after displaying all the rest layers according to the priority order, C layer color is transparently blended with the rest layers.		
	This command can be used by all "Graphics Controller".		

### 6.3.13 GdcOverlayBlend [Sets blend parameter for overlay blend]

Format	int	GdcOverlayBlend (GDC_UCHAR select, GDC_UCHAR blend)
Parameter	enable	Overlay blend selection
		GDC_BLEND_RATIO_C      Blend target is C layer color GDC_BLEND_RATIO_WMB    Blend target is W/M/B layer color
	blend	Blending ratio (only upper 4 bits are valid) Effective values are 0x00-0xf0
Return value	GDC_TRUE	Complete
	GDC_FALSE	Incomplete
Error code	None	
Description	Sets the blend coefficient to determine the C layer color when the overlay mode is blend mode.	

The followings are the meanings of blend coefficient and formula to determine the C layer color.

[Blend coefficient]

Blend	Blend coefficient
0x00	0
0x10	1/16
0x20	2/16
0x30	3/16
:	:
0xf0	15/16

[Blend formula]

- For GDC\_BLEND\_RATIO\_C

$$(C\_layer\_color * blend\_coefficient) + (W/M/B\_layer\_compound\_color * (1 - blend\_coefficient))$$

- For GDC\_BLEND\_RATIO\_WMB

$$(C\_layer\_color * (1 - blend\_coefficient)) + (W/M/B\_layer\_compound\_color * blend\_coefficient)$$

This command can be used by all "Graphics Controller".

### 6.3.14 GdcDispDisplayMode [Sets display mode]

Format            int   GdcDispDisplayMode (GDC\_UCHAR mode)

Parameter	mode	Display mode
		GDC_STANDARD_MODE            Standard display mode (default)
		GDC_OVERLAY_EXT_MODE        Extend overlay mode
		GDC_WINDOW_MODE             Window mode
		GDC_EXTEND_MODE              Extend display mode

Return value    GDC\_TRUE       Complete  
                   GDC\_FALSE      Incomplete

Error code       None

Description     Sets display mode of all layers.

                  This command is for MB86293 or later.

Difference among these modes are shown in table 6.3.14.

Table 6.3.14 Function list

Function	Extend display mode (Window mode + Extend overlay mode)	Window mode	Extend overlay mode	Standard display mode
Overlay	6 layer	6 layer	4 layer + right and left division	4 layer + right and left division
Displaying window	6 layer	6 layer	1 layer	1 layer
Displaying background color	OK	OK	OK	NG
Changes layer order	OK	NG	OK	NG
Palette number	4	2	4	2

Displayed images of extend display mode and standard display mode are shown in the figure 6.3.14




Figure 6.3.14 Displayed images of extend display mode and standard display mode

### 6.3.15 GdcDispDisplayLayerMode [Sets layer display mode]

Format        int   GdcDispDisplayLayerMode (GDC\_UCHAR layer, GDC\_ULONG mode)

Parameter	layer	Layer selection	
		GDC_DISP_LAYER_L0	L0 layer
		GDC_DISP_LAYER_L1	L1 layer
		GDC_DISP_LAYER_L2	L2 layer
		GDC_DISP_LAYER_L3	L3 layer
		GDC_DISP_LAYER_L4	L4 layer
		GDC_DISP_LAYER_L5	L5 layer
	mode	Layer display mode	
		GDC_STANDARD_MODE	Standard display mode (default)
		GDC_OVERLAY_EXT_MODE	Extend overlay mode
		GDC_WINDOW_MODE	Window mode
		GDC_EXTEND_MODE	Extend display mode

Return value    GDC\_TRUE        Complete  
                   GDC\_FALSE        Incomplete

Error code      GDC\_ERR\_INVALID\_LAYER (Invalid layer is specified)

Description     Changes display mode by each layer.

In extend display mode setting, window mode and an extend overlay mode can be set at the same time. GDC\_EXTEND\_MODE has the following meanings.

$$GDC\_EXTEND\_MODE = GDC\_WINDOW\_MODE \mid GDC\_OVERLAY\_EXT\_MODE$$

When L5 layer is used as a blend coefficient layer, this layer must be set extend display mode.

This command is for MB86293 or later.



### 6.3.16 GdcDispSetBackColor [Sets background color]

Format	int	GdcDispSetBackColor (GDC_COLOR32 color)
Parameter	color	24 bits background color
Return value	GDC_TRUE	Complete
	GDC_FALSE	Incomplete
Error code	None	
Description	Sets background color. This command is for MB86293 or later.	

### 6.3.17 GdcDispSetLayerWindow [Sets position and size of the window mode layer]

Format	int	GdcDispSetLayerWindow (GDC_UCHAR layer, GDC_USHORT x, GDC_USHORT y, GDC_USHORT w, GDC_USHORT h)
Parameter	layer	Layer selection
		GDC_DISP_LAYER_L0      L0 layer
		GDC_DISP_LAYER_L1      L1 layer
		GDC_DISP_LAYER_L2      L2 layer
		GDC_DISP_LAYER_L3      L3 layer
		GDC_DISP_LAYER_L4      L4 layer
		GDC_DISP_LAYER_L5      L5 layer
	x	x coordinates in the device coordinates
	y	y coordinates in the device coordinates
	w	Window width (pixel unit)
	h	Window height (pixel unit)
Return value	GDC_TRUE	Complete
	GDC_FALSE	Incomplete
Error code	GDC_ERR_INVALID_LAYER (Invalid layer is specified)	
Description	Sets x and y position and width and height of window mode layer. Setting to L1 layer is also available by the GdcDispTimingWindow command. This command is for MB86293 or later.	

### 6.3.18 GdcLayerOverlayPriorityMode [Sets overlay display mode in every layer]

**Format**           int   GdcLayerOverlayPriorityMode (GDC\_UCHAR layer, GDC\_UCHAR mode)

<b>Parameter</b>	<b>layer</b>	<b>Layer select</b>	
		GDC_DISP_LAYER_L0	L0 layer
		GDC_DISP_LAYER_L1	L1 layer
		GDC_DISP_LAYER_L2	L2 layer
		GDC_DISP_LAYER_L3	L3 layer
		GDC_DISP_LAYER_L4	L4 layer
		GDC_DISP_LAYER_L5	L5 layer
	<b>mode</b>	<b>Overlay mode</b>	
		GDC_OVERLAY_PRIORITY	Overlay with transparent color (default)
		GDC_OVERLAY_BLEND	Overlay with blend

**Return value**   GDC\_TRUE       Complete  
                   GDC\_FALSE     Incomplete

**Error code**     GDC\_ERR\_INVALID\_LAYER (Invalid layer is specified)

**Description**   Sets overlay display mode by each layer.  
                   Setting of C layer by the GdcOverlayPriorityMode command reflects on L0 layer.  
                   On the contrary, setting to L0 layer by this command refracts on C layer.  
                   When L5 layer is used as a blend coefficient layer, this layer is not target of overlaying by transparent color or blend.  
                   This command is for MB86293 or later.

### 6.3.19 GdcLayerOverlayBlend [Sets blend mode in every layer]

<b>Format</b>	<b>int</b>	GdcLayerOverlayBlend (GDC_UCHAR layer, GDC_UCHAR select, GDC_UCHAR correct, GDC_UCHAR source, GDC_UCHAR blend)
<b>Parameter</b>	<b>layer</b>	<b>Layer selection</b>
		GDC_DISP_LAYER_L0            L0 layer
		GDC_DISP_LAYER_L1            L1 layer
		GDC_DISP_LAYER_L2            L2 layer
		GDC_DISP_LAYER_L3            L3 layer
		GDC_DISP_LAYER_L4            L4 layer
		GDC_DISP_LAYER_L5            L5 layer
	<b>select</b>	<b>Selects of blend calculating method</b> GDC_BLEND_CURRENT_RATIO layer color * blend ratio + lower layer color *(1 - blend ratio) GDC_BLEND_ONE_MINUS_CURRENT_RATIO layer color * (1 - blend ratio) + lower layer color * blend ratio
	<b>correct</b>	<b>Correction by 1/256 value</b> GDC_BLEND_NO_CORRECT Uses the blend ratio GDC_BLEND_CORRECT When the blend ratio is not 0, add 1/256 (When using the blend ratio of 100%)
	<b>source</b>	<b>Selects source data of the blend ratio</b> GDC_BLEND_RATIO_CONSTANT Uses the fixed value as blend ratio specified by "blend" GDC_BLEND_RATIO_L5 Uses pixel value of L5 layer for the blend ratio
	<b>blend</b>	<b>Blend ratio coefficient</b> (used when "source" is GDC_BLEND_RATIO_CONSTANT) Effective values are 0-255
<b>Return value</b>	GDC_TRUE	Complete
	GDC_FALSE	Incomplete
<b>Error code</b>	GDC_ERR_INVALID_LAYER (Invalid layer is specified)	

**Description**     Sets the blend mode when overlay priority mode is “overlay with blend (GDC\_OVERLAY\_BLEND)”.

Setting by the GdcOverlayBlend command reflect on L0 layer.

“correct” and “source” are set to GDC\_BLEND\_NO\_CORRECT and GDC\_BLEND\_RATIO\_CONSTANT respectively when the mode is set by the GdcOverlayBlend command.

Setting of “source” is not valid when L5 layer is set.

When the L5 layer is used as a blend coefficient layer, set L5 layer as extend display mode by the GdcDispDisplayLayerMode command.

When the L1 layer is capture mode and L5 layer is used as blend coefficient layer, L1 layer is not blended correctly.

This command is for MB86293 or later.



## 6.4 Color Control Commands

### 6.4.1 GdcColorPalette [Sets palette colors]

Format	int GdcColorPalette (GDC_UCHAR layer, GDC_UCHAR number, GDC_UCHAR size, GDC_LPPCOL32 lpColor)	
Parameter	layer	C layer, MB layer palette selection  GDC_C_LAYER_PALETTE Select C layer palette GDC_MB_LAYER_PALETTE Select MB layer palette
	number	Sets the head palette number
	size	Sets the palette number
	lpColor	Pointer to the color data
Return value	GDC_TRUE	Complete
	GDC_FALSE	Incomplete
Error code	GDC_ERR_INVALID_LAYER (Invalid layer is specified)	
Description	<p>Sets color index code to palette table. If size is set to "0", all 256 entries of selected palette are set.</p> <p>Setting of palette is available without regard to display mode.</p> <p>However, L2,L3 layer palettes are available only in extend display mode(only in MB86293 or later).</p> <p>This command can be used by all "Graphics Controller".</p>	

### 6.4.2 GdcColorTransparent [Sets transparent color]

Format	int GdcColorTransparent (GDC_UCHAR layer, GDC_COLOR32 color)	
Parameter	layer	Layer selection
		GDC_DISP_LAYER_C C layer
		GDC_DISP_LAYER_ML ML layer
		GDC_DISP_LAYER_MR MR layer
	color	Transparent color code
Return value	GDC_TRUE	Complete
	GDC_FALSE	Incomplete
Error code	GDC_ERR_INVALID_LAYER (Invalid layer is specified)	
Description	Sets transparent color code. In indirect color mode (in which color palette is applied), the lower 8 bits is used.	
	L0, L2, L3 layers correspond to C, ML and MR layers.	
	The following values are used by color mode of layer.	
	- 8 bits color mode	: lower 8 bits of "color"
	- 16 bits color mode	: lower 16 bits of "color"
	- 24 bits color mode	: lower 24 bits of "color"
	This command can be used by all "Graphics Controller".	

### 6.4.3 GdcColorZeroMode [Sets color code 0 mode]

Format	int GdcColorZeroMode (GDC_UCHAR layer, GDC_UCHAR mode)		
Parameter	layer	Layer selection	
		GDC_DISP_LAYER_C	C layer
		GDC_DISP_LAYER_ML	ML layer
		GDC_DISP_LAYER_MR	MR layer
mode		Color 0 mode	
		GDC_COLOR_NOTTRANSPARENT	Not transparent color
		GDC_COLOR_TRANSPARENT	Transparent color
Return value	GDC_TRUE	Complete	
	GDC_FALSE	Incomplete	
Error code	GDC_ERR_INVALID_COLOR_MODE (Invalid color mode is specified)		
Description	Select handling of color value 0 (palette number 0) from the following.		
		<ul style="list-style-type: none"> <li>- Not treaded as transparent color, and treated as normal color value (palette number)</li> <li>- Treated as transparent color</li> </ul>	
	This command can be used by all "Graphics Controller".		

### 6.4.4 GdcChromaKeyMode [Sets Chroma-key mode]

Format	int GdcChromaKeyMode (GDC_UCHAR mode, GDC_UCHAR source)		
Parameter	mode	Chroma-key mode selection	
		GDC_ENABLE	Chroma-key operation enable
		GDC_DISABLE	Chroma-key operation disable
source		Source key color selection	
		GDC_CHROMAKEY_C	C layer color
		GDC_CHROMAKEY_DISP	Display color
Return value	GDC_TRUE	Complete	
	GDC_FALSE	Incomplete	
Error code	None		
Description	Sets whether Chroma-key is operated. When Chroma-key is operated, select target to be compared between C layer color and display color. When Chroma-key is not operated, setting of target of key color to be compared has no meaning.		
	This command can be used by all "Graphics Controller".		



### 6.4.5 GdcColorKey [Sets key color for Chroma-key]

Format	int GdcColorKey (GDC_COL16 color)	
Parameter	color	Key color for Chroma-key operation
Return value	GDC_TRUE	Complete
	GDC_FALSE	Incomplete
Error code	None	
Description	Sets the key color for Chroma-key operation. In indirect mode, the lower 8bit of this key color is applied as the color code of the key color. This command can be used by all "Graphics Controller".	

### 6.4.6 GdcColorPaletteOffset [Sets of the color palette offset]

Format	int GdcColorPalette (GDC_UCHAR layer, GDC_UCHAR number, GDC_UCHAR size, GDC_LPPCOL32 lpColor)	
Parameter	layer	Palette selection
		GDC_C_LAYER_PALETTE Selects C layer palette
		GDC_MB_LAYER_PALETTE Selects MB layer palette
		GDC_L0_LAYER_PALETTE Selects L0 layer palette (same as C layer palette)
		GDC_L1_LAYER_PALETTE Selects L1 layer palette (same as MB layer palette)
		GDC_L2_LAYER_PALETTE Selects L2 layer palette
		GDC_L3_LAYER_PALETTE Selects L3 layer palette
	sub_no	Sub palette number (Serial number of 16 divided parts of 256 palette) The range of value is 0-15, and more than 16 are not valid
Return value	GDC_TRUE	Complete
	GDC_FALSE	Incomplete
Error code	GDC_ERR_INVALID_LAYER (Invalid layer is specified)	
Description	Sets the sub palette number of the color palette. Sub palette number is the serial number of 16 divided parts of 256 palette. This command is for MB86293 or later.	

[Example of usage of the GdcColorPaletteOffset command]

Example for changing color set number to each sub palette numbers is shown in the figure 6.4.6.

In this example, 16 sub palettes have been already assigned to L0 layer palette.

GdcColorPaletteOffset(GDC_L0_LAYER_PALETTE, "sub palette number")		
	L0 layer palette	
sub palette number 0	palette 0	Palette 0 of sub palette number 0
	:	:
	:	:
sub palette number 1	palette 15	Palette 15 of sub palette number 0
	palette 16	Palette 0 of sub palette number 1
	:	:
	:	:
	:	:
sub palette number 15	palette 31	Palette 15 of sub palette number 1
	:	:
	:	:
	:	:
	:	:
sub palette number 15	palette 240	Palette 0 of sub palette number 15
	:	:
	:	:
	palette 255	Palette 15 of sub palette number 15

Figure 6.4.6 Example of usage of the GdcColorPaletteOffset command

## 6.5 Cursor Control Commands

### 6.5.1 GdcCursorAddress [Sets cursor pattern memory address]

Format	int GdcCursorAddress (GDC_UCHAR numCursor, GDC_ULONG lads)	
Parameter	numCursor	Cursor number (0 or 1)
	lads	Cursor pattern address
Return value	GDC_TRUE	Complete
	GDC_FALSE	Incomplete
Error code	GDC_ERR_INVALID_CURSOR_NUMBER (Invalid cursor number is specified)	
Description	Sets the start address of the graphics memory where the cursor pattern is stored. This command can be used by all "Graphics Controller".	

### 6.5.2 GdcCursorPattern [Sets cursor pattern]

Format	int GdcCursorPattern (GDC_UCHAR numCursor, GDC_LPCOL8 lpCursor)	
Parameter	numCursor	Cursor number (0 or 1)
	lpCursor	Pointer of cursor pattern
Return value	GDC_TRUE	Complete
	GDC_FALSE	Incomplete
Error code	GDC_ERR_INVALID_CURSOR_NUMBER (Invalid cursor number is specified)	
Description	Sets a cursor pattern. Transfer a cursor pattern data in main memory pointed via lpCursor to the graphics memory that start address is designated by the GdcCursorAddress command. Size of cursor pattern is fixed to 64*64. This command can be used by all "Graphics Controller".	

### 6.5.3 GdcCursorDisplay [Controls cursor display]

Format	int GdcCursorDisplay (GDC_UCHAR numCursor, GDC_UCHAR enable)		
Parameter	numCursor	Cursor number (0 or 1)	
	enable	Cursor display ON/OFF	
		GDC_ENABLE	Cursor display ON
		GDC_DISABLE	Cursor display OFF
Return value	GDC_TRUE	Complete	
	GDC_FALSE	Incomplete	
Error code	GDC_ERR_INVALID_CURSOR_NUMBER (Invalid cursor number is specified)		
Description	Controls cursor display ON or OFF. This command can be used by all "Graphics Controller".		

### 6.5.4 GdcCursorPos [Sets cursor display position]

Format	int GdcCursorPos (GDC_UCHAR numCursor, GDC_USHORT x, GDC_USHORT y)		
Parameter	numCursor	Cursor number (0 or 1)	
	x	x coordinates of cursor display position	
	y	y coordinates of cursor display position	
Return value	GDC_TRUE	Complete	
	GDC_FALSE	Incomplete	
Error code	GDC_ERR_INVALID_CURSOR_NUMBER (Invalid cursor number is specified)		
Description	Sets display position of cursor. This command can be used by all "Graphics Controller".		

### 6.5.5 GdcCursorPriority [Sets cursor display priority mode]

Format	int GdcCursorPriority (GDC_UCHAR numCursor, GDC_UCHAR mode)		
Parameter	numCursor	Cursor number (0 or 1)	
	mode	Cursor display priority mode	
		GDC_PRIORITY_C_LAYER	C layer is prioritized
		GDC_PRIORITY_CURSOR	Cursor is prioritized
Return value	GDC_TRUE	Complete	
	GDC_FALSE	Incomplete	
Error code	GDC_ERR_INVALID_CURSOR_NUMBER (Invalid cursor number is specified)		
Description	Selects which is prioritized in display, C layer or cursor. This command can be used by all "Graphics Controller".		

### 6.5.6 GdcCursorColorTransparent [Sets cursor transparent color]

Format	int GdcCursorColorTransparent (GDC_COL8 color)		
Parameter	color	Color code to be treat as transparent color	
Return value	GDC_TRUE	Complete	
	GDC_FALSE	Incomplete	
Error code	None		
Description	Sets a transparent color code for cursor. This command can be used by all "Graphics Controller".		

### 6.5.7 GdcCursorColorZeroMode [Sets cursor color code 0 mode]

Format	int	GdcCursorColorZeroMode (GDC_UCHAR mode)
Parameter	mode	Color code 0 mode
		GDC_COLOR_NOTTRANSPARENT    Not transparent color
		GDC_COLOR_TRANSPARENT        Transparent color
Return value	GDC_TRUE	Complete
	GDC_FALSE	Incomplete
Error code	GDC_ERR_INVALID_COLOR_MODE (Invalid color mode is specified)	
Description	<p>Selects the color option applied for color code 0 in cursor pattern. Color code 0 is treated as either transparent color or ordinary color code.</p> <p>This command can be used by all "Graphics Controller".</p>	

## 6.6 Drawing Frame Control Commands

### 6.6.1 GdcDrawDimension [Sets drawing frame]

Format	int GdcDrawDimension (GDC_UCHAR cmode, GDC_ULONG dadr, GDC_USHORT dw, GDC_USHORT dh)	
Parameter	cmode	Color mode  GDC_24BPP_FORMAT 24 bits color mode GDC_16BPP_FORMAT 16 bits color mode (default) GDC_8BPP_FORMAT 8 bits color mode
	dadr	Drawing frame base address
	dw	Drawing frame width (pixel unit)
	dh	Drawing frame height (pixel unit)
Return value	GDC_TRUE	Complete
	GDC_FALSE	Incomplete
Error code	GDC_ERR_INVALID_COLOR_MODE (Invalid color mode is specified)	
Description	Sets color mode and size of drawing frame. This command can be used by all "Graphics Controller".	

### 6.6.2 GdcSetZPrecision [Sets precision of Z value]

Format	int GdcSetZPrecision (GDC_ULONG mode)	
Parameter	mode	Precision of Z value  GDC_Z_16BIT Precision of Z value is 16 bits (default) GDC_Z_8BIT Precision of Z value is 8 bits
Return value	GDC_TRUE	Complete
	GDC_FALSE	Incomplete
Error code	GDC_ERR_NOT_READY ("Graphics Driver" is not initialized)	
Description	Sets precision of Z value. This command is for MB86293 or later.	

### 6.6.3 GdcBufferCreateZ [Sets Z buffer base address]

Format	int GdcBufferCreateZ (GDC_ULONG zadr)	
Parameter	zadr	Z buffer base address
Return value	GDC_TRUE	Complete
	GDC_FALSE	Incomplete
Error code	GDC_ERR_NOT_READY (“Graphics Driver” is not initialized)	
Description	Sets the base address of Z buffer. The vertical/horizontal size of Z buffer is assumed to be equal to that of drawing frame.	
	When precision of Z value is 16 bits, memory size of 16 bits per 1 pixel is needed.	
	When precision of Z value is 8 bits, memory size of 8 bits per 1 pixel is needed.	
	This command can be used by all “Graphics Controller”.	

### 6.6.4 GdcBufferCreateC [Sets base address of polygon drawing flag buffer]

Format	int GdcBufferCreateC (GDC_ULONG cadr)	
Parameter	cadr	Polygon drawing control buffer base address
Return value	GDC_TRUE	Complete
	GDC_FALSE	Incomplete
Error code	GDC_ERR_NOT_READY (“Graphics Driver” is not initialized)	
Description	Sets the base address of polygon drawing control buffer. The vertical/horizontal size of this control buffer is assumed to be equal to that of drawing frame. For each pixel, 1bit of data is required for this buffer.	
	This command can be used by all “Graphics Controller”.	

### 6.6.5 GdcBufferClearZ [Clears Z buffer]

Format	int GdcBufferClearZ (void)	
Parameter	None	
Return value	GDC_TRUE	Complete
	GDC_FALSE	Incomplete
Error code	GDC_ERR_NOT_READY (“Graphics Driver” is not initialized)	
Description	Clears Z buffer. Prior to hidden surface manipulation, Z buffer should be cleared.	
	This command can be used by all “Graphics Controller”.	



### 6.6.6 GdcBufferClearC [Clears polygon drawing flag buffer]

Format	int GdcBufferClearC (void)
Parameter	None
Return value	GDC_TRUE Complete GDC_FALSE Incomplete
Error code	GDC_ERR_NOT_READY (“Graphics Driver” is not initialized)
Description	Clears polygon drawing flag buffer. This command can be used by all “Graphics Controller”.

### 6.6.7 GdcDrawClipFrame [Sets drawing clip border]

Format	int GdcDrawClipFrame (GDC_USHORT x0, GDC_USHORT y0, GDC_USHORT x1, GDC_USHORT y1)
Parameter	x0 x coordinates of left top edge of clip border y0 y coordinates of left top edge of clip border x1 x coordinates of right bottom edge of clip border y1 y coordinates of right bottom edge of clip border
Return value	GDC_TRUE Complete GDC_FALSE Incomplete
Error code	GDC_ERR_NOT_READY (“Graphics Driver” is not initialized)
Description	Sets clip border of drawing. Clip border is set as a Blt located relatively from the base point of drawing frame. Drawing to the area outside of this clip border is not performed. This command can be used by all “Graphics Controller”.

### 6.6.8 GdcSetAlphaMapBase [Sets base address of alpha map area]

Format           int GdcSetAlphaMapBase (GDC\_ULONG adrs)

Parameter       adrs               Alpha map area base address

Return value    GDC\_TRUE         Complete

                  GDC\_FALSE       Incomplete

Error code       GDC\_ERR\_NOT\_READY (“Graphics Driver” is not initialized)

Description     Sets the base address of alpha map area.

Alpha map area is an alpha coefficient area to be used by the GdcBltCopyAltAlpha command. An offset from the graphics memory top must be set to “adrs”.

For details about alpha map, refer to hardware specification of the “Graphics Controller”.

This command is for MB86293 of later.

## 6.7 Primitive Drawing Commands for Device Coordinates

### 6.7.1 GdcPrimType [Starts drawing procedure]

Format	int GdcPrimType (GDC_UCHAR type)																																							
Parameter	<table border="0" style="width: 100%;"> <tr> <td style="vertical-align: top;">type</td> <td style="vertical-align: top;">Sets primitive type</td> <td></td> </tr> <tr> <td></td> <td>GDC_POINTS</td> <td>Point</td> </tr> <tr> <td></td> <td>GDC_LINE</td> <td>Line</td> </tr> <tr> <td></td> <td>GDC_POLYLINE</td> <td>Poly-line</td> </tr> <tr> <td></td> <td>GDC_LINES_FAST</td> <td>Fast 2D line</td> </tr> <tr> <td></td> <td>GDC_POLYLINE_FAST</td> <td>Fast 2D poly-line</td> </tr> <tr> <td></td> <td>GDC_TRIANGLES</td> <td>Triangle</td> </tr> <tr> <td></td> <td>GDC_TRIANGLE_STRIP</td> <td>Triangle strip</td> </tr> <tr> <td></td> <td>GDC_TRIANGLE_FAN</td> <td>Triangle fan</td> </tr> <tr> <td></td> <td>GDC_POLYGON</td> <td>Polygon</td> </tr> <tr> <td></td> <td>GDC_TRIANGLES_FAST</td> <td>Fast 2D triangle</td> </tr> <tr> <td></td> <td>GDC_TRIANGLE_STRIP_FAST</td> <td>Fast 2D triangle strip</td> </tr> <tr> <td></td> <td>GDC_TRIANGLE_FAN_FAST</td> <td>Fast 2D triangle fan</td> </tr> </table>	type	Sets primitive type			GDC_POINTS	Point		GDC_LINE	Line		GDC_POLYLINE	Poly-line		GDC_LINES_FAST	Fast 2D line		GDC_POLYLINE_FAST	Fast 2D poly-line		GDC_TRIANGLES	Triangle		GDC_TRIANGLE_STRIP	Triangle strip		GDC_TRIANGLE_FAN	Triangle fan		GDC_POLYGON	Polygon		GDC_TRIANGLES_FAST	Fast 2D triangle		GDC_TRIANGLE_STRIP_FAST	Fast 2D triangle strip		GDC_TRIANGLE_FAN_FAST	Fast 2D triangle fan
type	Sets primitive type																																							
	GDC_POINTS	Point																																						
	GDC_LINE	Line																																						
	GDC_POLYLINE	Poly-line																																						
	GDC_LINES_FAST	Fast 2D line																																						
	GDC_POLYLINE_FAST	Fast 2D poly-line																																						
	GDC_TRIANGLES	Triangle																																						
	GDC_TRIANGLE_STRIP	Triangle strip																																						
	GDC_TRIANGLE_FAN	Triangle fan																																						
	GDC_POLYGON	Polygon																																						
	GDC_TRIANGLES_FAST	Fast 2D triangle																																						
	GDC_TRIANGLE_STRIP_FAST	Fast 2D triangle strip																																						
	GDC_TRIANGLE_FAN_FAST	Fast 2D triangle fan																																						
Return value	<table border="0" style="width: 100%;"> <tr> <td style="vertical-align: top;">GDC_TRUE</td> <td>Complete</td> </tr> <tr> <td style="vertical-align: top;">GDC_FALSE</td> <td>Incomplete</td> </tr> </table>	GDC_TRUE	Complete	GDC_FALSE	Incomplete																																			
GDC_TRUE	Complete																																							
GDC_FALSE	Incomplete																																							
Error code	<ul style="list-style-type: none"> <li>- GDC_ERR_INVALID_PRIMITIVE (Invalid primitive is specified)</li> <li>- GDC_ERR_NOT_READY (“Graphics Driver” is not initialized)</li> </ul>																																							
Description	<p>Sets the primitive type to be drawn by the GdcDrawVertex2D[i] or the GdcDrawVertex3D[f] command. Once either of these commands is executed, same type of primitive will keep being drawn till the GdcPrimEnd command will be executed.</p> <p>This command can be used by all “Graphics Controller”.</p>																																							

### 6.7.2 GdcPrimEnd [Completes drawing procedure]

Format	void GdcPrimEnd (void)
Parameter	None
Return value	None
Description	<p>Stops drawing the primitive applied by the GdcPrimType command.</p> <p>This command can be used by all “Graphics Controller”.</p>

### 6.7.3 GdcTexCoord2D / 2Df / 2DNf [Sets coordinates of 2D texture]

**Format**            `void GdcTexCoord2D (GDC_FIXED32 u, GDC_FIXED32 v)`  
`void GdcTexCoord2Df (GDC_SFLOAT u, GDC_SFLOAT v)`  
`void GdcTexCoord2DNf (GDC_SFLOAT u, GDC_SFLOAT v)`

**Parameter**        `u`            `u` coordinates of texture mapped on the vertex  
`v`            `v` coordinates of texture mapped on the vertex

**Return value**     `None`

**Description**       Sets the texture coordinates (2D) for the vertex to be drawn by the vertex coordinate setting command. Once this command is executed, the same texture coordinates is continuously applied till this command will be executed.

The `GdcTexCoord2D` command must be used when the type of texture coordinate is `GDC_FIXED32`.

The `GdcTexCoord2Df` command must be used when the type of texture coordinate is `GDC_SFLOAT`.

The `GdcTexCoord2DNf` command must be used when the type of texture coordinate is `GDC_SFLOAT` and normalized. In this case, the range of texture coordinate must be within 0.0 to 1.0. The minimum size of texture coordinate is 0.0 and the maximum size is 1.0.

This command is applicable to the following primitives:

`GDC_TRIANGLES`  
`GDC_TRIANGLE_STRIP`  
`GDC_TRIANGLE_FAN`

This command can be used by all "Graphics Controller".

### 6.7.4 GdcTexCoord3D / 3Df / 3DNf [Sets coordinates of 3D texture]

Format	<pre>void GdcTexCoord3D (GDC_FIXED32 u, GDC_FIXED32 v, GDC_FIXED32 rw) void GdcTexCoord3Df (GDC_SFLOAT u, GDC_SFLOAT v, GDC_SFLOAT rw) void GdcTexCoord3DNf (GDC_SFLOAT u, GDC_SFLOAT v, GDC_SFLOAT rw)</pre>
Parameter	<pre>u          u coordinates of texture mapped on the vertex v          v coordinates of texture mapped on the vertex rw         Reciprocal of w coordinates of texture mapped on the vertex</pre>
Return value	None
Description	<p>Sets the texture coordinates (3D) for the vertex to be drawn by the vertex coordinate setting command. Once this command is executed, the same texture coordinates is continuously applied till this command will be executed.</p> <p>The GdcTexCoord3D command must be used when the type of texture coordinate is GDC_FIXED32.</p> <p>The GdcTexCoord3Df command must be used when the type of texture coordinate is GDC_SFLOAT.</p> <p>The GdcTexCoord3DNf command must be used when the type of texture coordinate is GDC_SFLOAT and normalized. In this case, the range of texture coordinate must be within 0.0 to 1.0. The minimum size of texture coordinate is 0.0 and the maximum size is 1.0.</p> <p>This command is applicable to the following primitives:</p> <pre>GDC_TRIANGLES GDC_TRIANGLE_STRIP GDC_TRIANGLE_FAN</pre> <p>This command can be used by all "Graphics Controller".</p>

### 6.7.5 GdcDrawVertex2D / 2Di [Sets coordinates of 2D vertex]

**Format**           void GdcDrawVertex2D (GDC\_FIXED32 x, GDC\_FIXED32 y)  
                  void GdcDrawVertex2Di (GDC\_LONG x, GDC\_LONG y)

**Parameter**     **x**            **x coordinates of 2D vertex**  
                  **y**            **y coordinates of 2D vertex**

**Return value**   None

**Description**   Sets 2D vertex coordinates and drawing a designated primitive.  
  
Current values of color and texture coordinates are used in drawing, which has been set by the vertex color setting command and texture coordinates setting command respectively.  
  
The GdcDrawVertex2D command must be used when the type of vertex coordinate is GDC\_FIXED32.  
  
The GdcDrawVertex2Di command must be used when the type of vertex coordinate is GDC\_LONG.

The GdcDrawVertex2Di command is applicable to the following primitives:

- GDC\_LINES\_FAST
- GDC\_POLYLINE\_FAST
- GDC\_POLYGON
- GDC\_TRIANGLES\_FAST
- GDC\_TRIANGLE\_STRIP\_FAST
- GDC\_TRIANGLE\_FAN\_FAST

This command can be used by all "Graphics Controller".

### 6.7.6 GdcDrawVertex3D / 3Df [Sets coordinates of 3D vertex]

**Format**            void GdcDrawVertex3D (GDC\_FIXED32 x, GDC\_FIXED32 y, GDC\_USHORT z)  
                     void GdcDrawVertex3Df (GDC\_SFLOAT x, GDC\_SFLOAT y, GDC\_SFLOAT z)

**Parameter**      x            x coordinates of 3D vertex  
                     y            y coordinates of 3D vertex  
                     z            z coordinates of 3D vertex

**Return value**   None

**Description**    Sets 3D vertex coordinates and drawing a designated primitive.  
Current values of color and texture coordinates are used in drawing, which has been set by the vertex color setting command and texture coordinates setting command respectively.

The GdcDrawVertex3D command must be used when the type of vertex coordinate is GDC\_FIXED32.

The GdcDrawVertex3Df command must be used when the type of vertex coordinate is GDC\_SFLOAT.

The GdcDrawVertex3Df command is applicable to the following primitives:

GDC\_TRIANGLES  
GDC\_TRIANGLE\_STRIP  
GDC\_TRIANGLE\_FAN

When drawing a polygon primitive (GDC\_POLYGON), z coordinates of a parameter is disregarded.

This command can be used by all "Graphics Controller".

### 6.7.7 GdcDrawPrimitive [Draws multiple 3D triangles]

<b>Format</b>	<b>int</b>	<b>GdcDrawPrimitive (GDC_ULONG type, GDC_VERTEX lpVertices, int count)</b>	
<b>Parameter</b>	<b>type</b>	<b>Sets primitive type</b>	
		<b>GDC_TRIANGLES</b>	<b>Triangle</b>
		<b>GDC_TRIANGLE_STRIP</b>	<b>Triangle strip</b>
		<b>GDC_TRIANGLE_FAN</b>	<b>Triangle fan</b>
	<b>lpVertices</b>	<b>Pointer of vertex parameter list (coordinates, color texture coordinates)</b>	
	<b>count</b>	<b>Number of vertices</b>	
<b>Return value</b>	<b>GDC_TRUE</b>	<b>Complete</b>	
	<b>GDC_FALSE</b>	<b>Incomplete</b>	
<b>Error code</b>	<b>None</b>		
<b>Description</b>	<b>Draws a primitive specified in the type formed with multiple vertices designated by lpVertices.</b>		
	<b>This command can be used by all "Graphics Controller".</b>		



## 6.8 Primitive Drawing Control Commands for Object Coordinates

### 6.8.1 GdcGeoPrimType [Starts drawing procedure]

Format	int GdcGeoPrimType (GDC_UCHAR type)		
Parameter	Type	Sets primitive type	
		GDC_POINTS	Point
		GDC_LINES	Line
		GDC_POLYLINE	Poly-line
		GDC_TRIANGLES	Triangle
		GDC_TRIANGLE_STRIP	Triangle strip
		GDC_TRIANGLE_FAN	Triangle fan
		GDC_POLYGON	Polygon
Return value	GDC_TRUE	Complete	
	GDC_FALSE	Incomplete	
Error code	- GDC_ERR_INVALID_PRIMITIVE (Invalid primitive is specified)		
	- GDC_ERR_NOT_READY ("Graphics Driver" is not initialized)		
Description	Sets primitive drawn with GdcGeoDrawVertex2D[f/i] or GdcGeoDrawVertex3D[f/i]. Once this command is executed, the same primitive is drawn until the GdcGeoPrimEnd command is executed. This command is for MB86291 or later.		

### 6.8.2 GdcGeoPrimEnd [Completes drawing procedure]

Format	void GdcGeoPrimEnd (void)
Parameter	None
Return value	None
Description	Terminates a series of processes to draw primitives following the GdcGeoPrimType command. This command is for MB86291 or later.

### 6.8.3 GdcGeoDrawVertex2D / 2Df / 2Di [Sets XY coordinates of vertex ]

**Format**           void GdcGeoDrawVertex2D (GDC\_FIXED32 x, GDC\_FIXED32 y)  
                  void GdcGeoDrawVertex2Df (GDC\_SFLOAT x, GDC\_SFLOAT y)  
                  void GdcGeoDrawVertex2Di (GDC\_LONG x, GDC\_LONG y)

**Parameter**     x            x coordinates of the vertex  
                  y            y coordinates of the vertex

**Return value**  None

**Description**  Specifies a vertex coordinates in object coordinates and drawing a primitive currently set. In this case, z is treated as zero.

Current values of color and texture coordinates are used in drawing, which has been set by the vertex color setting command and texture coordinates setting command respectively.

The GdcGeoDrawVertex2D command must be used when the type of vertex coordinate is GDC\_FIXED32.

The GdcGeoDrawVertex2Df command must be used when the type of vertex coordinate is GDC\_SFLOAT.

The GdcGeoDrawVertex2Di command must be used when the type of vertex coordinate is GDC\_LONG.

This command is for MB86291 or later.

### 6.8.4 GdcGeoDrawVertex3D / 3Df / 3Di [Sets XYZ coordinates of vertex]

**Format**

```
void GdcGeoDrawVertex3D (GDC_FIXED32 x,GDC_FIXED32 y, GDC_FIXED32 z)
void GdcGeoDrawVertex3Df (GDC_SFLOAT x, GDC_SFLOAT y, GDC_SFLOAT z)
void GdcGeoDrawVertex3Di (GDC_LONG x, GDC_LONG y, GDC_FIXED32 z)
```

**Parameter**

x	x coordinates of the vertex
y	y coordinates of the vertex
z	z coordinates of the vertex

**Return value** None Complete

**Description** Sets vertex coordinates in object coordinates and drawing a primitive currently set. In this case, z is treated as zero.

Current values of color and texture coordinates are used in drawing, which has been set by the vertex color setting command and texture coordinates setting command respectively.

The GdcGeoDrawVertex3D command must be used when the type of vertex coordinate is GDC\_FIXED32.

The GdcGeoDrawVertex3Df command must be used when the type of vertex coordinate is GDC\_SFLOAT.

The GdcGeoDrawVertex3Di command must be used when the type of vertex coordinate is GDC\_LONG.

However, when drawing a polygon primitive (GDC\_POLYGON) by MB86291/86292, z coordinates of a parameter is disregarded.

This command is for MB86291 or later.

### 6.8.5 GdcGeoTexCoord2DN / 2DNf [Sets texture coordinates]

**Format**           void GdcGeoTexCoord2DN (GDC\_FIXED32 u, GDC\_FIXED32 v)  
                  void GdcGeoTexCoord2DNf (GDC\_SFLOAT u, GDC\_SFLOAT v)

**Parameter**     u           Texture u coordinates of the vertex  
                  v           Texture v coordinates of the vertex

**Return value**   None

**Description**   Sets a texture coordinates (2 dimensions) of vertex in drawing with the vertex coordinates setting command. Once this command is executed, the same texture coordinates is used in drawing unless texture coordinates is changed by this command. This command treat texture coordinates as normalized (1.0 is maximum size of current texture).

The GdcGeoTexCoord2DN command must be used when the type of texture coordinate is GDC\_FIXED32.

The GdcGeoTexCoord2DNf command must be used when the type of texture coordinate is GDC\_SFLOAT.

This command is applicable to the following primitives:

GDC\_TRIANGLES  
GDC\_TRIANGLE\_STRIP  
GDC\_TRIANGLE\_FAN

However, MB86293 or later can also be used the following primitives:

GDC\_POLYGON

This command is for MB86291 or later.

## 6.8.6 GdcVertexColor3f / 32 [Sets color of vertex]

Format	void GdcVertexColor32 (GDC_COLOR32 color)
	void GdcVertexColor3f (GDC_SFLOAT r, GDC_SFLOAT g, GDC_SFLOAT b)
Parameter	<p>color            Packed format in which each color elements (r,g,b) is normalized to [0,255]. In this case, r,g,b are 8 bits respectively.</p> <p>r, g, b          Normalized values in which each color elements (r,g,b) are normalized to [0,1].</p>
Return value	<p>GDC_TRUE        Complete</p> <p>GDC_FALSE      Incomplete</p>
Description	<p>Sets a color of vertex. Once this command is executed, the same color is used in drawing for object coordinates unless the color is changed by this command.</p> <p>This command is used when shading mode is smooth shading. If the shading mode is flat shading, use GdcColor.</p> <p>The GdcVertexColor32 command must be used when the type of vertex color is GDC_COLOR32.</p> <p>The GdcVertexColor3f command must be used when the type of vertex color is GDC_SFLOAT.</p> <p>When drawing a polygon (GDC_POLYGON), setup of this command is disregarded.</p> <p>This command is for MB86291 or later.</p>

## 6.9 Drawing Attribute Control Commands

### 6.9.1 GdcColor [Sets vertex color/foreground color]

Format           int   GdcColor (GDC\_COLOR32 color)

Parameter       color               Vertex and foreground color

Return value    GDC\_TRUE           Complete

                  GDC\_FALSE        Incomplete

Error code      None

Description     Sets vertex color and foreground color applied for bitmap drawing and broken line drawing to be executed by set coordinates of vertex command. Once this command is executed, the same color is continuously applied till this command will be executed.

The following values are used by color mode.

- 8 bits color mode               : lower 8 bits of "color"

- 16 bits color mode              : lower 16 bits of "color"

- 24 bits color mode              : lower 24 bits of "color"

This command can be used by all "Graphics Controller".

## 6.9.2 GdcBackColor [Sets background color]

Format           int   GdcBackColor (GDC\_COLOR32 color)

Parameter       color            Background color

Return value    GDC\_TRUE        Complete

                  GDC\_FALSE     Incomplete

Error code      None

Description     Sets background color applied for binary pattern drawing and broken line drawing.  
Once this command is executed, the same color is continuously applied till this command will be executed.

The following values are used by color mode.

- 8 bits color mode           : lower 8 bits of "color"

- 16 bits color mode         : lower 16 bits of "color"

- 24 bits color mode         : lower 24 bits of "color"

In order to make background color transparent, sets the following bit as 1 by color mode.

- 8 bits color mode           : bit 15 of "color"

- 16 bits color mode         : bit 15 of "color"

- 24 bits color mode         : bit 31 of "color"

This command can be used by all "Graphics Controller".

## 6.9.3 GdcClipMode [Sets clipping mode]

Format           int   GdcClipMode (GDC\_ULONG mode)

Parameter       mode            Clipping mode

                  GDC\_CLIP\_X\_ON   Validates clipping toward x axis

                  GDC\_CLIP\_Y\_ON   Validates clipping toward y axis

                  GDC\_CLIP\_DISABLE Invalidates clipping

Return value    GDC\_TRUE        Complete

                  GDC\_FALSE     Incomplete

Error code      GDC\_ERR\_NOT\_READY ("Graphics Driver" is not initialized)

Description     Sets clipping mode.  
GDC\_CLIP\_X\_ON and GDC\_CLIP\_Y\_ON can be set at the same time with OR operator.

This command can be used by all "Graphics Controller".

## 6.9.4 GdcSetAttrLine [Sets line drawing attribute]

Format	int GdcSetAttrLine (GDC_ULONG target, GDC_ULONG param)	
Parameter	target	Line drawing attribute
		GDC_DEPTH_TEST                    Z value compare mode GDC_DEPTH_FUNC                    Z value compare type GDC_DEPTH_WRITE_MASK            Z value write permission mask GDC_BLEND_MODE                    Blending mode GDC_BROKEN_LINE                  Broken line mode GDC_LINE_WIDTH                    Line width GDC_ANTI_ALIAS                    Antialias option GDC_LINE_ENDPOINT                End of the line control
		[When the "Graphics Controller" is MB86291 or later, following functions are available]
		GDC_BROKEN_LINE_OFFSET    Offset control of broken line pattern
		GDC_BROKEN_LINE_PERIOD    Period set of broken line pattern
		[When the "Graphics Controller" is MB86293 or later, following functions are available]
		GDC_SHADOW_DEPTH_TEST    Z value compare mode of shadow
		GDC_SHADOW_DEPTH_FUNC    Z value compare type of shadow
		GDC_SHADOW_DEPTH_WRITE_MASK    Z value write permission mask of shadow
		GDC_SHADOW_BLEND_MODE    Blending mode of shadow
		GDC_SHADOW_BROKEN_LINE    Broken line mode of shadow
		GDC_SHADOW_LINE_WIDTH    Line width of shadow
		GDC_SHADOW_BROKEN_LINE_PERIOD    Period set of broken line pattern of shadow
		GDC_BORDER_DEPTH_TEST    Z value compare mode of border
		GDC_BORDER_DEPTH_FUNC    Z value compare type of border
		GDC_BORDER_DEPTH_WRITE_MASK    Z value write permission mask of border
		GDC_BORDER_BLEND_MODE    Blending mode of border
		GDC_BORDER_BROKEN_LINE    Broken line mode of border
		GDC_BORDER_LINE_WIDTH    Line width of border
		GDC_BORDER_BROKEN_LINE_PERIOD    Period set of broken line pattern of border
	param	Parameter corresponding to target (*1)
Return value	GDC_TRUE	Complete
	GDC_FALSE	Incomplete
Error code	- GDC_ERR_NOT_READY ("Graphics Driver" is not initialized) - GDC_ERR_ILLEGAL_LINE_WIDTH (Illegal width of line) - GDC_ERR_INVALID_ATTRIBUTE (Invalid attribute is specified)	
Description	Sets attribute for line drawing.  This command can be used by all "Graphics Controller".	



(\*1) Line drawing attribute ( target ) and parameter (param) corresponding to each line drawing attribute is shown below.

[Explanatory notes]

Line drawing attribute	Description of line drawing attribute
Parameter 1 that can set	Description of parameter 1
Parameter 2 that can set	Description of parameter 2
:	:
<b>GDC_DEPTH_TEST</b>	Sets Z value compare mode.
GDC_ENABLE	Validates Z value comparison.
GDC_DISABLE	Invalidates Z value comparison.
<b>GDC_DEPTH_FUNC</b>	Selects Z value comparison type.
GDC_DEPTH_NEVER	Always NOT drawn.
GDC_DEPTH_ALWAYS	Always drawn.
GDC_DEPTH_LESS	Drawn if current Z value is less than Z buffer value.
GDC_DEPTH_LEQUAL	Drawn if current Z value equal to or less than Z buffer value.
GDC_DEPTH_EQUAL	Drawn if current Z value equal to Z buffer value.
GDC_DEPTH_GEQUAL	Drawn if current Z value equal to or more than Z buffer value.
GDC_DEPTH_GREATER	Drawn if current Z value more than Z buffer value.
GDC_DEPTH_NOTEQUAL	Drawn if current Z value is not equal to Z buffer value.
<b>GDC_DEPTH_WRITE_MASK</b>	Enables write access to Z buffer.
GDC_ENABLE	If GDC_ENABLE, according to the result of Z value comparison, Z value is written to Z buffer.
GDC_DISABLE	Disable Z buffer write.
GDC_DISABLE	Enable Z buffer write.
<b>GDC_BLEND_MODE</b>	Sets blending mode of pixel write.
GDC_BLEND_COPY	Regular drawing operation (writes pixel color to drawing frame).
GDC_BLEND_ALPHA	Enables alpha blending.
GDC_BLEND_ROP	Draws with logical arithmetic.
<b>GDC_BROKEN_LINE</b>	Selects broken line mode.
GDC_ENABLE	Draws a broken line utilizing applied line pattern.
GDC_DISABLE	Draws a solid line.
<b>GDC_LINE_WIDTH</b>	Sets line width.
GDC_LINE_WIDTH_1	Draws a line of 1 pixel width.
GDC_LINE_WIDTH_2	Draws a line of 2 pixel width.
:	:
GDC_LINE_WIDTH_32	Draws a line of 32 pixel width.
<b>GDC_ANTI_ALIAS</b>	Sets antialias mode.
GDC_ENABLE	Enables antialias operation.
GDC_DISABLE	Disables antialias operation.
<b>GDC_LINE_ENDPOINT</b>	Controls the end point of line in GDC_LINES and GDC_LINES_FAST commands.
GDC_ENABLE	End point is not drawn in GDC_POLYLINE and GDC_POLYLINE_FAST commands regardless this setting.
GDC_DISABLE	Draws the end point.
GDC_DISABLE	NOT draws the end point.

GDC_BROKEN_LINE_OFFSET	Specifies the way of drawing broken line (only for MB86291).
GDC_ENABLE	Starts new drawing broken line pattern.
GDC_DISABLE	Continues from the last drawing broken line pattern.
GDC_BROKEN_LINE_PERIOD	Sets broken line pattern period (only for MB86291).
GDC_BROKEN_LINE_32	32 bits period.
GDC_BROKEN_LINE_24	24 bits period.
GDC_SHADOW_DEPTH_TEST	Sets Z value compare mode of shadow (only for MB86293 or later).
GDC_ENABLE	Validates Z value comparison.
GDC_DISABLE	Invalidates Z value comparison.
GDC_SHADOW_DEPTH_FUNC	Selects Z value comparison type of shadow (only for MB86293 or later).
GDC_DEPTH_NEVER	Always NOT drawn.
GDC_DEPTH_ALWAYS	Always drawn.
GDC_DEPTH_LESS	Drawn if current Z value is less than Z buffer value.
GDC_DEPTH_LEQUAL	Drawn if current Z value equal to or less than Z buffer value.
GDC_DEPTH_EQUAL	Drawn if current Z value equal to Z buffer value.
GDC_DEPTH_GEQUAL	Drawn if current Z value equal to or more than Z buffer value.
GDC_DEPTH_GREATER	Drawn if current Z value more than Z buffer value.
GDC_DEPTH_NOTEQUAL	Drawn if current Z value is not equal to Z buffer value.
GDC_SHADOW_DEPTH_WRITE_MASK	Enables write access to Z buffer of shadow (only for MB86293 or later).
GDC_ENABLE	Disable Z buffer write.
GDC_DISABLE	Enable Z buffer write.
GDC_SHADOW_BLEND_MODE	Sets blending mode of pixel write of shadow (only for MB86293 or later).
GDC_BLEND_COPY	Regular drawing operation (writes pixel color to drawing frame).
GDC_BLEND_ALPHA	Enables alpha blending.
GDC_BLEND_ROP	Draws with logical arithmetic.
GDC_SHADOW_BROKEN_LINE	Selects broken line mode of shadow (only for MB86293 or later).
GDC_ENABLE	Draws a broken line utilizing applied line pattern.
GDC_DISABLE	Draws a solid line.
GDC_SHADOW_LINE_WIDTH	Sets line width of shadow (only for MB86293 or later).
GDC_LINE_WIDTH_1	Draws a line of 1 pixel width.
GDC_LINE_WIDTH_2	Draws a line of 2 pixel width.
:	:
GDC_LINE_WIDTH_32	Draws a line of 32 pixel width.
GDC_SHADOW_BROKEN_LINE_PERIOD	Sets broken line pattern period of shadow (only for MB86293 or later).
GDC_BROKEN_LINE_32	32 bits period.
GDC_BROKEN_LINE_24	24 bits period.

<p><b>GDC_BORDER_DEPTH_TEST</b></p> <p style="padding-left: 20px;">GDC_ENABLE GDC_DISABLE</p>	<p>Sets Z value compare mode of border (only for MB86293 or later). Validates Z value comparison. Invalidates Z value comparison.</p>
<p><b>GDC_BORDER_DEPTH_FUNC</b></p> <p style="padding-left: 20px;">GDC_DEPTH_NEVER GDC_DEPTH_ALWAYS GDC_DEPTH_LESS GDC_DEPTH_LEQUAL</p> <p style="padding-left: 20px;">GDC_DEPTH_EQUAL GDC_DEPTH_GEQUAL</p> <p style="padding-left: 20px;">GDC_DEPTH_GREATER GDC_DEPTH_NOTEQUAL</p>	<p>Selects Z value comparison type of border (only for MB86293 or later). Always NOT drawn. Always drawn. Drawn if current Z value is less than Z buffer value. Drawn if current Z value equal to or less than Z buffer value. Drawn if current Z value equal to Z buffer value. Drawn if current Z value equal to or more than Z buffer value. Drawn if current Z value more than Z buffer value. Drawn if current Z value is not equal to Z buffer value.</p>
<p><b>GDC_BORDER_DEPTH_WRITE_MASK</b></p> <p style="padding-left: 20px;">GDC_ENABLE GDC_DISABLE</p>	<p>Enables write access to Z buffer of border (only for MB86293 or later). Disable Z buffer write. Enable Z buffer write.</p>
<p><b>GDC_BORDER_BLEND_MODE</b></p> <p style="padding-left: 20px;">GDC_BLEND_COPY</p> <p style="padding-left: 20px;">GDC_BLEND_ALPHA GDC_BLEND_ROP</p>	<p>Sets blending mode of pixel write of border (only for MB86293 or later). Regular drawing operation (writes pixel color to drawing frame). Enables alpha blending. Draws with logical arithmetic.</p>
<p><b>GDC_BORDER_BROKEN_LINE</b></p> <p style="padding-left: 20px;">GDC_ENABLE GDC_DISABLE</p>	<p>Selects broken line mode of border (only for MB86293 or later). Draws a broken line utilizing applied line pattern. Draws a solid line.</p>
<p><b>GDC_BORDER_LINE_WIDTH</b></p> <p style="padding-left: 20px;">GDC_LINE_WIDTH_1 GDC_LINE_WIDTH_2 : GDC_LINE_WIDTH_32</p>	<p>Sets line width of border (only for MB86293 or later). Draws a line of 1 pixel width. Draws a line of 2 pixel width. : Draws a line of 32 pixel width.</p>
<p><b>GDC_BORDER_BROKEN_LINE_PERIOD</b></p> <p style="padding-left: 20px;">GDC_BROKEN_LINE_32 GDC_BROKEN_LINE_24</p>	<p>Sets broken line pattern period of border (only for MB86293 or later). 32 bits period. 24 bits period.</p>

### 6.9.5 GdcSetAttrSurf [Sets surface drawing attribute]

Format	int GdcSetAttrSurf (GDC_ULONG target, GDC_ULONG param)	
Parameter	target	Surface drawing attribute
		<p>GDC_SHADE_MODE                    Shading mode</p> <p>GDC_DEPTH_TEST                    Z value compare mode</p> <p>GDC_DEPTH_FUNC                    Z value compare type</p> <p>GDC_DEPTH_WRITE_MASK            Z value write mask</p> <p>GDC_BLEND_MODE                    Blending mode</p> <p>GDC_TEXTURE_SELECT                Texture mode</p> <p>[When the "Graphics Controller" is MB86293 or later, following functions are available]</p> <p>GDC_ALPHA_SHADE_MODE            Alpha shading mode</p> <p>GDC_SHADOW_DEPTH_TEST           Z value compare mode of shadow</p> <p>GDC_SHADOW_DEPTH_FUNC           Z value compare type of shadow</p> <p>GDC_SHADOW_DEPTH_WRITE_MASK    Z value write mask of shadow</p> <p>GDC_SHADOW_BLEND_MODE           Blending mode of shadow</p> <p>GDC_NON_TOPLEFT_SHADE_MODE      Shading mode of non top-left primitive</p> <p>GDC_NON_TOPLEFT_DEPTH_TEST      Z value compare mode of non top-left primitive</p> <p>GDC_NON_TOPLEFT_DEPTH_FUNC      Z value compare type of non top-left primitive</p> <p>GDC_NON_TOPLEFT_DEPTH_WRITE_MASK Z value write mask of non top-left primitive</p> <p>GDC_NON_TOPLEFT_BLEND_MODE      Blending mode of non top-left primitive</p> <p>GDC_NON_TOPLEFT_TEXTURE_SELECT   Texture mode of non top-left primitive</p> <p>GDC_NON_TOPLEFT_ALPHA_SHADE_MODE Alpha shading mode of non top-left primitive</p>
	param	Parameter corresponding to target (*1)
Return value	GDC_TRUE	Complete
	GDC_FALSE	Incomplete
Error code	- GDC_ERR_NOT_READY ("Graphics Driver" is not initialized)	
	- GDC_ERR_INVALID_ATTRIBUTE (Invalid attribute is specified)	
Description	Sets attribute for surface drawing (not including texture mapping attribute). This command can be used by all "Graphics Controller".	

(\*1) Surface drawing attribute ( target ) and parameter (param) corresponding to each surface drawing attribute is shown below.

[Explanatory notes]

Surface drawing attribute	Description of surface drawing attribute
Parameter 1 that can set	Description of parameter 1
Parameter 2 that can set	Description of parameter 2
:	:
GDC_SHADE_MODE	Sets shading mode.
GDC_SHADE_FLAT	Flat shading.
GDC_SHADE_SMOOTH	Gouraud shading.
GDC_DEPTH_TEST	Sets Z value compare mode.
GDC_ENABLE	Validate Z value comparison.
GDC_DISABLE	Invalidate Z value comparison.
GDC_DEPTH_FUNC	Selects Z value comparison type.
GDC_DEPTH_NEVER	Always NOT drawn.
GDC_DEPTH_ALWAYS	Always drawn.
GDC_DEPTH_LESS	Drawn if current Z value is less than Z buffer value.
GDC_DEPTH_LEQUAL	Drawn if current Z value is equal to or less than Z buffer value.
GDC_DEPTH_EQUAL	Drawn if current Z value is equal to Z buffer value.
GDC_DEPTH_GEQUAL	Drawn if current Z value is equal to or more than Z buffer value.
GDC_DEPTH_GREATER	Drawn if current Z value is more than Z buffer value.
GDC_DEPTH_NOTEQUAL	Drawn if current Z value is not equal to Z buffer value.
GDC_DEPTH_WRITE_MASK	Enables write access to Z buffer.
	If GDC_ENABLE, according to the result of Z value comparison, Z value is written to Z buffer.
GDC_ENABLE	Disables Z buffer write.
GDC_DISABLE	Enables Z buffer write.
GDC_BLEND_MODE	Sets blending mode of pixel write.
GDC_BLEND_COPY	Regular drawing operation (writes pixel color to drawing frame).
GDC_BLEND_ALPHA	Enables alpha blending.
GDC_BLEND_ROP	Draws with logical arithmetic.
GDC_TEXTURE_SELECT	Sets texture mapping mode.
GDC_SELECT_TEXTURE	Draws with texture mapping.
GDC_SELECT_TILE	Draws with tiling.
GDC_SELECT_PLAIN	Invalidates texture mapping.
GDC_ALPHA_SHADE_MODE	Sets alpha shading mode (only for MB86293 or later).
GDC_SHADE_FLAT	Flat shading.
GDC_SHADE_SMOOTH	Gouraud shading.

GDC_SHADOW_DEPTH_TEST	Sets Z value compare mode of shadow (only for MB86293 or later).
GDC_ENABLE GDC_DISABLE	Validate Z value comparison. Invalidate Z value comparison.
GDC_SHADOW_DEPTH_FUNC	Selects Z value comparison type of shadow (only for MB86293 or later).
GDC_DEPTH_NEVER GDC_DEPTH_ALWAYS GDC_DEPTH_LESS GDC_DEPTH_LEQUAL	Always NOT drawn. Always drawn. Drawn if current Z value is less than Z buffer value. Drawn if current Z value is equal to or less than Z buffer value.
GDC_DEPTH_EQUAL GDC_DEPTH_GEQUAL	Drawn if current Z value is equal to Z buffer value. Drawn if current Z value is equal to or more than Z buffer value.
GDC_DEPTH_GREATER GDC_DEPTH_NOTEQUAL	Drawn if current Z value is more than Z buffer value. Drawn if current Z value is not equal to Z buffer value.
GDC_SHADOW_DEPTH_WRITE_MASK	Enables write access to Z buffer of shadow (only for MB86293 or later).  If GDC_ENABLE, according to the result of Z value comparison, Z value is written to Z buffer.
GDC_ENABLE GDC_DISABLE	Disables Z buffer write. Enables Z buffer write.
GDC_SHADOW_BLEND_MODE	Sets blending mode of pixel write of shadow (only for MB86293 or later).
GDC_BLEND_COPY GDC_BLEND_ALPHA GDC_BLEND_ROP	Regular drawing operation (writes pixel color to drawing frame). Enables alpha blending. Draws with logical arithmetic.

GDC_NON_TOPLEFT_SHADE_MODE	Sets shading mode of non top-left primitive (only for MB86293 or later).
GDC_SHADE_FLAT GDC_SHADE_SMOOTH	Flat shading. Gouraud shading.
GDC_NON_TOPLEFT_DEPTH_TEST	Sets Z value compare mode of non top-left primitive (only for MB86293 or later).
GDC_ENABLE GDC_DISABLE	Validate Z value comparison. Invalidate Z value comparison.
GDC_NON_TOPLEFT_DEPTH_FUNC	Selects Z value comparison type of non top-left primitive (only for MB86293 or later).
GDC_DEPTH_NEVER GDC_DEPTH_ALWAYS GDC_DEPTH_LESS GDC_DEPTH_LEQUAL	Always NOT drawn. Always drawn. Drawn if current Z value is less than Z buffer value. Drawn if current Z value is equal to or less than Z buffer value.
GDC_DEPTH_EQUAL GDC_DEPTH_GEQUAL	Drawn if current Z value is equal to Z buffer value. Drawn if current Z value is equal to or more than Z buffer value.
GDC_DEPTH_GREATER GDC_DEPTH_NOTEQUAL	Drawn if current Z value is more than Z buffer value. Drawn if current Z value is not equal to Z buffer value.
GDC_NON_TOPLEFT_DEPTH_WRITE_MASK	Enables write access to Z buffer of non top-left primitive (only for MB86293 or later).  If GDC_ENABLE, according to the result of Z value comparison, Z value is written to Z buffer.
GDC_ENABLE GDC_DISABLE	Disables Z buffer write. Enables Z buffer write.
GDC_NON_TOPLEFT_BLEND_MODE	Sets blending mode of pixel write of non top-left primitive (only for MB86293 or later).
GDC_BLEND_COPY  GDC_BLEND_ALPHA GDC_BLEND_ROP	Regular drawing operation (writes pixel color to drawing frame).  Enables alpha blending. Draws with logical arithmetic.
GDC_NON_TOPLEFT_TEXTURE_SELECT	Sets texture mapping mode of non top-left primitive (only for MB86293 or later).
GDC_SELECT_TEXTURE GDC_SELECT_TILE GDC_SELECT_PLAIN	Draws with texture mapping. Draws with tiling. Invalidates texture mapping.
GDC_NON_TOPLEFT_ALPHA_SHADE_MODE	Sets alpha shading mode of non top-left primitive (only for MB86293 or later).
GDC_SHADE_FLAT GDC_SHADE_SMOOTH	Flat shading. Gouraud shading.

### 6.9.6 GdcSetAttrTexture [Sets texture mapping attribute]

Format	int GdcSetAttrTexture (GDC_ULONG target, GDC_ULONG param)	
Parameter	target	Texture mapping attribute
		GDC_TEXTURE_PERSPECTIVE Perspective correction GDC_TEXTURE_FILTER Texture filter GDC_TEXTURE_WRAP_S S coordinates wrap GDC_TEXTURE_WRAP_T T coordinates wrap GDC_TEXTURE_BLEND Texture blend mode GDC_TEXTURE_ALPHA Texture alpha mode
		[When the "Graphics Controller" is MB86293 or later, following function is available]
		GDC_TEXTURE_FAST_MODE Bi-linear filtering fast mode
	param	Parameter corresponding to target (*1)
Return value	GDC_TRUE	Complete
	GDC_FALSE	Incomplete
Error code	- GDC_ERR_NOT_READY ("Graphics Driver" is not initialized)	
	- GDC_ERR_INVALID_ATTRIBUTE (Invalid attribute is specified)	
Description	Sets attribute for texture mapping. This command can be used by all "Graphics Controller".	

(\*1) Texture mapping attribute ( target ) and parameter (param) corresponding to each texture mapping attribute is shown below.

[Explanatory notes]

Texture mapping attribute	Description of texture mapping attribute
Parameter 1 that can set	Description of parameter 1
Parameter 2 that can set	Description of parameter 2
:	:
<b>GDC_TEXTURE_PERSPECTIVE</b>	Selects perspective correction mode.
GDC_ENABLE	Validates perspective correction.
GDC_DISABLE	Invalidates perspective correction (default).
<b>GDC_TEXTURE_FILTER</b>	Selects texture filter mode.
GDC_TEXTURE_POINT	Point sampling mode (default).
GDC_TEXTURE_BILINEAR	Bi-linear filtering mode.
<b>GDC_TEXTURE_WRAP_S</b>	Defines S coordinates wrapping option when S coordinates value exceed the texture size.
GDC_TEXTURE_REPEAT	Repeats the texture pattern.
GDC_TEXTURE_CLAMP	Sets out-most texture color (default).
GDC_TEXTURE_BORDER	Sets defined border color.



GDC_TEXTURE_WRAP_T	Sets T coordinates wrapping option when T coordinates value exceed the texture size.
GDC_TEXTURE_REPEAT	Repeats the texture pattern.
GDC_TEXTURE_CLAMP	Sets out-most texture color (default).
GDC_TEXTURE_BORDER	Sets defined border color.
GDC_TEXTURE_BLEND	Sets blending mode of texture color and polygon color. This is applicable only when texture mapping mode is selected.
GDC_TEXTURE_DECAL	Texture color is drawn (default).
GDC_TEXTURE_MODULATE	Blended color is drawn.
GDC_TEXTURE_STENCIL	If MSB of texture color is 1, texture color is drawn, otherwise polygon color is drawn.
GDC_TEXTURE_ALPHA	Sets alpha blending mode between drawn color and current pixel color of the drawing frame. This is applicable only when texture mapping and alpha blending are selected.
GDC_TEXTURE_ALPHA_ALL	Alpha blend between post texture mapping color and current pixel color of the drawing frame (default).
GDC_TEXTURE_ALPHA_STENCIL	If MSB of texture color is 1, texture color is drawn, otherwise not drawn.
GDC_TEXALPHA_ALPHA_STENCILALPHA	If MSB of texture color is 1, alpha blend between texture color and current pixel color in the drawing frame is performed, otherwise not drawn.
GDC_TEXTURE_FAST_MODE	Sets bi-linear fast mode (only for MB86293 or later).
GDC_ENABLE	Texture mapping is executed at fast speed using a default * 4 as texture area.
GDC_DISABLE	A default texture area is used (default).

### 6.9.7 GdcSetAttrBlit [Sets BitBlit attribute]

Format	int GdcSetAttrBlit (GDC_ULONG target, GDC_ULONG param)	
Parameter	target	Bitmap drawing attribute
		GDC_BLEND_MODE                      Blend mode
		[When the "Graphics Controller" is MB86291 or later, following function is available]
		GDC_TRANSPARENT_MODE              Transparent mode
	param	Parameter corresponding to target (*1)
Return value	GDC_TRUE	Complete
	GDC_FALSE	Incomplete
Error code	- GDC_ERR_NOT_READY ("Graphics Driver" is not initialized)	
	- GDC_ERR_INVALID_ATTRIBUTE (Invalid attribute is specified)	
Description	Sets attribute when copying and drawing BitBlit.	
	This blend mode setting function can be used by all "Graphics Controller".	
	The transparent mode setting function is only for MB86291 or later.	
	Sets the transparent color for the transparent mode with the GdcBlitColorTransparent command.	

(\*1) Bitmap drawing attribute ( target ) and parameter ( param ) corresponding to each bitmap drawing attributes are shown below.

[Explanatory notes]

Bitmap drawing attribute	Description of bitmap drawing attributes
Parameter 1 that can set	Description of parameter 1
Parameter 2 that can set	Description of parameter 2
:	:
GDC_BLEND_MODE	Sets blend mode.
GDC_BLEND_COPY	Regular drawing operation (writes pixel color to drawing frame).
GDC_BLEND_ROP	Draws with logical arithmetic.
GDC_TRANSPARENT_MODE	Sets transparent mode (only for MB86291 or later).
GDC_ENABLE	The color which was set by the GdcBlitColorTransparent command regards as transparent color.
GDC_DISABLE	The color which was set by the GdcBlitColorTransparent command is not treated as transparent color (default).



### 6.9.10 GdcSetTextureBorder [Sets texture border color]

Format	int	GdcSetTextureBorder (GDC_COLOR32 color)
Parameter	color	Texture border color
Return value	GDC_TRUE	Complete
	GDC_FALSE	Incomplete
Error code	GDC_ERR_NOT_READY (“Graphics Driver” is not initialized)	
Description	Sets the border color of the texture applied in border mode of texture wrap. The following values are used by color mode. - 8 bits color mode : lower 8 bits of “color” - 16 bits color mode : lower 16 bits of “color” - 24 bits color mode : lower 24 bits of “color” This command can be used by all “Graphics Controller”.	

### 6.9.11 GdcSetRop [Sets logical calculation mode]

Format            int   GdcSetRop (GDC\_UCHAR mode)

Parameter	mode	Logical arithmetic mode	
		GDC_ROP_CLEAR	All bits are set to 0
		GDC_ROP_AND	s & d
		GDC_ROP_AND_REVERSE	s & !d
		GDC_ROP_COPY	s
		GDC_ROP_AND_INVERTED	!s & d
		GDC_ROP_NOP	d
		GDC_ROP_XOR	s ^ d
		GDC_ROP_OR	s   d
		GDC_ROP_NOR	!(s   d)
		GDC_ROP_EQUIV	!(s ^ d)
		GDC_ROP_INVERT	!d
		GDC_ROP_OR_REVERSE	s   !d
		GDC_ROP_COPY_INVERTED	!s
		GDC_ROP_OR_INVERTED	!s   d
		GDC_ROP_NAND	!(s & d)
		GDC_ROP_SET	All bits are set to 1
			s:drawing value
			d:destination value

Return value    GDC\_TRUE        Complete

                  GDC\_FALSE       Incomplete

Error code      GDC\_ERR\_NOT\_READY (“Graphics Driver” is not initialized)

Description     Sets logical arithmetic type.

This operation is performed between the pixel color to be drawn and current pixel color in the drawing frame. Result of this operation is to be drawn to the drawing frame.

This operation is applicable only when GDC\_BLEND\_ROP option of GDC\_BLEND\_MODE is selected.

This command can be used by all “Graphics Controller”.

## 6.10 Attribute Control Commands for Object Coordinates

### 6.10.1 GdcGeoSetAttrMisc [Sets miscellaneous attribute]

Format	int GdcGeoSetAttrMisc (GDC_ULONG target, GDC_ULONG param)		
Parameter	target	Geometry attribute	
		GDC_GEO_VTX_COL	Enable/disable vertex color in smooth shading
		GDC_GEO_VTX_Z	Enable/disable z coordinates of vertex in Z value comparison
		GDC_GEO_VTX_ST	Enable/disable ST coordinates of vertex in texture mapping
		GDC_GEO_IN_FORMAT	Input format
	param	Parameter corresponding to target (*1)	
Return value	GDC_TRUE	Complete	
	GDC_FALSE	Incomplete	
Error code	- GDC_ERR_NOT_READY (“Graphics Driver” is not initialized)		
	- GDC_ERR_INVALID_ATTRIBUTE (Invalid attribute is specified)		
Description	Sets miscellaneous attribute for object coordinates. Attributes and parameters for them are described below. This command is for MB86291 or later.		

(\*1) Miscellaneous attribute ( target ) and parameter (param) corresponding to each miscellaneous attribute is shown below.

[Explanatory notes]

Miscellaneous attribute	Description of miscellaneous attribute
Parameter 1 that can set	Description of parameter 1
Parameter 2 that can set	Description of parameter 2
:	:
GDC_GEO_VTX_COL	Specifies when using color of vertex. Smooth shading mode (GDC_SHADE_SMOOTH) should also set smooth shading by the shade mode (GDC_SHADE_MODE) of the GdcSetAttrSurf command.
GDC_ENABLE	Enables vertex color.
GDC_DISABLE	Disables vertex color.
GDC_GEO_VTX_Z	Specifies when using z coordinates of vertex.
GDC_ENABLE	Enables Z value.
GDC_DISABLE	Disables Z value.
GDC_GEO_VTX_ST	Specifies when using texture coordinates of vertex. Texture mapping (GDC_SELECT_TEXTURE) should also set texture mapping by the texture mapping mode (GDC_TEXTURE_SELECT) of the GdcSetAttrSurf command.
GDC_ENABLE	Enables ST (texture coordinates).
GDC_DISABLE	Disables ST (texture coordinates).
GDC_GEO_IN_FORMAT	Specifies input format.
GDC_GEO_FLOAT_INPUT	Floating-point format.
GDC_GEO_FIXED_INPUT	Fixed-point format.
GDC_GEO_INT_INPUT	Integer format.

### 6.10.2 GdcGeoSetAttrLine [Sets line drawing attribute for object coordinates]

<b>Format</b>	int GdcGeoSetAttrLine (GDC_ULONG target, GDC_ULONG param)		
<b>Parameter</b>	<b>target</b>	<b>Line drawing attribute</b>	
		GDC_GEO_THICK_LINE_CORRECT	Sets correction mode of thick line connection
		GDC_GEO_BROKEN_LINE_CORRECT	Sets correction mode of broken line pattern
		GDC_GEO_BROKEN_LINE_CORRECT_LENGTH	Sets the number of broken line pattern address fixation pixel
		GDC_GEO_UNIFORM_LINE_WIDTH	Sets uniform mode of line width
		GDC_GEO_THICK_LINE_VERTICAL	Sets thick/broken line vertical mode
		GDC_GEO_BORDER_LINE	Sets drawing mode of border primitive
		GDC_GEO_SHADOW_MODE	Sets drawing mode of shadow primitive
	<b>param</b>	Parameter corresponding to target (*1)	
<b>Return value</b>	GDC_TRUE	Complete	
	GDC_FALSE	Incomplete	
<b>Error code</b>	- GDC_ERR_NOT_READY ("Graphics Driver" is not initialized)		
	- GDC_ERR_INVALID_ATTRIBUTE (Invalid attribute is specified)		
<b>Description</b>	Sets line drawing attribute in object coordinates. This command is for MB86293 or later.		



(\*1) Line drawing attribute ( target ) and parameter (param) corresponding to each line drawing attribute is shown below.

[Explanatory notes]

Line drawing attribute	Description of line drawing attribute
Parameter 1 that can set	Description of parameter 1
Parameter 2 that can set	Description of parameter 2
:	:
GDC_GEO_THICK_LINE_CORRECT	Sets thick line connection correct mode.
GDC_ENABLE	Enables thick line connection correct.
GDC_DISABLE	Disables thick line connection correct.
GDC_GEO_BROKEN_LINE_CORRECT	Sets broken line connection correct mode.
GDC_ENABLE	Refer to the same broken line pattern with front and back number pixel of broken line connection part (“broken line pattern address fixation mode”). Number of pixel is set by GDC_GEO_BROKEN_LINE_CORRECT_LENGTH.
GDC_DISABLE	Not correct broken line pattern (Default).
GDC_GEO_BROKEN_LINE_CORRECT_LENGTH	Sets the number of broken line pattern address fixation pixel. A recommended value is the same as line width.
0-32	This parameter is available when the correction mode of broken line pattern is “broken line pattern address fixation mode”. Number of pixel (default is 0).
GDC_GEO_UNIFORM_LINE_WIDTH	Sets uniform mode of line width.
GDC_ENABLE	Enables uniform of line width.
GDC_DISABLE	Disables uniform of line width.
GDC_GEO_THICK_LINE_VERTICAL	Sets thick/broken line vertical mode.
GDC_ENABLE	Draws perpendicular section of thick/broken line to an ideal line.
GDC_DISABLE	Draws perpendicular section of thick/broken line to a base axis.
GDC_GEO_BORDER_LINE	Sets drawing mode of border primitive.
GDC_ENABLE	Draws border primitive.
GDC_DISABLE	Not draw border primitive.

GDC_GEO_SHADOW_MODE	Sets drawing mode of shadow primitive.
GDC_ENABLE	Draws shadow primitive.
GDC_DISABLE	Not draw shadow primitive.

[Note] Following combinations are not available (not supported)

1. GDC\_GEO\_THICK\_LINE\_VERTICAL = GDC\_ENABLE  
    GDC\_GEO\_UNIFORM\_LINE\_WIDTH = GDC\_DISABLE
2. GDC\_GEO\_THICK\_LINE\_VERTICAL = GDC\_DISABLE  
    GDC\_GEO\_THICK\_LINE\_CORRECT = GDC\_ENABLE
3. GDC\_GEO\_THICK\_LINE\_VERTICAL = GDC\_DISABLE  
    GDC\_GEO\_BORDER\_LINE = GDC\_ENABLE
4. GDC\_GEO\_THICK\_LINE\_VERTICAL = GDC\_DISABLE  
    GDC\_GEO\_UNIFORM\_LINE\_WIDTH = GDC\_ENABLE
5. GDC\_GEO\_THICK\_LINE\_VERTICAL = GDC\_DISABLE  
    GDC\_GEO\_BROKEN\_LINE\_CORRECT = GDC\_ENABLE

### 6.10.3 GdcGeoSetAttrSurf [Sets surface drawing attribute for object coordinates]

<b>Format</b>	int GdcGeoSetAttrSurf (GDC_ULONG target, GDC_ULONG param)														
<b>Parameter</b>	<table border="0"> <tr> <td><b>target</b></td> <td>Surface drawing attribute</td> </tr> <tr> <td>GDC_GEO_FACE_CULL</td> <td>Enable/disable culling back face of triangle</td> </tr> <tr> <td>GDC_GEO_FACE_INVERT</td> <td>Specify direction of surface of triangle</td> </tr> <tr> <td colspan="2">[When the "Graphics Controller" is MB86293 or later, following functions are available]</td> </tr> <tr> <td>GDC_GEO_NON_TOPLEFT</td> <td>Sets drawing algorithm</td> </tr> <tr> <td>GDC_GEO_SHADOW_MODE</td> <td>Sets drawing mode of shadow primitive</td> </tr> <tr> <td><b>param</b></td> <td>Parameter corresponding to target (*1)</td> </tr> </table>	<b>target</b>	Surface drawing attribute	GDC_GEO_FACE_CULL	Enable/disable culling back face of triangle	GDC_GEO_FACE_INVERT	Specify direction of surface of triangle	[When the "Graphics Controller" is MB86293 or later, following functions are available]		GDC_GEO_NON_TOPLEFT	Sets drawing algorithm	GDC_GEO_SHADOW_MODE	Sets drawing mode of shadow primitive	<b>param</b>	Parameter corresponding to target (*1)
<b>target</b>	Surface drawing attribute														
GDC_GEO_FACE_CULL	Enable/disable culling back face of triangle														
GDC_GEO_FACE_INVERT	Specify direction of surface of triangle														
[When the "Graphics Controller" is MB86293 or later, following functions are available]															
GDC_GEO_NON_TOPLEFT	Sets drawing algorithm														
GDC_GEO_SHADOW_MODE	Sets drawing mode of shadow primitive														
<b>param</b>	Parameter corresponding to target (*1)														
<b>Return value</b>	<table border="0"> <tr> <td>GDC_TRUE</td> <td>Complete</td> </tr> <tr> <td>GDC_FALSE</td> <td>Incomplete</td> </tr> </table>	GDC_TRUE	Complete	GDC_FALSE	Incomplete										
GDC_TRUE	Complete														
GDC_FALSE	Incomplete														
<b>Error code</b>	<ul style="list-style-type: none"> <li>- GDC_ERR_NOT_READY ("Graphics Driver" is not initialized)</li> <li>- GDC_ERR_INVALID_ATTRIBUTE (Invalid attribute is specified)</li> </ul>														
<b>Description</b>	<p>Sets surface drawing attribute in object coordinates.</p> <p>It doesn't affect polygons.</p> <p>Attributes for surface drawing and parameters for them are described below.</p> <p>This command is for MB86291 or later.</p>														

(\*1) Surface drawing attribute ( target ) and parameter (param) corresponding to each surface drawing attribute is shown below.

[Explanatory notes]

Surface drawing attribute	Description of surface drawing attribute
Parameter 1 that can set	Description of parameter 1
Parameter 2 that can set	Description of parameter 2
:	:
GCD_GEO_FACE_CULL	Specifies culling back face of triangle.
GDC_ENABLE	Enables culling back face of triangle.
GDC_DISABLE	Disables culling back face of triangle.
GCD_GEO_FACE_INVERT	Specifies direction of surface of triangle.
	Counterclockwise surface is front facing by default.
GDC_ENABLE	Invert direction of surface from default.
GDC_DISABLE	Direction of surface is default.
GCD_GEO_NON_TOPLEFT	Sets drawing algorithm.
GDC_ENABLE	Non top left applying rule is used.
GDC_DISABLE	Non top left applying rule is not used.
GDC_GEO_SHADOW_MODE	Sets drawing mode of shadow primitive.
GDC_ENABLE	Draws shadow primitive.
GDC_DISABLE	Not draw shadow primitive.

### 6.10.4 GdcGeoLoadMatrix[f] [Sets matrix]

**Format**            int GdcGeoLoadMatrix (GDC\_FIXED32 \*ptMatrix)  
                      int GdcGeoLoadMatrixf (GDC\_SFLOAT \*ptMatrix)

**Parameter**        ptMatrix            A pointer to an array {m1, m2, m3, ..., m16} which corresponds to the 4 x 4 matrix M such as,

$$M = \begin{pmatrix} m1 & m5 & m9 & m13 \\ m2 & m6 & m10 & m14 \\ m3 & m7 & m11 & m15 \\ m4 & m8 & m12 & m16 \end{pmatrix}$$

**Return value**      GDC\_TRUE        Complete  
                      GDC\_FALSE      Incomplete

**Error code**        GDC\_ERR\_NOT\_READY (“Graphics Driver” is not initialized)

**Description**       Sets a 4 x 4 matrix that transforms an object coordinates to a clip coordinate. Each element in the matrix is put in the following order.

$$M = \begin{pmatrix} m1 & m5 & m9 & m13 \\ m2 & m6 & m10 & m14 \\ m3 & m7 & m11 & m15 \\ m4 & m8 & m12 & m16 \end{pmatrix}$$

Elements (m4 ,m8, m12, m16) in the matrix specify whether the projection type is orthographic or perspective. Therefore the projection type is set automatically by the result of their values.

If (m4 ,m8, m12, m16) == (0,0,0,1), then orthographic projection.

Else if (m4 ,m8, m12, m16) != (0,0,0,1) then perspective projection.

This command is for MB86291 or later.

### 6.10.5 GdcGeoNdcDcViewportCoef[f] [Sets coefficients of NdcDc transformation for XY]

Format	int GdcGeoNdcDcViewportCoef (GDC_FIXED32 scalex, GDC_FIXED32 offsetx, GDC_FIXED32 scaley, GDC_FIXED32 offsety)
	int GdcGeoNdcDcViewportCoeff (GDC_SFLOAT scalex, GDC_SFLOAT offsetx, GDC_SFLOAT scaley, GDC_SFLOAT offsety)
Parameter	scalex Magnification of x offsetx Offset of x scaley Magnification of y offsety Offset of y
Return value	GDC_TRUE Complete GDC_FALSE Incomplete
Error code	GDC_ERR_NOT_READY (“Graphics Driver” is not initialized)
Description	Sets the magnifications and offsets of x, y that is used for transforming Normalized Device Coordinates (NDC) to Device Coordinates (DC).  This command is for MB86291 or later.

### 6.10.6 GdcGeoNdcDcDepthCoef[f] [Sets coefficients of NdcDc transformation for Z]

Format	int GdcGeoNdcDcDepthCoef (GDC_FIXED32 scalez, GDC_FIXED32 offsetz)
	int GdcGeoNdcDcDepthCoeff (GDC_SFLOAT scalez, GDC_SFLOAT offsetz)
Parameter	scalez Magnification of z offsetz Offset of z
Return value	GDC_TRUE Complete GDC_FALSE Incomplete
Error code	GDC_ERR_NOT_READY (“Graphics Driver” is not initialized)
Description	Sets the magnification and offset of z that is used for transforming Normalized Device Coordinates (NDC) to Device Coordinates (DC).  This command is for MB86291 or later.

### 6.10.7 GdcGeoViewVolumeXYClip[f] [Sets view volume boundary for XY]

Format	int GdcGeoViewVolumeXYClip (GDC_FIXED32 xmin, GDC_FIXED32 xmax, GDC_FIXED32 ymin, GDC_FIXED32 ymax)
	int GdcGeoViewVolumeXYClipf (GDC_SFLOAT xmin, GDC_SFLOAT xmax, GDC_SFLOAT ymin, GDC_SFLOAT ymax)
Parameter	xmin Minimum clip value of x
	xmax Maximum clip value of x
	ymin Minimum clip value of y
	ymax Maximum clip value of y
Return value	GDC_TRUE Complete
	GDC_FALSE Incomplete
Error code	GDC_ERR_NOT_READY ("Graphics Driver" is not initialized)
Description	Sets the view volume boundary in the clip coordinates for x, y. This command is for MB86291 or later.

### 6.10.8 GdcGeoViewVolumeZClip[f] [Sets view volume boundary for Z]

Format	int GdcGeoViewVolumeZClip (GDC_FIXED32 zmin, GDC_FIXED32 zmax)
	int GdcGeoViewVolumeZClipf (GDC_SFLOAT zmin, GDC_SFLOAT zmax)
Parameter	zmin Minimum clip value of z
	zmax Maximum clip value of z
Return value	GDC_TRUE Complete
	GDC_FALSE Incomplete
Error code	GDC_ERR_NOT_READY ("Graphics Driver" is not initialized)
Description	Sets the view volume boundary in the clip coordinates for z. This command is for MB86291 or later.

### 6.10.9 GdcGeoViewVolumeWminClip[f] [Sets view volume boundary for w]

Format	int GdcGeoViewVolumeWminClip (GDC_FIXED32 wmin) int GdcGeoViewVolumeWminClipf (GDC_SFLOAT wmin)
Parameter	wmin Minimum clip value of w
Return value	GDC_TRUE Complete GDC_FALSE Incomplete
Error code	GDC_ERR_NOT_READY (“Graphics Driver” is not initialized)
Description	Sets the view volume boundary in the clip coordinates for w. As the front clip face (zmin) closes with the viewpoint limitlessly, w also approximates to zero limitlessly. Since w is used to calculate 1/w internally, wmin must be the one that does not occur overflow in division. w has only minimum value. wmin is not minus value. This command is for MB86291 or later.





### 6.10.11 GdcGeoSetLogOutMode [Sets log output mode of the device coordinates]

**Format**           int   GdcGeoSetLogOutMode (GDC\_ULONG mode)

<b>Parameter</b>	<b>mode</b>	<b>Log output mode of device coordinate</b>	
		GDC_GEO_LOGOUT_ENABLE	Outputs logs
		GDC_GEO_LOGOUT_DISABLE	Not output logs (default)
		GDC_GEO_LOGOUT_ONLY	Output logs without drawing

**Return value**   GDC\_TRUE   Complete  
                   GDC\_FALSE   Incomplete

**Error code**     GDC\_ERR\_NOT\_READY (“Graphics Driver” is not initialized)

**Description**   Sets log output mode of device coordinates. Each mode is explained below.

[GDC\_GEO\_LOGOUT\_ENABLE mode]

Log is outputted and drawing is executed.

[GDC\_GEO\_LOGOUT\_DISABLE mode]

Log is not outputted and drawing is executed.

[GDC\_GEO\_LOGOUT\_ONLY mode]

Log is outputted and drawing is not executed.

This mode is available only when drawing point primitive.

When “GDC\_GEO\_LOGOUT\_ONLY” is specified, log is not outputted when primitive except point is drawn.

This command is for MB86293 or later.

### 6.10.12 GdcGeoShadowXY [Sets xy offset of shadow]

<b>Format</b>	<b>int</b>	GdcGeoShadowXY (GDC_ULONG type, GDC_LONG offsetx, GDC_LONG offsety)	
<b>Parameter</b>	<b>type</b>	A kind of primitive	
		GDC_GEO_SHADOW	Shadow primitive
		GDC_GEO_SHADOW_COMPOSITION	Shadow composition primitive
	<b>offsetx</b>	x offset of shadow (or shadow composition) primitive for body primitive	
	<b>offsety</b>	y offset of shadow (or shadow composition) primitive for body primitive	
<b>Return value</b>	GDC_TRUE	Complete	
	GDC_FALSE	Incomplete	
<b>Error code</b>	GDC_ERR_NOT_READY (“Graphics Driver” is not initialized)		
<b>Description</b>	Sets offset of shadow from body. Offset must be specified with pixel unit.		
	When offset is positive number, position of x is right side of body, y is lower side of body.		
	When offset is negative number, position of x is left side of body, y is upper side of body.		
	Offset position of shadow form body must be set before drawing shadow primitive.		
	Shadow primitive drawing function is available in object coordinates drawing.		
	This command is for MB86293 or later.		

### 6.10.13 GdcGeoOverlapZ [Sets Z value of primitives (body / shadow / border / correction in top-left rule non-applicable mode)]

Format	int GdcGeoOverlapZ (GDC_ULONG origin_offset, GDC_ULONG non_topleft_offset, GDC_ULONG border_offset, GDC_ULONG shadow_offset)	
Parameter	origin_offset	Z value of body primitive
	non_topleft_offset	Z value of correction primitive in top-left rule non-applicable mode
	border_offset	Z value of border primitive
	shadow_offset	Z value of shadow primitive
Return value	GDC_TRUE	Complete
	GDC_FALSE	Incomplete
Error code	GDC_ERR_NOT_READY ("Graphics Driver" is not initialized)	
Description	Sets Z value of body, shadow, border and correction primitive in top-left rule non-applicable mode. Z value must be set before drawing these primitives. When precision of Z value is 8 bits, lower 8 bits of each parameter is effective. When precision of Z value is 16 bits, lower 16 bits of each parameter is effective. This command is for MB86293 or later.	

### 6.10.14 GdcGeoShadowColor [Sets color or shadow]

**Format**           int   GdcGeoShadowColor (GDC\_COLOR32 color)

**Parameter**    color               Sets color of shadow

**Return value** GDC\_TRUE        Complete

GDC\_FALSE      Incomplete

**Error code**    GDC\_ERR\_NOT\_READY (“Graphics Driver” is not initialized)

**Description** Sets color of shadow. This setting is effective in drawing lines with shadow, triangles with shadow, and polygons with shadow.

Once this command is executed, the same color is continuously applied till this command will be executed.

The following values are used by color mode.

- 8 bits color mode               : lower 8 bits of “color”

- 16 bits color mode              : lower 16 bits of “color”

- 24 bits color mode              : lower 24 bits of “color”

This command is for MB86293 or later.

### 6.10.15 GdcGeoShadowBackColor [Sets background color of shadow]

Format	int	GdcGeoShadowBackColor (GDC_COLOR32 color)
Parameter	color	Sets background color of shadow
Return value	GDC_TRUE	Complete
	GDC_FALSE	Incomplete
Error code	GDC_ERR_NOT_READY (“Graphics Driver” is not initialized)	
Description	Sets background color of shadow. Background color of shadow is effective when drawing lines with shadow and it's shadow is broken line. Background color is corresponding to 0 in bits of broken line pattern when drawing shadow as broken line (refer to figure 6.10.15).	




Figure 6.10.15 Relationship between foreground and background color of shadow when the broken line pattern is “0xf0f0f0”

Once this command is executed, the same color is continuously applied till this command will be executed.

The following values are used by color mode.

- 8 bits color mode : lower 8 bits of “color”
- 16 bits color mode : lower 16 bits of “color”
- 24 bits color mode : lower 24 bits of “color”

This command is for MB86293 or later.

### 6.10.16 GdcGeoBorderColor [Sets color or border]

Format	int	GdcGeoBorderColor (GDC_COLOR32 color)
Parameter	color	Sets color of border
Return value	GDC_TRUE	Complete
	GDC_FALSE	Incomplete
Error code	GDC_ERR_NOT_READY (“Graphics Driver” is not initialized)	
Description	Sets color of border. This setting is effective in drawing lines with border. Once this command is executed, the same color is continuously applied till this command will be executed. The following values are used by color mode. - 8 bits color mode : lower 8 bits of “color” - 16 bits color mode : lower 16 bits of “color” - 24 bits color mode : lower 24 bits of “color” This command is for MB86293 or later.	

### 6.10.17 GdcGeoBorderBackColor [Sets background color of border]

Format	int	GdcGeoBorderBackColor (GDC_COLOR32 color)
Parameter	color	Sets background color of border
Return value	GDC_TRUE	Complete
	GDC_FALSE	Incomplete
Error code	GDC_ERR_NOT_READY (“Graphics Driver” is not initialized)	
Description	<p>Sets background color of border. Background color of border is effective when drawing lines with border and it's border is broken line.</p> <p>Background color is corresponding to 0 in bits of broken line pattern when drawing border as broken line (refer to figure 6.10.17).</p>	




Figure 6.10.17 Relationship between foreground and background color of border when the broken line pattern is “0xf0f0f0”

Once this command is executed, the same color is continuously applied till this command will be executed.

The following values are used by color mode.

- 8 bits color mode : lower 8 bits of “color”
- 16 bits color mode : lower 16 bits of “color”
- 24 bits color mode : lower 24 bits of “color”

This command is for MB86293 or later.



## 6.11 Texture Pattern Control Commands

### 6.11.1 GdcTextureMemoryMode [Sets texture memory mode]

Format	int	GdcTextureMemoryMode (GDC_UCHAR mode)
Parameter	mode	Texture memory read
	GDC_TEX_MEM_MODE_EXT	Read from the graphics memory
	GDC_TEX_MEM_MODE_INT	Read from internal texture memory
Return value	GDC_TRUE	Complete
	GDC_FALSE	Incomplete
Error code	- GDC_ERR_NOT_READY ("Graphics Driver" is not initialized)	
	- GDC_ERR_INVALID_PARAMETER(Invalid parameter is specified)	
Description	Sets the source memory to refer texture pattern from, either internal texture memory or the graphics memory. This command can be used by all "Graphics Controller".	

### 6.11.2 GdcTextureLoadInt [Loads texture/tile pattern to internal texture memory]

Format	int	GdcTextureLoadInt (GDC_USHORT length, GDC_LPCOL16 lpTexture, GDC_ULONG oadr)
Parameter	length	Texture pattern size (pixel unit)
	lpTexture	Pointer to refer texture pattern
	oadr	Offset address of the memory texture pattern is stored
Return value	GDC_TRUE	Complete
	GDC_FALSE	Incomplete
Error code	- GDC_ERR_NOT_READY ("Graphics Driver" is not initialized)	
	- GDC_ERR_DATA_TOO_BIG (Too large data)	
Description	Loads texture pattern or tile pattern to internal texture memory. GDC_COL8 format texture data is assumed to be packed in GDC_COL16 texture format. This command can be used by all "Graphics Controller".	

### 6.11.3 GdcTextureLoadExt [Loads texture pattern to the graphics memory]

Format	int GdcTextureLoadExt (GDC_ULONG length, GDC_LPCOL16 lpTexture, GDC_ULONG adrs)	
Parameter	length	Texture pattern size (pixel unit)
	lpTexture	Pointer to refer texture pattern
	adrs	Offset address of the memory texture pattern is stored
Return value	GDC_TRUE	Complete
	GDC_FALSE	Incomplete
Error code	- GDC_ERR_NOT_READY (“Graphics Driver” is not initialized)	
	- GDC_ERR_DATA_TOO_BIG (Too large data)	
Description	Copies texture pattern to the graphics memory.	
	Prior to this command execution, size of the texture pattern should be set by the GdcTextureDimension command.	
	If length is longer than 65536, transfer will not complete successfully.	
	This command can be used by all “Graphics Controller”.	

### 6.11.4 GdcTextureLoadExt8 [Loads 8bpp texture pattern to the graphics memory]

Format	int GdcTextureLoadExt8 (GDC_LPCOL8 lpTexture, GDC_ULONG adrs)	
Parameter	lpTexture	Pointer to refer texture pattern
	adrs	Offset address of the memory texture pattern is stored
Return value	GDC_TRUE	Complete
	GDC_FALSE	Incomplete
Error code	- GDC_ERR_NOT_READY (“Graphics Driver” is not initialized)	
	- GDC_ERR_DATA_TOO_BIG (Too large data)	
Description	Copies 8bpp texture pattern to the graphics memory.	
	An offset from the graphics memory top must be set to “adrs”.	
	Prior to this command execution, size of the texture pattern should be set by the GdcTextureDimension command.	
	This command is for MB86293 or later.	

### 6.11.5 GdcTextureLoadExt16 [Loads 16bpp texture pattern to the graphics memory]

Format	int GdcTextureLoadExt16 (GDC_LPCOL16 lpTexture, GDC_ULONG adrs)	
Parameter	lpTexture	Pointer to refer texture pattern
	adrs	Offset address of the memory texture pattern is stored
Return value	GDC_TRUE	Complete
	GDC_FALSE	Incomplete
Error code	- GDC_ERR_NOT_READY (“Graphics Driver” is not initialized)	
	- GDC_ERR_DATA_TOO_BIG (Too large data)	
Description	Copies 16bpp texture pattern to the graphics memory.	
	An offset from the graphics memory top must be set to “adrs”.	
	Prior to this command execution, size of the texture pattern should be set by the GdcTextureDimension command.	
	This command is for MB86293 or later.	

### 6.11.6 GdcTextureLoadExt24 [Loads 24bpp texture pattern to the graphics memory]

Format	int GdcTextureLoadExt24 (GDC_LPCOL24 lpTexture, GDC_ULONG adrs)	
Parameter	lpTexture	Pointer to refer texture pattern
	adrs	Offset address of the memory texture pattern is stored
Return value	GDC_TRUE	Complete
	GDC_FALSE	Incomplete
Error code	- GDC_ERR_NOT_READY (“Graphics Driver” is not initialized)	
	- GDC_ERR_DATA_TOO_BIG (Too large data)	
Description	Copies 24bpp texture pattern to the graphics memory.	
	An offset from the graphics memory top must be set to “adrs”.	
	Prior to this command execution, size of the texture pattern should be set by the GdcTextureDimension command.	
	This command is for MB86293 or later.	

### 6.11.7 GdcTextureLoadInt16Fast [Loads texture pattern to internal texture memory]

Format	int GdcTextureLoadInt16Fast (GDC_LPCOL16 lpTexture, GDC_ULONG adrs)	
Parameter	lpTexture	Pointer to refer texture pattern
	adrs	Offset address of the memory texture pattern is stored
Return value	GDC_TRUE	Complete
	GDC_FALSE	Incomplete
Error code	- GDC_ERR_NOT_READY (“Graphics Driver” is not initialized)	
	- GDC_ERR_DATA_TOO_BIG (Too large data)	
Description	Copies 16bpp texture pattern to internal texture memory.	
	An offset from the internal texture memory top must be set to “adrs”.	
	Prior to this command execution, size of the texture pattern should be set by the GdcTextureDimension command.	
	This command is for MB86293 or later.	

### 6.11.8 GdcTextureLoadExt16Fast [Loads texture pattern to the graphics memory]

Format	int GdcTextureLoadExt16Fast (GDC_LPCOL16 lpTexture, GDC_ULONG adrs)	
Parameter	lpTexture	Pointer to refer texture pattern
	adrs	Offset address of the memory texture pattern is stored
Return value	GDC_TRUE	Complete
	GDC_FALSE	Incomplete
Error code	- GDC_ERR_NOT_READY (“Graphics Driver” is not initialized)	
	- GDC_ERR_DATA_TOO_BIG (Too large data)	
Description	Copies 16bpp texture pattern to internal texture memory.	
	An offset from the internal texture memory top must be set to “adrs”.	
	Prior to this command execution, size of the texture pattern should be set by the GdcTextureDimension command.	
	This command is for MB86293 or later.	

### 6.11.9 GdcTextureDimension [Sets texture / tile information]

<b>Format</b>	<code>int GdcTextureDimension (GDC_ULONG adrs, GDC_ULONG adrs, GDC_ULONG tw, GDC_ULONG th)</code>								
<b>Parameter</b>	<table border="0"> <tr> <td><code>adrs</code></td> <td>Start address of texture/tile pattern</td> </tr> <tr> <td><code>oadrs</code></td> <td>Offset</td> </tr> <tr> <td><code>tw</code></td> <td>Pattern data width (power of 2)</td> </tr> <tr> <td><code>th</code></td> <td>Pattern data height (power of 2)</td> </tr> </table>	<code>adrs</code>	Start address of texture/tile pattern	<code>oadrs</code>	Offset	<code>tw</code>	Pattern data width (power of 2)	<code>th</code>	Pattern data height (power of 2)
<code>adrs</code>	Start address of texture/tile pattern								
<code>oadrs</code>	Offset								
<code>tw</code>	Pattern data width (power of 2)								
<code>th</code>	Pattern data height (power of 2)								
<b>Return value</b>	<table border="0"> <tr> <td><code>GDC_TRUE</code></td> <td>Complete</td> </tr> <tr> <td><code>GDC_FALSE</code></td> <td>Incomplete</td> </tr> </table>	<code>GDC_TRUE</code>	Complete	<code>GDC_FALSE</code>	Incomplete				
<code>GDC_TRUE</code>	Complete								
<code>GDC_FALSE</code>	Incomplete								
<b>Error code</b>	<ul style="list-style-type: none"> <li>- <code>GDC_ERR_NOT_READY</code> (“Graphics Driver” is not initialized)</li> <li>- <code>GDC_ERR_ILLEGAL_DIMENSION</code> (Illegal vertical/horizontal size of pattern data)</li> </ul>								
<b>Description</b>	<p>Sets following texture information .</p> <ul style="list-style-type: none"> <li>- Start address of texture/tile pattern</li> <li>- Offset</li> <li>- Pattern data width</li> <li>- Pattern data height</li> </ul> <p>“adrs” and “oadrs” must be specified with suitable value for the stored position of the referred pattern according to the table 6.11.9a.</p>								

**Table 6.11.9a Values to be specified to “adrs” and “oadrs”**

Stored position of referred pattern	adrs	oadrs
Internal texture	0	Offset from top address of internal texture memory
Extend texture	Start address of texture pattern from top address of the graphics memory	0
Internal tile	0	Offset from top address of internal texture memory
Extend tile	Base address of stored area of tile pattern	Offset from base address of stored area of tile pattern

[Note]

Available destination address of texture/tile pattern is changed according to the “Graphics Controller”.

This command can be used by all “Graphics Controller”.

Range of pattern data width and pattern data height according to the “Graphics Controller” are shown in the table 6.11.9b.

**Table 6.11.9b Range of pattern data width and pattern data height**

	MB86290A/291/292	MB86293 or later
Internal texture memory	16,32,64	16,32,64
The graphics memory	16,32,64,128,256	16-4096 (power of 2)

This command can be used by all “Graphics Controller”.

However, external tile function is only for MB86293 or later with which internal texture memory is not equipped.

### 6.11.10GdcBltTexture [Loads Blt texture to internal texture memory for MB86290A]

Format	int	GdcBltTexture (GDC_ULONG sadrs, GDC_ULONG sstride, GDC_USHORT x, GDC_USHORT y, GDC_USHORT w, GDC_USHORT h, GDC_ULONG oadrs)
Parameter	sadr sstride  x y w h oadrs	Memory address of the base point of the source drawing frame Stride (memory size of horizontal span ) of the source drawing frame  x coordinates of the top left vertex of source Blt y coordinates of the top left vertex of source Blt Horizontal width of the Blt field (pixel unit) Vertical height of the Blt field (pixel unit) Offset address of destination memory where texture pattern to be stored
Return value	GDC_TRUE GDC_FALSE	Complete Incomplete
Error code	- GDC_ERR_NOT_READY (“Graphics Driver” is not initialized) - GDC_ERR_ILLEGAL_DIMENSION (Illegal vertical/horizontal size of pattern data)	
Description	Loads texture pattern from the graphics memory to the internal texture memory. This command is only for MB86290A. When the “Graphics Controller” is MB86291, GdcGeoBltTexture must be used.	

### 6.11.11 GdcGeoBltTexture [Loads Blt texture to internal texture memory for MB86291 or later]

Format	int	GdcGeoBltTexture (GDC_ULONG sadrs, GDC_ULONG sstride, GDC_USHORT x, GDC_USHORT y, GDC_USHORT w, GDC_USHORT h, GDC_ULONG oadrs)
Parameter	sadr sstride  x y w h oadrs	Memory address of the base point of the source drawing frame Stride (memory size of horizontal span ) of the source drawing frame  x coordinates of the top left vertex of source Blt y coordinates of the top left vertex of source Blt Horizontal width of the Blt field (pixel unit) Vertical height of the Blt field (pixel unit) Offset address of destination memory where texture pattern to be stored
Return value	GDC_TRUE GDC_FALSE	Complete Incomplete
Error code	- GDC_ERR_NOT_READY (“Graphics Driver” is not initialized) - GDC_ERR_ILLEGAL_DIMENSION (Illegal vertical/horizontal size of pattern data)	
Description	Loads texture pattern from the graphics memory to the internal texture memory. This command is for MB86291 or later. When the “Graphics Controller” is MB86290A, GdcBltTexture must be used.	



## 6.12 Binary Pattern Drawing Commands

### 6.12.1 GdcBitPatternDraw [Draws binary pattern]

Format	int GdcBitPatternDraw (GDC_USHORT x, GDC_USHORT y, GDC_USHORT w, GDC_USHORT h, GDC_LPBINIMAGE lpPattern)	
Parameter	x	x coordinates of the drawing frame when the top left point of binary pattern is drawn
	y	y coordinates of the drawing frame when the top left point of binary pattern is drawn
	w	Binary pattern data width (pixel unit)
	h	Binary pattern data height (pixel unit)
	lpPattern	Pointer to binary pattern data
Return value	GDC_TRUE	Complete
	GDC_FALSE	Incomplete
Error code	- GDC_ERR_NOT_READY (“Graphics Driver” is not initialized) - GDC_ERR_DATA_TOO_BIG (Too large data)	
Description	Draws a binary pattern. Foreground color (pixel of binary pattern “1”) is drawn in the color applied by the GdcColor command, and background color (pixel of binary pattern “0”) is drawn in the color applied the GdcBackColor command. This command can be used by all “Graphics Controller”.	

### 6.12.2 GdcBitPatternMode [Sets enlarge/shrink mode]

Format	int GdcBitPatternMode (GDC_UCHAR mode)		
Parameter	mode	Enlarge/shrink mode(GDC_BPSCALE_H and GDC_BPSCALE_V are applicable at the same time)	
		GDC_BPSCALE_H_EQUIV	Horizontal enlarge x1
		GDC_BPSCALE_H_TWICE	Horizontal enlarge x2
		GDC_BPSCALE_H_HALF	Horizontal enlarge x1/2
		GDC_BPSCALE_V_EQUIV	Vertical enlarge x1
		GDC_BPSCALE_V_TWICE	Vertical enlarge x2
		GDC_BPSCALE_V_HALF	Vertical enlarge x1/2
Return value	GDC_TRUE	Complete	
	GDC_FALSE	Incomplete	
Error code	GDC_ERR_NOT_READY (“Graphics Driver” is not initialized)		
Description	Sets enlarge/shrink mode for binary pattern drawing. This command can be used by all “Graphics Controller”.		

## 6.13 BLT Commands

### 6.13.1 GdcBltCopy [Copies BitBlt pattern in current drawing frame]

Format	int	GdcBltCopy (GDC_USHORT x0, GDC_USHORT y0, GDC_USHORT x1, GDC_USHORT y1, GDC_USHORT w, GDC_USHORT h)
Parameter	x0 y0 x1 y1 w h	x coordinates of the top left vertex of source Blt y coordinates of the top left vertex of source Blt x coordinates of the bottom right vertex of destination y coordinates of the bottom right vertex of destination Horizontal width of the Blt field (pixel unit) Vertical height of the Blt field (pixel unit)
Return value	GDC_TRUE GDC_FALSE	Complete Incomplete
Error code	- GDC_ERR_NOT_READY - GDC_ERR_ILLEGAL_DIMENSION	("Graphics Driver" is not initialized) (Illegal vertical/horizontal size of pattern data)
Description	Draws bitmap pattern to the drawing frame by Blt copy. The destination field is current drawing frame in the graphics memory. This command can be used by all "Graphics Controller".	

### 6.13.2 GdcBltCopyAlt, GdcBltCopyAltSync [Copies BitBlt pattern between any drawing frame]

Format	<pre> int  GdcBltCopyAlt (GDC_USHORT x0, GDC_USHORT y0,                    GDC_USHORT x1, GDC_USHORT y1,                    GDC_USHORT w, GDC_USHORT h,                    GDC_ULONG  sadr, GDC_ULONG  sstride,                    GDC_ULONG  dadr, GDC_ULONG  dstride)  int  GdcBltCopyAltSync (GDC_USHORT x0, GDC_USHORT y0,                        GDC_USHORT x1, GDC_USHORT y1,                        GDC_USHORT w, GDC_USHORT h,                        GDC_ULONG  sadr, GDC_ULONG  sstride,                        GDC_ULONG  dadr, GDC_ULONG  dstride) </pre>
Parameter	<pre> x0          x coordinates of the top left vertex of source Blt y0          y coordinates of the top left vertex of source Blt x1          x coordinates of the top left vertex of destination y1          y coordinates of the top left vertex of destination w          Horizontal width of the Blt field (pixel unit) h          Vertical height of the Blt field (pixel unit) sadr       Memory address of the base point of the source drawing frame sstride    Stride (memory size of horizontal span ) of the source drawing            frame dadr       Memory address of the base point of the destination drawing            frame dstride    Stride (memory size of horizontal span) of the destination drawing            frame </pre>
Return value	<pre> GDC_TRUE    Complete GDC_FALSE   Incomplete </pre>
Error code	<pre> - GDC_ERR_NOT_READY ("Graphics Driver" is not initialized) - GDC_ERR_ILLEGAL_DIMENSION (Illegal vertical/horizontal size of pattern data) </pre>
Description	<p>Draws bit map pattern to the drawing frame by Blt copy. Any drawing frame in the graphics memory is applicable to source and destination. Color mode of source and destination must be the same. The GdcBltCopyAltSync command is synchronously executed to the vertical blanking interval. Source and destination field must not be overlapped to each other. Clipping operation by the GdcDrawClipFrame command is not applicable.</p> <p>This command can be used by all "Graphics Controller".</p>

### 6.13.3 GdcBltdraw [Draws BitBltdraw pattern]

Format	int GdcBltdraw (GDC_USHORT x, GDC_USHORT y, GDC_USHORT w, GDC_USHORT h, GDC_LPLONG lpRect)	
Parameter	x	x coordinates of the top left vertex of source Blt
	y	y coordinates of the top left vertex of source Blt
	w	Horizontal width of the Blt field (pixel unit)
	h	Vertical height of the Blt field (pixel unit)
	lpRect	Pointer to refer the pattern data
Return value	GDC_TRUE	Complete
	GDC_FALSE	Incomplete
Error code	- GDC_ERR_NOT_READY (“Graphics Driver” is not initialized) - GDC_ERR_DATA_TOO_BIG (Too large data)	
Description	<p>Draws bitmap pattern to the drawing frame by Blt copy. Source field is main memory. Color mode of the source field is assumed to be the same as that of current drawing frame.</p> <p>The data format of lpRect is to be the same as that of current drawing frame.</p> <p>Maximum data size of the Blt to be transferred at a time is 65535-2 double words.</p> <p>This command can be used by all “Graphics Controller”.</p>	

### 6.13.4 GdcBltdfill [Fills BitBltdfill field]

Format	int GdcBltdfill (GDC_USHORT x, GDC_USHORT y, GDC_USHORT w, GDC_USHORT h)	
Parameter	x	x coordinates of the top left vertex of source Blt
	y	y coordinates of the top left vertex of source Blt
	w	Horizontal width of the Blt field (pixel unit)
	h	Vertical height of the Blt field (pixel unit)
Return value	GDC_TRUE	Complete
	GDC_FALSE	Incomplete
Error code	GDC_ERR_NOT_READY (“Graphics Driver” is not initialized)	
Description	<p>Fills a Blt field with the foreground color or tile pattern specified by the GdcColor command.</p> <p>This command can be used by all “Graphics Controller”.</p>	

### 6.13.5 GdcBlitColorTransparent [Sets transparent color of transparent BitBlit]

Format	int	GdcBlitColorTransparent (GDC_COLOR32 color)
Parameter	color	Color code treated as transparent color
Return value	GDC_TRUE	Complete
	GDC_FALSE	Incomplete
Error code	GDC_ERR_NOT_READY (“Graphics Driver” is not initialized)	
Description	Sets the transparent color referred when the Blt pattern is copied/drawn in the transparent mode. The following values are used by color mode. - 8 bits color mode : lower 8 bits of “color” - 16 bits color mode : lower 16 bits of “color” - 24 bits color mode : lower 24 bits of “color” This command is for MB86291 or later.	

### 6.13.6 GdcBltCopyAltAlpha [Copies BitBlt pattern with alpha blending]

Format	int GdcBltCopyAltAlpha(GDC_USHORT x0, GDC_USHORT y0, GDC_USHORT x1, GDC_USHORT y1, GDC_USHORT bx, GDC_USHORT by, GDC_USHORT w, GDC_USHORT h, GDC_ULONG sadr, GDC_ULONG sstride, GDC_ULONG bstride)	
Parameter	x0	x coordinates of the top left vertex of source Blt
	y0	y coordinates of the top left vertex of source Blt
	x1	x coordinates of the top left vertex of destination
	y1	y coordinates of the top left vertex of destination
	bx	x coordinates of the top left vertex of alpha map area
	by	y coordinates of the top left vertex of alpha map area
	w	Horizontal width of the Blt field (pixel unit)
	h	Vertical height of the Blt field (pixel unit)
	sadr	Memory address of the base point of the source drawing frame
	sstride	Stride (memory size of horizontal span ) of the source drawing frame
	bstride	Stride of the alpha map area (pixel unit)
Return value	GDC_TRUE	Complete
	GDC_FALSE	Incomplete
Error code	GDC_ERR_NOT_READY (“Graphics Driver” is not initialized)	
Description	<p>Execute alpha blending with source Blt area and destination area.</p> <p>Copies alpha blended area to the x1,y1 coordinates of current drawing frame.</p> <p>Source Blt area is specified with sadrs,sstride,x0,y0,w,h and destination Blt area is specified with x1,y1.</p> <p>Alpha blend coefficient area is specified with bstride, bx, by, w, h and it's top address is specified by the GdcAlphaMapBase command.</p> <p>This command is for MB86293 or later.</p>	

## 6.14 Video Capture Commands

Please use a subsequent video capture command (GdcCap\*) after initializing a digital video decoder with an I<sup>2</sup>C control command (GdcI2C\*), when using the digital video decoder connected with an I<sup>2</sup>C interface.

For details information, refer to the “Application Note”.

### 6.14.1 GdcCapSetVideoCaptureMode [Sets mode of video capture]

**Format**            void   GdcCapSetVideoCaptureMode (GDC\_ULONG mode)

**Parameter**        mode       Sets modes of video capture. The value is set to VCM (Video Capture Mode) register as it is. For details information about VCM register, refer to the “Graphics Controller” hardware specifications of using.  
 Macros representing each mode are prepared. These can be used as the need arises.  
 Sets each mode by combining in the table 6.14.1 macros.

**Table 6.14.1 Video capture mode control macro list**

Macros	Meaning
GDC_CAP_START	Starts capturing
GDC_CAP_STOP	Stops capturing
GDC_CAP_ENABLE_V_INTERPOLATION	Performs the interpolation of perpendicular direction
GDC_CAP_DISABLE_V_INTERPOLATION	NOT perform the interpolation of perpendicular direction
GDC_CAP_NTSC	Video= NTSC
GDC_CAP_PAL	Video=PAL

**Return value**    None

**Description**     Sets a value to VCM(Video Capture Mode) register, and sets video capture mode.  
 This command is for MB86291 or later.




### 6.14.2 GdcCapGetErrorStatus [Gets error status of video capture]

**Format** GDC\_ULONG GdcCapGetErrorStatus(void)

**Parameter** None

**Return value** Video Capture Status (VCS) in the following format:



**bit 0-4:** Error status Yes = except 00000, No = all 0

**All other bits:**unsetled

Figure 6.14.2 Error status of video capture

**Description** Reads VCS (Video Capture Status) register and returns error status.

This command is for MB86291 or later.

### 6.14.3 GdcCapClearErrorStatus [Clears error status of video capture]

**Format** void GdcCapClearErrorStatus(void)

**Parameter** None

**Return value** None

**Description** Sets 0 to VCS (Video Capture Status) register and clears error status.

This command is for MB86291 or later.

### 6.14.4 GdcCapSetVideoCaptureBuffer [Sets video capture buffer]

Format	void	GdcCapSetVideoCaptureBuffer (GDC_ULONG saddr, GDC_ULONG eaddr, GDC_ULONG stride)
Parameter	saddr	Specifies the start address of the video capture buffer by offset value from the graphics memory
	eaddr	Specifies the end address +1 of the video capture buffer by offset value from the graphics memory
	stride	Sets width of memory (stride) for video capture buffer in blocks of 64 byte
Return value	None	
Description	Sets video capture buffer. The start address needs to be in a 16 byte boundary. Please specify the end address +1 of the video capture buffer as the end address. The video capture buffer size need a size which is a part for the picture to take at least. This command is for MB86291 or later.	

### 6.14.5 GdcCapSetImageArea [Sets range of image]

Format	void	GdcCapSetImageArea (GDC_USHORT x0, GDC_USHORT y0, GDC_USHORT x1, GDC_USHORT y1)
Parameter	x0	The upper left x coordinates of the picture
	y0	The upper left y coordinates of the picture
	x1	The lower right x coordinates of the picture
	y1	The lower right y coordinates of the picture
Return value	None	
Description	Sets the range for the image to be written to the video capture buffer. The picture of the range of (x0,y0) and (x1,y1) which are the starting point (0,0) of the upper left of the input picture is written to buffer. Please set coordinates $x0 < x1$ and $y0 < y1$ to specify the range of the picture. This command is for MB86291 or later.	

### 6.14.6 GdcCapSetWindowMode [Sets w-layer mode]

Format	void GdcCapSetWindowMode (GDC_ULONG format, GDC_ULONG mode,)		
Parameter	format	Sets color format of W layer	
		Sets YC modes when using video capture	
		GDC_CAP_RGB_MODE	RGB mode (default)
		GDC_CAP_YC_MODE	YC mode
	mode	Sets whether W layer is used as a normal display layer or a video capture	
		GDC_CAP_NORMAL_MODE	Normal mode (default)
		GDC_CAP_CAPTURE_MODE	Capture mode
Return value	None		
Description	Sets mode of W layer. When using video capture, be sure to set mode. Before execute this command, sets attribute of W layer by the GdcDispDimension command beforehand. Color mode supports only 16 bits mode. This command is for MB86291 or later.		

### 6.14.7 GdcCapSetVideoCaptureScale [Sets scale of video capture]

**Format** void GdcCapSetVideoCaptureScale (GDC\_FIXED\_SCALE hscale, GDC\_FIXED\_SCALE vscale)

**Parameter** hscale Horizontal scaling rate (default = 0x0800)  
vscale Vertical scaling rate (default = 0x0800)

**Return value** None

**Description** Sets scales for enlarging and reducing video capture.  
Sets horizontal scaling rate (hscale) which is cast to “GDC\_FIXED\_SCALE” type.  
Sets vertical scaling rate(vscale) which is cast to “GDC\_FIXED\_SCALE” type.  
This scaling rate is made by dividing number of horizontal pixels of captured image by number of horizontal pixels of image to be displayed.  
The style of GDC\_FIXED\_SCALE is decimal point of fixation of 5 bits of integer part and 11 bits of decimal part.  
The range of value is as follows.  
--MB86291/86292:0xffff(1/31.99951171875magnifications)  
-0x0800(equivalent magnifications).  
--MB86293 or later:0xffff(1/31.99951171875magnifications)  
-0x0400(2 times magnifications).  
Initial value of hscale and vscale is 0x0800(equivalent magnifications) respectively.  
Examples of calculation of scaling rate is shown below.

[Example of calculation of scaling rate]

(1)When the image of size 720\*576 is reduced to the size 648\*490, scaling rate is calculated as below.

--Reduction of horizontal direction

720pixel to 648pixel

720/648=1.111

1.111\*2048=2275 (expressed in hexadecimal is 0x08e3)

--Reduction of vertical direction

576line to 490line

576/490=1.176

1.176\*2048=2275 (expressed in hexadecimal is 0x0968)

--A value to be set to “hscale” is “0x08e3”.

--A value to be set to “vscale” is “0x0968”.

(2)When 1/n times, scaling rate is calculated as below.

--hscale = n \* 2048

--vscale = n \* 2048

(3)When n times, scaling rate is calculated as below.

--hscale = 1/n \* 2048

--vscale = 1/n \* 2048

This command is for MB86291 or later.

However enlarge function is available only with the "Graphics Controller" which is MB86293 or later and supports video capture function.

### 6.14.8 GdcCapSetAttrMisc [Sets attribute of video capture]

Format	int GdcCapSetAttrMisc (GDC_ULONG target, GDC_ULONG param)	
Parameter	target	Video capture attribute GDC_CAP_ODD_MODE Odd number mode GDC_CAP_CNV_MODE Non-interlace conversion mode
	param	Parameter corresponding to target (*1)
Return value	GDC_TRUE	Complete
	GDC_FALSE	Incomplete
Description	Sets attribute of video capture. The attribute of video capture and the parameter are shown below. This command is for MB86291 or later.	

(\*1) Video capture attribute ( target ) and parameter (param) corresponding to each video capture attributes are shown below.

[Explanatory notes]

Video capture attribute	Description of video capture attributes
Parameter 1 that can set	Description of parameter 1
Parameter 2 that can set	Description of parameter 2
:	:
GDC_CAP_ODD_MODE	Specifies the capture method.
GDC_CAP_EVEN_AND_ODD_MODE	Captures both the odd number and the even number fields.
GDC_CAP_ODD_ONLY_MODE	Captures only the odd number field.
GDC_CAP_CNV_MODE	Specifies the non-interlace conversion mode of the picture which is captured.
GDC_CAP_CNV_BOB_MODE	BOB mode (*2).
GDC_CAP_CNV_WEAVE_MODE	WEAVE mode (*3).

(\*2)BOB mode :The mode is a frame which is the even field of the raster is averaged interpolation then it is added to the odd field.

(\*3)WEAVE mode :The mode is a frame which is the odd field and the even field merge on the video capture buffer.

**6.14.9 GdcCapSetInputDataCountNTSC [Sets the video capture buffer for NTSC]**

Format	void	GdcCapSetInputDataCountNTSC (GDC_ULONG blank_data, GDC_ULONG valid_data)
Parameter	blank_data	The horizontal blanking interval is specified by the dot clock cycle number
	valid_data	The data number of the term of validity is specified by the dot clock cycle number
Return value	None	
Description	<p>Sets the input video stream number at the time of NTSC format.</p> <p>This command is used to detect an error occurred. When the input data is not same as the value set up by this command, an error occurs. The video capture status becomes the value other than zero at this time.</p> <p>Also, capturing is continued when the error occurred.</p> <p>This command is for MB86291 or later.</p>	

**6.14.10 GdcCapSetInputDataCountPAL [Sets the video capture buffer for PAL]**

Format	void	GdcCapSetInputDataCountPAL (GDC_ULONG blank_data, GDC_ULONG valid_data)
Parameter	blank_data	The horizontal blanking interval is specified by the dot clock cycle number
	valid_data	The data number of the term of validity is specified by the dot clock cycle number
Return value	None	
Description	<p>Sets the input video stream number at the time of PAL format.</p> <p>This command is used to detect an error occurred. When the input data is not same as the value set up by this command, an error occurs. The video capture status becomes the value other than zero at this time.</p> <p>Also, capturing is continued when the error occurred.</p> <p>This command is for MB86291 or later.</p>	



### 6.14.11 GdcCapSetLPFMode [Sets low pass filter mode]

**Format** void GdcCapSetLPFMode (GDC\_ULONG vlpf\_y, GDC\_ULONG vlpf\_c,  
GDC\_ULONG hlpf\_y, GDC\_ULONG hlpf\_c)

**Parameter** vlpf\_y The vertical LPF coefficient code for luminosity signals (0-2)  
vlpf\_c The vertical LPF coefficient code for different color signals (0-2)  
hlpf\_y The horizontal LPF coefficient code for luminosity signals (0-3)  
hlpf\_c The horizontal LPF coefficient code for different color signals (0-3)

**Return value** None

**Description** The mode (formula) of the low pass filter at the time of a video capture is set up. One of the following of coefficients can be specified in vlpf\_y of an argument, and vlpf\_c. When a coefficient is 0, it outputs as it is, without covering a low pass filter. The initial value of vlpf\_y and vlpf\_c are 0.

Table 6.14.11a Low pass filter formula (for vlpf\_y and vlpf\_c)

Coefficient	Low pass filter formula
0	$y[i,j] = x[i,j]$
1	$y[i,j] = x[i,j-1]/4 + x[i,j]/2 + x[i,j+1]/4$
2	$y[i,j] = x[i,j-1]*3/16 + x[i,j]*5/8 + x[i,j+1]*3/16$

where

x[i,j] : input pixel value at i-th column and j-th raster

y[i,j] : output pixel value at i-th column and j-th raster

One of the following of coefficients can be specified in hlpf\_y of an argument, and hlpf\_c. When a coefficient is 0, it outputs as it is, without covering a low pass filter.

The initial value of hlpf\_y and hlpf\_c are 0.

Table 6.14.11b Low pass filter formula (for hlpf\_y and hlpf\_c)

Coefficient	Low pass filter formula
0	$y[i,j] = x[i,j]$
1	$y[i,j] = x[i-1,j]/4 + x[i,j]/2 + x[i+1,j]/4$
2	$y[i,j] = x[i-1,j]*3/16 + x[i,j]*5/8 + x[i+1,j]*3/16$
3	$y[i,j] = x[i-2,j]*3/32 + x[i-1,j]/4 + x[i,j]*5/16$ $+ x[i+1,j]/4 + x[i+2,j]*3/32$

where

x[i,j] : input pixel value at i-th column and j-th raster

y[i,j] : output pixel value at i-th column and j-th raster

This command is for MB86291 or later.

## 6.15 I<sup>2</sup>C Control Commands

### 6.15.1 GdcI2CGetBusStatus [Gets I<sup>2</sup>C bus status]

**Format**            GDC\_ULONG    GdcI2CGetBusStatus (void)

**Parameter**        None

**Return value**    I<sup>2</sup>C bus status in the following format (value of BSR register):

bit 31	---	7	6	5	4	3	2	1	0
		x	x	x	x	x	x	x	x

**bit7:Detects START/STOP condition**  
 0:STOP condition  
 1:START condition (The bus is in use)

**bit6:Detects repeated START condition**  
 0:Repeated START condition was not detected  
 1:START condition was detected again while bus is in use

**bit5:Indicates Arbitration lost**  
 0:Arbitration lost was not detected  
 1:Arbitration lost occurred during master transmission

**bit4:Status of Acknowledge**  
 0:No acknowledge  
 1:Acknowledge

**bit3:Status of data transfer**  
 0:Receiving status  
 1:Transmitting status

**bit2:Detects addressing**  
 0:Addressing was not performed in a slave mode  
 1:Addressing was performed in a slave mode

**bit1:Detects "General call address (00h)"**  
 0:"General call address(00h)" was not received in a slave mode  
 1:"General call address(00h)" was received in a slave mode

**bit0:Detects the first byte**  
 0:Received data is not the 1<sup>st</sup> byte  
 1:Receiverd data is the 1<sup>st</sup> byte (address data)

**Description**      Reads BSR (Bus Status Register) and returns I<sup>2</sup>C bus status.  
 This command is for MB86291S or MB86292S.

### 6.15.2 GdcI2CSetBusControl [Controls I<sup>2</sup>C bus]

**Format** void GdcI2CSetBusControl (GDC\_UCHAR param)

**Return value** param The parameter for I<sup>2</sup>C bus control (the following format)

bit 7	6	5	4	3	2	1	0
x	x	x	x	x	x	x	x

**bit7:**Flag bit for request of bus error interruption

- 0:Clears a request flag of bus error interruption
- 1:Don't care

**bit6:**Permits bus error interruption

- 0:Prohibition of bus error interruption
- 1:Permission of bus error interruption

**bit5:**Generates START condition

- 0:Don't care
- 1:START condition is generated again at the time of master transmission

**bit4:**Selects master/slave mode

- 0:Becomes a slave mode after generation of STOP condition and completing transfer
- 1:Becomes a master mode, generates START condition and starts transfer

**bit3:**Permits generation of acknowledge at the time of data reception

- 0:Acknowledge is not generated
- 1:Acknowledge is generated

**bit2:** Permits generation of acknowledge at the time of "General call address(00h)" reception

- 0: Acknowledge is not generated
- 1: Acknowledge is generated

**bit1:**Permits interruption

- 0:Prohibition of interrupt
- 1:Permission of interrupt

**bit0:**Flag bit for request of interruption for transfer end

- 0:Clears the flag
- 1:Don't care

**Return value** None

**Description** Controls I<sup>2</sup>C bus by value of parameter for I<sup>2</sup>C bus control.

This command is for MB86291S or MB86292S.

### 6.15.3 GdcI2CGetBusControlStatus [Gets I<sup>2</sup>C bus control status]

**Format** GDC\_ULONG GdcI2CGetBusControlStatus (void)

**Parameter** None

**Return value** I<sup>2</sup>C bus control status in the following format (value of BCR register):

bit 7	6	5	4	3	2	1	0
x	x		x	x	x	x	x

**bit7:** Flag bit for request of bus error interruption

0:A bus error was not detected

1:Invalid START condition or STOP condition was detected while data transfer

**bit6:** Permission of bus error interruption

0:Prohibition of bus error interruption

1:Permission of bus error interruption

**bit4:** Master / slave mode

0:Slave

1:Master

**bit3:** Permission of generating acknowledge at the time of data reception

0:Acknowledge is not generated

1:Acknowledge is generated

**bit2:** Permission of generating acknowledge at the time of "General call address (00h)" reception

0:Acknowledge is not generated

1:Acknowledge is generated

**bit1:** Permission of interruption

0:Prohibition of interrupt

1:Permission of interrupt

**bit0:** Flag bit for request of interruption for transfer end

0:The transfer is not ended

1:It is set when 1 byte transfer including the acknowledge bit is completed and it corresponds to the following conditions

- It is a bus master
- It is an addressed slave
- It received "General call address (00h)"
- It was going to generate START condition while other systems by which arbitration lost happened used the bus

**Description** Reads BCR (Bus Control Register) and returns I<sup>2</sup>C bus control status.

This command is for MB86291S or MB86292S.

### 6.15.4 GdcI2CSetClock [Sets I<sup>2</sup>C clock]

**Format** void GdcI2CSetClock (GDC\_UCHAR param)

**Parameter** param Parameter for setup of I<sup>2</sup>C clock (the following format)

bit 7	6	5	4	3	2	1	0
	x	x	x	x	x	x	x

bit6:Selects standard-mode / high-speed-mode

0:Standard-mode

1:High-speed-mode

bit5:Permits I<sup>2</sup>C operation

0:Prohibition of operation

1:Permission of operation

bit4-0:Frequency of a transfer clock

0000-1111

Table 6.15.4 I<sup>2</sup>C clock parameter format

For details information about I<sup>2</sup>C clock, refer to the chapter of the “clock control register” of “I<sup>2</sup>C Interface specification”.

**Return value** None

**Description** Writes parameter to CCR (Clock Control Register) and sets transfer clock.  
This command is for MB86291S or MB86292S.

### 6.15.5 GdcI2CSetData [Sets transfer data]

**Format** void GdcI2CSetData (GDC\_UCHAR param)

**Parameter** param Value of transfer data

**Return value** None

**Description** Writes value of transfer data to DAR (Data Register).  
This command is for MB86291S or MB86292S.

## 7 System dependent Commands

This section describes which the “Graphics Controller” a system dependence command can be used with it. It is necessary for a graphics application developer to make these.

### 7.1 System Dependent Commands

System dependent commands list is shown in the table 7.1.

Table 7.1 System dependent commands list

No.	Command name	Function
1	GdcSetDisplayListBuffer	Sets Display List buffer
2	GdcFlushDisplayList	Transfers a Display List
3	GdcGetHostRegisterAddress	Gets host interface register area address
4	GdcGetDispRegisterAddress	Gets display control register area address
5	GdcGetDrawRegisterAddress	Gets drawing control register area address

## 8 System dependent Commands Interface

This section describes calling conventions interface and processing contents of a system dependent command.

### 8.1 Explanatory notes

Each item of a driver command reference seems to become following.

Format	Prototype declaration of a command.
Parameter	Description of a parameter.
Return value	The return value and the description.
Called by	The command name of a calling origin.
Description	Description of the command.

## 8.2 Command Interface

### 8.2.1 GdcSetDisplayListBuffer [Sets Display List buffer]

**Format**            `int GdcSetDisplayListBuffer (GDC_ULONG **base, GDC_ULONG *total_size, GDC_ULONG *num)`

**Parameter**

<code>base</code>	Pointer to get the start address of the Display List buffer field
<code>total_size</code>	Pointer to get the size of the Display List buffer field
<code>num</code>	Pointer to get the block count of the Display List buffer field

Effective values are 1 or 2

**Return value**

<code>GDC_TRUE</code>	Complete
<code>GDC_FALSE</code>	Incomplete

**Called by**        `GdcInitialize` command

**Description**    This command sets the Display List buffer information, such as the start address, size and block configuration of the Display List buffer field acquired by the application program, to the “Graphics Driver” through respective pointers. The start address, size (total byte count) and number of blocks must be set to the area which are pointed by the parameters, `base`, `total_size` and `num` respectively. The start address of the Display List buffer needs to be the host CPU address, even though the MB86290 series controls the data transfer. 1 (1 block) or 2 (2 blocks) is applied as a number of blocks.

**[1 block configuration]**

In 1 block configuration, the “Graphics Driver” uses the entire Display List buffer area as 1 block. In 1 block configuration, when a Display List transfer is started, driver command waits for the end of this transfer and then returns to the application. This means the execution time of each command depends on whether or not Display List transfers occur.

**[2 blocks configuration]**

In 2 blocks configuration, the entire Display List buffer area is divided into 2 equal blocks and these 2 blocks are used exclusively. When 1 block is fully filled with Display List information, transfer of that Display List is started and continuous part of the Display List is filled into the other block. In 2 blocks configuration, by using DMA function or master function of the “Graphics Controller”, the “Graphics Driver” does not need to check the completion of Display List transfer by itself.



[Error manipulation]

If this command fails to acquire the Display List buffer area, sets GDC FALSE to the return value. In this case, the GdcInitialize command ends as initialization failure (GDC\_FALSE).

[Remark]

- The size of Display List buffer must be a multiple of 32byte.

This command can be used by all "Graphics Controller".

Example

```
#define BUF_NUM 2
#define BUF_SIZE ((2*256*256+32)*BUF_NUM)

int GdcSetDisplayListBuffer(GDC_ULONG **base, GDC_ULONG *total_size,
GDC_ULONG *num){
    /* Acquisition of Display List buffer area */
    /* A malloc function is a library function of ANSI regulation.
    In this driver, since it does not provide, prepares according to the environment
    of use. */
    if( (*base = (GDC_ULONG *)malloc(BUF_SIZE)) == NULL )
        return(GDC_FALSE); /* Acquisition failure */

    *total_size = BUF_SIZE;
    *num = BUF_NUM;
    return(GDC_TRUE); /* Acquisition complete */
}
```

## 8.2.2 GdcFlushDisplayList [Transfers a Display List]

**Format** void GdcFlushDisplayList (GDC\_ULONG \*src, GDC\_ULONG count)

**Parameter** src Source address (Display List buffer)

count Transfer count

**Return value** None

**Called by** GdcFlush, GdcVFlush command

All drawing commands

**Description** This command is to transfer a Display List of the size specified by “count” started from the source address specified by “src”. The “src” specifies the Display List buffer address mapped to the host CPU address field. The unit of “count” is what specified by the GdcSetDMAMode command (32byte or 4byte). If the GdcSetDMAMode command is not applied since DMA is not used, this unit is set to 4 byte. For the Display List transfer, the following three methods are applicable. For each procedure, refer to the description [Display List transfer procedure] as follows:

- DMA transfer
- Transfer of Local Display List
- CPU transfer

This command can be used by all “Graphics Controller”.

[Display List transfer procedure]

\* DMA transfer

This is a method of Display List transfers utilizing the DMA controller of the host CPU (the “Graphics Controller” does not contain a DMA controller). The operation procedure of this case is shown as follows. Prior to call this command, DMA transfer mode must be appropriately set on both DMAC (the host CPU) and the “Graphics Controller”.

- (1) Checks DMA transfer enable/disable
  - Checks the appropriate operation mode check of the DMAC and wait till it will be ready to accept a new DMA transaction request.
- (2) Sets DMA (According to the applied procedure for the DMAC, set the following parameter)
  - Source address (the address specified in “src”).
  - Destination address (Display List FIFO of the “Graphics Controller”).
  - Transfer count (the value specified in “count”).
- (3) Sets transfer count (the MB86290 Series side)
  - Sets DMA transfer count (the value specified in “count”) to DTC (DMA Transfer Count) register.
- (4) Starts DMA transaction
  - Appropriate start up operation for the applied DMA controller.
- (5) Issues the DMA request
  - Sets 1 to DRQ (DMA ReQuest) register.
- (6) Waits for the completion of the DMA transfer
  - 1 block configuration Display List buffer is applied, wait till the end of DMA transaction.

[Remark]

When the unit of transfer count is 32byte, if the total byte size of the Display List is not a multiple of 32byte, the driver command fills appropriate number of NOP and makes the size to be a multiple of 32byte.

**[Example]**

```

/* Start address of the host interface register field */
/* Please set a suitable value to the following #####
   according to the environment of use*/
#define HOSTBASE 0x#####

/* Start address of drawing control register field */
/* Please set a suitable value to the following #####
   according to the environment of use*/
#define DRAWBASE      0x#####

#define WRITE_DTC(i)      ( *(GDC_ULONG*)(HOSTBASE+0x00) = (i) )
#define WRITE_DRQ(i)     ( *(GDC_ULONG*)(HOSTBASE+0x18) = (i) )

#ifndef GDC_MB86290A
#define FIFO_ADDRESS      (DRAWBASE+0x4a0) /* for MB86290A */
#else
#define FIFO_ADDRESS      (DRAWBASE+0x8400) /* for MB86291 or later */
#endif

void GdcFlushDisplayList(GDC_ULONG *src, GDC_ULONG count){
    /* Polling for DMA ready DMA */
    /* Please create DMA_BUSY function according to the environment of use */
    while( DMA_BUSY() );

    /* Sets transfer count */
    /* Please create SET_DMA_COUNT function according to the environment of use */
    SET_DMA_COUNT(CHANNEL0, count);

    /* Sets source address */
    /* Please create SET_DMA_SRC function according to the environment of use */
    SET_DMA_SRC(CHANNEL0, src);

    /* Sets destination address */
    /* Please create SET_DMA_DEST function according to the environment of use */
    SET_DMA_DEST(CHANNEL0, FIFO_ADDRESS);

    /* Sets transfer count (Graphics Controller) */
    WRITE_DTC(count);

    /* Trigger of DMA transaction */
    /* Please create DMA_START function according to the environment of use */
    DMA_START();

    /* Issue of external DMA request */
    WRITE_DRQ(1);

#ifndef SINGLE_DL_BUFFER
    /* Wait for the next Display List buffer write to be ready */
    while( DMA_BUSY() );
#endif
}

```



**\*CPU transfer**

This is a method to write the transfer data (Display List) to the Display List FIFO of MB86290 Series by software. The operation procedure of this case is shown as follows. Repeat (1) through (4) for the times specified by "count".

- (1) Acquires the Display List FIFO status
  - Calls the GdcGetFIFOStatus command and acquire the Display List FIFO status information.
- (2) Checks the Display List FIFO status
  - Checks the empty entries of the Display List FIFO from the above status information. If FIFO is full, keep repeating (1) and (2) till open entries will be available.
- (3) Transfers 4byte of data from the source address to the Display List FIFO
- (4) Posts increment (+4) source address

**[Example]**

```

/* Start address of drawing control register field */
/* Please set a suitable value to the following #####
   according to the environment of use*/
#define DRAWBASE      0x#####
#define FIFO_FULL    0x2

#ifdef GDC_MB86290A
/* for MB86290A */
#define WRITE_FIFO(i)    (*(volatile GDC_ULONG*)(DRAWBASE+0x4a0) = (i) )
#else
/* for MB86291 */
#define WRITE_FIFO(i)    (*(volatile GDC_ULONG*)(DRAWBASE+0x8400) = (i) )
#endif

void GdcFlushDisplayList(GDC_ULONG *src, GDC_ULONG count){
    int  i;

    for(i = 0; i < count; i++){
        /* If FIFO is full, wait until open entry will be available */
        while(GdcGetFIFOStatus() & FIFO_FULL);

        /* Transfers data to the FIFO */
        WRITE_FIFO(*src++);
    }
}

```

### 8.2.3 GdcGetHostRegisterAddress [Gets host interface register area address]

Format	GDC_ULONG *GdcGetHostRegisterAddress (void)
Parameter	None
Return value	Start address of host interface register field
Called by	GdcInitialize command
Description	Start address of host interface register field is returned. This command can be used by all "Graphics Controller".

### 8.2.4 GdcGetDispRegisterAddress [Gets display control register area address]

Format	GDC_ULONG *GdcGetDispRegisterAddress (void)
Parameter	None
Return value	Start address of display control register field
Called by	GdcInitialize command
Description	Start address of display control register field is returned. This command can be used by all "Graphics Controller".

### 8.2.5 GdcGetDrawRegisterAddress [Gets drawing control register area address]

Format	GDC_ULONG *GdcGetDrawRegisterAddress (void)
Parameter	None
Return value	Start address of drawing control register field
Called by	GdcInitialize command
Description	Start address of drawing control register field is returned. This command can be used by all "Graphics Controller".