



Processors and Peripherals

QUICK REFERENCE GUIDE

Document No. 60311

May 1982

Quick Reference Guide for Processors and Peripherals

Reference Guide Conventions

The following conventions are adhered to throughout this guide.

1. All numbers not subscripted are assumed to be decimal unless noted in a table or chart.
2. A "\$" appearing anywhere in this text other than character charts, shall denote an unused or unassigned item.
3. All items of information are generated for those model codes with which they are listed and cannot be assumed to apply to any models not listed.

This guide is designed to aid the programmer and system analyst in using Datapoint equipment.

Under no circumstances is this guide to be used as a reference in the establishment of specifications or performance criteria. The appropriate product specification, reference manual, or software user's guide should be consulted for that purpose.

Suggestions and additions will be gratefully accepted. Write the Software Support Group, 9725 Datapoint Drive, San Antonio, Texas 78284.

Copyright 1982 by Datapoint Corporation. 4/82. All rights reserved. The "D" logo and Datapoint are trademarks of Datapoint Corporation registered in the U.S. Patent and Trademark Office. System features are subject to change without notice. Document no. 60311.

Quick Reference Guide for Processors and Peripherals

Table of Contents

| | |
|--|----|
| Device Address Assignments..... | 4 |
| External Commands..... | 6 |
| Cassette Tape Decks..... | 7 |
| CRT/Keyboard (5500 and 6600 processors)..... | 8 |
| 9350, 9367 Disk Controller/Drive..... | 9 |
| 9370, 9374 Disk Controller/Drive..... | 10 |
| 9380 Disk Controller/Drive..... | 11 |
| 9390/9391 Storage Module System..... | 12 |
| 7 and 9 Track Tape Transport | |
| 9550/9551, 9552/9553, 9554, 9555..... | 13 |
| 9558..... | 14 |
| 1600 BPI Magnetic Tape System (9580, 9581, 9583)..... | 15 |
| Printers | |
| 9212/9214, 9242, 9260, 9265, 9280, 9291, 9292..... | 16 |
| 9232/9234..... | 17 |
| 9601/9602, 9621/9622, 9257/9258..... | 18 |
| Multiple Port Communications Adaptor (9460, 9462)..... | 19 |
| Multiple Function Communications Adaptor (9481)..... | 20 |
| Asynchronous Communications Adaptors..... | 23 |
| 9404 Synchronous Communications Adaptor..... | 26 |
| 9405 Synchronous Communications Adaptor..... | 27 |
| 9483 Resource Interface Module..... | 28 |
| 1800/3800 Serial Interface Module..... | 29 |
| Machine Instructions | |
| 2200..... | 30 |
| 5500..... | 32 |
| 6600, 8600..... | 38 |
| 8800..... | 40 |
| Assembler Directives..... | 44 |
| Labels..... | 45 |
| Expressions..... | 45 |
| Assembler Pseudo-instructions..... | 46 |
| Assembly Error Flags..... | 46 |
| MACROS..... | 47 |
| Assembler Execution..... | 47 |
| ROM Debug Entry Point Vectors..... | 48 |
| ROM Debug Display Format..... | 48 |
| ROM Debug Command Summaries | |
| 6600..... | 50 |
| 1800, 3800..... | 51 |
| 1550..... | 52 |
| 8600..... | 53 |
| 8800..... | 54 |
| 1130..... | 55 |
| 1150/1170..... | 56 |
| Character Transmission and Translation Table..... | 57 |

Quick Reference Guide for Processors and Peripherals

Device Address Assignments

| Device | Binary | Octal |
|---|----------|-------|
| Cassette deck | 11110000 | 360 |
| 940X - DSREMOTE #2 | 11101000 | 350 |
| 940X - DSREMOTE #3 | 11100100 | 344 |
| 940X - DSREMOTE #4 | 11100010 | 342 |
| CRT/Keyboard | 11100001 | 341 |
| 940X - DSREMOTE #5 | 11011000 | 330 |
| 940X - DSREMOTE #6 | 11010100 | 324 |
| 940X - DSREMOTE #1 | 11010010 | 322 |
| 9481 - Multifunction Communications Adaptor #1 | 11010001 | 321 |
| 9481 - Multifunction Communications Adaptor #2 | 11001100 | 314 |
| 9481 - Multifunction Communications Adaptor #3 | 11001010 | 312 |
| 9481 - Multifunction Communications | 11001001 | 311 |
| Local Printer #3 | 11000011 | 306 |
| Local Printer #2 | 11000101 | 305 |
| Local Printer #1 | 11000110 | 303 |
| Local Printer #4 | 10111000 | 270 |
| Magnetic Tape #1 (Mode 0) | 10110100 | 264 |
| Magnetic Tape #2 | 10110010 | 262 |
| Magnetic Tape #3 | 10110001 | 261 |
| 9483 RIM #4 | 10101100 | 254 |
| 9483 RIM #5 | 10101010 | 252 |
| 9483 RIM #6 | 10101001 | 251 |
| 9404 Synchronous Combox #2 | 10100110 | 246 |
| 9404 Synchronous Combox #1 | 10100101 | 245 |
| 9404 Synchronous Combox #3 | 10100011 | 243 |
| 9483 RIM #1 | 10011100 | 234 |
| 9483 RIM #2 | 10011010 | 232 |
| 9483 RIM #3 | 10011001 | 231 |
| 9420 Parallel Interface #1 | 10010110 | 226 |
| 9420 Parallel Interface #2 | 10010101 | 225 |
| 9420 Parallel Interface #3 | 10010011 | 223 |
| 9426 IBM Channel Simulator | 10001110 | 216 |
| 9426 IBM Channel Adaptor | 10001101 | 215 |
| 9420 Parallel Interface | 10001011 | 213 |
| Card Reader | 10000111 | 207 |
| 9350 Disk Controller | 01111000 | 170 |
| Cartridge Disk | 01110100 | 164 |
| Magnetic Tape (Mode 1 only) | 01110010 | 162 |
| 9390 Disk | 01110001 | 161 |
| 940X - DSREMOTE #7 | 01101100 | 154 |
| 940X - DSREMOTE #8 | 01101010 | 152 |
| 9462 Multiport Adaptor #1 | 01101001 | 151 |
| 940X - DSREMOTE #9 | 01100110 | 146 |
| 940X - DSREMOTE #10 | 01100101 | 145 |
| 940X - DSREMOTE #11 | 01100011 | 143 |
| Local Printer #5 | 01011100 | 134 |
| Local Printer #6 | 01011010 | 132 |

Quick Reference Guide for Processors and Peripherals

| Device | Binary | Octal |
|---------------------------|----------|-------|
| Local Printer #7 | 01011001 | 131 |
| Mass Storage Disk | 01010110 | 126 |
| Mass Storage Disk | 01010101 | 125 |
| Mass Storage Disk | 01010011 | 123 |
| Mass Storage Disk #3 | 01001110 | 116 |
| Mass Storage Disk #2 | 01001101 | 115 |
| 9370/9374 Disk Controller | 01001011 | 113 |
| Mass Storage Disk | 01000111 | 107 |
| Diskette #1 | 00111100 | 074 |
| Diskette #2 | 00111010 | 072 |
| Diskette #3 | 00111001 | 071 |
| 940X - DSREMOTE #12 | 00110110 | 066 |
| 940X - DSREMOTE #13 | 00110101 | 065 |
| 940X - DSREMOTE #14 | 00110011 | 063 |
| 9462 Multiport Adaptor #4 | 00101110 | 056 |
| 9462 Multiport Adaptor #2 | 00101101 | 055 |
| 9462 Multiport Adaptor #3 | 00101011 | 053 |
| Unassigned | 00100111 | 047 |
| Unassigned | 00011110 | 036 |
| Unassigned | 00011101 | 035 |
| Unassigned | 00011011 | 033 |
| Unassigned | 00010111 | 027 |
| Unassigned | 00001111 | 017 |

Note 1: Each communications adaptor will have the device address of the unit it is servicing.

Note 2: Individual disk drives are addressed via the disk controller.

Note 3: Address 0115 is used when converting from 9370 hardware to 9374 hardware or vice versa (using special copyfile overlay).

Quick Reference Guide for Processors and Peripherals

External Commands

Command - EX (EXPRESSION)

| All Devices | | | |
|-----------------------|---------------------|-------------------------|-----------------|
| COMMAND EXPRESSION | OPERATION NUMBER | COMMAND CODE (OCTAL) | FUNCTION |
| ADR | 1 | 121 | Address Device* |
| STATUS | 2 | 123 | Sense Status* |
| DATA | 3 | 125 | Sense Data* |
| WRITE | 4 | 127 | Write Strobe* |
| COM1 | 5 | 131 | Command 1* |
| COM2 | 6 | 133 | Command 2* |
| COM3 | 7 | 135 | Command 3* |
| COM4 | 8 | 137 | Command 4* |
| \$ | 9 | 141 | \$ |
| \$ | 10 | 143 | \$ |
| \$ | 11 | 145 | \$ |
| \$ | 12 | 147 | \$ |
| BEEP | 13 | 151 | Beep |
| CLICK | 14 | 153 | Click |


*Note: Also see Debug Command Summary.

| Cassette Tape Decks | | | |
|---------------------|-------------------|---------------------------|---------------------|
| EXPRESSION | COMMAND NUMBER | OPERATION CODE (OCTAL) | COMMAND FUNCTION |
| DECK1 | 15 | 155 | Select Rear Deck |
| DECK2 | 16 | 157 | Select Front Deck |
| RBK | 17 | 161 | Read Block |
| WBK | 18 | 163 | Write Block |
| \$ | 19 | 165 | \$ |
| BSP | 20 | 167 | Backspace One Block |
| SF | 21 | 171 | Slew Forward |
| SB | 22 | 173 | Slew Backward |
| REWIND | 23 | 175 | Rewind Tape |
| TSTOP | 24 | 177 | Stop Tape |

Quick Reference Guide for Processors and Peripherals

Cassette Tape Decks

Status word - EX STATUS




Tape Unit Physical Specifications (ANSI Decks)


| | |
|--|------------------------------|
| Density | 47 characters/inch |
| Speed | 7.5 inches/second |
| Recording Rate | 350 characters/second |
| Capacity | 115,000 characters (typical) |
| Start/Stop Time (Inter-Record Gap) | 305 msec |
| Start/Stop Distance (Inter-Record Gap) | 2.2 inches |
| Rewind Speed | 90 inches/second |
| Rewind Time (maximum) | 40 seconds |
| Characters Transfer Time | 2.8 msec |

CRT/Keyboard (5500 and 6600 style processors)

Status Word - EX STATUS



Control Word - EX COM1



Control Word - EX COM2

Horizontal Cursor Position
 (Decimal 0-79, octal 0-117. Starting at left of screen)


Control Word - EX COM3

Vertical Cursor Position
 (Decimal 0-11, octal 0-13. Starting at top of screen)


*"Write Ready" is valid only if cursor is positioned to a valid screen position.

9350, 9367 Disk Controller/Drive

Status Word - EX STATUS




Control Word - EX COM1



Control Word - EX COM2

Select Cylinder Number (0-312 octal)

Control Word - EX COM3



Control Word - EX COM4

Select Buffer Page Byte Address (0-255 decimal, 0-377 octal)

Quick Reference Guide for Processors and Peripherals

9370, 9374 Disk Controller/Drive

Status Word - EX STATUS

| | | | | | | | | |
|---|---|---|---|---|---|---|---|---|
| 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 | (Bit Set -> Condition True) |
| | | | | | | | | Drive On-Line and File Safe (9374 - Drive |
| | | | | | | | | On-line and No Write check) |
| | | | | | | | | Data Transfer in Progress |
| | | | | | | | | Drive Busy |
| | | | | | | | | Seek Incomplete Error |
| | | | | | | | | CRC Error |
| | | | | | | | | Write Protect Enable |
| | | | | | | | | Sector Not Found |
| | | | | | | | | Buffer Parity Error |

Control Word - EX COM1

| | | | | | | | | |
|---|---|---|---|---|---|---|---|--|
| 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 | |
| | | | | | | | | 0000 Master Clear |
| | | | | | | | | 0001 Disk Read |
| | | | | | | | | 0010 Disk Write |
| | | | | | | | | 0011 Disk Write Verify (Write followed by read |
| | | | | | | | | check of CRC) |
| | | | | | | | | 0100 Restore Selected Drive |
| | | | | | | | | 0101 Select Physical Drive as per contents of |
| | | | | | | | | EX COM2 Register (0-7) |
| | | | | | | | | 0110 Select Cylinder as per contents of EX |
| | | | | | | | | COM2 Register (0-312 octal) (9374 - Sets |
| | | | | | | | | upper 8 bits of cylinder address |
| | | | | | | | | 0111 Verify Drive Type: 001 -> Datapoint 9370, |
| | | | | | | | | 020 -> Datapoint 9374 |
| | | | | | | | | 1000 Format Track |
| | | | | | | | | 1001 Select Head as per contents of EX COM2 |
| | | | | | | | | Register (0-19 decimal, 0-23 octal) (9374 |
| | | | | | | | | - 0-17 octal) |
| | | | | | | | | 1010 Select Sector as per contents of EX COM2 |
| | | | | | | | | Register (0-24 decimal, 0-27 octal) 9374 |
| | | | | | | | | - Sets upper 5 bits of sector address |
| | | | | | | | | 1011 Clear Buffer Parity Error |
| | | | | | | | | 1100 Diagnostic Reset: Clear File Unsafe |
| | | | | | | | | (9374 - not used) |
| | | | | | | | | 1101 Set Track Offset per contents of EX COM2 |
| | | | | | | | | register. (9374 only) |
| | | | | | | | | 0000 \$ |

Control Word - EX COM2

Sets drive cylinder, sector and head in conjunction with proper EX COM1 command. 9374 - also used for track offset selection.

Control Word - EX COM3


Select buffer page (0-15 decimal, 0-17 octal).

Control Word - EX COM4


Select buffer page byte address.

9380 Disk Controller/Drive

Status Word - EX STATUS




Control Word - EX COM1



Control Word - EX COM2

Select Track and Seek (0-76 decimal, 0-114 octal)

Control Word - EX COM3



Control Word - EX COM4

Select Buffer Page Byte Address (0-255 decimal, 0-377 octal)

Note 1: Buffer memory parity will be in error on power-up until buffer is written in.

Note 2: The 9380 contains two physical sectors for each logical sector.

9390/9391 Storage Module System

Status Word - EX STATUS

| | | | | | | | | | |
|---|---|---|---|---|---|---|---|-------|--|
| 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 | | (Bit Set -> Condition True) |
| | | | | | | | | _____ | MPE - Parity error when reading from buffer |
| | | | | | | | | _____ | RE - Rate Error |
| | | | | | | | | _____ | POR - Indicates controller is doing or has done a power-on sequence |
| | | | | | | | | _____ | INS - Installed. True when controller power on |
| | | | | | | | | _____ | CSS - Control Store Scan - First step of power on sequence; test firmware for CRC errors |
| | | | | | | | | _____ | ERR - Error: an unrecoverable error has occurred in the controller of a type not reportable in command string sense byte |
| | | | | | | | | _____ | RDY - Ready: Power-on sequence has successfully completed |
| | | | | | | | | _____ | DA - Diagnostic acknowledge |

Control Word - EX COM2

| | | | | | | | | |
|---|---|---|---|---|---|---|---|---|
| 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 | |
| | | | | | | | | |
| | | | | | | | | 000 Not used |
| | | | | | | | | 001 Set 6600 Diagnostic Mode |
| | | | | | | | | 010 Clear Interface Status Bits |
| | | | | | | | | 011 Set Buffer Address to Command/Status Page, byte 255 |
| | | | | | | | | \$ |

Control Word - EX COM3

Selects one of 60 buffer memory pages


Control Words - EX COM2, EX COM3, EX COM4

Places the controller in DATA mode


Quick Reference Guide for Processors and Peripherals

7 and 9 Track Tape Transport (9550/9551, 9552/9553, 9554, 9555)

Status Word - EX STATUS



Control Word - EX COM1



Control Word - EX COM2
Write Buffer Content on Tape

Control Word - EX COM3
Clear Buffer

Control Word - EX COM4
§

7 Track Tape Transport (9558)

Status Word - EX STATUS

| | | | | | | | | |
|---|---|---|---|---|---|---|---|----------------------------------|
| 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 | (Bit Set -> Condition True) |
| | | | | | | | | Deck Ready |
| | | | | | | | | Parity Error |
| | | | | | | | | Read Ready/Write Buffer Full |
| | | | | | | | | Write Ready/Read Buffer Overflow |
| | | | | | | | | BOT Detected |
| | | | | | | | | File Mark Detected |
| | | | | | | | | Deck in service |
| | | | | | | | | EOT Detected |

Control Word - EX COM1

| | | | | | | | | |
|---|---|---|---|---|---|---|---|---------------------|
| 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 | Write Record |
| X | X | X | 0 | 0 | 0 | 0 | 0 | Write File Mark |
| X | X | X | 0 | 0 | 0 | 0 | 1 | Erase 3" Tape |
| X | X | X | 0 | 0 | 0 | 1 | 1 | Read Record |
| X | X | X | 0 | 0 | 1 | 0 | 0 | Advance Record |
| X | X | X | 0 | 0 | 1 | 0 | 1 | Advance File Mark |
| X | X | X | 0 | 0 | 1 | 1 | 0 | Backspace Record |
| X | X | X | 0 | 0 | 1 | 1 | 1 | Backspace File Mark |
| X | X | X | 0 | 1 | 0 | 0 | 0 | Rewind |
| 0 | 0 | 0 | 0 | 1 | 0 | 0 | 1 | Drive 0 Select |
| 0 | 1 | 0 | 0 | 1 | 0 | 0 | 1 | Drive 1 Select |
| 1 | 0 | 0 | 0 | 1 | 0 | 0 | 1 | Drive 2 Select |
| 1 | 1 | 0 | 0 | 1 | 0 | 0 | 1 | Drive 3 Select |
| X | X | X | 0 | 1 | 0 | 1 | 0 | Slew Write |
| X | X | X | 0 | 1 | 0 | 1 | 1 | Slew Read |
| X | X | X | 0 | 1 | 1 | 0 | 0 | Slew Halt |
| X | X | X | 0 | 1 | 1 | 0 | 1 | Load Write Pointer |
| X | X | X | 0 | 1 | 1 | 1 | 0 | Load Read Pointer |
| X | X | X | 1 | 0 | 0 | 0 | 0 | Write Edit |
| X | X | X | 1 | 0 | 1 | 1 | 0 | Backspace Edit |

Control Word - EX COM2

Write Buffer Content on Tape

Control Word - EX COM3

Clear Buffer

Control Word - EX COM4 (First Output)

| | | | | | | | | |
|---|---|---|---|---|---|---|---|---------------------|
| 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 | |
| | | | | | | | | |
| | | | | | | | | Buffer Page Address |
| | | | | | | | | \$ |


Control Word - EX COM4 (Second Output)

| | | | | | | | | |
|---|---|---|---|---|---|---|---|--------------------------|
| 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 | |
| | | | | | | | | |
| | | | | | | | | Buffer Page Byte Address |


Quick Reference Guide for Processors and Peripherals

1600 BPI Magnetic Tape System (9580, 9581, 9583)

Status Word - EX STATUS



Control Word - EX COM1




Control Word - EX COM2

Write Buffer Contents on Tape


Control Word - EX COM3

Clear Buffer

Control Word - EX COM4 (First Output)



Control Word - EX COM4 (Second Output)



Quick Reference Guide for Processors and Peripherals

Printers (9212/9214, 9242, 9260, 9265, 9280, 9291, 9292)

Status Word - EX STATUS

| | | | | | | | | |
|---|---|---|---|---|---|---|---|-----------------------------|
| 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 | (Bit Set -> Condition True) |
| | | | | | | | | Printer Busy |
| | | | | | | | | Printer Available |
| | | | | | | | | Printer Addressed |
| | | | | | | | | \$ |

Character Transmission - EX WRITE

See Character Transmission and Translation Table


Printer Control Codes (in octal)

- 012 Line Feed
- 013 Vertical Tab (Centronics only)
- 014 Form Feed
- 015 Print
- 016 Elongated Print (Centronics only)

Note 1: Printer Control Codes are in addition to printing the buffer (i.e. data followed by a 014 will print the buffer and form feed).

Freedom Printer (9232/9234)

Status Word - EX STATUS



Character Transmission - EX WRITE

See "Character Transmission and Translation Table"

Printer Control Codes¹ (in octal)


- 001 Tab to column (MSB, LSB)
- 002 Secondary tractor line feed
- 005 Set secondary tractor left margin and tab to column (MSB, LSB)
- 012 Line feed
- 013 Vertical tab
- 014 Form feed
- 015 Print
- 016 Primary tractor micro-line feed
- 036 Secondary tractor micro-line feed

Note 1: Printer Control Codes are in addition to printing the buffer (i.e., data followed by a 014 will print the buffer and form feed).

Quick Reference Guide for Processors and Peripherals

Printers (9601/9602, 9621/9622, 9257/9258)

Status Word - EX STATUS



9601/9602 Control Codes


| | |
|----------------------|---|
| Initialize | 033 0143 |
| Default | 033 0121 |
| Set Form Length | 033 0133 n 073 x 0162 |
| Set Left Margin | 033 0133 n 0161 |
| Set Spacing | 033 0133 h 073 n 040 0107 |
| Load Character Table | 033 0120 040 n 073 p 073 040 e 073 040 w 073 041 e 073 041 w 073 ... 0176 e 073 0176 w 073 0177 e 073 0177 w 033 0134 |
| Pause | 033 0120 044 MSG 033 0134 |
| Vertical Tab | 033 133 n 0145 |
| Micro Line Feed | 016 |
| Line Feed | 012 |
| Form Feed | 014 |
| Thin Space | 033 0133 n 0141 |
| Space | 040 |
| Horizontal Tab | 033 0133 n 0140 |
| Carriage Return | 015 |
| Print | 040 033 0116 041 |
| Print | 0177 033 0116 042 |
| Bell | 007 |
| Delete | 0177 |
| Printer On | 032 |
| Printer Off | 024 |

9621/9622 Control Codes


| | |
|------------------------|---------------------------------|
| Carriage Return | 015 |
| Tab to Column | 001 msb lsb |
| Line Feed | 012 |
| Micro Line Feed | 016 |
| Form Feed | 014 |
| Downline Load | |
| Forms Length | 033 014 n2 n1 |
| Forms Length Reset | 023 |
| Select a Resident Font | 033 0133 #a 0155 |
| Horizontal Tab Set | 033 0120 042 #1 ... #i 033 0134 |
| Vertical Tab Set | 033 0120 043 #1 ... #i 033 0134 |

Multiple Port Communications Adaptor (9460, 9462)


Status Word¹ - EX STATUS



Control Word - EX COM1




Control Word - EX COM2



Transmit and Receive Character Formats

| Control Bit Position | Start Bit | Information Bits | Stop Bits | Code Bit Positions |
|----------------------|-----------|------------------|-----------|--------------------|
| 210-Octal | | | | 7 6 5 4 3 2 1 0 |
| 000-0 | 1 | 5 | 1 | x x x 5 4 3 2 1 |
| 001-1 | 1 | 6 | 1 | x x 6 5 4 3 2 1 |
| 010-2 | 1 | 7 | 1 | x 7 6 5 4 3 2 1 |
| 011-3 | 1 | 8 | 1 | 8 7 6 5 4 3 2 1 |
| 100-4 | 1 | 5 | 2 | x x x 5 4 3 2 1 |
| 101-5 | 1 | 6 | 2 | x x 6 5 4 3 2 1 |
| 110-6 | 1 | 7 | 2 | x 7 6 5 4 3 2 1 |
| 111-7 | 1 | 8 | 2 | 8 7 6 5 4 3 2 1 |

Control Word - EX COM3



Control Word - EX COM4 - Not used

Control Word - EX WRITE

Transfers character in A register to the currently selected port for transmission.

Note 1: Until a port is selected, the STATUS word is a logical OR value of the status of all eight ports.

Quick Reference Guide for Processors and Peripherals

Multi Function Communications Adaptor (9481)

Status Word - EX STATUS

| | | | | | | | | |
|---|---|---|---|---|---|---|---|----------------------------------|
| 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 | (Bit Set -> Condition True) |
| 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | Set normal status mode |
| 0 | 0 | 1 | 0 | 0 | 0 | 0 | 0 | Set transmit buffer status mode |
| 1 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | Set modem status mode |
| 1 | 1 | 0 | 0 | 0 | 0 | 0 | 0 | Set Receive Status Mode |
| 0 | 0 | 1 | 1 | 0 | 0 | 0 | 0 | Set ACU Status Mode |
| 0 | 0 | 1 | 1 | 0 | 0 | 0 | 1 | Clear Transmit Buffer |
| 0 | 0 | 1 | 1 | 0 | 0 | 1 | 0 | Set BSC Mode |
| 0 | 0 | 1 | 1 | 0 | 0 | 1 | 1 | Reset Line Active Status |
| 0 | 0 | 1 | 1 | 1 | n | n | n | Set Generalized Synchronous Mode |
| | | | | n | n | n | | Character length (bits) |
| | | | | 0 | 0 | 0 | | 8 |
| | | | | 0 | 0 | 1 | | 8 |
| | | | | 0 | 1 | 0 | | 8 |
| | | | | 0 | 1 | 1 | | 8 |
| | | | | 1 | 0 | 0 | | 4 |
| | | | | 1 | 0 | 1 | | 5 |
| | | | | 1 | 1 | 0 | | 6 |
| | | | | 1 | 1 | 1 | | 7 |

SDLC Normal Status Byte

| | | | | | | | | |
|---|---|---|---|---|---|---|---|---|
| 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 | |
| | | | | | | | | Receive Ready |
| | | | | | | | | Line Active |
| | | | | | | | | \$ |
| | | | | | | | | 00 Character is data character. |
| | | | | | | | | 01 Character is an SDLC FLAG (0176) but the preceding two CRC bytes indicate an error occurred in the previous frame. |
| | | | | | | | | 10 Character is a control character other than FLAG. |
| | | | | | | | | 11 Character is an SDLC FLAG and the two preceding CRC bytes were valid, indicating that no error occurred. |

BSC Normal Status

| | | | | | | | | |
|---|---|---|---|---|---|---|---|--------------------|
| 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 | |
| | | | | | | | | Receive Ready |
| | | | | | | | | \$ |
| | | | | | | | | End of Block (EOB) |
| | | | | | | | | CRC Good |

Generalized Synchronous Normal Status Byte


| | | | | | | | | |
|---|---|---|---|---|---|---|---|---------------|
| 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 | |
| | | | | | | | | Receive Ready |
| | | | | | | | | \$ |

Transmit Buffer Status


| | | | | | | | | |
|---|---|---|---|---|---|---|---|----------------------------|
| 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 | |
| | | | | | | | | Buffer Positions Available |
| | | | | | | | | \$ |

Quick Reference Guide for Processors and Peripherals


Receive Buffer Status




Modem Status



Automatic Calling Unit (ACU) Status




Control Word - EX COM1



Control Words - EX COM2 and EX WRITE

Transfer data to buffer. EX COM2 is used to insert special control codes into the data stream.

Control Word - EX COM3



Quick Reference Guide for Processors and Peripherals

| Dial Digit NB1 - NB8 (bits 0 - 3) | | | | | |
|-----------------------------------|-----|-----|-----|-----|--|
| Dial Digit | NB8 | NB4 | NB2 | NB1 | |
| 0 | 1 | 1 | 1 | 1 | |
| 1 | 1 | 1 | 1 | 0 | |
| 2 | 1 | 1 | 0 | 1 | |
| 3 | 1 | 1 | 0 | 0 | |
| 4 | 1 | 0 | 1 | 1 | |
| 5 | 1 | 0 | 1 | 0 | |
| 6 | 1 | 0 | 0 | 1 | |
| 7 | 1 | 0 | 0 | 0 | |
| 8 | 0 | 1 | 1 | 1 | |
| 9 | 0 | 1 | 1 | 0 | |
| EON | 0 | 0 | 1 | 1 | |
| SEP | 0 | 0 | 1 | 0 | |

EON (003) End of Number Code

SEP (002) Separator or inter-digit relay code

Control Word - EX COM4

Used to set the receive and transmit rate.

Quick Reference Guide for Processors and Peripherals

Asynchronous Communications Adaptors

Status Word - EX STATUS (Bit set -> Condition True)

Status

| <u>Word</u> | <u>Bits</u> | <u>9400</u> | <u>9401</u> | <u>9402</u> | <u>9403</u> | <u>9410</u> |
|-------------|-------------|------------------------------|--------------------------|--------------------------|-------------|---------------------------|
| 0 | | Transmit Ready | Same | Same | Same | Present Next Digit |
| 1 | | Receive Ready | Same | Same | Same | Data Line Occupied |
| 2 | | Break Received | Same | Same | Same | Distant Station Connected |
| 3 | | Clear to Send (CB) | Same | Same | \$ | Abandon Call |
| 4 | | Reverse Carrier Present (SB) | \$ | Same | \$ | Power Indication |
| 5 | | Ringing Present (CE) | Same | Same | \$ | Standby Indicator |
| 6 | | Main Carrier Present (CF) | Carrier Present (CAR) | Same | \$ | \$ |
| 7 | | \$ | Data Coupler Ready (DCR) | Data Coupler Ready (DCR) | \$ | \$ |

Quick Reference Guide for Processors and Peripherals

Control Word - EX COM1

EX COM1

| Word | Bits | 9400 | 9401 | 9402 | 9403 | 9410 |
|------|------|------------------------------|--------------------------------|-------------------|------|------------------------------------|
| 0 | | Request to Send | Same | Same | \$ | Data Terminal Ready |
| 1 | | Invert Received Data Line | Same | Same | \$ | Request to Send Mn. Channel |
| 2 | | Supervisory Channel On | \$ | Same | \$ | Sig. Rate Sel./Transmit Freq. Sel. |
| 3 | | Invert Transmitted Data Line | Same | Same | Same | Select Standby |
| 4 | | Data Terminal Ready | Off Hook | Off Hook | \$ | Receiver Cut-off Mn. Channel |
| 5 | | \$ | \$ | Send 2025 Hz | \$ | Return to Non-Data Mode |
| 6 | | \$ | Orig.=1 ¹ Ans.=0 | Orig.=1 Ans.=0 | \$ | Request to Send Rev. Channel |
| 7 | | \$ | Send Dial Pulses | Send Dial Pulses | \$ | Receiver Cut-off Rev. Channel |

Control Word - EX COM2 (1st execution)

Receive Time Base - least significant byte (see charts)

Control Word - EX COM2 (2nd execution)

Receive Time Base - most significant byte (see charts)

Control Word - EX COM3 (1st execution)

Transmit Time Base - least significant byte (see charts)

Control Word - EX COM3 (2nd execution)

Transmit Time Base - most significant byte (see charts)

Note 1: 2025 Hz is used for transmission if this bit is 0.

Time Base Chart (EIA) 9400, 9401, 9402, 9403

| | | |
|----------|---------|---------|
| Receive | EX COM2 | EX COM2 |
| Transmit | EX COM3 | EX COM3 |

Quick Reference Guide for Processors and Peripherals


| <u>Bit Rate</u> | <u>1st Mask Word (Octal)</u> | <u>2nd Mask Word (Octal)</u> |
|-----------------|------------------------------|------------------------------|
| 100 | 375 (dialing) | 000 |
| 110 | 375 | 106 |
| 220 | 376 | 243 |
| 440 | 377 | 121 |
| 150 | 376 | 000 |
| 300 | 377 | 000 |
| 600 | 377 | 200 |
| 1200 | 377 | 300 |
| 1800 | 377 | 325 |
| 2400 | 377 | 340 |

Time Base Chart (CCITT) 9410


Receive EX COM2 EX COM2
Transmit EX COM3 EX COM3

| <u>Bit Rate</u> | <u>1st Mask Word (Octal)</u> | <u>2nd Mask Word (Octal)</u> |
|-----------------|------------------------------|------------------------------|
| 50 | 030 | 000 |
| 75 | 020 | 000 |
| 100 | 014 | 000 |
| 200 | 006 | 000 |
| 110 | 365 | 027 |
| 220 | 372 | 214 |
| 440 | 375 | 106 |
| 150 | 370 | 000 |
| 300 | 374 | 000 |
| 600 | 376 | 000 |
| 1200 | 377 | 000 |
| 2400 | 377 | 200 |
| 4800 | 377 | 300 |
| 9600 | 377 | 340 |

Control Word - EX COM4 (9400, 9401, 9402, 9403)




Control Word - EX COM4 (9410)




9404 Synchronous Communications Adaptor

Status Word - EX STATUS



Control Word - EX COM1



Control Word - EX COM2

Write single "DLE" ("DLE" character loaded in the A register, EBCDIC only)

Control Word - EX COM3

New SYNC


Control Word - EX COM4

\$


Quick Reference Guide for Processors and Peripherals

9405 Synchronous Communications Adaptor (9404 with 712 clock option)

Status Word - EX STATUS



Control Word - EX COM1




Control Word - EX COM2

Write single "DLE" ("DLE" character loaded in the A register, EBCDIC only)

Control Word - EX COM3

New SYNC

Control Word - EX COM4



Note 1: The toggle switch on the 9405 board must be flipped for 600/1200 BAUD operation.

9483 Resource Interface Module

Status Word - EX STATUS

| 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 | |
|---|---|---|---|---|---|---|---|-------------------------------------|
| | | | | | | | | (Bit Set -> Condition True) |
| | | | | | | | | Transmitter Available |
| | | | | | | | | Transmitted Message Acknowledged |
| | | | | | | | | System Reconfiguration has occurred |
| | | | | | | | | Transmitter Parity Error |
| | | | | | | | | Power-on reset occurred |
| | | | | | | | | Device Available (Always 1) |
| | | | | | | | | Interface Parity Error |
| | | | | | | | | Receiver Inhibited |

Control Word - EX COM1

General RIM command defined by the contents of the processor output bus.

Control Word - EX COM4

Sets buffer address to the contents of the processor output bus and sets DATA mode in the RIM. All three page registers remain unchanged. The next EX WRITE or INPUT instruction executed will access the location in the buffer memory specified by this address and the processor page register.

1800/3800 Serial Interface Module

| | |
|-------------------|---------------------------------------|
| SISTART (165) | Serial Interface START |
| SISYNC (111 165) | Serial Interface SYNChronize |
| SIIN (163) | Serial Interface IN |
| SIMIN (062 163) | Serial Interface Multiple In |
| SICOUT (167) | Serial Interface Control OUT |
| SICMOUT (111 167) | Serial Interface Control Multiple OUT |
| SIOUT (062 167) | Serial Interface OUT |
| SIMOUT (113 167) | Serial Interface Multiple OUT |

SIMODIN (161) Serial Interface MODem IN

| | | | | | | | | |
|---|---|---|---|---|---|---|---|-------------------------------|
| 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 | |
| | | | | | | | | |
| | | | | | | | | \$ |
| | | | | | | | | Clear to Send |
| | | | | | | | | Data Set Ready |
| | | | | | | | | Received Line Signal Detector |
| | | | | | | | | Ring Indicator |
| | | | | | | | | \$ |

SIMODOUT (062 161) Serial Interface MODem OUT

| | | | | | | | | |
|---|---|---|---|---|---|---|---|----------------------|
| 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 | |
| | | | | | | | | |
| | | | | | | | | Request to Send |
| | | | | | | | | Data Terminal Ready |
| | | | | | | | | \$ |
| | | | | | | | | New Sync/Rate Select |
| | | | | | | | | Break/Spare |
| | | | | | | | | \$ |

SIACUIN (111 161) Serial Interface ACU IN

| | | | | | | | | |
|---|---|---|---|---|---|---|---|---|
| 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 | |
| | | | | | | | | |
| | | | | | | | | Present Next Digit/Secondary Signal Detect |
| | | | | | | | | Data Line Occupied/Secondary Clear to Send |
| | | | | | | | | Call Origination Status/Secondary Received Data |
| | | | | | | | | Abandon Call and Retry/Signal Quality Detector |
| | | | | | | | | Power indication |
| | | | | | | | | Spare |
| | | | | | | | | \$ |

SIACUOUT (113 161) Serial Interface ACU OUT

| | | | | | | | | |
|---|---|---|---|---|---|---|---|--|
| 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 | |
| | | | | | | | | |
| | | | | | | | | Digit 1 |
| | | | | | | | | Digit 2 |
| | | | | | | | | Digit 4 |
| | | | | | | | | Digit 8 |
| | | | | | | | | Digit Present/Secondary Transmitted Data |
| | | | | | | | | Call Request/Secondary Request to Send |
| | | | | | | | | \$ |

Quick Reference Guide for Processors and Peripherals

2200 Machine Instructions (SNAP)

| Function | Operation Code | Description |
|------------|----------------|--------------------------------|
| Lrd (exp) | 0nd6,vvv | Load immediate |
| Lrdrs | 3ndns | Load |
| AD (exp) | 004,vvv | Add immediate |
| ADrs | 20ns | Add |
| AC (exp) | 014,vvv | Add with carry immediate |
| ACrs | 21ns | Add with carry |
| SU (exp) | 024,vvv | Subtract immediate |
| SURs | 22ns | Subtract |
| SB (exp) | 034,vvv | Subtract with borrow immediate |
| SBRs | 23ns | Subtract with borrow |
| ND (exp) | 044,vvv | And immediate |
| NDrs | 24ns | And |
| OR (exp) | 064,vvv | Or immediate |
| ORrs | 26ns | Or |
| XR (exp) | 054,vvv | Exclusive - or immediate |
| XRRs | 25ns | Exclusive - or |
| CP (exp) | 074,vvv | Compare immediate |
| CPrs | 27ns | Compare |
| SRC | 012 | Shift right circular |
| SLC | 002 | Shift left circular |
| JMP (adr) | 104,lsb,msb | Unconditional jump |
| JTc (adr) | 1p0,lsb,msb | Jump on true flag |
| JFc (adr) | 1m0,lsb,msb | Jump on false flag |
| CALL (adr) | 106,lsb,msb | Unconditional call |
| CTc (adr) | 1p2,lsb,msb | Call on true flag |
| CFc (adr) | 1m2,lsb,msb | Call on false flag |
| RET | 007 | Unconditional return |
| RTc | 0p3 | Return on true flag |
| RFc | 0m3 | Return on false flag |
| BETA* | 020 | Register and F/F mode swap |
| ALPHA* | 030 | Register and F/F mode swap |
| PUSH* | 070 | Address onto stack |
| POP* | 060 | Address from stack |
| DI* | 040 | Disable interrupt |
| EI* | 050 | Enable interrupt |
| NOP | 300 | No operation |
| HALT | 377 | Halt |
| INPUT | 101 | Input |
| EX | See tables | External command |

rs=source register
 rd=destination register
 (exp)=one-byte expression
 (adr)=two-byte address
 c=condition flag
 nd,ns=register reference number
 vvv=expression value
 lsb=least significant byte of address
 msb=most significant byte of address

*Version II 2200 only
 1. Add 1.6 usec if memory reference
 2. Add 1.6 usec if transfer occurs
 p,m=condition code reference

Quick Reference Guide for Processors and Peripherals

Register Reference Table

| <u>r</u> | <u>n</u> |
|----------|----------|
| A | 0 |
| B | 1 |
| C | 2 |
| D | 3 |
| E | 4 |
| H | 5 |
| L | 6 |
| X* | 7 |
| M | 7 |

*5500 only

M=memory reference. Memory location specified by HL* (or currently selected register pair).

Condition (Flip-flop) Code Reference Table

| <u>C</u> | <u>m</u> | <u>p</u> |
|-----------------------|----------|----------|
| C (Carry) | 0 | 4 |
| Z (Zero) | 1 | 5 |
| S (Sign) | 2 | 6 |
| P (Parity) | 3 | 7 |
| (true= odd parity) | | |

Register Codes (5500 only)

| <u>r</u> | [r] (register select opcode) | [pr] (register select for paged instructions) |
|----------|------------------------------------|---|
| A | no code (implicit) | 105 |
| B | 111 | 114 |
| C | 062 | 124 |
| D | 113 | 134 |
| E | 174 | 144 |
| H | 115 | 154 |
| L | 176 | 164 |
| X | 117 | no code (cannot be used) |

Register Pair Codes (5500 only)

| <u>rp</u> | [rp] - <u>register pair select code</u> |
|-----------|---|
| HL | 176 (implicit) |
| BC | 062 |
| DE | 174 |
| XA | 022 |

Quick Reference Guide for Processors and Peripherals

5500 Machine Instructions (SNAP/3)

| Function | Operation Code | Description |
|-------------|--------------------------------|---|
| L(rd)M | | |
| L(rd)M (rp) | [rp],3n _d 7 | Load register from memory, memory address in rp |
| LM(rs) | | |
| LM(rs) (rp) | [rp],37n _s | Load memory from register memory address in rp |
| L(rd) (rs) | 3n _d n _s | Load |
| L(r)data | 0nd6,vvv | Load immediate |
| AD(rs) | 20ns | Add |
| AC(rs) | 21ns | Add with carry |
| SU(rs) | 22ns | Subtract |
| SB(rs) | 23ns | Subtract with borrow |
| ND(rs) | 24ns | And |
| XR(rs) | 25ns | Exclusive Or |
| OR(rs) | 26ns | Or |
| CP(rs) | 27ns | Compare |
| AD(rs) (rd) | | |
| AC(rs) (rd) | | |
| SU(rs) (rd) | | |
| SB(rs) (rd) | | |
| ND(rs) (rd) | | |
| XR(rs) (rd) | | |
| OR(rs) (rd) | | |
| CP(rs) (rd) | | |
| ADM | | |
| ACM | | |
| SUM | | |
| SBM | | |
| NDM | | |
| XRM | | |
| ORM | | |
| CPM | | |
| ADM(rd) | | |
| ACM(rd) | | |
| SUM(rd) | | |
| SBM(rd) | | |
| NDM(rd) | | |
| XRM(rd) | | |
| ORM(rd) | | |
| CPM(rd) | | |
| AD data | 004,vvv | Add immediate |
| AC data | 014,vvv | Add with carry immediate |
| SU data | 024,vvv | Subtract immediate |
| SB data | 034,vvv | Subtract with borrow immediate |
| ND data | 044,vvv | And immediate |

Quick Reference Guide for Processors and Peripherals

| Function | Operation Code | Description |
|---------------------|----------------|--|
| XR data | 054,vvv | Exclusive or immediate |
| OR data | 064,vvv | Or immediate |
| CP data | 074,vvv | Compare immediate |
| AD(r) data | | |
| AC(r) data | | |
| SU(r) data | | |
| SB(r) data | | |
| ND(r) data | | |
| XR(r) data | | |
| OR(r) data | | |
| CP(r) data | | |
| SLC | 002 | Shift left circular |
| SRC | 012 | Shift right circular |
| SRE | 032 | Shift right extended |
| SLC(r) | [rd],002 | Shift left circular, other than A reg. |
| SRC(r) | [rd],012 | Shift right circular, other than A reg. |
| SRE(r) | [rd],032 | Shift right extended, other than A reg. |
| JMP loc | 104,lsb,msb | Unconditional jump |
| Jcc loc | | |
| Jcc loc (fall thru) | | |
| EJMP loc | | |
| NOJ loc | 045 | NOP jump, skip next two bytes |
| NOP | 300 | No operation |
| CALL loc | 106,lsb,msb | Unconditional call |
| Ccc loc | | |
| Ccc loc (fall thru) | | |
| RET | 007 | Unconditional return |
| Rcc | | |
| Rcc (fall thru) | | |
| UR | | |
| EUR | | |
| IN | | |
| IN(r) | | |
| PIN | 103 | Input w/parity testing |
| PIN(rd) | [rd],103 | Input w/parity testing, to other than A register |
| EX ADR | | |
| EX(r)ADR | | |
| EX (exp) | | |
| EX(r) (exp) | | |
| EX STATUS | | |
| EX(r)STATUS | | |
| EX DATA | | |
| EX(r) DATA | | |
| EX WRITE | | |

Quick Reference Guide for Processors and Peripherals

| Function | Operation Code | Description |
|------------------|----------------|--|
| EX(r)WRITE | | |
| EX COM1 | | |
| EX(r)COM1 | | |
| EX COM2 & 3 | | |
| EX(r) COM2 & 3 | | |
| EX COM4 | | |
| EX(r) COM4 | | |
| MIN | 111,061 | Multiple In, DMA-type command. I/O device to memory starting at HL. |
| MOUT | 111,071 | Multiple Out, DMA-type command. I/O device from memory starting at HL. |
| BETA | 020 | Register and F/F Mode Swap |
| BETA (in Beta) | | |
| ALPHA | 030 | Register and F/F Mode Swap |
| ALPHA (in Alpha) | | |
| DI | 040 | Disable Interrupt |
| EI | 050 | Enable Interrupt |
| POP | 060 | Address from Stack |
| POP (rp) | [rp],060 | Address from stack, into rp |
| PUSH | 070 | Address onto Stack |
| PUSH (rp) | [rp],070 | Address onto stack, from rp |
| PUSH loc | | |
| BT (B=0) | 021 | Block transfer |
| BT (B≠0) | | |
| BTR (B=0) | 111,021 | Block transfer reverse |
| BTR (B≠0) | | |
| BCV (B=0) | | |
| BCV (B≠0) | | |
| BCP (B=0) | 041 | Block Compare |
| BCP (B≠0) | | |
| BFAC | 011 | Binary field add with carry |
| BFSB | 031 | Binary field subtract with borrow |
| DFAC | 111,041 | Decimal field add with carry |
| DFSB | 062,041 | Decimal field subtract with borrow |
| BFSL | 075 | Binary field shift left |
| BFSR | 111,075 | Binary field shift right |
| STKS | 065 | Stack store, save stack in memory |
| STKL | 111,065 | Stack load, restore stack from memory |
| REGS | 055 | Register store, save registers in memory, descending from top of stack address |
| REGL | 111,055 | Register load, restore registers from memory, descending from address in HL |
| CCS | | |
| CCS. (rd) | [rd],042 | Condition code save in rd, add rd to itself to restore conditions |
| | | Increment Register Pair Instructions |

Quick Reference Guide for Processors and Peripherals

| Function | Operation Code | Description |
|---|-------------------------|--|
| INCP HL | 015 | HL by 1 |
| INCP HL,A | 017 | HL by contents of A |
| INCP (rp) | | |
| INCP (rp),2 | | |
| INCP (rp),A | | |
| INCP XA | 022,015 | XA by 1 |
| INCP XA,2 | 111,015 | XA by 2 |
| INCP XA,A | 022,017 | XA by contents of A |
| Decrement Register Pair Instructions | | |
| DECP HL | 035 | HL by 1 |
| DECP HL,A | 037 | HL by contents of A |
| DECP (rp) | | |
| DECP (rp),2 | | |
| DECP (rp),A | | |
| DECP XA | 022,035 | XA by 1 |
| DECP XA,2 | 111,035 | XA by 2 |
| DECP XA,A | 022,037 | XA by A |
| DL DE,HL | 047 | |
| DL BC,HL | 111,047 | |
| DL BC,BC | 062,047 | |
| DL BC,DE | 113,047 | |
| DL DE,BC | 174,047 | |
| DL DE,DE | 115,047 | |
| DL HL,BC | 176,047 | |
| DL HL,DE | 117,047 | |
| DL HL,HL | 057 | |
| DS DE,HL | 027 | |
| DS BC,HL | 111,027 | |
| DS BC,DE | 113,027 | |
| DS DE,BC | 174,027 | |
| DS HL,BC | 176,027 | |
| DS HL,DE | 117,027 | |
| PL (r),loc | | |
| PS (r),loc | | |
| DPL (rp),loc | | |
| DPS (rp),loc | | |
| INCI(dsp),005,lsb,[i] (idx) | | Increment index by lsb of (dsp) |
| DECI(dsp), (idx) | 025,lsb,[i] | Decrement index by lsb of (dsp) |
| INCI*(dsp), (idx) | 111,005,lsb, msb,[i] | Increment index by msb,lsb of (dsp) |
| DECI*(dsp), (idx) | 111,025,lsb, msb,[i] | Decrement index by msb,lsb of (dsp) |
| LFII(rp), | [rp],005,lsb, | Load from index incremented, add lsb of (dsp) to |

Quick Reference Guide for Processors and Peripherals

| Function | Operation Code | Description |
|--------------------------|---------------------------|--|
| (dsp), (idx) | [i] | index value and save result in rp (does not modify value in index) |
| LFID(rp), (dsp), (idx) | [rp], 005, lsb, [i] | Load from index decremented, subtract lsb from index and save result in rp (does not modify value in index). |
| LFII(rp), * (dsp), (idx) | [srp], 005, lsb, msb, [i] | Load from index incremented, same as LFII above, but using msb, lsb of (dsp) |
| LFID(rp), * (dsp), (idx) | [srp], 025, lsb, msb, [i] | Load from index decremented, same as LFID above, but using msb, lsb of (dsp). |
| BRL | | |
| BRL(r) | | |
| STL | 077 | Sector table load |
| SC | 067 | System Call, call 0167452 |
| BP | 052 | Break Point, call 0167460 (DEBUG) |
| HALT | 377 | Halt |
| HALT (user mode) | | |
| QQQQ (undefined) | | |
| QQQQ(r) | | |
| EX BEEP | | See external command tables |
| EX BEEP (in progress) | | |
| EX CLICK | | |
| EX CLICK (in progress) | | |
| Sync (010) | | |
| DPLR | | |
| DPSR | | |
| STLor | | |
| INFO | | |
| INFO2 | 062, 010 | |
| INFO3 | 113, 010 | |
| INFO4 | 174, 010 | |
| INFO5 | 115, 010 | |
| INFO6 | 176, 010 | |
| INFO7 | 117, 010 | |
| INFO8 | 022, 010 | |
| | | System Status Information |
| SYSTAT1 | 111, 157 | |
| SYSTAT2 | 062, 157 | |
| SYSTAT3 | 113, 157 | |
| SYSTAT4 | 174, 157 | |
| SYSTAT5 | 115, 157 | |
| SYSTAT6 | 176, 157 | |
| SYSTAT7 | 117, 157 | |
| SYSTAT8 | 022, 157 | |
| LODCF | 155 | Load character font |
| ACDO | rp 151 | Perform audio |

Quick Reference Guide for Processors and Peripherals

| Function | Operation Code | Description |
|------------------|----------------|----------------------------------|
| ACDOO | rp 153 | Perform audio override |
| ACCGP | | |
| SYSSAV | 062,020 | |
| ALPHAL | 111,030 | Alpha & beta, save & load |
| sub-instructions | | |
| BETAL | 111,020 | |
| SYSRET | 062,030 | System return |
| SYSMOV | rp,065 | System save area move |
| SYSMOV BC | 062,065 | |
| SYSMOV DE | 174,065 | |
| SYSMOV HL | 176,065 | |
| SYSMOV XA | 022,065 | |
| DMPIN(141) | | |
| DMPSIN(143) | | |
| DMPOUT(145) | | |
| DMPROUT(147) | | |
| BLKOUT(173) | | |
| BLKIN(177) | | |
| | 1800 only | |
| UBOUT | 0145 | Output to device using Strobe 1 |
| UBIN | 0111 0145 | Input from device using Strobe 1 |
| UBOUT2 | 0062 0145 | Output to device using Strobe 2 |
| UBIN2 | 0113 0145 | Input from device using Strobe 2 |

rs=source register

rd=destination register

(exp)=one-byte expression

(adr)=two-byte address

c=condition flag

nd,ns=register reference number

vvv=expression value

lsb=least significant byte of address

msb=most significant byte of address

rp=register pair

[rp]=register pair select code

[r]=register select code

(op)=arithmetic or logical operator: AD, AC, SU, SB, ND, OR, XR, CP

[pr]=register select code for paged instructions

(i)=expression for lsb of index address

(dsp)=expression for displacement of index instructions

[i]=lsb value of (i)

[srp]=special register pair select code for index instructions

BC=113

DE=115

HL=117

Quick Reference Guide for Processors and Peripherals

6600, 8600 Machine Instructions

| Function | Operation Code | Description |
|-----------------|-------------------|---|
| BFLR(op) | | Binary field left to right operations |
| BFLRAD | 111 006 | |
| BFLRAC | 111 016 | |
| BFLRSU | 111 026 | |
| BFLRSB | 111 036 | |
| BFLRND | 111 046 | |
| BFLRXR | 111 056 | |
| BFLROR | 111 066 | |
| D(op)M(rp) | | Double memory to register operations |
| DADM(rp) | [rp] 013 | |
| DACM(rp) | [rp] 310 | |
| DSUM(rp) | [rp] 033 | |
| DSBM(rp) | [rp] 330 | |
| DNDM(rp) | [rp] 043 | |
| DXRM(rp) | [rp] 053 | |
| DORM(rp) | [rp] 063 | |
| DCPM(rp) | [rp] 073 | |
| DPLR(rp),loc | | Double paged load reversed |
| DPLR BC,loc | 062 114 LSP | |
| DPLR DE,loc | 174 134 LSP | |
| DPLR HL,loc | 176 154 LSP | |
| DPSR(rp),loc | | Double paged store reversed |
| DPSR BC,loc | 062 116 LSP | |
| DPSR DE,loc | 174 136 LSP | |
| DPSR HL,loc | 176 156 LSP | |
| STLO(r) | | Sector table load starting at offset |
| STLOA | 022 077 | |
| STLOB | 111 077 | |
| STLOC | 062 077 | |
| STLOD | 113 077 | |
| STLOE | 174 077 | |
| INFO | 111010 | System information |
| D(op)P(rp),loc | | Double paged to register operations |
| DADP(rp),loc | [rp+1] 013 LOCLSB | |
| DACP(rp),loc | [rp+1] 310 LOCLSB | |
| DSUP(rp),loc | [rp+1] 033 LOCLSB | |
| DSBP(rp),loc | [rp+1] 330 LOCLSB | |
| DNDP(rp),loc | [rp+1] 043 LOCLSB | |
| DXRP(rp),loc | [rp+1] 053 LOCLSB | |
| DORP(rp),loc | [rp+1] 063 LOCLSB | |
| DCPP(rp),loc | [rp+1] 073 LOCLSB | |
| D(op)I(rp),data | | Double immediate to register operations |
| DADI(rp),data | [rp]110 LSB MSB | |

Quick Reference Guide for Processors and Peripherals

| Function | Operation Code | Description |
|----------------------|----------------|--------------------------------------|
| DACI(rp),data | [rp]311 | LSB MSB |
| DSUI(rp),data | [rp]130 | LSB MSB |
| DSBI(rp),data | [rp]331 | LSB MSB |
| DNDI(rp),data | [rp]140 | LSB MSB |
| DXRI(rp),data | [rp]150 | LSB MSB |
| DORI(rp),data | [rp]160 | LSB MSB |
| DCPI(rp),data | [rp]170 | LSB MSB |
| DM(op)(rp) | | Double register to memory operations |
| DMAD(rp) | [rp+1] 110 | |
| DMAC(rp) | [rp+1] 311 | |
| DMSU(rp) | [rp+1] 130 | |
| DMSB(rp) | [rp+1] 331 | |
| DMND(rp) | [rp+1] 140 | |
| DMXR(rp) | [rp+1] 150 | |
| DMOR(rp) | [rp+1] 160 | |
| P(op)(r),loc | | Single paged to register operations |
| PAD(r),loc | [r] 106 | LOCLSB |
| PAC(r),loc | [r] 112 | LOCLSB |
| PSU(r),loc | [r] 122 | LOCLSB |
| PSB(r),loc | [r] 132 | LOCLSB |
| PND(r),loc | [r] 142 | LOCLSB |
| PXR(r),loc | [r] 152 | LOCLSB |
| POR(r),loc | [r] 162 | LOCLSB |
| PCP(r),loc | [r] 172 | LOCLSB |
| COMP(rp) | | 2's complement a register pair |
| COMP BC | 062 011 | |
| COMP DE | 174 011 | |
| COMP HL | 176 011 | |
| COMPS(rp) | | 2's complement a register pair |
| COMPS BC | 113 011 | |
| COMPS DE | 115 011 | |
| COMPS HL | 117 011 | |
| IMULT | 111 011 | Integer multiply: HLDE=HL*BC |
| IDIV | 062 031 | Integer divide: DE/BC=>Q(DE),R(HL) |
| DIDIV | 111 031 | Double integer divide: |
| HLDE/BC=>Q(DE),R(HL) | | |
| LLDEL | 111 051 | Doubly linked list delete |
| LLINS | 062 051 | Doubly linked list insert |

Quick Reference Guide for Processors and Peripherals

8800 Machine Instructions

| Function | Operation Code | Description |
|---------------|----------------|---|
| L(r) | 0d6(vvv) | Load immediate |
| L(rd)M | 3d7 | Load |
| L(rd)(rs) | 3ds | Load |
| LM(rs) | 37s | Load |
| L(rd)M(rp) | | Load register from memory using BC, DE, or XA for address |
| LM(rs)(rp) | rp37s | Load register from memory using BC, DE, or XA for address |
| PL | | Paged load |
| PL A, (loc) | 105 LSP | |
| PL B, (loc) | 114 LSP | |
| PL C, (loc) | 124 LSP | |
| PL D, (loc) | 134 LSP | |
| PL E, (loc) | 144 LSP | |
| PL H, (loc) | 154 LSP | |
| PL L, (loc) | 164 LSP | |
| PS | | Paged store |
| PS A, (loc) | 107 LSP | |
| PS B, (loc) | 116 LSP | |
| PS C, (loc) | 126 LSP | |
| PS D, (loc) | 136 LSP | |
| PS E, (loc) | 146 LSP | |
| PS H, (loc) | 156 LSP | |
| PS L, (loc) | 166 LSP | |
| DL | | Double load |
| DL DE,HL | 047 | |
| DL BC,HL | 111 047 | |
| DL BC,BC | 062 047 | |
| DL BC,DE | 113 047 | |
| DL DE,BC | 174 047 | |
| DL DE,DE | 115 047 | |
| DL HL,BC | 176 047 | |
| DL HL,DE | 117 047 | |
| DL HL,HL | 057 | |
| DS | | Double store |
| DS DE,HL | 027 | |
| DS BC,HL | 111 027 | |
| DS BC,DE | 113 027 | |
| DS DE,BC | 174 027 | |
| DS HL,BC | 176 027 | |
| DS HL,DE | 117 027 | |
| DPL | | Double paged load |
| DPL BC, (loc) | 111 124 LSP | |
| DPL DE, (loc) | 113 144 LSP | |
| DPL HL, (loc) | 115 164 LSP | |

Quick Reference Guide for Processors and Peripherals

| Function | Operation Code | Description |
|----------------|----------------|--------------------------------|
| DPS BC, (loc) | 111 126 LSP | Double paged store |
| DPS DE, (loc) | 113 146 LSP | |
| DPS HL, (loc) | 115 166 LSP | |
| DPLR(rp), loc | | Double paged load reversed |
| DPLR BC, loc | 062 114 LSP | |
| DPLR DE, loc | 174 134 LSP | |
| DPLR HL, loc | 176 154 LSP | |
| DPSR(rp), loc | | Double paged store reversed |
| DPSR BC, loc | 062 116 LSP | |
| DPSR DE, loc | 174 136 LSP | |
| DPSR HL, loc | 176 156 LSP | |
| REGS | 055 | Register store |
| REGL | 111 055 | Register load |
| POP | 060 | Pop |
| PUSH | 070 | Push |
| PUSH(rp) | rp 070 | Push using BC, DE, or XA |
| PUSH loc | 051 (adr) | Push immediate |
| POP(rp) | rp 060 | Push using BC, DE, or XA |
| STKS | 065 | Stack store |
| STKL | 111 065 | Stack load |
| AD data | 004 (vvv) | Add immediate |
| AD(rs), ADM | 20s, 207 | Add |
| AC data | 014 | Add with carry immediate |
| AC(rs), ACM | 21s, 217 | Add |
| SU data | 024 | Subtract immediate |
| SU(rs), SUM | 22s, 227 | Subtract |
| SB data | 034 | Subtract with borrow immediate |
| SB(rs), SBM | 23s, 237 | Subtract with borrow |
| ND data | 044 (vvv) | And immediate |
| ND(rs), NDM | 24s, 247 | And |
| OR data | 064 (vvv) | Or immediate |
| OR(rs), ORM | 26s, 267 | Or |
| XR data | 054 (vvv) | Exclusive or immediate |
| XR(rs), XRM | 25s, 257 | Exclusive or |
| CP data | 074 (vvv) | Compare immediate |
| CP(rs), CPM | 27s, 277 | Compare |
| SRC | 002 | Shift right circular |
| SRE | 032 | Shift right extended |
| (op) (rs) (r) | r2ps | ADAB adds A to B |
| (op)M(r) | r0p> | ADM6 adds (HL) to C |
| (op) (r) (vvv) | r0p4 | SVC 20 subtracts 20 from C |
| SRC(r) | r012 | SRCB shifts B to right |
| SLC(r) | r002 | SLCD shifts D to left |
| SRE(r) | | SRED shifts D to right |

Quick Reference Guide for Processors and Peripherals

| Function | Operation Code | Description |
|----------------|----------------|--------------------------------------|
| P(op)(r),loc | | Single paged to register operation |
| PAD(r),loc | [r]106 | LOCLSB |
| PAC(r),loc | [r]112 | LOCLSB |
| PSU(r),loc | [r]122 | LOCLSB |
| PSB(r),loc | [r]132 | LOCLSB |
| PND(r),loc | [r]142 | LOCLSB |
| PXR(r),loc | [r]152 | LOCLSB |
| POR(r),loc | [r]162 | LOCLSB |
| PCP(r),loc | [r]172 | LOCLSB |
| | | |
| INCP | | Increment register pair |
| INCP HL | 015 | |
| INCP HL,2 | 117 015 | |
| INCP HL,A | 017 | |
| INCP BC | 062 015 | |
| INCP BC,2 | 113 015 | |
| INCP BC,A | 062 017 | |
| INCP DE | 174 015 | |
| INCP DE,2 | 115 015 | |
| INCP DE,A | 174 017 | |
| INCP XA | 022 015 | |
| INCP XA,2 | 111 015 | |
| INCP XA,A | 022 017 | |
| | | |
| DECP | | Decrement register pair |
| DECP HL | 035 | |
| DECP HL,2 | 117 035 | |
| DECP HL,A | 037 | |
| DECP BC | 062 035 | |
| DECP BC,2 | 113 035 | |
| DECP BC,A | 062 037 | |
| DECP DE | 174 035 | |
| DECP DE,2 | 115 035 | |
| DECP DE,A | 174 037 | |
| DECP XA | 022 035 | |
| DECP XA,2 | 111 035 | |
| DECP XA,A | 022 037 | |
| | | |
| D(op)M(rp) | | Double memory to register operations |
| DADM(rp) | [rp] 013 | |
| DACM(rp) | [rp] 310 | |
| DSUM(rp) | [rp] 033 | |
| DSBM(rp) | [rp] 330 | |
| DNDM(rp) | [rp] 043 | |
| DXRM(rp) | [rp] 053 | |
| DORM(rp) | [rp] 063 | |
| DCPM(rp) | [rp] 073 | |
| | | |
| D(op)P(rp),loc | | Double paged to register operations |
| DADP(rp),loc | [rp+1] 013 | LOCLSB |
| DACP(rp),loc | [rp+1] 310 | LOCLSB |

Quick Reference Guide for Processors and Peripherals

| Function | Operation Code | Description |
|--------------|----------------|-------------|
| DSUP(rp),loc | [rp+1] 033 | LOCLSB |
| DSBP(rp),loc | [rp+1] 330 | LOCLSB |
| DNDP(rp),loc | [rp+1] 043 | LOCLSB |
| DXRP(rp),loc | [rp+1] 053 | LOCLSB |
| DORP(rp),loc | [rp+1] 063 | LOCLSB |
| DCPP(rp),loc | [rp+1] 073 | LOCLSB |

Assembler Directives--SNAP

| | | |
|------------|---------|---|
| (L) EQU | (e) | Set value of label to (e) |
| SET | (e) | Set and use ABSOLUTE PAB (ASSEMBLER 4: set LC) |
| SKIP | (e) | Increment AC and LC by (e) |
| TP | | Tabulate AC and LC to next page boundary |
| TM | (e) | Tabulate page if less than (e) bytes in present page |
| DC | (e) | Generate 1-byte values for expressions (1 byte per character for string expressions) |
| DA | (e) | Generate 2-byte values for expressions |
| RPT | (e) | Repeat next line of code (e) times |
| END | (e) | End assembly pass; (e) is program transfer address |
| LIST | (e) | Set assembly listing control flags (L, F, G, I, M) |
| . | | Comment line (. in first column) |
| + | | Form feed, then print comment line |
| * | | Form feed if within 2" of end of page (comment line) |
| INC | (e) | Include source file named by (e) |
| LOC | (e),exp | Set LC to (e) and turn L flag on (exp not normally necessary) |
| LOC | *,exp | Set LC to AC and turn L flag off (exp not normally necessary) |
| (L) ORG | (e),flg | Set first and current word address of a new PAB named (L) (flags are T, P, C) |
| USE | (e) | Use PAB (e), set AC to current word address of PAB |
| USE | * | Revert to use of last PAB used |
| ERR | | Produce a P error |
| IFnn | (e) | Turn assembly off, if condition "nn" is not met. Condition test compares first field of expression to second field. If second field not given, assume \emptyset |
| | | Conditions: |
| | | EQ - equal |
| | | GT - greater than |
| | | LT - less than |
| | | NE - not equal |
| | | GE - greater than or equal |
| | | LE - less than or equal |
| | | Z - field 1 zero |
| | | NZ - field 1 not zero |
| | | C - field 1 zero (clear) |
| | | S - field 1 not zero (set) |
| | | STR - field 1 begins with * |
| | | NSTR - no * in field 1 |
| XIF | | Turn assembly back on if it has been turned off |
| TITLE | | Page effect and print following line as title |
| MLIB | (e) | Include macro library (e) |
| MACRO | | Macro definition follows |
| MEND | | End of macro definition |
| ALIGN | (e) | Increment AC and LC to next memory location that is a multiple of (e) [(e)=2 ⁿ] |
| (L) PROG | | Label is name for following program module |
| SNAPOPT | | 4, 2, 6, X, R |
| TESTnnexp, | (exp) | Pass 2 relation test |

Quick Reference Guide for Processors and Peripherals

AC=Address counter
LC=Location counter
(L)=Label required
(e)=expression (allowed or required)

Labels--SNAP/3

Labels consist only of alphanumeric characters and \$. A label must begin with an alpha character. Special terminating characters (not part of the label) indicate special qualities for the label.

| Label Length (characters) | Over-length label action | Terminating Character | Characteristic Assigned |
|---------------------------|------------------------------------|-----------------------|--|
| 8 | uses first 7 and last 1 characters | * = | program entry point redefinition external definition |

Expressions

Numeric expressions use 16-bit two's complement values. If the instruction requires only one byte, the msb of the expression is discarded.

Expression evaluation is strictly left to right, all operators having equal precedence. SNAP/3 allows the use of parentheses to modify order of evaluation per normal algebraic convention.

| Binary Operators | | Unary Operators | |
|------------------|-------------------------|-----------------|--|
| + | add | < | shift left number of places indicated by next value |
| - | subtract | > | shift right number of places indicated by next value |
| * | multiply | - | negation |
| / | integer division | * | set star flag |
| .AND. | logical AND | | |
| .OR. | logical OR | | |
| .XOR. | logical exclusive-OR | | |
| .MOD. | remainder from division | | |

Strings can be included in all expressions. A string is delimited by apostrophes. The value of a character in a string is the ASCII value for the character with the parity bit (bit 7) always zero.

Note: Only the DC directive allows strings more than one character long. For this case, one byte of code is generated for each character.

Quick Reference Guide for Processors and Peripherals

Assembler Pseudo-instructions

| Instruction | Expansion | Code |
|-----------------------|--|-----------------------------------|
| HL (e) | LL lsb LH msb | 066 lsb 056 msb |
| DE (e) | LE lsb LD msb | 046 lsb 036 msb |
| BC (e) | LC lsb LB msb | 036 lsb 026 msb |
| XA (e) | | |
| MSr _s (e) | LL lsb LMr _s | 066 lsb 37n _s |
| MSr _s *(e) | LL lsb LH msb LMr _s | 066 lsb 056 msb 37n _s |
| MLr _d (e) | LL lsb Lr _d ^M | 066 lsb 3n _d 7 |
| MLr _d *(e) | LL lsb LH msb Lr _d ^M | 066 lsb 056 msb 3n _d 7 |
| SRN (e) | RPT (e) SRC | 012 012 ((e) times) |
| SLN (e) | RPT (e) SLC | 002 002 ((e) times) |
| CCLr | ADnn | (r)20r |

r_s=source register
 r_d=destination register
 (e)=expression
 lsb=low-order byte of expression value
 msb=high-order byte of expression value
 n=register reference number

Assembly Error Flags--SNAP/3

- D Different definition of labels (pass 1 only, all but first occurrence ignored on pass 2)
- I Instruction mnemonic undefined
- E Expression or label error (unrecognizable character)
- U Undefined label (value of zero assigned)
- F File error, inclusion limits exceeded or END found in included file
- P Programmer produced, ERR instruction encountered
- > Indicates external reference - not an error condition
- O Overflow on page sensitive PAB

MACROS

Macro Definition (Prototype)

```
MACRO
[label] name [symbol[(default)]][,symbol[(default)]]...
.
. code
.
MEND
```

Macro Call

```
[label] name [expression][,expression]...
```

The replacement of symbols by expressions is position-dependent. If no expression is given for a symbol, the default replaces the symbol; if no default is given, the symbol disappears from the expanded code.

Macro names follow the same syntax rules as labels.

[] above encloses optional fields.

Macro Directives

MIFnn Identical to IFnn directive, for use only in macro definitions. (MIFnn compares strings, rather than numeric values.)

MXIF Identical to XIF directive, for use only in macro definitions.

Assembler Execution

```
SNAP/3 source[,object][,ept][,print][,include][;<option characters>]
```

| | |
|------------|--|
| A | Causes an absolute output file to be produced, instead of a relocatable file |
| D | Causes a source and object code listing to be displayed on the CRT; may be specified in addition to the L option. |
| F, G, I, M | Turns on corresponding listing control flags. |
| L | Produces a source and object code listing, which will appear on the local printer if neither the P, Q, nor S option appears. |
| P | Causes the L or X option listing to be to a print file. |
| Q | Same as P option, but specifies that the listing should be appended or queued after any information already in the print file. |
| S | Causes the L or X option listing to be to the local printer. |
| T | Forces a two-pass assembly and must be specified if the resulting relocatable output file is to be loaded by the DOS relocatable loader (DOS function 15). |
| X | Produces a cross-reference, map listing and may appear with or without the L option. |
| 2, 6, U | Turns on the assembly options. |

Quick Reference Guide for Processors and Peripherals

ROM Debug Entry Point Vectors

| | |
|---------|---|
| 0167400 | Memory Parity Failure Vector |
| 0167406 | Input Parity Failure Vector |
| 0167414 | Output Parity Failure Vector |
| 0167422 | Write Protect Violation Vector |
| 0167430 | Access Protect Violation Vector |
| 0167436 | Privileged Instruction Violation Vector |
| 0167444 | One Millisecond Clock Vector |
| 0167452 | User System Call Vector |
| 0167460 | Breakpoint Vector |
| 0167466 | Unassigned Instruction |
| 0167474 | Sector Table Parity Error |

ROM Debug Display Format

| | |
|---------|--|
| AAAAAA | CURADR (The current address in octal) |
| X NNN | ASCII, 8-bit octal C (CURADR) |
| MMMMMM | 16-bit (LSB, MSB) address formed at CURADR, CURADR + 1 |
| nnnnnnn | Command entry position |

Quick Reference Guide for Processors and Peripherals

6600 ROM Debug Command Summary

| | | |
|------------|-----|---|
| nnn | A | Address the (n) or current I/O device |
| nnn nnn | B | Set a breakpoint to the (n) or current address |
| nnn nnn | C | Call the (n) or current address |
| nnn nnn | D | Decrement the current address by (n) or 1 |
| (nnn nnn) | E | Continue execution or replace top stack location with (n) and continue execution |
| nnn | F | Fetch next data byte from (n) or current device |
| nnn | G | Go to Data mode in (n) or current device on "E", "U", or "i" command |
| n | H | RIM buffer test for RIM number n, where n is from 1 to 6 |
| (nnn) nnn | I | Increment the current address by (n) or current device on "E", "U" or "i" command |
| nnn nnn | J | Jump to given (n) or current address |
| 12345 | K | Set ASCII key-in mode |
| | L | Link to address pointed to by current address |
| (nnn) nnn | M | Modify the contents of the current address |
| nnnnnn | N | Set physical address to nnnnnn |
| nn | O | Select Origin entry table |
| [*](ENTER) | | Set Origin addressing to entry value and display |
| [*](nnn) | | Set Origin addressing to (n), enter in table and display |
| (nnn) nnn | P | Load Base register with (nnnnnn-01000000)>8 |
| 12345 | Q | Load the sector table |
| | R | Switch ALPH/BETA mode and display |
| nn | S | Display the (nth) stack location item |
| 12345 | T | Start the primary 6600 memory test |
| nnn nnnn | U | Continue execution as in "E" command but in USER mode (Interrupts enabled.) |
| nnn | V | EX COM4 Device must be addressed for I/O commands |
| nn | W | EX WRITE status is displayed after command issue |
| nnn | X | EX COM1 (nnn) is the output byte |
| nnn | Y | EX COM2 |
| nnn | Z | EX COM3 |
| ? | | Displays processor version, Micro-Code and Macro-Code revision levels |
| nnn | x | Display x register or modify to nnn |
| (nnn) nnn | a | A Modify register pair if |
| nnn | b | B argument exceeds eight bits |
| (nnn) nnn | c | C |
| nnn | d | D The LSB register specifies |
| (nnn) nnn | e | E the pair (i.e., L for H & L) |
| nnn | h | H |
| (nnn) nnn | l | L |
| nnn | f | Displays or updates the condition flags |
| nnn nnn | i | Same as 'E' above with interrupts enabled |
| nnn nnn | r | PUSH value (nnn nnn) onto stack |
| nn | s | POP stack (nn) times |
| nnn | p | Load base register direct with value (nnn) |
| 12345 | t | Alternate memory test |
| nnn | y | EX DATA (nnn) on output bus |
| nnn | z | EX STATUS (nnn) on output bus |
| nnnnnn | ENT | Set logical address to 'nnnnnn' |
| CAN | | Cancel entry line |

Quick Reference Guide for Processors and Peripherals

| | |
|-------------|--|
| BKSP | Backspace one on entry line |
| (nnn) nnn. | Modify and increment |
| nnn (nnn) ^ | Modify and increment using the last non-null value |

Quick Reference Guide for Processors and Peripherals

1800, 3800 ROM Debug Command Summary

| | |
|----|--|
| A | Address given or last I/O device |
| B | Set breakpoint at given or current address |
| C | Call the given or current address (forces system mode) |
| D | Decrement the current address |
| E | Continue execution of program |
| F | Fetch next data byte from current I/O device |
| G | Go to data mode in the current device |
| *H | Hardware floppy diagnostic/3800 RIM buffer test |
| I | Increment current address |
| J | Jump to the given or current address |
| L | Link to address pointed to by current address |
| M | Modify the current address contents |
| P | Display base register or load W/value - 0100000 |
| *Q | Load the sector table |
| R | Switch Alpha/Beta register mode |
| S | Display specified stack item |
| *T | Start memory test |
| U | Sets user mode and does an 'E' command |
| V | EX COM4 to last I/O device |
| W | EX WRITE to last I/O device |
| X | EX COM1 to last I/O device |
| Y | EX COM2 to last I/O device |
| Z | EX COM3 to last I/O device |
| a | A register display or set |
| b | B register display or set |
| c | C register display or set |
| d | D register display or set |
| e | E register display or set |
| f | Condition flags display |
| h | H register display or set |
| i | 'E' command with EI/RET |
| j | Display test |
| l | L register display or set |
| p | Display base register or set with C |
| x | Register display |
| y | EX STATUS |
| z | EX DATA |
| ? | Processor and Macro ROM type/version |
| . | 'M' command followed by 'I' command |
| ~ | '.' using last value |
| # | Clear all break points |

*Must be preceded by '12345' except 3800 RIM Buffer Test. Then the "H" must be preceded by the RIM number under test. (See device address assignments.)

Quick Reference Guide for Processors and Peripherals

1550 ROM Debug Command Summary

| | | |
|-----------|---------|--|
| n | A | Align diskette head |
| nnn nnn | B | Set breakpoint at given or current address |
| nnn nnn | C | Call given or current address |
| nnn nnn | D | Decrement current address |
| | E | Continue execution |
| nnn | F | Fill screen with given octal value |
| | G | Display general communications channel status |
| | H | SIO loopback test |
| nnn nnn | I | Increment given or current address |
| nnn nnn | J | Jump to given address |
| | K | Keyin on top line of screen |
| nnn | L | Link to given address or the address pointed to by the current address |
| (nnn) nnn | M | Modify contents of the location pointed to by the current address |
| | N | Set the current address to that of a two-byte area containing the # assigned to the interrupted task |
| 123450 | | Initiate a loopback test |
| | P | Display printer channel status |
| 12345 | R | System reset |
| nnn | S | Display specified stack item |
| 12345 | T | Start memory test |
| n | V | Diskette verification |
| n | X | Start continuous diskette controller buffer test |
| n | Z | Diskette track 0 sensor alignment |
| (nnn) nnn | . | 'M' command followed by 'I' |
| | < | Input a character from the channel last selected by a P/G or p/g command |
| nnn | > | Output a character from the channel last selected by a P/G or p/g command to data port last selected |
| | ? | Identify firmware version number |
| nnn nnn | <enter> | Change current address |
| | # | Clear breakpoint |
| (nnn) nnn | a | Display/modify contents of A register |
| nnn | b | Display/modify contents of B register |
| (nnn) nnn | c | Display/modify contents of C register |
| nnn | d | Display/modify contents of D register |
| (nnn) nnn | e | Display/modify contents of E register |
| nnn | f | Display/modify contents of condition code F register |
| (nnn) nnn | g | Write given command to general comm channel |
| nnn | h | Display/modify contents of H register |
| (nnn) nnn | l | Display/modify contents of L register |
| (nnn) nnn | p | Write given command to printer channel |
| nnnnnn | x | Display/modify contents of IX register |
| nnnnnn | y | Display modify contents of IY register |

8600 ROM Debug Command Summary

| | |
|---------------|--|
| nnn nnn A | Set current I/O address to given or current address |
| nnn nnn B | Set breakpoint at given or current address |
| nnn nnn C | Call given or current address |
| nnn nnn D | Decrement current address by 1 or nnn nnn |
| nnn nnn E | Continue execution from nnn nnn |
| nnn nnn I | Increment current address by 1 or given |
| nnn nnn J | Jump to given or current address |
| nnn K | Set control register to nnn |
| (nnn) nnn M | Modify contents of current address location |
| nnn nnn N | Set current address to nnn nnn |
| nnn O | Set origin table pointer and origin mode |
| nnn nnn P | Load the base register with given |
| 12345 Q | Load sector table selected by control register |
| R | Perform Alpha/Beta switch |
| nn S | Display stack entry nn |
| nnn T | Display sector table entry nnn |
| 12345 T | Start processor and memory self-test |
| nnn Y | Modify or display the saved system status |
| Z | Display all registers and register pairs: FFF AAA BBB CCC DDD EEE HHH LLL XXX BBBCCC DDDEEE HHHLLL XXXAAA STKP |
| (nnn) nnn a | Modify/display A register |
| nnn b | Modify/display B register |
| (nnn) nnn c | Modify/display C register |
| nnn d | Modify/display D register |
| (nnn) nnn e | Modify/display E register |
| nn f | Modify/display condition code flags |
| (nnn) nnn h | Modify/display H register |
| nnn nnn i | Set addressing bias to given and select I/O space |
| nnn k | Modify/display saved control register to nnn |
| nnn l | Modify/display L register |
| nnn nnn o | Set addressing bias to nnn nnn and select memory space |
| nnn nnn p | Load saved base register with upper 8 bits of nnn nnn |
| nn r | Pop stack (nn) times |
| nnn nnn s | Push nnn nnn onto stack |
| 12345 t | Go to diagnostic mini exec |
| nnn x | Modify/display X register |
| z | Display CP/RIM ID |
| nnn nnn ENTER | Set relative address in memory or I/O space |
| CANCEL | Cancel command input line |
| BACKSPACE | Backspace one space on input line |
| (nnn) nnn . | Modify memory and increment current address |
| (nnnnnn) ^ | Same as '.' but save nnnnnn; if no nnnnnn, use the last nnnnnn saved |
| # | Clear all active debug set breakpoints |
| ? | Display processor identification data |

8800 ROM Debug Command Summary

| | |
|-------------|--|
| nnnnnn00 | Increment the current address by nnnnnn |
| nnnnnn01 | Decrement the current address by nnnnnn |
| (nnn)nnn03 | Modify the contents of the current address to nnn and of the next higher address to (nnn) |
| nnnnnn04 | Display the program counter or modify PC to nnnnnn |
| (nnn)nnn05 | Display the register pair XA or modify X to (nnn) and A to nnn and display |
| (nnn)nnn06 | Display or modify BC |
| (nnn)nnn07 | Display or modify DE |
| (nnn)nnn08 | Display or modify HL |
| nnn09 | Display or modify flags |
| nnn10 | EXSTATUS and output data byte nnn to addressed device |
| nnn11 | EX DATA and output data byte nnn to addressed device |
| nnn12 | EX WRITE and output data byte nnn to addressed device |
| nnn13 | EX COM1 and output data byte nnn to addressed device |
| nnn14 | EX COM2 and output data byte nnn to addressed device |
| nnn15 | EX COM3 and output data byte nnn to addressed device |
| nnn16 | EX COM4 and output data byte nnn to addressed device |
| nnn17 | Address the given or current I/O device |
| nnn18 | Fetches next data byte from current or given I/O device |
| 19 | Exit from DEBUG |
| nnnnnn21 | Jump to address nnnnnn, default = current address |
| nnnnnn22 | Modify the displayed (CMD29) scratch pad entry to nnnnnn |
| 24 | Switch from user to kernal sector table |
| 25 | Switch from kernal to user sector table |
| nnn26 | Display the (nnn)th user stack entry, default = top stack entry |
| nnn27 | Display the (nnn)th sector table entry, default = entry #0 |
| nnn28 | Modify the displayed sector table entry with nnn |
| nnnnnn29 | Display the contents of scratch pad entry location nnnnnn |
| nnnnnn30 | Display the user stack pointer or modify to nnnnnn |
| nnnnnn31 | Display the user sector table pointers from the saved state or modify to nnnnnn |
| nnnnnn32 | Display the user stack bounds from the saved state or modify to nnnnnn |
| nnnnnn33 | Display the user base register/instruction register from the saved state or modify to nnnnnn |
| 34 | Switch between the data and instruction sector tables for memory accesses |
| nnnnnnDSP | Display the contents of nnn and the next higher address, default = current address |
| (nnn)nnnMOD | Modify the current address by nnn and the next higher address by (nnn) and increment the address |
| BSP & ENTER | Cancel the entry line |
| BSP | Backspace by one character on the entry line |

Quick Reference Guide for Processors and Peripherals

1130 ROM Debug Commands

| | |
|---------------|---|
| (nnn) A | Address the I/O device specified by nnn and return with status |
| nnnnn C | Call memory address nnnnn returning to Debug |
| D | Decrement current address by 1 |
| F | Fetch data byte from currently addressed I/O device |
| I | Increment current memory address by 1 |
| nnnnn J | Jump to memory address nnnnn |
| L | Link to address pointed to by current address |
| (nnn)nnn M | Modify current address to given |
| O | Enter diskette test cycle |
| (nnn) S | Display contents of nnn level of hardware stack |
| T | Enter memory test cycle |
| nnn V | Execute EX COM4 to previously addressed I/O device, display status of A register |
| nnn W | Execute EX WRITE to previously addressed I/O device, display status of A register |
| nnn X | Execute EX COM1 to previously addressed I/O device, display status of A register. For diskettes: 0X to 3X - Select drive 0 to 3 4X - Clear parity error flag 5X - Read sector from diskette to buffer 6X - Write sector from buffer to diskette 7X - Write verify sector from buffer to diskette 10X - Restore selected drive n11X - Select buffer page n (0 to 3) |
| nnn Y | Execute EX COM2 to previously addressed I/O device, display status of A register |
| nnn Z | Execute EX COM3 to previously addressed I/O device, display status of A register |
| a | Display A register |
| b | Display B register |
| c | Display C register |
| d | Display D register |
| e | Display E register |
| f | Display condition codes |
| h | Display H register |
| l | Display L register |
| (nnn) . | Modify current address of memory to nnn |
| (nnnnn) ENTER | Modify current address to nnnnn |
| CANCEL | Cancel entry line |

Quick Reference Guide for Processors and Peripherals

1150/1170 ROM Debug Command Summary

| | | |
|-----------|-----------|--|
| nnn | A | Address given or current I/O device |
| nnn nnn | B | Set breakpoint at given or current address |
| nnn nnn | C | Call given or current address |
| nnn nnn | D | Decrement current address by 1 or nnn nnn |
| nnn nnn | E | Continue execution |
| nnn | F | Fetch next data byte from current or given I/O device |
| nnn | G | Go to data mode in current or given I/O device when 'E' command is given |
| 12345 | H | Start 1150 system diagnostic test |
| nnn nnn | I | Increment current address by 1 or nnn nnn |
| nnn nnn | J | Jump to given current address |
| 12345 | K | Set ASCII keyin mode |
| | L | Link to address pointed to by current address |
| (nnn) nnn | M | Modify contents of current address location |
| nn | O | Selects given into origin table |
| nnn nnn | P | Load base register with 8-bit value |
| 12345 | Q | Load sector table |
| | R | Switch Alpha/Beta mode register display |
| nn | S | Display given stack item |
| 12345 | T | Start primary memory test |
| nnn nnn | U | User mode execute with optional return to nnn nnn address |
| nnn | V | EX COM4 Device must be address with a command |
| nnn | W | EX WRITE Status is displayed |
| nnn | X | EX COM1 after the command is issued |
| nnn | Y | EX COM2 'nnn' is current output byte. |
| nnn | Z | EX COM3 |
| nnn | x | Display/modify X register |
| (nnn) nnn | a | Display/modify A register |
| nnn | b | Display/modify B register |
| (nnn) nnn | c | Display/modify C register |
| nnn | d | Display/modify D register |
| (nnn) nnn | e | Display/modify E register |
| nnn | h | Display/modify H register |
| (nnn) nnn | l | Display/modify L register |
| nnn | f | Display/modify condition flag |
| nnn nnn | i | Same as 'E' but with interrupts enabled |
| nnn nnn | h | PUSH given value onto stack |
| nn | s | POP stack (nn) times |
| nnn | p | Load base register with given value |
| 12345 | t | Start pseudo-random memory test |
| nnn | y | EX DATA with given on output bus |
| nnn | z | EX STATUS with given on output bus |
| nnn nnn | ENTER | Set current address to given |
| | CANCEL | Cancel entry line |
| | BACKSPACE | Backspace on entry line |
| (nnn) nnn | . | Modify contents and increment current address |
| (nnn) nnn | ^ | Modify contents and increment current address |
| | # | Clear all breakpoints |

Quick Reference Guide for Processors and Peripherals

CHARACTER TRANSMISSION AND TRANSLATION TABLE

| Dec | Octal | Hex | ASCII | EBCDIC | IBM BCD | Honeywell BCD | EBCDIC Card Code | Binary |
|-----|-------|-----|-------|--------|---------|---------------|------------------|------------|
| 0 | 000 | 00 | NUL | NUL | | 0 | 12-0-1-8-9 | 00 000 000 |
| 1 | 001 | 01 | SOH | SOH | 1 | 1 | 12-1-9 | 00 000 001 |
| 2 | 002 | 02 | STX | STX | 2 | 2 | 12-2-9 | 00 000 010 |
| 3 | 003 | 03 | ETX | ETX | 3 | 3 | 12-3-9 | 00 000 011 |
| 4 | 004 | 04 | EOT | PF | 4 | 3 | 12-4-9 | 00 000 100 |
| 5 | 005 | 05 | ENQ | HT | 5 | 5 | 12-5-9 | 00 000 101 |
| 6 | 006 | 06 | ACK | LC | 6 | 6 | 12-6-9 | 00 000 110 |
| 7 | 007 | 07 | BEL | DEL | 7 | 7 | 12-7-9 | 00 000 111 |
| 8 | 010 | 08 | BS | | 8 | 8 | 12-8-9 | 00 001 000 |
| 9 | 011 | 09 | HT | RLF | 9 | 9 | 12-1-8-9 | 00 001 001 |
| 10 | 012 | 0A | LF | SMM | 0 | 1 | 12-2-8-9 | 00 001 010 |
| 11 | 013 | 0B | VT | VT | = | = | 12-3-8-9 | 00 001 011 |
| 12 | 014 | 0C | FF | FF | / | : | 12-4-8-9 | 00 001 100 |
| 13 | 015 | 0D | CR | CR | : | : | 12-5-8-9 | 00 001 101 |
| 14 | 016 | 0E | SO | SO | > | > | 12-6-8-9 | 00 001 110 |
| 15 | 017 | 0F | SI | SI | @ | & | 12-7-8-9 | 00 001 111 |
| 16 | 020 | 10 | DLE | DLE | Space | + | 12-11-1-8-9 | 00 010 000 |
| 17 | 021 | 11 | DC1 | DC1 | / | A | 11-1-9 | 00 010 001 |
| 18 | 022 | 12 | DC2 | DC2 | S | B | 11-2-9 | 00 010 010 |
| 19 | 023 | 13 | DC3 | TM/DC3 | T | C | 11-3-9 | 00 010 011 |
| 20 | 024 | 14 | DC4 | RES | U | D | 11-4-9 | 00 010 100 |
| 21 | 025 | 15 | NAK | NL | V | E | 11-5-9 | 00 010 101 |
| 22 | 026 | 16 | SYN | BS | W | F | 11-6-9 | 00 010 110 |
| 23 | 027 | 17 | ETB | IL | X | G | 11-7-9 | 00 010 111 |
| 24 | 030 | 18 | CAN | CAN | Y | H | 11-8-9 | 00 011 000 |
| 25 | 031 | 19 | EM | Em | Z | I | 11-1-8-9 | 00 011 001 |
| 26 | 032 | 1A | SUB | CC | = | ; | 11-2-8-9 | 00 011 010 |
| 27 | 033 | 1B | ESC | CUI | . | . | 11-3-8-9 | 00 011 011 |
| 28 | 034 | 1C | FS | IFS | (|) | 11-4-8-9 | 00 011 100 |
| 29 | 035 | 1D | GS | IGS | _ | % | 11-5-8-9 | 00 011 101 |
| 30 | 036 | 1E | RS | IRS | ~ | dirty loz. | 11-6-8-9 | 00 011 110 |
| 31 | 037 | 1F | US | IUS | " | ? | 11-7-8-9 | 00 011 111 |
| 32 | 040 | 20 | SPACE | DS | - | - | 11-0-1-8-9 | 00 100 000 |
| 33 | 041 | 21 | ! | SOS | J | J | 0-1-9 | 00 100 001 |
| 34 | 042 | 22 | " | FS | K | K | 0-2-9 | 00 100 010 |
| 35 | 043 | 23 | # | | L | L | 0-3-9 | 00 100 011 |
| 36 | 044 | 24 | \$ | BYP | M | M | 0-4-9 | 00 100 100 |
| 37 | 045 | 25 | % | LF | N | N | 0-5-9 | 00 100 101 |
| 38 | 046 | 26 | & | ETB | O | O | 0-6-9 | 00 100 110 |
| 39 | 047 | 27 | ' | ESC | P | P | 0-7-9 | 00 100 111 |

Quick Reference Guide for Processors and Peripherals

| Dec | Octal | HEX | ASCII | EBCDIC | IBM BCD | Honeywell BCD | EBCDIC Card Code | Binary |
|-----|-------|-----|-------|--------|---------|---------------|------------------|------------|
| 40 | 050 | 28 | (| | Q | Q | 0-8-9 | 00 101 000 |
| 41 | 051 | 29 |) | | R | R | 0-1-8-9 | 00 101 001 |
| 42 | 052 | 2A | * | SM | ! | # | 0-2-8-9 | 00 101 010 |
| 43 | 053 | 2B | + | CU2 | \$ | \$ | 0-3-8-9 | 00 101 011 |
| 44 | 054 | 2C | , | | * | * | 0-4-8-9 | 00 101 100 |
| 45 | 055 | 2D | - | ENQ |] | " | 0-5-8-9 | 00 101 101 |
| 46 | 056 | 2E | . | ACK | ; | = | 0-6-8-9 | 00 101 110 |
| 47 | 057 | 2F | / | BEL | ^ | ! | 0-7-8-9 | 00 101 111 |
| 48 | 060 | 30 | 0 | | + | < | 12-11-0-1-8-9 | 00 110 000 |
| 49 | 061 | 31 | 1 | | A | / | 1-9 | 00 110 001 |
| 50 | 062 | 32 | 2 | SYN | B | S | 2-9 | 00 110 010 |
| 51 | 063 | 33 | 3 | | C | T | 3-9 | 00 110 011 |
| 52 | 064 | 34 | 4 | PN | D | U | 4-9 | 00 110 100 |
| 53 | 065 | 35 | 5 | RS | E | V | 5-9 | 00 110 101 |
| 54 | 066 | 36 | 6 | UC | F | W | 6-9 | 00 110 110 |
| 55 | 067 | 37 | 7 | EOT | G | X | 7-9 | 00 110 111 |
| 56 | 070 | 38 | 8 | | H | Y | 8-9 | 00 111 000 |
| 57 | 071 | 39 | 9 | | I | Z | 1-8-9 | 00 111 001 |
| 58 | 072 | 3A | : | | ? | @ | 2-8-9 | 00 111 010 |
| 59 | 073 | 3B | ; | CU3 | . | . | 3-8-9 | 00 111 011 |
| 60 | 074 | 3C | < | DC4 |) | CR | 4-8-9 | 00 111 100 |
| 61 | 075 | 3D | = | NAK | [| clean loz. | 5-8-9 | 00 111 101 |
| 62 | 076 | 3E | > | | < | ¢ | 6-8-9 | 00 111 110 |
| 63 | 077 | 3F | ? | SUB | # | | 7-8-9 | 00 111 111 |
| 64 | 100 | 40 | @ | SPACE | | | NO PUNCHES | 01 000 000 |
| 65 | 101 | 41 | A | | | | 12-0-1-9 | 01 000 001 |
| 66 | 102 | 42 | B | | | | 12-0-2-9 | 01 000 010 |
| 67 | 103 | 43 | C | | | | 12-0-3-9 | 01 000 011 |
| 68 | 104 | 44 | D | | | | 12-0-4-9 | 01 000 100 |
| 69 | 105 | 45 | E | | | | 12-0-5-9 | 01 000 101 |
| 70 | 106 | 46 | F | | | | 12-0-6-9 | 01 000 110 |
| 71 | 107 | 47 | G | | | | 12-0-7-9 | 01 000 111 |
| 72 | 110 | 48 | H | | | | 12-0-8-9 | 01 001 000 |
| 73 | 111 | 49 | I | | | | 12-1-8 | 01 001 001 |
| 74 | 112 | 4A | J | ¢ | | | 12-2-8 | 01 001 010 |
| 75 | 113 | 4B | K | . | | | 12-3-8 | 01 001 011 |
| 76 | 114 | 4C | L | < | | | 12-4-8 | 01 001 100 |
| 77 | 115 | 4D | M | (| | | 12-5-8 | 01 001 101 |
| 78 | 116 | 4E | N | + | | | 12-6-8 | 01 001 110 |
| 79 | 117 | 4F | O | | | | 12-7-8 | 01 001 111 |

Quick Reference Guide for Processors and Peripherals

| Dec | Octal | HEX | ASCII | IBM Honeywell EBCDIC | | Card Code | Binary |
|-----|-------|-----|-------|----------------------|---------|-------------|------------|
| | | | | EBCDIC | BCD BCD | | |
| 80 | 120 | 50 | P | | & | 12 | 01 010 000 |
| 81 | 121 | 51 | Q | | | 12-11-1-9 | 01 010 001 |
| 82 | 122 | 52 | R | | | 12-11-2-9 | 01 010 010 |
| 83 | 123 | 53 | S | | | 12-11-3-9 | 01 010 011 |
| 84 | 124 | 54 | T | | | 12-11-4-9 | 01 010 100 |
| 85 | 125 | 55 | U | | | 12-11-5-9 | 01 010 101 |
| 86 | 126 | 56 | V | | | 12-11-6-9 | 01 010 110 |
| 87 | 127 | 57 | W | | | 12-11-7-9 | 01 010 111 |
| 88 | 130 | 58 | X | | | 12-11-8-9 | 01 011 000 |
| 89 | 131 | 59 | Y | | | 11-1-8 | 01 011 001 |
| 90 | 132 | 5A | Z | | ! | 11-2-8 | 01 011 010 |
| 91 | 133 | 5B | [| | \$ | 11-3-8 | 01 011 011 |
| 92 | 134 | 5C | ◇ | | * | 11-4-8 | 01 011 100 |
| 93 | 135 | 5D |] | |) | 11-5-8 | 01 011 101 |
| 94 | 136 | 5E | ^ | | ; | 11-6-8 | 01 011 110 |
| 95 | 137 | 5F | _ | | ┘ | 11-7-8 | 01 011 111 |
| 96 | 140 | 60 | \ | | - | 11 | 01 100 000 |
| 97 | 141 | 61 | a | | / | 0-1 | 01 100 001 |
| 98 | 142 | 62 | b | | | 11-0-2-9 | 01 100 010 |
| 99 | 143 | 63 | c | | | 11-0-3-9 | 01 100 011 |
| 100 | 144 | 64 | d | | | 11-0-4-9 | 01 100 100 |
| 101 | 145 | 65 | e | | | 11-0-5-9 | 01 100 101 |
| 102 | 146 | 66 | f | | | 11-0-6-9 | 01 100 110 |
| 103 | 147 | 67 | g | | | 11-0-7-9 | 01 100 111 |
| 104 | 150 | 68 | h | | | 11-0-8-9 | 01 101 000 |
| 105 | 151 | 69 | i | | | 0-1-8 | 01 101 001 |
| 106 | 152 | 6A | j | | | 12-11 | 01 101 010 |
| 107 | 153 | 6B | k | | , | 0-3-8 | 01 101 011 |
| 108 | 154 | 6C | l | | % | 0-4-8 | 01 101 100 |
| 109 | 155 | 6D | m | | | 0-5-8 | 01 101 101 |
| 110 | 156 | 6E | n | | > | 0-6-8 | 01 101 110 |
| 111 | 157 | 6F | o | | ? | 0-7-8 | 01 101 111 |
| 112 | 160 | 70 | p | | | 12-11-0 | 01 110 000 |
| 113 | 161 | 71 | q | | | 12-11-0-1-9 | 01 110 001 |
| 114 | 162 | 72 | r | | | 12-11-0-2-9 | 01 110 010 |
| 115 | 163 | 73 | s | | | 12-11-0-3-9 | 01 110 011 |
| 116 | 164 | 74 | t | | | 12-11-0-4-9 | 01 110 100 |
| 117 | 165 | 75 | u | | | 12-11-0-5-9 | 01 110 101 |
| 118 | 166 | 76 | v | | | 12-11-0-6-9 | 01 110 110 |
| 119 | 167 | 77 | w | | | 12-11-0-7-9 | 01 110 111 |

Quick Reference Guide for Processors and Peripherals

| Dec | Octal | HEX | ASCII | IBM Honeywell | | EBCDIC Card Code | Binary |
|-----|-------|-----|-------|---------------|-----|---------------------|------------|
| | | | | EBCDIC | BCD | | |
| 120 | 170 | 78 | x | | | 12-11-0-8-9 | 01 111 000 |
| 121 | 171 | 79 | y | / | | 1-8 | 01 111 001 |
| 122 | 172 | 7A | z | : | | 2-8 | 01 111 010 |
| 123 | 173 | 7B | { | # | | 3-8 | 01 111 011 |
| 124 | 174 | 7C | } | @ | | 4-8 | 01 111 100 |
| 125 | 175 | 7D | ~ | ' | | 5-8 | 01 111 101 |
| 126 | 176 | 7E | DEL | " | | 6-8 | 01 111 110 |
| 127 | 177 | 7F | | | | 7-8 | 01 111 111 |
| 128 | 200 | 80 | | | | 12-0-1-8 | 10 000 000 |
| 129 | 201 | 81 | | a | | 12-0-1 | 10 000 001 |
| 130 | 202 | 82 | | b | | 12-0-2 | 10 000 010 |
| 131 | 203 | 83 | | c | | 12-0-3 | 10 000 011 |
| 132 | 204 | 84 | | d | | 12-0-4 | 10 000 100 |
| 133 | 205 | 85 | | e | | 12-0-5 | 10 000 101 |
| 134 | 206 | 86 | | f | | 12-0-6 | 10 000 110 |
| 135 | 207 | 87 | | g | | 12-0-7 | 10 000 111 |
| 136 | 210 | 88 | | h | | 12-0-8 | 10 001 000 |
| 137 | 211 | 89 | | i | | 12-0-9 | 10 001 001 |
| 138 | 212 | 8A | | | | 12-0-2-8 | 10 001 010 |
| 139 | 213 | 8B | | | | 12-0-3-8 | 10 001 011 |
| 140 | 214 | 8C | | | | 12-0-4-8 | 10 001 100 |
| 141 | 215 | 8D | | | | 12-0-5-8 | 10 001 101 |
| 142 | 216 | 8E | | | | 12-0-6-8 | 10 001 110 |
| 143 | 217 | 8F | | | | 12-0-7-8 | 10 001 111 |
| 144 | 220 | 90 | | | | 12-11-1-8 | 10 010 000 |
| 145 | 221 | 91 | | j | | 12-11-1 | 10 010 001 |
| 146 | 222 | 92 | | k | | 12-11-2 | 10 010 010 |
| 147 | 223 | 93 | | l | | 12-11-3 | 10 010 011 |
| 148 | 224 | 94 | | m | | 12-11-4 | 10 010 100 |
| 149 | 225 | 95 | | n | | 12-11-5 | 10 010 101 |
| 150 | 226 | 96 | | o | | 12-11-6 | 10 010 110 |
| 151 | 227 | 97 | | p | | 12-11-7 | 10 010 111 |
| 152 | 230 | 98 | | q | | 12-11-8 | 10 011 000 |
| 153 | 231 | 99 | | r | | 12-11-9 | 10 011 001 |
| 154 | 232 | 9A | | | | 12-11-2-8 | 10 011 010 |
| 155 | 233 | 9B | | | | 12-11-3-8 | 10 011 011 |
| 156 | 234 | 9C | | | | 12-11-4-8 | 10 011 100 |
| 157 | 235 | 9D | | | | 12-11-5-8 | 10 011 101 |
| 158 | 236 | 9E | | | | 12-11-6-8 | 10 011 110 |
| 159 | 237 | 9F | | | | 12-11-7-8 | 10 011 111 |

Quick Reference Guide for Processors and Peripherals

| Dec | Octal | HEX | ASCII | EBCDIC | IBM Honeywell BCD BCD | EBCDIC Card Code | Binary |
|-----|-------|-----|-------|--------|--------------------------|---------------------|------------|
| 160 | 240 | A0 | | | | 11-0-1-8 | 10 100 000 |
| 161 | 241 | A1 | | ~ | | 11-0-1 | 10 100 001 |
| 162 | 242 | A2 | | s | | 11-0-2 | 10 100 010 |
| 163 | 243 | A3 | | t | | 11-0-3 | 10 100 011 |
| 164 | 244 | A4 | | u | | 11-0-4 | 10 100 100 |
| 165 | 245 | A5 | | v | | 11-0-5 | 10 100 101 |
| 166 | 246 | A6 | | w | | 11-0-6 | 10 100 110 |
| 167 | 247 | A7 | | x | | 11-0-7 | 10 100 111 |
| 168 | 250 | A8 | | y | | 11-0-8 | 10 101 000 |
| 169 | 251 | A9 | | z | | 11-0-9 | 10 101 001 |
| 170 | 252 | AA | | | | 11-0-2-8 | 10 101 010 |
| 171 | 253 | AB | | | | 11-0-3-8 | 10 101 011 |
| 172 | 254 | AC | | | | 11-0-4-8 | 10 101 100 |
| 173 | 255 | AD | | | | 11-0-5-8 | 10 101 101 |
| 174 | 256 | AE | | | | 11-0-6-8 | 10 101 110 |
| 175 | 257 | AF | | | | 11-0-7-8 | 10 101 111 |
| 176 | 260 | B0 | | | | 12-11-0-1-8 | 10 110 000 |
| 177 | 261 | B1 | | | | 12-11-0-1 | 10 110 001 |
| 178 | 262 | B2 | | | | 12-11-0-2 | 10 110 010 |
| 179 | 263 | B3 | | | | 12-11-0-3 | 10 110 011 |
| 180 | 264 | B4 | | | | 12-11-0-4 | 10 110 100 |
| 181 | 265 | B5 | | | | 12-11-0-5 | 10 110 101 |
| 182 | 266 | B6 | | | | 12-11-0-6 | 10 110 110 |
| 183 | 267 | B7 | | | | 12-11-0-7 | 10 110 111 |
| 184 | 270 | B8 | | | | 12-11-0-8 | 10 111 000 |
| 185 | 271 | B9 | | | | 12-11-0-9 | 10 111 001 |
| 186 | 272 | BA | | | | 12-11-0-2-8 | 10 111 010 |
| 187 | 273 | BB | | | | 12-11-0-3-8 | 10 111 011 |
| 188 | 274 | BC | | | | 12-11-0-4-8 | 10 111 100 |
| 189 | 275 | BD | | | | 12-11-0-5-8 | 10 111 101 |
| 190 | 276 | BE | | | | 12-11-0-6-8 | 10 111 110 |
| 191 | 277 | BF | | | | 12-11-0-7-8 | 10 111 111 |
| 192 | 300 | C0 | | | | 12-0 | 11 000 000 |
| 193 | 301 | C1 | | A | | 12-1 | 11 000 001 |
| 194 | 302 | C2 | | B | | 12-2 | 11 000 010 |
| 195 | 303 | C3 | | C | | 12-3 | 11 000 011 |
| 196 | 304 | C4 | | D | | 12-4 | 11 000 100 |
| 197 | 305 | C5 | | E | | 12-5 | 11 000 101 |
| 198 | 306 | C6 | | F | | 12-6 | 11 000 110 |
| 199 | 307 | C7 | | G | | 12-7 | 11 000 111 |

Quick Reference Guide for Processors and Peripherals

| IBM Honeywell EBCDIC | | | | | | | | |
|----------------------|-------|-----|-------|--------|-----|-----|-------------|------------|
| Dec | Octal | HEX | ASCII | EBCDIC | BCD | BCD | Card Code | Binary |
| 200 | 310 | C8 | | H | | | 12-8 | 11 001 000 |
| 201 | 311 | C9 | | I | | | 12-9 | 11 001 001 |
| 202 | 312 | CA | | | | | 12-0-2-8-9 | 11 001 010 |
| 203 | 313 | CB | | | | | 12-0-3-8-9 | 11 001 011 |
| 204 | 314 | CC | | | | | 12-0-4-8-9 | 11 001 100 |
| 205 | 315 | CD | | | | | 12-0-5-8-9 | 11 001 101 |
| 206 | 316 | CE | | | | | 12-0-6-8-9 | 11 001 110 |
| 207 | 317 | CF | | | | | 12-0-7-8-9 | 11 001 111 |
| 208 | 320 | D0 | | | | | 11-0 | 11 010 000 |
| 209 | 321 | D1 | | J | | | 11-1 | 11 010 001 |
| 210 | 322 | D2 | | K | | | 11-2 | 11 010 010 |
| 211 | 323 | D3 | | L | | | 11-3 | 11 010 011 |
| 212 | 324 | D4 | | M | | | 11-4 | 11 010 100 |
| 213 | 325 | D5 | | N | | | 11-5 | 11 010 101 |
| 214 | 326 | D6 | | O | | | 11-6 | 11 010 110 |
| 215 | 327 | D7 | | P | | | 11-7 | 11 010 111 |
| 216 | 330 | D8 | | Q | | | 11-8 | 11 011 000 |
| 217 | 331 | D9 | | R | | | 11-9 | 11 011 001 |
| 218 | 332 | DA | | | | | 12-11-2-8-9 | 11 011 010 |
| 219 | 333 | DB | | | | | 12-11-3-8-9 | 11 011 011 |
| 220 | 334 | DC | | | | | 12-11-4-8-9 | 11 011 100 |
| 221 | 335 | DD | | | | | 12-11-5-8-9 | 11 011 101 |
| 222 | 336 | DE | | | | | 12-11-6-8-9 | 11 011 110 |
| 223 | 337 | DF | | | | | 12-11-7-8-9 | 11 011 111 |
| 224 | 340 | E0 | | ◇ | | | 0-2-8 | 11 100 000 |
| 225 | 341 | E1 | | | | | 11-0-1-9 | 11 100 001 |
| 226 | 342 | E2 | | S | | | 0-2 | 11 100 010 |
| 227 | 343 | E3 | | T | | | 0-3 | 11 100 011 |
| 228 | 344 | E4 | | U | | | 0-4 | 11 100 100 |
| 229 | 345 | E5 | | V | | | 0-5 | 11 100 101 |
| 230 | 346 | E6 | | W | | | 0-6 | 11 100 110 |
| 231 | 347 | E7 | | X | | | 0-7 | 11 100 111 |
| 232 | 350 | E8 | | Y | | | 0-8 | 11 101 000 |
| 233 | 351 | E9 | | Z | | | 0-9 | 11 101 001 |
| 234 | 352 | EA | | | | | 11-0-2-8-9 | 11 101 010 |
| 235 | 353 | EB | | | | | 11-0-3-8-9 | 11 101 011 |
| 236 | 354 | EC | | | | | 11-0-4-8-9 | 11 101 100 |
| 237 | 355 | ED | | | | | 11-0-5-8-9 | 11 101 101 |
| 238 | 356 | EE | | | | | 11-0-6-8-9 | 11 101 110 |
| 239 | 357 | EF | | | | | 11-0-7-8-9 | 11 101 111 |

Quick Reference Guide for Processors and Peripherals

| Dec | Octal | HEX | ASCII | IBM Honeywell | | EBCDIC Card Code | Binary |
|-----|-------|-----|-------|---------------|---------|---------------------|------------|
| | | | | EBCDIC | BCD BCD | | |
| 240 | 360 | F0 | | 0 | | 0 | 11 110 000 |
| 241 | 361 | F1 | | 1 | | 1 | 11 110 001 |
| 242 | 362 | F2 | | 2 | | 2 | 11 110 010 |
| 243 | 363 | F3 | | 3 | | 3 | 11 110 011 |
| 244 | 364 | F4 | | 4 | | 4 | 11 110 100 |
| 245 | 365 | F5 | | 5 | | 5 | 11 110 101 |
| 246 | 366 | F6 | | 6 | | 6 | 11 110 110 |
| 247 | 367 | F7 | | 7 | | 7 | 11 110 111 |
| 248 | 370 | F8 | | 8 | | 8 | 11 111 000 |
| 249 | 371 | F9 | | 9 | | 9 | 11 111 001 |
| 250 | 372 | FA | | | | 12-11-0-2-8-9 | 11 111 010 |
| 251 | 373 | FB | | | | 12-11-0-3-8-9 | 11 111 011 |
| 252 | 374 | FC | | | | 12-11-0-4-8-9 | 11 111 100 |
| 253 | 375 | FD | | | | 12-11-0-5-8-9 | 11 111 101 |
| 254 | 376 | FE | | | | 12-11-0-6-8-9 | 11 111 110 |
| 255 | 377 | FF | | | | 12-11-0-7-8-9 | 11 111 111 |